FUELMISER

Edition 1

ENGINE MANAGEMENT PARTS

FORWARD TO CONTENTS

TECHNICAL SUPPORT

FUELMISER

Wherever you are, Motospecs technical support is only a phone call away. The technical support line can provide information on vehicle fitment, product range and latest application listings.

If assistance is required, please call . . .

1800 245 748 (free call)

Monday to Friday 8.00am-5.00pm (Eastern Standard Time)
or fax: 02 9847 5757 or email: ms_sales@motospecs.com

To ensure you receive a quick response to your question, please have the following information at hand:

- Make / Model / Year or build date, chassis number (if applicable).
- Product name.
- Product part number on pack and batch code/production date on label.

WARRANTY Motospecs recognises the importance of customer confidence and satisfaction in the quality of its products. Champion Ignition and Electrical products are warranted against faulty materials and workmanship when used for their designated purpose for a period of 2 years or 40,000km from date of fitment, whichever occurs first.

Warranty does not cover faulty fitment.

CLAIMS must be submitted through the distributor accompanied by the faulty product, proof of purchase and the reason for the failure.

CREDIT for items supplied as ordered will be at the discretion of Motospecs.

FREIGHT charges on returns will be borne by the customer.

COPYRIGHT NOTICE 2009

Motospecs is the owner of Copyright in this production, including layout, drawings, photographs, text and part number systems. This publication must not be reproduced in whole or in part without written authorisation from Motospecs. ABN 97 097 993 283.

This catalogue has been prepared for the Australian and New Zealand markets and whilst every care is exercised in compiling these recommendations, they do not form part of any contract. Due to vehicle production changes and supersessions, Motospecs does not accept responsibility for the accuracy of information or any claim arising from the interpretation of information in respect to vehicles, equipment and published references. Manufacturers' names appearing in this catalogue are used for identification purposes only.

FUELMISER

ENGINE MANAGEMENT PARTS CONTENTS

APPLICATION GUIDE

Accel Performance Distributors ... 2
Alfa Romeo ... 2-5
Audi ... 6-9
Austin ... 9-10
Bedford ... 10
BMW ... 11-22
Chevrolet ... 22-23
Chrysler ... 23-28
Citroen ... 28-29
Daewoo ... 29-32
Daihatsu ... 32-38
Daimler ... 38
Dodge ... 38-39
Eunos ... 40-41
Ferrari ... 41
Fiat ... 41
Ford ... 42-83
Hillman ... 83-84
Holden ... 84-122
Holden HDT ... 122
Holden HSV ... 123-127
Honda ... 128-142
Hyundai ... 142-150
International ... 150-151
Isuzu ... 151
Jaguar ... 152-153
Jeep ... 154
Kia ... 154-156
Lada ... 156-157
Lancia ... 157
Landrover ... 157-158
Lexus ... 159-161
Leyland ... 161-162
Mallory Performance Distributors ... 163
Mazda ... 163-184
Mercedes ... 184-192
MG ... 192-193
Mitsubishi ... 193-219
Morris ... 219
Niki ... 219
Nissan ... 220-246
Peugeot ... 246-247
Porsche ... 247-249
Proton ... 249-250
Rambler ... 251
Renault ... 251-253
Rover ... 253-255
SAAB ... 256-257
Seat ... 258
Ssangyong ... 258
Subaru ... 259-263
Suzuki ... 264-271
Toyota ... 272-314
Triumph ... 314-317
Universal Applications ... 317
Vauxhall ... 317
Volkswagen ... 318-323
Volvo ... 323-328
Yugo ... 328

IDENTIFICATION GUIDE

IGNITION

Coils ... 330-339
Coil Resistors ... 339
Condensers ... 340-343
Distributor Caps ... 343-357
Modules ... 358-360
Pickup and Triggers ... 360-361
Points and Contact Sets ... 362-364
Rotors ... 365-374

SENSORS, SWITCHES & RELAYS

Air Flow and Air Mass Sensors ... 374-376
Air Temperature Sensors ... 377-378
Camshaft and Crankshaft Sensors ... 378-390
Coolant Temperature Sensors / Switches ... 391-396

SENSORS, SWITCHES & RELAYS

Exhaust Oxygen Sensors ... 397-408
Idle Speed Control Valves ... 408-409
Knock Control Sensors ... 409-410
MAP Sensors ... 411-412
Throttle Position Sensor / Switches ... 412-414
Brake and Clutch Pedal Switches ... 415-417
Headlight and Dimmer Switches ... 426
Ignition Switches ... 427
Neutral Start Switches ... 427
Oil Pressure Sensors / Switches ... 418-420
Power Steering Switches ... 427
Radiator Fan Switches ... 421-426
Reverse Light Switches ... 428
Starter Relays / Switches ... 428

Accel Performance Distributors	Part No	Qty	Notes
30 Series **V8 Points Distributor**			
Ignition – Distributor Cap	**BD1580**	1	
Ignition – Distributor Condenser	**UC11E**	1	
Ignition – Distributor Points / Contact Set	**S7860**	1	
Ignition – Distributor Rotor	**DR1570**	1	
34 Series **V8 Points Distributor**			
Ignition – Distributor Cap	**BD2000**	1	
Ignition – Distributor Condenser	**UC11E**	1	
Ignition – Distributor Points / Contact Set	**S7550**	1	
Ignition – Distributor Rotor	**AL104**	1	
37 Series **V8 Points Distributor**			
Ignition – Distributor Cap	**BD1290**	1	
Ignition – Distributor Condenser	**UC11E**	1	
Ignition – Distributor Points / Contact Set	**S7860**	1	
Ignition – Distributor Rotor	**DR1250**	1	
41and 51 Series **V8 Electronic Distributor**			
Ignition – Distributor Cap	**BD2000**	1	
Ignition – Distributor Rotor	**AL104**	1	
43 Series **V8 Electronic Distributor**			
Ignition – Distributor Cap	**BD1290**	1	
Ignition – Distributor Rotor	**DR1250**	1	
Alfa Romeo			
33 Incl. Ti: Super **5/84-1/89 4 Cyl 1.5L 301.82: 305.26 1.7L 305.50 SOHC 8V 2xCarb. FWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	From 1985
33 IE **10/88-6/90 4 Cyl 1.7L AR305.58 SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS790**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS145**	1	
Switch – Oil Pressure Warning Light	**CPS21**	1	
Switch – Radiator Fan	**CFS33**	1	
33 Boxer QV **7/90-12/92 4 Cyl 1.7L AR307 DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS790**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS145**	1	

Alfa Romeo	Part No	Qty	Notes
33 S P4			
5/91-12/92 4 Cyl 1.7L AR307 DOHC 16V EFi 4WD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Temperature Gauge	**CTS145**	1	
75			
10/86-4/88 V6 Cyl 2.5L AR0191 DOHC MPFi RWD			
Ignition – Coil – Standard	**CC215**	1	Manual Transmission
Ignition – Distributor Cap	**BH140**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH177**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
Sensor – Coolant Temperature	**CCS25**	1	
Switch – Radiator Fan	**CFS35**	1	
75 Twin Spark			
1/88-12/92 4 Cyl 2.0L AR062.24 DOHC 8V MPFi RWD			
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS133**	1	
Switch – Radiator Fan	**CFS35**	1	
75			
1/88-4/90 V6 Cyl 2.5L AR019.11 SOHC 12V MPFi RWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH140**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH177**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
75			
3/88-12/92 V6 Cyl 3.0L AR061.74 SOHC 12V MPFi RWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH140**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH177**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
Sensor – Coolant Temperature	**CCS25**	1	
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Switch – Radiator Fan	**CFS35**	1	
90			
6/85-2/88 V6 Cyl 2.5L AR016.46 & AR019.11 DOHC EFi RWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH140**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH177**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
Sensor – Coolant Temperature	**CCS25**	1	
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire: Unleaded Fuel
Switch – Oil Pressure Warning Light	**CPS20**	1	
Switch – Radiator Fan	**CFS35**	1	
147 Selespeed			
9/01-on 4 Cyl 2.0L AR32310 DOHC 16V MPFi FWD			
Sensor – Air Flow / MAF	**CAF001**	1	

Alfa Romeo	Part No	Qty	Notes
156 Twin Spark & Sportswagon			
2/99-12/02 4 Cyl 2.0L AR323.01 DOHC 16V EFi FWD			
Sensor – Air Flow / MAF	**CAF001**	1	
164			
2/89-12/92 V6 Cyl 3.0L AR064.10 & AR643.01 SOHC 12V EFi FWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BD580**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH225**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Alfasud			
3/74-12/78 4 Cyl 1.2L AS301.10 OHC 8V Carb. FWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor: To 1978
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor: To 1978
Ignition – Distributor Rotor	**BH89**	1	Bosch Points Distributor: To 1978
Sensor – Temperature Gauge	**CTS133**	1	
Switch – Oil Pressure Warning Light	**CPS21**	1	
Switch – Radiator Fan	**CFS34**	1	
Alfasud Sprint			
7/79-5/85 4 Cyl 1.5L AR301 SOHC Carb. & 2xCarb. FWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor: From 1982
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor: From 1982
Ignition – Module	**CM413**	1	
Sensor – Temperature Gauge	**CTS133**	1	
Switch – Oil Pressure Warning Light	**CPS21**	1	
Switch – Radiator Fan	**CFS34**	1	
Alfetta			
3/74-12/78 4 Cyl 1.8L AR016 DOHC 2xCarb. RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH72**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC86**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH89**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS133**	1	
Switch – Oil Pressure Warning Light	**CPS20**	1	
Switch – Radiator Fan	**CFS35**	1	
Alfetta 2000			
3/78-11/78 4 Cyl 2.0L AR016.2 DOHC 2xCarb. RWD			
Ignition – Coil – Standard	**CIC31**	1	Points Ignition
Ignition – Coil – Standard	**CC215**	1	Electronic Ignition
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	Points Ignition
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Points / Contact Set	**S156**	1	Marelli Points Distributor
Ignition – Distributor Rotor	**FR519**	1	Marelli Points Distributor
Ignition – Distributor Rotor	**BH95**	1	Bosch Electronic Distributor: From 1978
Ignition – Module	**CM413**	1	
Sensor – Temperature Gauge	**CTS133**	1	
Switch – Oil Pressure Warning Light	**CPS20**	1	
Switch – Radiator Fan	**CFS35**	1	

Alfa Romeo	Part No	Qty	Notes
Berlina 1750: 2000			
6/68-6/76 4 Cyl 1.8L DOHC Carb: 2.0L DOHC 2xCarb. RWD			
Ignition – Coil – Standard	**CIC31**	1	Points Ignition
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	Points Ignition
Ignition – Distributor Cap	**BH72**	1	Bosch Points Distributor
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor: From 1974
Ignition – Distributor Condenser	**BC86**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH89**	1	All
Giulia 1300 Ti			
3/68-6/71 4 Cyl 1.3L DOHC Carb. RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH72**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC86**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH89**	1	Bosch Points Distributor
Giulietta			
7/80-3/86 4 Cyl 1.8L AR016.08: 2.0L AR016.55 DOHC 16V 2xCarb. RWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
Sensor – Temperature Gauge	**CTS133**	1	
Switch – Oil Pressure Warning Light	**CPS20**	1	
Switch – Radiator Fan	**CFS35**	1	
GT1300 Junior: GT1600			
8/68-6/74 4 Cyl 1.3L DOHC 2xCarb: 1.6L DOHC Carb. RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Points / Contact Set	**S156**	1	Marelli Points Distributor
GTV 6			
3/83-9/86 V6 Cyl 2.5L AR01646 DOHC EFi RWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH140**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH177**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	Leaded Fuel: To 1985
Sensor – Coolant Temperature	**CCS25**	1	
Sensor – Exhaust Oxygen	**COS811**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Oil Pressure Warning Light	**CPS20**	1	
Switch – Radiator Fan	**CFS35**	1	
Spider			
6/98-9/03 4 Cyl 2.0L AR323.10 DOHC 16V MPFi FWD			
Sensor – Air Flow / MAF	**CAF002**	1	
Sprint			
6/85-2/88 4 Cyl 1.5L AR301.46 DOHC 2xCarb. FWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor

Audi	Part No	Qty	Notes
5+5			
10/81-6/84 5 Cyl 2.2L WE SOHC EFi FWD			
Ignition – Module	**CM409**	1	
Sensor – Exhaust Oxygen	**COS738**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Switch – Oil Pressure Warning Light	**CPS20**	1	
Switch – Radiator Fan	**CFS18**	1	
5E			
3/78-11/82 5 Cyl 2.2L WE SOHC Fi FWD			
Ignition – Module	**CM409**	1	
80 CC			
6/86-7/87 4 Cyl 1.8L JN SOHC 8V EFi FWD			
Ignition – Distributor Cap	**BH136**	1	Bosch Electronic Distributor
Ignition – Module	**CM409**	1	
Sensor – Coolant Temperature	**CCS34**	1	
Sensor – Exhaust Oxygen	**COS811**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS157**	1	
Switch – Oil Pressure Warning Light	**CPS40**	1	
Switch – Radiator Fan	**CFS36**	1	
80 *(NZ Market)*			
1987-89 4 Cyl 1.8L			
Ignition – Coil – Standard	**CC211**	1	Bosch Electronic Distributor
Ignition – Distributor Cap	**BH136**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor
80			
8/88-12/88 4 Cyl 1.8L SD SOHC 8V EFi FWD			
Sensor – Coolant Temperature	**CCS34**	1	
Switch – Radiator Fan	**CFS36**	1	
80 Quattro			
10/88-6/89 4 Cyl 1.8L SD OHC EFi 4WD			
Sensor – Coolant Temperature	**CCS34**	1	
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Switch – Radiator Fan	**CFS36**	1	
80 B3 RWD			
1/89-3/89 4 Cyl 2.0L 3A SOHC 8V EFi RWD			
Ignition – Coil and Igniter	**CC374**	1	
Ignition – Module	**CM409**	1	
80 B3 FWD			
4/89-7/92 4 Cyl 2.0L AAD SOHC 8V EFi FWD			
Ignition – Coil and Igniter	**CC374**	1	
Ignition – Module	**CM409**	1	
Sensor – Exhaust Oxygen	**COS811**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
80 B4 2.0E			
8/92-8/95 4 Cyl 2.0L ABK SOHC 8V EFi FWD			
Ignition – Coil and Igniter	**CC376**	1	
Ignition – Distributor Cap	**JP987**	1	
Ignition – Distributor Rotor	**DR127**	1	
Ignition – Module	**CM409**	1	
Sensor – Temperature Gauge	**CTS157**	1	
Switch – Radiator Fan	**CFS36**	1	2 Terminal
Switch – Radiator Fan	**CFS19**	1	3 Terminal

Audi	Part No	Qty	Notes
80 B4 2.3E **8/92-9/93 5 Cyl 2.3L NG SOHC 10V EFi FWD**			
Ignition – Coil and Igniter	**CC374**	1	
Sensor – Exhaust Oxygen	**COS811**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Radiator Fan	**CFS36**	1	2 Terminal
Switch – Radiator Fan	**CFS19**	1	3 Terminal
80 B4 2.8E **8/92-3/94 V6 Cyl 2.8L AAH SOHC 12V EFi FWD**			
Switch – Radiator Fan	**CFS36**	1	2 Terminal
Switch – Radiator Fan	**CFS19**	1	3 Terminal
80 B4 2.6E **10/93-8/95 V6 Cyl 2.6L ABC SOHC 12V EFi FWD**			
Sensor – Exhaust Oxygen	**COS789**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Switch – Radiator Fan	**CFS36**	1	2 Terminal
Switch – Radiator Fan	**CFS19**	1	3 Terminal
90 Sport: Quattro **5/89-7/92 5 Cyl 2.3L: NG SOHC 10V EFi FWD: 7A DOHC 20V EFi 4WD**			
Ignition – Coil and Igniter	**CC375**	1	
Ignition – Distributor Rotor	**DR541**	1	
Ignition – Pickup / Trigger	**CIT141**	1	
Sensor – Coolant Temperature	**CCS32**	1	
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Switch – Radiator Fan	**CFS36**	1	2 Terminal
Switch – Radiator Fan	**CFS19**	1	3 Terminal
100 CD **12/83-2/85 5 Cyl 2.1L KF SOHC 10V EFi FWD**			
Ignition – Module	**CM409**	1	
Switch – Radiator Fan	**CFS36**	1	2 Terminal
Switch – Radiator Fan	**CFS19**	1	3 Terminal
100 CD **3/85-12/87 5 Cyl 2.2L HX SOHC 10V EFi FWD**			
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor
Ignition – Module	**CM409**	1	
100 CD **1/88-2/90 5 Cyl 2.3L NF SOHC 10V EFi FWD**			
Ignition – Module	**CM409**	1	
Sensor – Coolant Temperature	**CCS38**	1	
Sensor – Exhaust Oxygen	**COS793**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS116**	1	
Switch – Oil Pressure Warning Light	**CPS20**	1	
Switch – Radiator Fan	**CFS36**	1	2 Terminal
Switch – Radiator Fan	**CFS19**	1	3 Terminal
100 **4/89-3/91 5 Cyl 2.3L AAR SOHC 10V EFi FWD**			
Ignition – Coil and Igniter	**CC374**	1	
Sensor – Coolant Temperature	**CCS38**	1	
Sensor – Exhaust Oxygen	**COS793**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Switch – Radiator Fan	**CFS36**	1	2 Terminal
Switch – Radiator Fan	**CFS19**	1	3 Terminal

Audi	Part No	Qty	Notes
100 C4 Incl. Quattro			
7/93-11/94 V6 Cyl 2.8L AAH SOHC 12V EFi FWD & 4WD			
Sensor – Coolant Temperature	**CCS34**	1	
Sensor – Exhaust Oxygen	**COS789**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Switch – Radiator Fan	**CFS19**	1	
100 C4 2.6			
10/93-11/94 V6 Cyl 2.6L ABC SOHC 12V EFi FWD			
Sensor – Coolant Temperature	**CCS34**	1	
Switch – Radiator Fan	**CFS19**	1	
200T Turbo			
5/82-6/84 5 Cyl 2.1L KG SOHC 10V MPFi FWD			
Ignition – Module	**CM409**	1	
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
200 Turbo			
10/86-12/90 5 Cyl 2.2L MC SOHC 10V EFi FWD			
Ignition – Coil and Igniter	**CC374**	1	
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Switch – Radiator Fan	**CFS19**	1	
A3 8L 1.6			
5/97-7/04 4 Cyl 1.6L AEH SOHC 8V MPFi FWD			
Ignition – Coil and Igniter	**CC377**	1	
Sensor – Air Flow / MAF	**CAF027**	1	To Vin 8LV200000
Sensor – Air Flow / MAF	**CAF019**	1	From Vin 8LW000001
Sensor – Knock Control	**CKS116**	1	To Vin 8LX180000
Sensor – Temperature Gauge	**CCS53**	1	4 Pin green (dual): From Vin 8LX035001
A3 8L 1.8			
5/97-7/04 4 Cyl 1.8L AGN DOHC 20V MPFi FWD			
Ignition – Coil and Igniter	**CC377**	1	
Sensor – Air Flow / MAF	**CAF012**	1	2 Bolt Mount: 5 Terminal Connector
Sensor – Air Flow / MAF	**CAF027**	1	4 Bolt Mount: 3 Terminal Connector
Sensor – Air Temperature – Inlet	**CAT024**	1	
A4 B5 1.8			
8/95-6/01 4 Cyl 1.8L ADR DOHC 20V MPFi FWD			
Sensor – Air Flow / MAF	**CAF027**	1	To Vin 8DX199999
Sensor – Air Flow / MAF	**CAF006**	1	From Vin 8DX200001
Sensor – Air Temperature – Inlet	**CAT024**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS109**	1	Green
Sensor – Temperature Gauge	**CCS54**	1	4 Pin (dual): To Vin 8DX500000
Sensor – Temperature Gauge	**CCS53**	1	4 Pin green (dual): From Vin 8DY000001
A4 B5 2.6			
8/95-3/98 V6 Cyl 2.6L ABC SOHC 12V MPFi FWD			
Sensor – Exhaust Oxygen	**COS788**	2	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	2	Universal 3 Wire
A4 B5 1.8 Quattro			
1/96-10/96 4 Cyl 1.8L ADR DOHC 20V MPFi AWD			
Sensor – Air Flow / MAF	**CAF027**	1	To Vin 8DX199999
Sensor – Air Flow / MAF	**CAF006**	1	From Vin 8DX200001
Sensor – Air Temperature – Inlet	**CAT024**	1	

Audi	Part No	Qty	Notes
A4 B5 1.8 Turbo **6/96-5/99 4 Cyl 1.8L AEB DOHC 20V MPFi FWD**			
Sensor – Air Flow / MAF	**CAF020**	1	
A4 B5 1.8 **1/97-5/99 4 Cyl 1.8L ADR DOHC 20V MPFi FWD**			
Sensor – Air Temperature – Inlet	**CAT024**	1	
A8 Quattro **5/95-11/00 V8 Cyl 4.2L ABZ DOHC 32V MPFi 4WD**			
Sensor – Coolant Temperature	**CCS32**	1	
Fox **1973-79 4 Cyl 1.5L ZC OHC: 1.6L FS DOHC 16V: Carb. FWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH100**	1	
Ignition – Distributor Points / Contact Set	**S11V**	1	
Ignition – Distributor Rotor	**BH95**	1	
Sensor – Temperature Gauge	**CTS116**	1	
Switch – Radiator Fan	**CFS18**	1	
Quattro **11/90-5/92 V8 Cyl 3.6L PTK DOHC 32V EFi 4WD**			
Sensor – Coolant Temperature	**CCS32**	1	
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 2 Wire
S4 Turbo **7/93-2/95 5 Cyl 2.2L AAN DOHC 20V EFi 4WD**			
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Austin			
1800 **1965-70 4 Cyl 1.8L B Carb. FWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD268**	1	Lucas Points Distributor: To 1967
Ignition – Distributor Cap	**BD278**	1	Lucas Points Distributor: From 1967
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor: To 1967
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor: From 1967
Sensor – Temperature Gauge	**CTS128**	1	
Switch – Oil Pressure Warning Light	**CPS35**	1	
Freeway **1962-65 6 Cyl 2.4L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD250**	1	Lucas Points Distributor

Austin	Part No	Qty	Notes
Healey 3000 A110 Mk.III			
1963-68 6 Cyl 2.9L Carb. RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: From 1964
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor: From 1964
Ignition – Distributor Rotor	**BD250**	1	Lucas Points Distributor: From 1964
Healey Sprite Mk.I: Mk.II: Mk.IIA: Mk.III			
1956-67 4 Cyl 947cc A: 1.1L A: Carb. RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD268**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor
Switch – Oil Pressure Warning Light	**CPS35**	1	
Kimberley: Tasman			
1970-73 6 Cyl 2.2L X6 SOHC Carb. FWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS128**	1	
Switch – Oil Pressure Warning Light	**CPS35**	1	
Bedford			
CF			
1970-73 4 Cyl 2.0L Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**UC11E**	1	Delco Points Distributor
Ignition – Distributor Points / Contact Set	**S50**	1	Denso Points Distributor
Switch – Oil Pressure Warning Light	**CPS34**	1	
CF			
1973-81 6 Cyl 2.8L: 3.0L Holden OHV 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS123**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	

BMW	Part No	Qty	Notes
3.0: 3.0Si: 3.0CSi: 3.3L E3 **11/71-6/78 6 Cyl 3.0L: 3.3L OHC 2xCarb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC86**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S4V**	1	3.0, 3.0Si, 3.0CSi: Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	3.3L: Bosch Points Distributor
Ignition – Distributor Rotor	**DR460**	1	Bosch Points Distributor
316i E36 **3/95-4/99 4 Cyl 1.6L M43B16 SOHC 8V EFi RWD**			
Ignition – Coil – Standard	**CC368**	1	
Sensor – Camshaft	**CSCA185**	1	To 9/1995
Sensor – Camshaft	**CSCA193**	1	From 9/1995
Sensor – Crankshaft	**CSCA186**	1	To 9/1995
Sensor – Crankshaft	**CSCA169**	1	From 9/1995
Sensor – Exhaust Oxygen	**COS811**	1	Direct Fit 4 Wire: To 9/1995
Sensor – Exhaust Oxygen	**COS863**	1	Direct Fit 4 Wire: From 1/1996
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS153**	1	
Switch – Oil Pressure Warning Light	**CPS49**	1	
Switch – Radiator Fan	**CFS76**	1	
316Ti E46 **10/01-7/05 4 Cyl 1.8L N42B18 DOHC 16V ESPFI RWD**			
Sensor – Camshaft	**CSCA122**	1	
Sensor – Crankshaft	**CSCA142**	1	
Sensor – Exhaust Oxygen	**COS933**	1	Direct Fit 1 Wire: Front Pipe Front
Sensor – Exhaust Oxygen	**COS891**	1	Direct Fit 1 Wire: Front Pipe Rear
Sensor – Exhaust Oxygen	**COS933**	1	Direct Fit 1 Wire: Rear Pipe Front
Sensor – Exhaust Oxygen	**COS891**	1	Direct Fit 1 Wire: Rear Pipe Rear
Sensor – Exhaust Oxygen – Universal	**COS720**	4	Universal 1 Wire: All
Switch – Oil Pressure Warning Light	**CPS49**	1	
318i E21: E30 **3/80-10/87 4 Cyl 1.8L M10 SOHC 8V EFi RWD**			
Ignition – Distributor Cap	**BH136**	1	Bosch Electronic Distributor: E21 & E30
Ignition – Distributor Rotor	**DR460**	1	Bosch Electronic Distributor: E21 & E30
Ignition – Module	**CM413**	1	E21 & E30
Sensor – Coolant Temperature	**CCS25**	1	E30
Sensor – Exhaust Oxygen	**COS812**	1	Direct Fit 4 Wire: E30
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: E30
Sensor – Temperature Gauge	**CTS140**	1	E30
Switch – Oil Pressure Warning Light	**CPS42**	1	E30
Switch – Radiator Fan	**CFS76**	1	E30
318i B709 *(NZ Market)* **1984-91 4 Cyl 1.8L E30**			
Ignition – Distributor Cap	**BH136**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH225**	1	Bosch Electronic Distributor
318i E30 **11/88-3/91 4 Cyl 1.8L M40B18 SOHC 8V EFi RWD**			
Ignition – Distributor Cap	**BH232**	1	
Ignition – Distributor Rotor	**BH225**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS140**	1	
Switch – Oil Pressure Warning Light	**CPS49**	1	
Switch – Radiator Fan	**CFS76**	1	

BMW	Part No	Qty	Notes
318is E30			
7/90-3/91 4 Cyl 1.8L M42B18 DOHC 16V EFi RWD			
Sensor – Crankshaft	**CSCA187**	1	
Sensor – Exhaust Oxygen	**COS812**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Oil Pressure Warning Light	**CPS49**	1	
318i E36			
4/91-8/98 4 Cyl 1.8L M40B18 SOHC 8V EFi RWD			
Ignition – Distributor Cap	**BH232**	1	
Ignition – Distributor Rotor	**BH225**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA180**	1	
Sensor – Exhaust Oxygen	**COS877**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Oil Pressure Warning Light	**CPS49**	1	
Switch – Radiator Fan	**CFS76**	1	With Air Conditioning
318is E36			
4/92-5/96 4 Cyl 1.8L M42B18 DOHC 16V EFi RWD			
Sensor – Exhaust Oxygen	**COS829**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen	**COS913**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: All Locations
318Ti E36			
4/96-5/01 4 Cyl 1.9L M44B19 DOHC 16V MPFi RWD			
Ignition – Coil – Standard	**CC368**	1	
318i E46			
9/98-12/01 4 Cyl 1.9L M43B19 SOHC 8V MPFi RWD			
Sensor – Air Flow / MAF	**CAF009**	1	
Sensor – Camshaft	**CSCA122**	1	
Sensor – Crankshaft	**CSCA140**	1	
Sensor – Exhaust Oxygen	**COS865**	2	Direct Fit 4 Wire: Front of Catalyst
Sensor – Exhaust Oxygen	**COS891**	1	Direct Fit 1 Wire: Rear of Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front of Catalyst
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: Rear of Catalyst
318i E46			
10/01-4/05 4 Cyl 2.0L N42B20 DOHC 16V MPFi RWD			
Sensor – Exhaust Oxygen	**COS891**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen	**COS934**	1	Direct Fit 1 Wire: Front Pipe Catalyst
Sensor – Exhaust Oxygen	**COS933**	1	Direct Fit 1 Wire: After Catalyst
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: All Locations
318Ti E46			
10/01-7/05 4 Cyl 2.0L N42B20 DOHC 16V MPFi RWD			
Sensor – Camshaft	**CSCA122**	1	
Sensor – Crankshaft	**CSCA142**	1	
320: 320i E21			
3/76-2/80 4 Cyl 2.0L M10B20 SOHC Carb. RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC446**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S12**	1	Bosch Points Distributor: To 6/1976
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor: From 7/1976
Ignition – Distributor Rotor	**DR460**	1	Bosch Points Distributor

BMW	Part No	Qty	Notes
320i E30			
2/88-3/90 6 Cyl 2.0L M20B20 SOHC 12V EFi RWD			
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS811**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS140**	1	
Switch – Oil Pressure Warning Light	**CPS44**	1	
Switch – Radiator Fan	**CFS40**	1	On at 95°C Off at 90°C
Switch – Radiator Fan	**CFS39**	1	On at 102°C Off 97°C
320i E36			
4/91-12/95 6 Cyl 2.0L M50B20 DOHC 24V EFi RWD			
Ignition – Coil – Standard	**CC363**	1	
Sensor – Exhaust Oxygen	**COS889**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS140**	1	
Switch – Oil Pressure Warning Light	**CPS44**	1	
Switch – Radiator Fan	**CFS40**	1	On at 95°C Off at 90°C
Switch – Radiator Fan	**CFS39**	1	On at 102°C Off 97°C
320i E46			
10/00-4/05 6 Cyl 2.2L M54B22 DOHC 24V MPFi RWD			
Ignition – Coil – Standard	**CC370**	1	To 9/2002
Sensor – Air Flow / MAF	**CAF016**	1	
Sensor – Camshaft	**CSCA119**	1	LH Side
Sensor – Camshaft	**CSCA122**	1	RH Side
Sensor – Crankshaft	**CSCA140**	1	
Sensor – Exhaust Oxygen	**COS877**	1	Direct Fit 4 Wire: Front Manifold
Sensor – Exhaust Oxygen	**COS934**	1	Direct Fit 1 Wire: Rear Manifold
Sensor – Exhaust Oxygen	**COS912**	1	Direct Fit 1 Wire: Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Front Manifold
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: Rear Manifold and Catalyst
323i E21: E30			
6/79-12/85 6 Cyl 2.3L M20B23 SOHC 8V KJET RWD			
Ignition – Distributor Cap	**BH138**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH129**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	To 9/1984
323i E36			
1/96-8/98 6 Cyl 2.5L M52B25 DOHC 24V SEPFI RWD			
Sensor – Camshaft	**CSCA120**	1	
Sensor – Crankshaft	**CSCA139**	1	
323i E46			
9/98-10/00 6 Cyl 2.5L M52B25 DOHC 24V MPFi RWD			
Ignition – Coil – Standard	**CC370**	6	
Sensor – Air Flow / MAF	**CAF016**	1	From 9/1998
325e: 325i E30			
1/86-3/91 6 Cyl 2.5L M20B25 & 2.7L M20B27 SOHC 12V LJET RWD			
Ignition – Distributor Cap	**BD580**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH225**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS829**	1	Direct Fit 4 Wire: 325e
Sensor – Exhaust Oxygen	**COS811**	1	Direct Fit 4 Wire: 325i
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS137**	1	
Switch – Oil Pressure Warning Light	**CPS44**	1	325e
Switch – Oil Pressure Warning Light	**CPS49**	1	325i
Switch – Radiator Fan	**CFS40**	1	On at 95°C Off at 90°C
Switch – Radiator Fan	**CFS39**	1	On at 102°C Off 97°C

BMW	Part No	Qty	Notes
325is E30			
9/88-3/90 6 Cyl 2.5L M20B25 SOHC 12V MPFi RWD			
Sensor – Exhaust Oxygen	**COS811**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
325i E36			
4/91-5/95 6 Cyl 2.5L M50B25 DOHC 24V LJET RWD			
Sensor – Exhaust Oxygen	**COS889**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen	**COS811**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS140**	1	
Switch – Oil Pressure Warning Light	**CPS49**	1	
Switch – Radiator Fan	**CFS40**	1	On at 95°C Off at 90°C
Switch – Radiator Fan	**CFS39**	1	On at 102°C Off at 97°C
325i E46			
10/00-4/05 6 Cyl 2.5L M54B25 DOHC 24V MPFi RWD			
Sensor – Air Flow / MAF	**CAF016**	1	
Sensor – Camshaft	**CSCA119**	1	LH Side: Inlet
Sensor – Camshaft	**CSCA122**	1	RH Side: Exhaust
Sensor – Crankshaft	**CSCA140**	1	
Sensor – Exhaust Oxygen	**COS866**	1	Direct Fit 4 Wire: Front Manifold
Sensor – Exhaust Oxygen	**COS934**	1	Direct Fit 1 Wire: Rear Manifold
Sensor – Exhaust Oxygen	**COS912**	1	Direct Fit 1 Wire: Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Front Manifold
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: Rear Manifold and Catalyst
325Ci E46			
10/00-2/07 6 Cyl 2.5L M54B25 DOHC 24V ESPFI RWD			
Sensor – Air Flow / MAF	**CAF016**	1	
Sensor – Camshaft	**CSCA119**	1	LH Side: Inlet
Sensor – Camshaft	**CSCA122**	1	RH Side: Exhaust
Sensor – Crankshaft	**CSCA140**	1	
Sensor – Exhaust Oxygen	**COS912**	1	Direct Fit 1 Wire: Manifold Front
Sensor – Exhaust Oxygen	**COS934**	1	Direct Fit 1 Wire: Manifold Rear
Sensor – Exhaust Oxygen	**COS912**	1	Direct Fit 1 Wire: Catalyst
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: All Locations
325ti E46			
3/02-7/05 6 Cyl 2.5L M54B25 DOHC 24V EPFI RWD			
Sensor – Air Flow / MAF	**CAF016**	1	
Sensor – Camshaft	**CSCA119**	1	LH Side: Inlet
Sensor – Camshaft	**CSCA122**	1	RH Side: Exhaust
Sensor – Crankshaft	**CSCA140**	1	
Sensor – Exhaust Oxygen	**COS866**	1	Direct Fit 4 Wire: Front Manifold
Sensor – Exhaust Oxygen	**COS934**	1	Direct Fit 1 Wire: Rear Manifold
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Front Manifold
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: Rear Manifold
328i E36			
6/95-8/00 6 Cyl 2.8L M52B28 DOHC 24V EFi RWD			
Sensor – Camshaft	**CSCA120**	1	
Sensor – Crankshaft	**CSCA139**	1	To 9/1998
Sensor – Crankshaft	**CSCA140**	1	From 9/1998

BMW	Part No	Qty	Notes
328Ci E46			
6/99-9/00 6 Cyl 2.8L M52B28 DOHC 24V MPFi RWD			
Sensor – Air Flow / MAF	**CAF016**	1	
Sensor – Camshaft	**CSCA119**	1	LH Side: Inlet
Sensor – Camshaft	**CSCA122**	1	RH Side: Exhaust
Sensor – Crankshaft	**CSCA140**	1	
Sensor – Exhaust Oxygen	**COS865**	2	Direct Fit 4 Wire: Rear Manifold
Sensor – Exhaust Oxygen	**COS866**	1	Direct Fit 4 Wire: Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Rear Manifold and Catalyst
330i E46			
9/00-4/05 6 Cyl 3.0L M54B30 DOHC 24V ESPFI RWD			
Sensor – Air Flow / MAF	**CAF028**	1	
Sensor – Camshaft	**CSCA119**	1	LH Side: Inlet
Sensor – Camshaft	**CSCA122**	1	RH Side: Exhaust
Sensor – Crankshaft	**CSCA140**	1	
Sensor – Exhaust Oxygen	**COS934**	2	Direct Fit 1 Wire: Front Manifold
Sensor – Exhaust Oxygen	**COS865**	2	Direct Fit 4 Wire: Rear Manifold
Sensor – Exhaust Oxygen	**COS912**	2	Direct Fit 1 Wire: Rear Manifold and Catalyst
Sensor – Exhaust Oxygen	**COS934**	1	Direct Fit 1 Wire: Rear of Catalyst
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: Front and Rear Manifold: Catalyst and Rear of Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Rear Manifold
330Ci E46			
9/00-2/07 6 Cyl 3.0L M54B30 DOHC 24V MPFi RWD			
Sensor – Air Flow / MAF	**CAF028**	1	
Sensor – Camshaft	**CSCA119**	1	LH Side: Inlet
Sensor – Camshaft	**CSCA122**	1	RH Side: Exhaust
Sensor – Crankshaft	**CSCA140**	1	
Sensor – Exhaust Oxygen	**COS934**	1	Direct Fit 1 Wire: Front Manifold
Sensor – Exhaust Oxygen	**COS912**	1	Direct Fit 1 Wire: Rear Manifold
Sensor – Exhaust Oxygen	**COS865**	2	Direct Fit 4 Wire: Rear Manifold
Sensor – Exhaust Oxygen	**COS934**	1	Direct Fit 1 Wire: Rear of Catalyst
Sensor – Exhaust Oxygen – Universal	**COS720**	3	Universal 1 Wire: Front and Rear Manifold: Rear of Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Rear Manifold
520: 520i E12			
5/73-12/78 4 Cyl 2.0L M10 SOHC 2xCarb. & EFi RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH72**	1	Bosch Points Distributor: To 1975
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor: From 1975
Ignition – Distributor Condenser	**BC74**	1	Bosch Points Distributor: To 1975
Ignition – Distributor Condenser	**BC446**	1	Bosch Points Distributor: From 1975
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor: To 1975
Ignition – Distributor Rotor	**DR460**	1	Bosch Points Distributor
520i E28			
3/83-12/85 6 Cyl 2.0L M20B20 SOHC 12V L Jetronic RWD			
Ignition – Distributor Cap	**BH138**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH129**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
Sensor – Coolant Temperature	**CCS25**	1	
Sensor – Temperature Gauge	**CTS140**	1	
Switch – Oil Pressure Warning Light	**CPS49**	1	
Switch – Radiator Fan	**CFS40**	1	On at 95°C Off at 90°C
Switch – Radiator Fan	**CFS39**	1	On at 102°C Off 97°C

BMW	Part No	Qty	Notes
520i E34			
11/90-3/96 6 Cyl 2.0L M50B20 DOHC 24V MPFi RWD			
Ignition – Module	**CM413**	1	
Sensor – Camshaft	**CSCA183**	1	To 9/1992
Sensor – Camshaft	**CSCA120**	1	From 9/1992
Sensor – Crankshaft	**CSCA188**	1	To 9/1992
Sensor – Exhaust Oxygen	**COS809**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen	**COS889**	1	Direct Fit 4 Wire: Before muffler
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Before muffler
Sensor – Temperature Gauge	**CTS140**	1	
Switch – Oil Pressure Warning Light	**CPS49**	1	
Switch – Radiator Fan	**CFS40**	1	On at 95°C Off at 90°C
Switch – Radiator Fan	**CFS39**	1	On at 102°C Off 97°C
523i E39			
4/96-11/00 6 Cyl 2.5L M52B25 DOHC 24V MPFi RWD			
Sensor – Camshaft	**CSCA120**	1	To 9/1998
Sensor – Camshaft	**CSCA119**	1	LH Side: From 9/1998
Sensor – Camshaft	**CSCA122**	1	RH Side: From 9/1998
Sensor – Crankshaft	**CSCA139**	1	To 9/1998
Sensor – Crankshaft	**CSCA140**	1	From 9/1998
Sensor – Exhaust Oxygen	**COS776**	1	Direct Fit 1 Wire: Manifold Rear
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: Rear Manifold
525 E12			
3/74-8/75 6 Cyl 2.5L OHC 2xCarb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC86**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR460**	1	Bosch Points Distributor
525e E28			
1/86-8/88 6 Cyl 2.7L M20B27 SOHC 12V EFi RWD			
Ignition – Distributor Cap	**BD580**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH225**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
Sensor – Exhaust Oxygen	**COS829**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS140**	1	
Switch – Oil Pressure Warning Light	**CPS44**	1	
Switch – Radiator Fan	**CFS40**	1	On at 95°C Off at 90°C
Switch – Radiator Fan	**CFS39**	1	On at 102°C Off 97°C
525i E34			
9/88-10/90 6 Cyl 2.5L M20B25 SOHC 12V EFi RWD			
Ignition – Distributor Cap	**BD580**	1	
Sensor – Crankshaft	**CSCA205**	1	Motronic
Sensor – Exhaust Oxygen	**COS809**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CCS26**	1	
Switch – Oil Pressure Warning Light	**CPS49**	1	
Switch – Radiator Fan	**CFS40**	1	On at 95°C Off at 90°C
Switch – Radiator Fan	**CFS39**	1	On at 102°C Off 97°C

BMW	Part No	Qty	Notes
525i E34			
11/90-12/96 6 Cyl 2.5L M50B25 DOHC 24V EFi RWD			
Ignition – Module	**CM413**	1	
Sensor – Camshaft	**CSCA183**	1	Without VCT: To 9/1992
Sensor – Camshaft	**CSCA181**	1	With VCT: From 9/1992
Sensor – Crankshaft	**CSCA188**	1	
Sensor – Exhaust Oxygen	**COS809**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CCS26**	1	
Switch – Oil Pressure Warning Light	**CPS49**	1	
Switch – Radiator Fan	**CFS40**	1	On at 95°C Off at 90°C
Switch – Radiator Fan	**CFS39**	1	On at 102°C Off 97°C
528 E12			
1975 6 Cyl 2.8L M30 OHC 2xCarb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR460**	1	Bosch Points Distributor
528i E12			
8/77-12/83 6 Cyl 2.8L M30B28 SOHC EFi RWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH140**	1	Bosch Electronic Distributor: To 1981
Ignition – Distributor Rotor	**BH129**	1	Bosch Electronic Distributor: To 1981
Ignition – Module	**CM413**	1	
528i E28			
1/84-12/85 6 Cyl 2.8L M30B28 OHC EFi RWD			
Ignition – Distributor Cap	**BH140**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH177**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS25**	1	
Sensor – Exhaust Oxygen	**COS776**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS137**	1	
Switch – Oil Pressure Warning Light	**CPS44**	1	
Switch – Radiator Fan	**CFS40**	1	On at 95°C Off at 90°C
Switch – Radiator Fan	**CFS39**	1	On at 102°C Off 97°C
528i E39			
4/96-11/00 6 Cyl 2.8L M52B28 DOHC EFi RWD			
Sensor – Air Flow / MAF	**CAF016**	1	
530i E34			
4/93-3/96 V8 Cyl 3.0L M60B30 DOHC 32V EFi RWD			
Sensor – Camshaft	**CSCA121**	1	
Sensor – Coolant Temperature	**CCS32**	1	For Electronic Power Regulation
Sensor – Crankshaft	**CSCA141**	1	
Switch – Radiator Fan	**CFS76**	1	
530i E39			
3/01-4/04 6 Cyl 3.0L M54B30 DOHC 24V ESPFI RWD			
Ignition – Coil – Standard	**CC370**	6	To 9/2002
Sensor – Air Flow / MAF	**CAF028**	1	

BMW	Part No	Qty	Notes
535i E28			
1/86-8/88 6 Cyl 3.4L M30 SOHC 12V EFi RWD			
Ignition – Distributor Cap	**BD580**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH225**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS785**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Switch – Radiator Fan	**CFS76**	1	
535i E34			
9/88-5/93 6 Cyl 3.4L M30B35 SOHC 12V EFi RWD			
Ignition – Distributor Cap	**BD580**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA182**	1	
Sensor – Exhaust Oxygen	**COS809**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen	**COS874**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Sensor – Throttle Position	**CTPS144**	1	Manual Transmission
535is E34			
6/89-12/90 6 Cyl 3.4L M30B35 SOHC 12V EFi RWD			
Ignition – Coil – Standard	**CC361**	1	
Sensor – Exhaust Oxygen	**COS809**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen	**COS874**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
535i E39			
10/96-10/03 V8 Cyl 3.5L M62B35 DOHC 32V EFi RWD			
Sensor – Exhaust Oxygen	**COS877**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
540i E34			
4/93-3/96 V8 Cyl 4.0L M60B40 DOHC 32V EFi RWD			
Sensor – Air Flow / MAF	**CAF018**	1	
Sensor – Camshaft	**CSCA121**	1	
Sensor – Coolant Temperature	**CCS32**	1	For Electronic Power Regulation
Sensor – Crankshaft	**CSCA141**	1	
Sensor – Exhaust Oxygen	**COS811**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Switch – Radiator Fan	**CFS76**	1	
540i E39			
10/96-10/03 V8 Cyl 4.4L M62B44 DOHC 32V MPFi RWD			
Sensor – Air Flow / MAF	**CAF018**	1	
Sensor – Exhaust Oxygen	**COS877**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
633CSi E24			
3/77-12/80 6 Cyl 3.2L M30 SOHC EFi RWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH140**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH129**	1	Bosch Electronic Distributor
Sensor – Exhaust Oxygen	**COS874**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire

BMW	Part No	Qty	Notes
635CSi E24			
5/86-9/89 6 Cyl 3.4L M30 SOHC 12V EFi RWD			
Ignition – Distributor Cap	**BD580**	1	Bosch Electronic Distributor
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS156**	1	
Switch – Oil Pressure Warning Light	**CPS43**	1	
Switch – Radiator Fan	**CFS40**	1	On at 95°C Off at 90°C
Switch – Radiator Fan	**CFS39**	1	On at 102°C Off 97°C
730i E32			
11/90-5/93 6 Cyl 3.0L M30B30 SOHC 12V EFi RWD			
Sensor – Exhaust Oxygen	**COS809**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Radiator Fan	**CFS76**	1	
730iL E32			
11/92-10/94 V8 Cyl 3.0L M60B30 DOHC 32V MPFi RWD			
Sensor – Camshaft	**CSCA121**	1	
Sensor – Coolant Temperature	**CCS32**	1	For Electronic Power Regulation
Sensor – Crankshaft	**CSCA141**	1	
Sensor – Exhaust Oxygen	**COS874**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Switch – Radiator Fan	**CFS76**	1	
730iL E38			
11/94-5/96 V8 Cyl 3.0L M60B30 DOHC 32V MPFi RWD			
Sensor – Exhaust Oxygen	**COS863**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
733i E32			
2/78-4/83 6 Cyl 3.2L M30 SOHC EFi RWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH140**	1	Bosch Electronic Distributor: To 1982
Ignition – Distributor Rotor	**BH177**	1	Bosch Electronic Distributor: To 1982
Sensor – Coolant Temperature	**CCS25**	1	
Sensor – Exhaust Oxygen	**COS776**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
735i E23			
5/83-2/84 6 Cyl 3.2L M30 SOHC 12V EFi RWD			
Ignition – Coil – Standard	**CC213**	1	
735i E32			
3/85-9/88 6 Cyl 3.4L M30 SOHC 12V EFi RWD			
Sensor – Coolant Temperature	**CCS25**	1	
Sensor – Temperature Gauge	**CTS153**	1	
Switch – Oil Pressure Warning Light	**CPS49**	1	
Switch – Radiator Fan	**CFS40**	1	On at 95°C Off at 90°C
Switch – Radiator Fan	**CFS39**	1	On at 102°C Off 97°C
735i E32			
3/87-12/90 6 Cyl 3.4L M30 SOHC 12V EFi RWD			
Sensor – Exhaust Oxygen	**COS810**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire

BMW	Part No	Qty	Notes
735iL E32			
10/88-11/92 6 Cyl 3.4L M30 SOHC 12V MPFi RWD			
Ignition – Distributor Cap	**BD580**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH225**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS25**	1	
Sensor – Exhaust Oxygen	**COS809**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS153**	1	
Switch – Oil Pressure Warning Light	**CPS49**	1	
Switch – Radiator Fan	**CFS40**	1	On at 95°C Off at 90°C
Switch – Radiator Fan	**CFS39**	1	On at 102°C Off 97°C
740iL E32			
11/92-10/94 V8 Cyl 4.0L M60B40 DOHC 32V MPFi RWD			
Sensor – Exhaust Oxygen	**COS874**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Radiator Fan	**CFS76**	1	
740iL E38			
11/94-6/96 V8 Cyl 4.0L M60B40 DOHC 32V MPFi RWD			
Sensor – Exhaust Oxygen	**COS863**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
750iL E32			
1/88-10/94 V12 Cyl 5.0L M70 DOHC 24V EFi RWD			
Sensor – Exhaust Oxygen	**COS815**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Sensor – Temperature Gauge	**CTS153**	1	
Switch – Radiator Fan	**CFS76**	1	
750iL E38			
11/94-1/01 V12 Cyl 5.4L M73 SOHC 24V EFi RWD			
Sensor – Exhaust Oxygen	**COS877**	2	Direct Fit 4 Wire: Before Catalyst
Sensor – Exhaust Oxygen	**COS834**	2	Direct Fit 4 Wire: After Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	4	Universal 4 Wire: Before and After Catalyst
Switch – Radiator Fan	**CFS76**	1	
850i E31			
7/90-12/92 V12 Cyl 5.0L M70 SOHC 24V EFi RWD			
Sensor – Exhaust Oxygen	**COS877**	2	Direct Fit 4 Wire: LH & RH Side Front of Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: LH & RH Side Front of Catalyst
Sensor – Temperature Gauge	**CTS153**	1	
Switch – Radiator Fan	**CFS76**	1	
1600: 1602 E10			
10/67-7/73 4 Cyl 1.6L M116 SOHC Carb. RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH72**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC63**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S4V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
1800 E10			
5/67-4/69 4 Cyl 1.8L M118 Carb. RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH72**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC86**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH89**	1	Bosch Points Distributor

BMW	Part No	Qty	Notes
2000 E10			
5/67-6/72 4 Cyl 2.0L M05 SOHC Carb. & Fi RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH72**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC63**	1	Bosch Points Distributor: Carb
Ignition – Distributor Condenser	**BC74**	1	Bosch Points Distributor: Fi
Ignition – Distributor Points / Contact Set	**S4V**	1	Bosch Points Distributor: Carb
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor: Fi
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
2002: 2002Ti E10			
6/68-3/76 4 Cyl 2.0L SOHC Carb. & Fi RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC86**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH89**	1	Bosch Points Distributor: Non RPM Limited
Ignition – Distributor Rotor	**DR460**	1	Bosch Points Distributor: RPM Limited to 6600
2500: 2800 E3			
1/69-6/75 6 Cyl 2.5L M06 SOHC 2xCarb: 2.8L M06 SOHC Carb. RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC86**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH89**	1	Bosch Points Distributor
M3 E36			
6/94-1/96 6 Cyl 3.0L S50B30 DOHC 24V EFi RWD			
Sensor – Exhaust Oxygen	**COS874**	1	Direct Fit 4 Wire: LH Side Front of Catalyst
Sensor – Exhaust Oxygen	**COS811**	1	Direct Fit 4 Wire: RH Side Front of Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: LH & RH Side Front of Catalyst
M3 E46			
5/01-9/07 6 Cyl 3.2L S54B32 DOHC 24V PFI RWD			
Sensor – Camshaft	**CSCA123**	1	RH Side: Exhaust
Sensor – Crankshaft	**CSCA142**	1	
Sensor – Exhaust Oxygen	**COS935**	1	Direct Fit 1 Wire: Manifold Front
Sensor – Exhaust Oxygen	**COS900**	1	Direct Fit 1 Wire: Manifold Rear
Sensor – Exhaust Oxygen	**COS936**	1	Direct Fit 1 Wire: LH Side Rear of Catalyst
Sensor – Exhaust Oxygen	**COS934**	1	Direct Fit 1 Wire: RH Side Rear of Cat
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: All
M5 E34			
7/90-5/93 6 Cyl 3.5L S38 DOHC EFi RWD			
Sensor – Exhaust Oxygen	**COS791**	1	Direct Fit 3 Wire: 1990-92
Sensor – Exhaust Oxygen	**COS809**	1	Direct Fit 4 Wire: 1992-93
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 3 Wire: 1990-92
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: 1992-93
Switch – Radiator Fan	**CFS76**	1	
M5 E39			
3/99-10/03 V8 Cyl 5.0L S62B50 DOHC MPFi RWD			
Sensor – Camshaft	**CSCA123**	2	Exhaust
Sensor – Exhaust Oxygen	**COS834**	1	Direct Fit 4 Wire: Front of Catalyst
Sensor – Exhaust Oxygen	**COS866**	1	Direct Fit 4 Wire: Rear of Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear of Catalyst

BMW	Part No	Qty	Notes
M535i E28			
1/86-8/88 6 Cyl 3.4L M30B35 SOHC 12V EFi RWD			
Ignition – Distributor Cap	**BD580**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH225**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
X5 E53			
3/01-12/03 V8 Cyl 4.4L M62B44 DOHC 32V ESPFI FT4WD			
Sensor – Exhaust Oxygen	**COS877**	2	Direct Fit 4 Wire: LH & RH Side Before Catalyst
Sensor – Exhaust Oxygen	**COS865**	2	Direct Fit 4 Wire: LH & RH Side After Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	4	Universal 4 Wire: LH & RH Side Before and After Catalyst
X5 E53			
3/01-12/03 6 Cyl 3.0L M54B30 DOHC 24V ESPFI FT4WD			
Sensor – Air Flow / MAF	**CAF028**	1	
X5 E53			
2/02-10/03 V8 Cyl 4.6L M54B30 DOHC 32V ESPFI 4WD			
Ignition – Coil – Standard	**CC370**	8	
Sensor – Coolant Temperature	**CCS55**	1	
Sensor – Coolant Temperature	**CCS56**	1	In bottom radiator outlet
Sensor – Exhaust Oxygen	**COS877**	2	Direct Fit 4 Wire: LH & RH Side Before Catalyst
Sensor – Exhaust Oxygen	**COS865**	2	Direct Fit 4 Wire: LH & RH Side After Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	4	Universal 4 Wire: LH & RH Side Before and After Catalyst
Switch – Oil Pressure Warning Light	**CPS49**	1	
Chevrolet			
C20: C30			
1975-79 6 Cyl 292ci Carb. RWD			
Ignition – Coil – Standard	**CC207**	1	
Ignition – Distributor Cap Cover	**BC195**	1	Delco Electronic Distributor: From 1978
Ignition – Distributor Condenser	**BC231**	1	Delco Electronic Distributor: From 1978
Ignition – Distributor Rotor	**DR173**	1	Delco Electronic Distributor: From 1978
Ignition – Module	**CM410**	1	
C20: C30			
1979-81 V8 Cyl 350ci Carb. RWD			
Ignition – Coil – Standard	**CC207**	1	
Ignition – Distributor Cap	**BD171**	1	Delco Electronic Distributor
Ignition – Distributor Cap Cover	**BC195**	1	Delco Electronic Distributor
Ignition – Distributor Condenser	**BC231**	1	Delco Electronic Distributor
Ignition – Distributor Rotor	**DR173**	1	Delco Electronic Distributor
Ignition – Module	**CM410**	1	
C50: C60			
1975-77 6 Cyl 292ci Carb. RWD			
Ignition – Module	**CM410**	1	
Camaro			
1977-78 V8 Cyl 305ci Carb. RWD			
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS22**	1	
Caprice			
1987-88 V8 Cyl 305ci LG4 Carb. RWD			
Ignition – Coil – Standard	**CC207**	1	
Ignition – Distributor Cap	**BD249**	1	Delco Electronic Distributor

Chevrolet	Part No	Qty	Notes
Corvette **1970-75 V8 Cyl 454ci Carb. RWD**			
Ignition – Module	**CM410**	1	
K20 **1978-79 6 Cyl 292ci Carb. RWD**			
Ignition – Module	**CM410**	1	
Monte Carlo **1987-88 V8 Cyl 305, 350ci Carb. RWD**			
Ignition – Coil – Standard	**CC207**	1	
Ignition – Distributor Cap	**BD249**	1	Delco Electronic Distributor
Chrysler			
Centura KB **4/75-6/77 4 Cyl 2.0L OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**RB102**	1	Ducellier Points Distributor
Ignition – Distributor Rotor	**RB99**	1	Ducellier Points Distributor
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Centura KB: KC **4/75-6/78 6 Cyl 3.5L Hemi 215: 4.0L 245 OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	All
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH79**	1	Bosch Electronic Distributor
Ignition – Module	**CM423**	1	Electronic Ignition
Sensor – Temperature Gauge	**CTS127**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Galant GA **8/71-12/72 4 Cyl 1.3L 4G30: 1.5L 4G31 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**MC418**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	

Chrysler	Part No	Qty	Notes
Galant GB: GC: GD **11/72-6/77 4 Cyl 1.6L 4G32 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH96**	1	Bosch Points Distributor: To 1975
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor: From 1975
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor: To 1975
Ignition – Distributor Condenser	**MC409**	1	Mitsubishi Points Distributor: From 1975
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor: To 1975
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor: From 1975
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor: To 1975
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor: From 1975
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Brake Light	**CSL27**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Jeep Cherokee XJ Limited **4/94-1/98 6 Cyl 4.0L MX OHV 12V EFi 4WD**			
Sensor – Exhaust Oxygen	**COS804**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Oil Pressure Warning Light	**CPS39**	1	
Jeep Grand Cherokee ZG **3/96-7/99 6 Cyl 4.0L MX OHV PFI 4WD**			
Sensor – Exhaust Oxygen	**COS804**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Oil Pressure Warning Light	**CPS39**	1	
Jeep Wrangler TJ Sport **10/96-1/05 6 Cyl 4.0L MX OHV 12V MPFi 4WD**			
Sensor – Exhaust Oxygen	**COS804**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Oil Pressure Warning Light	**CPS39**	1	
Lancer LA **9/74-12/76 4 Cyl 1.4L 4G33 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH96**	1	Bosch Points Distributor: To 1975
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor: To 1975
Ignition – Distributor Condenser	**MC418**	1	Mitsubishi Points Distributor: To 1975
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor: To 1975
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor: To 1975
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor: To 1975
Ignition – Distributor Rotor	**JR517**	1	Mitsubishi Points Distributor: To 1975
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS22**	1	

Chrysler	Part No	Qty	Notes
Lancer LB: LC			
1/77-8/81 4 Cyl 1.4L 4G33: 1.6L 4G32 SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC409**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS22**	1	
Neon			
7/96-8/99 4 Cyl 2.0L S4RE SOHC 16V MPFi FWD			
Ignition – Distributor Cap	**JP714**	1	
Ignition – Distributor Rotor	**JR639**	1	
Sensor – Exhaust Oxygen	**COS805**	1	Direct Fit 4 Wire: Manifold
Sensor – Exhaust Oxygen	**COS807**	1	Direct Fit 4 Wire: Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Manifold and Pipe
Sensor – MAP	**CMS228**	1	
Neon PL200			
9/99-3/01 4 Cyl 2.0L YD5 SOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC378**	1	
Sensor – Camshaft	**CSCA104**	1	
Regal VH			
6/71-4/73 V8 Cyl 318ci OHV 16V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD280**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD257**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS121**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Valiant RV1: SV1			
1/62-6/63 6 Cyl 225ci SLANT OHV 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**AL103**	1	Autolite Points Distributor
Ignition – Distributor Condenser	**BC868**	1	Autolite Points Distributor
Ignition – Distributor Points / Contact Set	**S95V**	1	Autolite Points Distributor
Ignition – Distributor Rotor	**AL104**	1	Autolite Points Distributor
Sensor – Temperature Gauge	**CTS121**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Valiant AP5: AP6: VC: VE: VF			
6/63-5/70 6 Cyl 225ci SLANT OHV 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC63**	1	Bosch Points Distributor: To 1965
Ignition – Distributor Points / Contact Set	**S4V**	1	Bosch Points Distributor: To 1965
Ignition – Distributor Points / Contact Set	**S1V**	1	Bosch Points Distributor: From 1966
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS121**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	

Chrysler	Part No	Qty	Notes
Valiant AP6: VC: VE **11/65-2/69 V8 Cyl 273ci OHV 16V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**AL105**	1	Autolite Points Distributor
Ignition – Distributor Condenser	**BC868**	1	Autolite Points Distributor
Ignition – Distributor Points / Contact Set	**S95V**	1	Autolite Points Distributor
Ignition – Distributor Rotor	**AL104**	1	Autolite Points Distributor
Sensor – Temperature Gauge	**CTS121**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Valiant VF: VG **3/69-5/71 V8 Cyl 318ci OHV 16V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD280**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD257**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS121**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Valiant VG: VH **5/70-4/73 6 Cyl 245ci : 265ci Hemi OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS121**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Valiant CH **1971-73 6 Cyl 265ci Hemi OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Valiant VH **6/71-4/73 6 Cyl 215ci Hemi OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Valiant CH **11/71-3/73 V8 Cyl 360ci OHV 16V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Valiant VH **1972-73 V8 Cyl 340ci Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	

Chrysler	Part No	Qty	Notes
Valiant VJ: VK **1973-76 6 Cyl 245ci: 265ci Hemi OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH79**	1	Bosch Electronic Distributor
Ignition – Module	**CM423**	1	
Sensor – Temperature Gauge	**CTS121**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Valiant CJ **1973-75 6 Cyl 265ci Hemi OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH79**	1	Bosch Electronic Distributor
Ignition – Module	**CM423**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Valiant VJ: VK **1973-76 V8 Cyl 318ci Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH84**	1	Bosch Electronic Distributor
Ignition – Distributor Cap	**BD280**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BH87**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BD257**	1	Lucas Electronic Distributor
Ignition – Module	**CM423**	1	
Sensor – Temperature Gauge	**CTS121**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Valiant VJ **1973-75 V8 Cyl 340ci Carb. RWD**			
Ignition – Module	**CM423**	1	
Valiant VJ **1973-76 V8 Cyl 360ci Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH84**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH87**	1	Bosch Electronic Distributor
Ignition – Module	**CM423**	1	
Valiant CK: CL: CM **10/75-10/78 6 Cyl 245ci: 265ci Hemi OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH79**	1	Bosch Electronic Distributor
Ignition – Module	**CM423**	1	
Sensor – Temperature Gauge	**CTS121**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	

Chrysler	Part No	Qty	Notes
Valiant CL: CM			
11/76-6/81 V8 Cyl 5.2L 318 Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH84**	1	Bosch Electronic Distributor: To 1978
Ignition – Distributor Cap	**BH150**	1	Bosch Electronic Distributor: From 1978
Ignition – Distributor Rotor	**BH87**	1	Bosch Electronic Distributor
Ignition – Module	**CM423**	1	Without ELB
Sensor – Temperature Gauge	**CTS121**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Voyager GS			
2/97-4/01 V6 Cyl 3.3L A4 OHV 12V MPFi FWD			
Sensor – Exhaust Oxygen	**COS754**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Citroen			
AX GT			
1/91-12/93 4 Cyl 1.4L KDZ SOHC 8V EFi FWD			
Switch – Radiator Fan	**CFS18**	1	2 Push On Terminals: On at 95°C Off at 90°C: To Vin 03828
Switch – Radiator Fan	**CFS82**	1	2 Push On Terminals: On at 97°C Off at 92°C: From Vin 03829: To Vin 05225
BX16 RS: TRS *(NZ Market)*			
1983-89 4 Cyl 1.6L XU5:S:2C:1C			
Ignition – Coil – Standard	**CC215**	1	Bosch Electronic Distributor
BX16 TRS			
1/86-4/88 4 Cyl 1.6L XU52C SOHC 8V Carb. FWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BD126**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH107**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
BX19 GT			
1/86-12/87 4 Cyl 1.9L XU92C SOHC 8V Carb. FWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BD126**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH107**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
BX19 *(NZ Market)*			
1986-90 4 Cyl 1.9L XU9JA, J1			
Ignition – Coil – Standard	**CC215**	1	Bosch Electronic Distributor
BX19 TRI: TZI			
12/88-2/94 4 Cyl 1.9L XU9JA SOHC 12V EFi FWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Module	**CM413**	1	
CX25 IE Pallas: Gti			
7/84-12/85 4 Cyl 2.5L 081 OHV EFi FWD			
Ignition – Distributor Rotor	**RB99**	1	Ducellier Electronic Distributor
Ignition – Module	**CM413**	1	
Sensor – Coolant Temperature	**CCS26**	1	

Citroen	Part No	Qty	Notes
CX2200 **3/76-6/78 4 Cyl 2.2L 073 OHV Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Points / Contact Set	**S226**	1	Marelli Points Distributor: To 1977
Ignition – Distributor Rotor	**RB99**	1	Ducellier Points Distributor: To 1977
CX2400 **12/77-5/83 4 Cyl 2.3L 079 OHV Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Rotor	**RB99**	1	Ducellier Points and Electronic Dist.: From 1978
XM **3/91-10/94 V6 Cyl 3.0L ZPJ SOHC 12V PFI FWD**			
Ignition – Distributor Rotor	**BH225**	1	Bosch Electronic Distributor
Daewoo			
1.5 **7/94-10/95 4 Cyl 1.5L G15MF SOHC 8V MPFi FWD**			
Ignition – Coil – Standard	**CC318**	1	
Ignition – Distributor Cap	**DR114**	1	Delco Electronic Distributor
Ignition – Distributor Rotor	**DR73**	1	Delco Electronic Distributor
Ignition – Module	**CM415**	1	
Ignition – Pickup / Trigger	**CIT100**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS134**	1	In Manifold
Sensor – Throttle Position	**CTPS131**	1	
Switch – Brake Light	**CSL55**	1	5 Speed Manual
Switch – Radiator Fan	**CFS52**	1	
Cielo **10/95-4/98 4 Cyl 1.5L G15MF SOHC 8V: A15MF DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC318**	1	
Ignition – Distributor Cap	**DR114**	1	Delco Electronic Distributor
Ignition – Distributor Rotor	**DR73**	1	Delco Electronic Distributor
Ignition – Module	**CM415**	1	
Ignition – Pickup / Trigger	**CIT100**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS136**	1	
Sensor – Throttle Position	**CTPS131**	1	G15MF Engine
Switch – Oil Pressure Warning Light	**CPS48**	1	G15MF Engine
Switch – Oil Pressure Warning Light	**CPS57**	1	A15MF Engine
Switch – Radiator Fan	**CFS52**	1	

Daewoo	Part No	Qty	Notes
Espero			
3/95-7/97 4 Cyl 2.0L C20JE SOHC 8V EFi FWD			
Ignition – Coil – Standard	**CC318**	1	From 8/1995
Ignition – Distributor Cap	**DR114**	1	Delco Electronic Distributor
Ignition – Distributor Rotor	**DR73**	1	Delco Electronic Distributor
Ignition – Module	**CM415**	1	
Ignition – Pickup / Trigger	**CIT100**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS147**	1	
Sensor – Throttle Position	**CTPS131**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL55**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Radiator Fan	**CFS52**	1	
Valve – Idle Speed Control	**CIA008**	1	
Kalos T200			
4/03-12/04 4 Cyl 1.5L F15S3 SOHC 8V MPFi FWD			
Sensor – Air Temperature – Inlet	**CAT023**	1	
Sensor – Crankshaft	**CSCA178**	1	
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Temperature Gauge	**CTS146**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Radiator Fan	**CFS52**	1	
Korando			
11/98-6/00 6 Cyl 3.2L M162.993 DOHC 24V MPFi 4WD			
Ignition – Coil – Standard	**CC369**	1	
Lacetti J200			
9/03-12/04 4 Cyl 1.8L C18SED DOHC 16V EPFI FWD			
Sensor – Air Temperature – Inlet	**CAT023**	1	
Sensor – Camshaft	**CSCA84**	1	
Sensor – Crankshaft	**CSCA25**	1	
Sensor – Exhaust Oxygen	**COS873**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS136**	1	
Sensor – Knock Control	**CKS113**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Valve – Idle Speed Control	**CIA008**	1	
Lanos ATA: ATF *(NZ Market)*			
1997-01 4 Cyl 1.5L G15MF SOHC			
Ignition – Distributor Cap	**DR114**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**DR73**	1	Denso Electronic Distributor

Daewoo	Part No	Qty	Notes
Lanos			
8/97-3/03 4 Cyl 1.5L A15SM SOHC 8V: 1.6L A16DM DOHC 16V EFi FWD			
Ignition – Coil and Igniter	**CC348**	1	
Sensor – Air Temperature – Inlet	**CAT023**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA26**	1	LX6
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Knock Control	**CKS111**	1	A16DM: 3 Pin: From 9/1998 To 5/1999
Sensor – Knock Control	**CKS113**	1	A16DM: 3 Pin: From 6/1999
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS136**	1	
Sensor – Throttle Position	**CTPS131**	1	
Leganza			
7/97-1/04 4 Cyl 2.0L C20SED: 2.2L T22SED DOHC 16V EFi FWD			
Ignition – Coil and Igniter	**CC348**	1	
Sensor – Air Temperature – Inlet	**CAT023**	1	
Sensor – Camshaft	**CSCA84**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA25**	1	T22SED Engine
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen	**COS734**	1	T22SED: Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	T22SED: Universal 2 Wire
Sensor – MAP	**CMS210**	1	
Sensor – Temperature Gauge	**CTS136**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Radiator Fan	**CFS52**	1	C20SED Engine
Valve – Idle Speed Control	**CIA008**	1	
Matiz M100			
10/99-7/02 3 Cyl 0.8L F8CV SOHC 6V EPFI FWD			
Ignition – Coil – Standard	**CC221**	1	
Ignition – Distributor Cap	**JP410**	1	DAC
Ignition – Distributor Cap	**JP407**	1	MANDO
Sensor – Crankshaft	**CSCA77**	1	MANDO
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire: To 12/2000
Sensor – Exhaust Oxygen	**COS873**	1	Direct Fit 4 Wire: From 12/2000
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: To 7/2002
Sensor – Temperature Gauge	**CTS136**	1	
Musso			
7/98-12/02 6 Cyl 3.2L M162.990 DOHC 24V ESPFI FT4WD			
Ignition – Coil – Standard	**CC369**	3	
Sensor – Camshaft	**CSCA107**	1	
Sensor – MAP	**CMS229**	1	
Nubira J100: J150			
6/97-5/00 4 Cyl 1.6L A16DMS DOHC 16V MPFi FWD			
Ignition – Coil and Igniter	**CC348**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA26**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Knock Control	**CKS111**	1	From 11/1998
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS146**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Radiator Fan	**CFS52**	1	

Daewoo	Part No	Qty	Notes
Nubira J100: J150			
5/98-8/03 4 Cyl 2.0L X20SED DOHC 16V MPFi FWD			
Ignition – Coil and Igniter	**CC348**	1	
Sensor – Air Temperature – Inlet	**CAT023**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Knock Control	**CKS113**	1	3 Pin: From 7/2001
Sensor – MAP	**CMS210**	1	
Sensor – Temperature Gauge	**CTS127**	1	Series I: To 5/2000
Sensor – Temperature Gauge	**CTS136**	1	Series II: From 10/1999
Sensor – Throttle Position	**CTPS131**	1	
Valve – Idle Speed Control	**CIA008**	1	
Tacuma U100			
10/00-12/04 4 Cyl 2.0L T20SED DOHC 16V EPFI FWD			
Ignition – Coil and Igniter	**CC348**	1	
Sensor – Camshaft	**CSCA84**	1	
Sensor – Exhaust Oxygen	**COS734**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire: After Catalyst
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: After Catalyst
Sensor – Knock Control	**CKS113**	1	
Sensor – MAP	**CMS210**	1	
Sensor – Temperature Gauge	**CTS136**	1	
Sensor – Throttle Position	**CTPS131**	1	
Valve – Idle Speed Control	**CIA008**	1	
Daihatsu			
Applause A101			
10/89-1/98 4 Cyl 1.6L HDE SOHC 16V EFi FWD			
Ignition – Coil – Standard	**CC255**	1	To 6/1992
Ignition – Coil – Standard	**CC281**	1	From 7/1992 To 9/1997
Ignition – Distributor Cap	**JP732**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**DR128**	1	Denso Electronic Distributor
Ignition – Module & Pickup / Trigger	**CM404**	1	From 1/1990
Sensor – Coolant Temperature	**CCS30**	1	To 4/1994
Sensor – Coolant Temperature	**CCS39**	1	From 4/1994
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS56**	1	
Switch – Reverse Light	**CRS101**	1	
Applause A101B			
10/97-11/99 4 Cyl 1.6 HDE SOHC 16V EFi FWD			
Ignition – Coil – Standard	**CC281**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Charade G10: G11 Incl. CXT Turbo			
4/80-5/87 3 Cyl 1.0L CB20: CB50: 60 SOHC 6V Carb. FWD			
Ignition – Distributor Cap	**JP572**	1	Denso Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS72**	1	

Daihatsu	Part No	Qty	Notes
Charade G11 *(NZ Market)* **1983-88 3 Cyl 1.0L CB SOHC 6V**			
Ignition – Coil – Standard	**CC211**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP572**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Charade G100 Turbo **6/87-10/88 3 Cyl 1.0L CB61 SOHC 6V Carb. FWD**			
Ignition – Coil – Standard	**CC255**	1	
Ignition – Distributor Cap	**JP572**	1	
Charade G100 **6/87-1/93 3 Cyl 1.0L CB23 SOHC 6V Carb. FWD**			
Ignition – Coil – Standard	**CC255**	1	
Ignition – Distributor Cap	**JP572**	1	Denso Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS72**	1	
Charade G102S *(NZ Market)* **1988-92 4 Cyl 1.3L HC SOHC 16V**			
Ignition – Coil – Standard	**CC255**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP732**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**DR128**	1	Denso Electronic Distributor
Charade G102 **10/88-7/93 4 Cyl 1.3L HCE SOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC255**	1	From 11/1990
Ignition – Distributor Cap	**JP732**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**DR843**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS30**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS56**	1	
Charade G200S *(NZ Market)* **1993-97 4 Cyl 1.3L HC-E SOHC 16V**			
Ignition – Distributor Cap	**JP732**	1	Denso Electronic Distributor
Charade G200: G200B: G203: G203B: G203C **6/93-6/00 4 Cyl 1.3L HCE: 1.5L HEE SOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC282**	1	
Ignition – Distributor Cap	**JP834**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR818**	1	Denso Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT029**	1	
Sensor – Coolant Temperature	**CCS30**	1	G200B
Sensor – Coolant Temperature	**CCS33**	1	G200 with HCE engine: G203 with HEE engine
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Radiator Fan	**CFS74**	1	
Charade G200 **10/93-4/96 3 Cyl 1.0L CB SOHC 6V Carb. FWD**			
Ignition – Coil – Standard	**CC282**	1	
Switch – Radiator Fan	**CFS72**	1	

Daihatsu	Part No	Qty	Notes
Charade G202: G202B **8/94-3/98 3 Cyl 1.0L CB24 SOHC 6V Carb. FWD**			
Ignition – Distributor Rotor	**JR801**	1	Denso Electronic Distributor
Switch – Radiator Fan	**CFS74**	1	
Charade L500 Centro **3/95-12/97 3 Cyl 0.7L EFEL SOHC 12V EFi FWD**			
Ignition – Distributor Cap	**JP809**	1	
Ignition – Distributor Rotor	**JR819**	1	
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Charade L251S **6/03-12/05 3 Cyl 1.0L EJDE DOHC 12V EPFI FWD**			
Sensor – Air Temperature – Inlet	**CAT029**	1	
Copen L880 Turbo **10/03-12/05 4 Cyl 0.7L JBDET DOHC 16V EPFI FWD**			
Sensor – Air Temperature – Inlet	**CAT029**	1	
Cuore L700S **7/00-9/03 3 Cyl 1.0L EJDE DOHC 12V MPFi FWD**			
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Radiator Fan	**CFS37**	1	
Delta SV17 **1972-76 4 Cyl 1.6L 12R OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP516**	1	Denso Points Distributor: From 1973
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor: From 1973
Ignition – Distributor Points / Contact Set	**S202V**	1	Denso Points Distributor: From 1973
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor: From 1973
Delta V30: V31: V32: V34 **1979-84 4 Cyl 2.0L 5R OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP642**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Delta V67: V68 **11/84-10/88 4 Cyl 2.0L 3YC OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor: From 1985
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor: From 1985
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor: From 1985
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: From 1985
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	

Daihatsu	Part No	Qty	Notes
F10			
1975-77 4 Cyl 1.0L FE OHV Carb. 4WD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP516**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
F20: F25			
1979-6/84 4 Cyl 1.6L 12R OHV 8V Carb. 4WD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	F20: Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	F25: Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	F20: Denso Points Distributor
Ignition – Distributor Rotor	**JR513**	1	F25: Denso Points Distributor
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Feroza F300: F310			
10/88-1/99 4 Cyl 1.6L HDE SOHC 16V EFi 4WD			
Ignition – Coil – Standard	**CC255**	1	From 9/1990 To 5/1992
Ignition – Coil – Standard	**CC281**	1	From 9/1990 To 5/1992
Ignition – Distributor Cap	**BD102**	1	
Ignition – Distributor Rotor	**DR128**	1	
Sensor – Coolant Temperature	**CCS30**	1	
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL27**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Handi Van L55V: L60V			
5/81-1/86 2 Cyl 547cc AB30 OHV: 617cc AD10 SOHC 4V Carb. FWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP556**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Handi Van L80V			
3/86-6/90 3 Cyl 846cc ED10 SOHC 6V Carb. FWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP686**	1	Denso Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S214V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Daihatsu	Part No	Qty	Notes
Hi Jet S60T			
9/77-6/82 2 Cyl 547cc AB20 SOHC 4V Carb. RWD			
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor: From 1979
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor: From 1979
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: From 1979
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Hi Jet S70			
7/82-5/84 3 Cyl 843cc CD20 SOHC 6V Carb. RWD			
Ignition – Coil – Standard	**CC211**	1	Denso Points Distributor
Ignition – Distributor Cap	**JP686**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Hi Jet S75: S76			
6/84-6/86 3 Cyl 993cc CB22 SOHC 6V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP692**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Switch – Oil Pressure Warning Light	**CPS23**	1	
Hi Jet S85VL *(NZ Market)*			
1983-93 3 Cyl 1.0L CB22 SOHC			
Ignition – Coil – Standard	**CC211**	1	
Ignition – Distributor Cap	**JP986**	1	
Hi Jet S85			
10/87-6/90 3 Cyl 993cc CB22 SOHC 6V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Mira L201			
11/90-12/92 3 Cyl 847cc ED10 SOHC 6V Carb. FWD			
Ignition – Coil – Standard	**CC255**	1	To 8/1992
Ignition – Distributor Cap	**JP808**	1	
Ignition – Distributor Rotor	**JR819**	1	
Mira L200: L201			
12/92-4/95 3 Cyl 660cc EFEL SOHC 12V EFi FWD			
Ignition – Coil – Standard	**CC282**	1	
Ignition – Distributor Cap	**JP808**	1	
Ignition – Distributor Cap	**JP809**	1	From 1992
Ignition – Distributor Rotor	**JR801**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS30**	1	
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS90**	1	

Daihatsu	Part No	Qty	Notes
Move L601			
2/97-1/99 3 Cyl 847cc ED20 SOHC 6V MPFi FWD			
Ignition – Coil – Standard	**CC282**	1	
Ignition – Distributor Cap	**JP809**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR801**	1	Denso Electronic Distributor
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Pyzar G303			
2/97-9/98 4 Cyl 1.5L HEEG SOHC 16V EFi FWD			
Ignition – Coil – Standard	**CC282**	1	
Ignition – Distributor Cap	**JP834**	1	Denso Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT029**	1	
Pyzar G301			
10/98-7/00 4 Cyl 1.6L HDEP SOHC 16V EFi FWD			
Ignition – Coil – Standard	**CC255**	1	
Ignition – Distributor Cap	**JP834**	1	Denso Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT029**	1	
Rocky F80: F85: F87 Carb			
6/84-1/89 4 Cyl 2.0L 3YC OHV 8V Carb. 4WD			
Ignition – Coil – Standard	**CIC32R**	1	Points Ignition
Ignition – Coil – Standard	**CC217**	1	Electronic Ignition: From 9/1987
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Points Ignition
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Points Ignition
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor: To 1987
Ignition – Distributor Cap	**JP584**	1	Electronic Ignition: From 9/1987
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor: To 1987
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor: To 1987
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: To 1987
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Rocky F70 Incl Turbo: F75 Diesel			
1985-92 4 Cyl 2.8L DL OHV Di 4WD			
Sensor – Temperature Gauge	**CTS113**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Rocky F80: F85 EFi			
10/87-1/89 4 Cyl 2.0L 3YE OHV 8V EFi 4WD			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Distributor Cap	**JP584**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Points Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Rocky F75 Turbo: F77 Diesel			
1988-93 4 Cyl 2.8L DL OHV Di 4WD			
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Rocky F73 Diesel: F78 Turbo Diesel			
8/93-1/99 4 Cyl 2.8L DL52 OHV 8V Di 4WD			
Sensor – Coolant Temperature	**CCS21**	1	
Sirion M101: M300			
9/00-12/05 4 Cyl 1.3L K3VE DOHC 16V EPFI FWD			
Sensor – Air Temperature – Inlet	**CAT029**	1	

Daihatsu	Part No	Qty	Notes
Terios J100 *(NZ Market)* **1997-99 4 Cyl 1.3L HCEJ SOHC**			
Ignition – Distributor Cap	**JP732**	1	
Terios J100 **7/97-10/00 4 Cyl 1.3L HCEJ SOHC 16V PFI 4WD**			
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Terios J102 **10/00-12/05 4 Cyl 1.3L K3VE DOHC 16V ESPFI 4WD**			
Sensor – Air Temperature – Inlet	**CAT029**	1	
YRV M201 **7/01-1/05 4 Cyl 1.3L K3VE DOHC 16V ESPFI FWD**			
Sensor – Air Temperature – Inlet	**CAT029**	1	
Daimler			
Double Six Series II **1973-9/79 V12 Cyl 5.3L Carb. & MPFi RWD**			
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Sovereign Series II **1/79-12/82 6 Cyl 4.2L EFi RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD290**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC104**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L24V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD287**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Dodge			
AT4 **1964-66 6 Cyl All OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC63**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S4V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
AT4 **1967-73 6 Cyl All OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S1V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor

Dodge	Part No	Qty	Notes
AT4			
1970-73 6 Cyl 245ci Hemi 245 OHV 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
AT4			
1970-73 V8 Cyl 318ci Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD280**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD257**	1	Lucas Points Distributor
D5N			
1973-74 V8 Cyl 318/360 Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD280**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD257**	1	Lucas Electronic Distributor
D5N			
1973-76 6 Cyl Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
D5N			
1974-79 V8 Cyl 318ci Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH84**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH87**	1	Bosch Electronic Distributor
D5N			
1976-79 6 Cyl 245ci Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Electronic Distributor
Phoenix			
1970-73 V8 Cyl 318ci Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD130**	1	
Ignition – Distributor Condenser	**BC868**	1	
Ignition – Distributor Rotor	**AL104**	1	
Ignition – Distributor Points / Contact Set	**S95V**	1	

Eunos	Part No	Qty	Notes
30X EC			
11/92-5/96 V6 Cyl 1.8L K8 DOHC 24V EFi FWD			
Ignition – Coil – Standard	**CC248**	1	
Ignition – Distributor Cap	**JP726**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR135**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA61**	1	In Distributor
Sensor – Crankshaft	**CSCA49**	1	External to Distributor
Sensor – Exhaust Oxygen	**COS880**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS119**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS149**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
500 CA			
11/92-12/96 V6 Cyl 2.0L KF DOHC 24V EFi FWD			
Ignition – Distributor Cap	**JP408**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR405**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA61**	1	In Distributor
Sensor – Crankshaft	**CSCA49**	1	External to Distributor
Sensor – Exhaust Oxygen	**COS764**	1	Direct Fit 4 Wire: Front
Sensor – Exhaust Oxygen	**COS763**	1	Direct Fit 4 Wire: Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Sensor – Knock Control	**CKS119**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS149**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
500 CA8P *(NZ Market)*			
1994-99 V6 Cyl 1.8L K8			
Ignition – Distributor Cap	**JP726**	1	
Ignition – Distributor Rotor	**DR135**	1	
800 TA5A *(NZ Market)*			
1992-96 V6 Cyl 2.5L KL DOHC			
Ignition – Distributor Cap	**JP726**	1	
800 TA			
3/94-5/96 V6 Cyl 2.5L KL DOHC 24V EFi RWD			
Ignition – Coil – Standard	**CC252**	1	
Ignition – Distributor Cap	**BD134**	1	
Ignition – Distributor Rotor	**DR135**	1	
Ignition – Module & Pickup / Trigger	**CSCA59**	1	
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Exhaust Oxygen	**COS764**	1	Direct Fit 4 Wire: Front
Sensor – Exhaust Oxygen	**COS763**	1	Direct Fit 4 Wire: Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS119**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS149**	1	
Switch – Brake Light	**CSL69**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS24**	1	20 kPa
Switch – Oil Pressure Warning Light	**CPS37**	1	40 kPa
800M TA			
3/94-5/96 6 Cyl 2.3L KJ (Miller) EFi RWD			
Sensor – Air Temperature – Inlet	**CAT013**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL69**	1	Without Cruise Control

Eunos	Part No	Qty	Notes
Presso EC8S *(NZ Market)* **1991-95 V6 Cyl 1.8L K8**			
Ignition – Distributor Cap	**JP726**	1	
Ignition – Distributor Rotor	**DR135**	1	
Ferrari			
328 GTS **6/86-6/90 V8 Cyl 3.2L DOHC 32V EFi RWD**			
Sensor – Exhaust Oxygen	**COS788**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
348 TS **11/90-12/94 V8 Cyl 3.4L DOHC 32V EFi RWD**			
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Mondial 3.2 **6/86-6/90 V8 Cyl 3.2L DOHC 32V EFi RWD**			
Sensor – Exhaust Oxygen	**COS788**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Mondial **6/90-6/94 V8 Cyl 3.4L DOHC 32V EFi RWD**			
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Fiat			
Argenta **3/83-9/85 4 Cyl 2.0L 132D DOHC EFi RWD**			
Ignition – Coil – Standard	**CC212**	1	
Switch – Oil Pressure Warning Light	**CPS21**	1	
Croma **3/88-7/89 4 Cyl 2.0L DOHC EFi FWD**			
Ignition – Module	**CM409**	1	
Regata 85S **10/85-12/87 4 Cyl 1.5L 138B SOHC Carb. FWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**FT558**	1	Marelli Electronic Distributor
Ignition – Module	**CM410**	1	
Switch – Oil Pressure Warning Light	**CPS21**	1	
Regata 100S **10/85-7/89 4 Cyl 1.6L 149A DOHC Carb. FWD**			
Ignition – Distributor Cap	**FT558**	1	Marelli Electronic Distributor
Ignition – Module	**CM410**	1	Digiplex Electronic Ignition
Switch – Oil Pressure Warning Light	**CPS21**	1	
Super Brava **8/81-9/85 4 Cyl 2.0L 132C DOHC Carb. RWD**			
Ignition – Module	**CM410**	1	
X1/9 **5/78-12/83 4 Cyl 1.3L 128AS: 1.5L 138AS OHC Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Condenser	**MC41**	1	Marelli Points Distributor
Ignition – Distributor Points / Contact Set	**S152V**	1	Marelli Points Distributor
Switch – Oil Pressure Warning Light	**CPS21**	1	

Ford	Part No	Qty	Notes
Bronco **1/81-12/84 6 Cyl 4.1L OHV Carb. 4WD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH118**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	
Bronco **3/81-8/85 V8 Cyl 5.8L C OHV Carb. 4WD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH84**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS29**	1	
Bronco **9/85-12/87 V8 Cyl 5.0L 302W OHV 16V EFi 4WD**			
Ignition – Coil – Standard	**CC205**	1	
Ignition – Distributor Cap	**FO100**	1	Ford Electronic Distributor
Ignition – Distributor Cap Base	**BC146**	1	Ford Electronic Distributor
Ignition – Distributor Rotor	**FO95**	1	Ford Electronic Distributor
Ignition – Module	**CM426**	1	Ford Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – MAP	**CMS205**	1	
Capri **5/69-4/73 4 Cyl 1.6L JB Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**FO92**	1	Ford Points Distributor: To 1971
Ignition – Distributor Cap	**BD278**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**AC61**	1	Ford Points Distributor: To 1971
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**S82V**	1	Ford Points Distributor: To 1971
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**FO77**	1	Ford Points Distributor: To 1971
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Capri **2/70-4/73 V6 Cyl 3.0L Essex OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**AC61**	1	Ford Points Distributor
Ignition – Distributor Points / Contact Set	**S83V**	1	Ford Points Distributor
Ignition – Distributor Rotor	**FO77**	1	Ford Points Distributor
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	

Ford	Part No	Qty	Notes
Capri SA **10/89-9/90 4 Cyl 1.6L B6 SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC219**	1	
Ignition – Distributor Cap	**JP680**	1	
Ignition – Distributor Rotor	**JR617**	1	
Ignition – Module	**CM405**	1	
Ignition – Pickup / Trigger	**CIT106**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS736**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS111**	1	
Sensor – Throttle Position	**CTPS104**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Radiator Fan	**CFS51**	1	
Capri SA: SB (SA Series II): SC: SE Turbo **10/89-7/94 4 Cyl 1.6L B6T DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC219**	1	
Ignition – Distributor Cap	**JP706**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR625**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM425**	1	Cylinder Sensor
Ignition – Pickup / Trigger	**CIT106**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS736**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS115**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Radiator Fan	**CFS42**	1	
Capri SB (SA Series II): SC: SE **10/90-7/94 4 Cyl 1.6L B6 DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC219**	1	
Ignition – Distributor Cap	**BD129**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM424**	1	Mitsubishi Electronic Distributor
Ignition – Pickup / Trigger	**CIT121**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS736**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS115**	1	
Sensor – Throttle Position	**CTPS104**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Radiator Fan	**CFS42**	1	
Corsair UA **11/89-12/92 4 Cyl 2.0L CA20E SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH176**	1	Bosch Electronic Distributor: To 6/1991
Ignition – Distributor Rotor	**BH229**	1	Bosch Electronic Distributor: To 6/1991
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS748**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Switch – Oil Pressure Warning Light	**CPS22**	1	

Ford	Part No	Qty	Notes
Corsair UA **11/89-12/92 4 Cyl 2.4L KA24E SOHC 12V EFi FWD**			
Ignition – Coil – Standard	**CC223**	1	
Ignition – Distributor Cap	**JP720**	1	Hitachi Electronic Distributor: To 6/1991
Ignition – Distributor Rotor	**JR643**	1	Hitachi Electronic Distributor: To 6/1991
Ignition – Module	**CM428**	1	
Sensor – Air Temperature – Inlet	**CAT008**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Crankshaft	**CSCA05**	1	
Sensor – Exhaust Oxygen	**COS748**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Throttle Position	**CTPS136**	1	Auto Transmission
Sensor – Throttle Position	**CTPS137**	1	Manual Transmission
Switch – Oil Pressure Warning Light	**CPS28**	1	
Cortina Mk.1 **1/63-12/65 4 Cyl 1.2L OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD276**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Cortina GT **7/63-12/66 4 Cyl 1.5L 8V OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD270**	1	Lucas Points Distributor: From 1965
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: From 1965
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor: From 1965
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor: From 1965
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Cortina 220: 240: 440 **1/65-8/71 4 Cyl 1.3L OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	From 1967
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	From 1967
Ignition – Distributor Cap	**FO92**	1	Ford Points Distributor: From 1967
Ignition – Distributor Cap	**BD278**	1	Lucas Points Distributor: From 1967
Ignition – Distributor Condenser	**AC61**	1	Ford Points Distributor: From 1967
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: From 1967
Ignition – Distributor Points / Contact Set	**S82V**	1	Ford Points Distributor: From 1967
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor: From 1967
Ignition – Distributor Rotor	**FO77**	1	Ford Points Distributor: From 1967
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor: From 1967
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Cortina 220: 240: 440 **3/65-12/67 4 Cyl 1.5L 8V OHV Carb. RWD**			
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Cortina GT Mk.2 **1/67-12/67 4 Cyl 1.5L 8V OHV Carb. RWD**			
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	

Ford	Part No	Qty	Notes
Cortina 220: 240: 440 **1/68-8/71 4 Cyl 1.6L OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**FO92**	1	Ford Points Distributor
Ignition – Distributor Cap	**BD278**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**AC61**	1	Ford Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**S82V**	1	Ford Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**FO77**	1	Ford Points Distributor
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Cortina GT Mk.2 **8/68-8/71 4 Cyl 1.6L OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	From 1967
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	From 1967
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Cortina TC: TD: TE: TF **8/71-8/82 4 Cyl 2.0L SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**FO92**	1	Ford Points Distributor: To 1973
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Cap	**BD278**	1	Lucas Points Distributor: To 1976
Ignition – Distributor Condenser	**AC61**	1	Ford Points Distributor: To 1973
Ignition – Distributor Condenser	**BC101**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: To 1976
Ignition – Distributor Points / Contact Set	**S83V**	1	Ford Points Distributor: To 1973
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor: To 1976
Ignition – Distributor Rotor	**FO77**	1	Ford Points Distributor: To 1973
Ignition – Distributor Rotor	**BH89**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor: To 1976
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Brake Light	**CSL51**	1	To 5/1977
Switch – Brake Light	**CSL20**	1	From 6/1977
Switch – Oil Pressure Warning Light	**CPS34**	1	

Ford	Part No	Qty	Notes
Cortina TC: TD: TE: TF			
10/72-8/82 6 Cyl 3.3L 200: 4.1L 250 OHV 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	Points Ignition
Ignition – Coil – Standard	**CC215**	1	Electronic Ignition
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Points Ignition
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Points Ignition
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Cap	**BH118**	1	Bosch Electronic Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Brake Light	**CSL51**	1	To 5/1977
Switch – Brake Light	**CSL20**	1	From 6/1977
Switch – Oil Pressure Warning Light	**CPS34**	1	
Cougar SW, SX			
10/99-3/04 V6 Cyl 2.5L DURATEC DOHC 24V MPFi FWD			
Ignition – Coil – Standard	**CC210**	1	To 8/2000
Ignition – Coil – Standard	**CC387**	1	From 9/2000
Sensor – Camshaft	**CSCA106**	1	From 9/2000
Sensor – Coolant Temperature	**CCS43**	1	To 8/2000
Sensor – Coolant Temperature	**CCS44**	1	From 9/2000
Sensor – Crankshaft	**CSCA143**	1	
Sensor – Exhaust Oxygen	**COS765**	2	Direct Fit 4 Wire: Manifold
Sensor – Exhaust Oxygen	**COS767**	1	Direct Fit 4 Wire: Before Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Brake Light	**CSL62**	1	
Courier			
11/78-7/85 4 Cyl 1.8L VC: 2.0L MA SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	1.8L
Switch – Oil Pressure Warning Light	**CPS25**	1	2.0L
Courier Diesel			
4/81-4/96 4 Cyl 2.2L S2: R2 SOHC 8V Di RWD			
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Ford	Part No	Qty	Notes
Courier PC **6/85-5/92 4 Cyl 2.0L FE SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS111**	1	To 1/1990
Sensor – Temperature Gauge	**CTS115**	1	From 1/1990
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
Courier PC **5/87-11/92 4 Cyl 2.6L 4G54 SOHC 8V Carb. 4WD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP564**	1	
Ignition – Module & Pickup / Trigger	**CM404**	1	
Courier PC **1/89-6/93 4 Cyl 2.2L F2 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP680**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM405**	1	
Ignition – Pickup / Trigger	**CIT106**	1	
Ignition – Pickup / Trigger	**CIT107**	1	
Sensor – Temperature Gauge	**CTS111**	1	To 1/1990
Sensor – Temperature Gauge	**CTS115**	1	From 1/1990
Courier PC: PD: PE: PG **10/91-7/04 4 Cyl 2.6L G6: G6E SOHC 12V EFi RWD: 4WD**			
Ignition – Coil – Standard	**CC209**	1	
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR792**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM421**	1	
Sensor – Air Temperature – Inlet	**CAT013**	1	
Sensor – Coolant Temperature	**CCS46**	1	
Sensor – Crankshaft	**CSCA53**	1	In Distributor: To 11/2002
Sensor – Crankshaft	**CSCA144**	1	From 11/2002
Sensor – Exhaust Oxygen	**COS779**	1	Direct Fit 2 Wire: To 2/1999
Sensor – Exhaust Oxygen	**COS763**	1	Direct Fit 2 Wire: From 2/1999
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Temperature Gauge	**CTS111**	1	To 11/2002
Sensor – Temperature Gauge	**CTS110**	1	From 11/2002
Sensor – Throttle Position	**CTPS148**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS74**	1	
Courier PD Diesel: PE: PG: PH Turbo Diesel **5/96-12/06 4 Cyl 2.5L WL: WLAT SOHC 12V Di RWD: 4WD**			
Sensor – Temperature Gauge	**CTS110**	1	
Courier PH **8/04-2/06 4 Cyl 2.6L G6E SOHC 12V EPFI RWD: 4WD**			
Sensor – Temperature Gauge	**CTS110**	1	

Ford	Part No	Qty	Notes
Courier PH			
2/05-12/06 V6 Cyl 4.0L 13V SOHC 12V ESPFI RWD: 4WD			
Ignition – Coil – Standard	**CC273**	1	
Switch – Brake Light	**CSL47**	1	
D200: D300			
1966-79 6 Cyl 240ci: 300ci Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**FO91**	1	Ford Points Distributor
Ignition – Distributor Condenser	**FC79**	1	Ford Points Distributor
Ignition – Distributor Points / Contact Set	**S80V**	1	Ford Points Distributor
Ignition – Distributor Rotor	**DR158**	1	Ford Points Distributor: From 1967
Econovan			
6/79-4/84 4 Cyl 1.6L NA SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Econovan			
4/84-5/97 4 Cyl 1.8L F8 SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP680**	1	Mitsubishi Points Distributor: Manual Trans.: From 10/1985 To 1/1997
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor: From 11/1986
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Dist.: Manual Transmission: From 10/1985 To 1/1997
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Dist.: Manual Transmission: From 10/1985 To 1/1997
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Dist.: Manual Transmission: From 10/1985 To 1/1997
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Dist.: Auto Transmission: From 3/1988 To 1/1997
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Dist.: Manual Trans.: From 11/1986 To 1/1997
Ignition – Pickup / Trigger	**CIT106**	1	From 11/1986 To 1/1989
Ignition – Pickup / Trigger	**CIT107**	1	From 7/1989
Sensor – Temperature Gauge	**CTS111**	1	To 1/1990
Sensor – Temperature Gauge	**CTS115**	1	From 1/1990
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	

Ford	Part No	Qty	Notes
Econovan			
4/84-12/88 4 Cyl 2.0L FE SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Points Distributor: Auto Transmission
Ignition – Distributor Cap	**JP680**	1	Mitsubishi Points Dist: Manual Transmission
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Ignition – Pickup / Trigger	**CIT106**	1	From 11/1986
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
Econovan Diesel			
4/84-5/97 4 Cyl 2.2L R2 SOHC 8V Di RWD			
Sensor – Temperature Gauge	**CTS111**	1	To 1/1990
Sensor – Temperature Gauge	**CTS115**	1	From 1/1990
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Econovan			
5/84-12/85 4 Cyl 1.4L UC SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Econovan			
3/86-2/88 4 Cyl 2.0L FE SOHC 8V Carb. 4WD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP680**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Ignition – Pickup / Trigger	**CIT106**	1	From 11/1986
Sensor – Temperature Gauge	**CTS111**	1	To 1/1990
Sensor – Temperature Gauge	**CTS115**	1	From 1/1990
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
Econovan			
1/89-5/97 4 Cyl 2.0L FE SOHC 8V Carb. RWD			
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Dist.: Auto Transmission
Ignition – Distributor Cap	**JP680**	1	Mitsubishi Electronic Dist.: Manual Transmission
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Dist.: Auto Transmission
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Dist.: Manual Transmission
Ignition – Module	**CM408**	1	Auto Transmission
Ignition – Module	**CM405**	1	Manual Transmission
Sensor – Temperature Gauge	**CTS111**	1	To 1/1990
Sensor – Temperature Gauge	**CTS115**	1	From 1/1990
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	

Ford	Part No	Qty	Notes
Econovan JG: JH **6/97-2/03 4 Cyl 2.0L FE SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC209**	1	
Ignition – Distributor Cap	**JP680**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM405**	1	
Ignition – Pickup / Trigger	**CIT107**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Econovan JH **3/03-7/06 4 Cyl 1.8L F8: 2.0L FES SOHC 8V EPFI RWD**			
Ignition – Coil – Standard	**CC209**	1	
Ignition – Distributor Cap	**JP698**	1	
Ignition – Distributor Rotor	**DR792**	1	
Ignition – Module	**CM421**	1	
Sensor – Air Temperature – Inlet	**CAT013**	1	Outside air
Sensor – Coolant Temperature	**CCS46**	1	
Sensor – Exhaust Oxygen	**COS902**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS147**	1	
Escape BA **2/01-3/03 V6 Cyl 3.0L DURATEC AJ DOHC 24V MPFi 4WD**			
Sensor – Crankshaft	**CSCA145**	1	
Sensor – Exhaust Oxygen	**COS836**	1	Direct Fit 4 Wire: Front Manifold
Sensor – Exhaust Oxygen	**COS916**	1	Direct Fit 4 Wire: Rear Manifold
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Front and Rear Manifold
Switch – Oil Pressure Warning Light	**CPS53**	1	
Escape ZB **1/04-5/06 4 Cyl 2.3L L3 MZR DOHC 16V MPFi 4WD**			
Sensor – Camshaft	**CSCA160**	1	
Escape ZC **6/06-2/08 V6 Cyl 3.0L DURATEC DOHC 24V MPFi 4WD**			
Sensor – Exhaust Oxygen	**COS836**	1	Direct Fit 4 Wire: Front Manifold
Sensor – Exhaust Oxygen	**COS916**	1	Direct Fit 4 Wire: Rear Manifold
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Front and Rear Manifold
Escort Mk.I **3/70-9/75 4 Cyl 1.1L: 1.3L OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**FO98**	1	Ford Points Distributor
Ignition – Distributor Cap	**BD278**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**AC61**	1	Ford Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**S82V**	1	Ford Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**FO77**	1	Ford Points Distributor
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	1.1L
Switch – Oil Pressure Warning Light	**CPS32**	1	1.3L

Ford	Part No	Qty	Notes
Escort Mk.I Twin Cam **5/70-10/71 4 Cyl 1.6L DOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD268**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor
Escort Mk.II **10/75-8/82 4 Cyl 1.3L: 1.6L Crossflow: 2.0L OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Cap	**FO92**	1	Ford Points Distributor
Ignition – Distributor Cap	**BD276**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**BC101**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**AC61**	1	Ford Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S82V**	1	Ford Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BH89**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**FO77**	1	Ford Points Distributor
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Oil Pressure Warning Light	**CPS32**	1	
Explorer UN: UP **10/96-6/99 V6 Cyl 4.0L VGE4 OHV 12V EFi 4WD**			
Ignition – Coil – Standard	**CC273**	1	
Sensor – Air Temperature – Inlet	**CAT018**	1	In air cleaner tube: From 9/1997
Sensor – Camshaft	**CSCA92**	1	Distributor Drive
Sensor – Coolant Temperature	**CCS43**	1	
Sensor – Crankshaft	**CSCA70**	1	
Sensor – Exhaust Oxygen	**COS802**	2	Direct Fit 4 Wire: LH & RH Side Engine Pipe
Sensor – Exhaust Oxygen	**COS836**	2	Direct Fit 4 Wire: After Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	4	Universal 4 Wire: LH & RH Side Engine Pipe and After Catalyst
Explorer UN: UP **10/96-6/99 V6 Cyl 4.0L SOHC 12V EFi 4WD**			
Ignition – Coil – Standard	**CC273**	1	
Sensor – Air Temperature – Inlet	**CAT018**	1	In air cleaner tube: From 9/1997
Sensor – Coolant Temperature	**CCS43**	1	To 8/1997
Sensor – Coolant Temperature	**CCS40**	1	From 9/1997
Sensor – Exhaust Oxygen	**COS836**	1	Direct Fit 4 Wire: LH Side Eng Pipe
Sensor – Exhaust Oxygen	**COS802**	1	Direct Fit 4 Wire: RH Side Eng Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: LH & RH Side Engine Pipe
Switch – Oil Pressure Warning Light	**CPS37**	1	

Ford	Part No	Qty	Notes
Explorer UQ: US **6/99-10/01 V6 Cyl 4.0L VGE4 OHV 12V MPFi 4WD**			
Ignition – Coil – Standard	**CC273**	1	
Sensor – Camshaft	**CSCA92**	1	Distributor Drive
Sensor – Crankshaft	**CSCA70**	1	
Sensor – Exhaust Oxygen	**COS802**	2	Direct Fit 4 Wire: LH & RH Side Engine Pipe
Sensor – Exhaust Oxygen	**COS836**	2	Direct Fit 4 Wire: After Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	4	Universal 4 Wire: LH & RH Side Engine Pipe and After Catalyst
Explorer UQ: US **6/99-10/01 V6 Cyl 4.0L SOHC 12V MPFi 4WD**			
Ignition – Coil – Standard	**CC273**	1	
Sensor – Camshaft	**CSCA92**	1	
Sensor – Coolant Temperature	**CCS40**	1	
Sensor – Crankshaft	**CSCA70**	1	
Sensor – Exhaust Oxygen	**COS836**	1	Direct Fit 4 Wire: LH Side Eng Pipe
Sensor – Exhaust Oxygen	**COS802**	2	Direct Fit 4 Wire: RH Side Eng Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	3	Universal 4 Wire: LH & RH Side Engine Pipe
Sensor – Throttle Position	**CTPS119**	1	
Explorer UT **11/01-2/03 V6 Cyl 4.0L XZA SOHC 12V EPFI 4WD**			
Ignition – Coil – Standard	**CC273**	1	
Sensor – Coolant Temperature	**CCS44**	1	
Sensor – Exhaust Oxygen	**COS757**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen	**COS802**	2	Direct Fit 4 Wire: LH & RH Side Engine Pipe
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: LH & RH Side Engine Pipe & After Catalyst
Explorer UT **11/01-2/03 V8 Cyl 4.6L 2ZA SOHC 16V EPFI 4WD**			
Sensor – Exhaust Oxygen	**COS802**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Explorer UX **3/03-11/03 V6 Cyl 4.0L XZA SOHC 12V EPFI 4WD**			
Ignition – Coil – Standard	**CC273**	1	
Sensor – Exhaust Oxygen	**COS888**	2	Direct Fit 4 Wire: LH & RH Side Engine Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: LH & RH Side Engine Pipe & After Catalyst
Explorer UX **3/03-11/03 V8 Cyl 4.6L 2ZA SOHC 16V EPFI 4WD**			
Sensor – Exhaust Oxygen	**COS888**	2	Direct Fit 4 Wire: LH & RH Side Engine Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: LH & RH Side Engine Pipe & After Catalyst

Ford	Part No	Qty	Notes
F100: F250: F350			
1/70-12/85 6 Cyl 4.1L 250 OHV 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	Points Ignition
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Points Ignition
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Points Ignition
Ignition – Coil – Standard	**CC215**	1	Electronic Ignition
Ignition – Distributor Cap	**FO91**	1	Ford Points Distributor
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Cap	**BH118**	1	Bosch Electronic Distributor
Ignition – Distributor Condenser	**FC79**	1	Ford Points Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S80V**	1	Ford Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR158**	1	Ford Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor
F100			
1/77-12/77 V8 Cyl 5.0L C OHV 16V Carb. 4WD			
Ignition – Coil – Standard	**CIC32R**	1	Points Ignition
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Points Ignition
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Points Ignition
Ignition – Distributor Cap	**BH84**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH87**	1	Bosch Points Distributor
F100: F250			
1/78-12/85 V8 Cyl 5.8L 351C OHV 16V Carb. 4WD			
Ignition – Coil – Standard	**CIC32R**	1	Points Ignition
Ignition – Coil – Standard	**CC215**	1	Electronic Ignition
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Points Ignition
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Points Ignition
Ignition – Distributor Cap	**BH84**	1	Bosch Points and Electronic Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor: To 1981
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor: To 1981
Ignition – Distributor Rotor	**BH87**	1	Bosch Points Distributor: To 1981
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor: From 1979
Ignition – Module	**CM418**	1	Bosch Electronic Distributor: From 1981
F100: F150: F250: F350			
9/85-12/89 V8 Cyl 5.0L 302W OHV 16V EFi RWD & 4WD			
Ignition – Coil – Standard	**CC215**	1	Electronic Ignition: Oil Filled Coil
Ignition – Coil – Standard	**CC205**	1	Electronic Ignition: Transformer Coil
Ignition – Distributor Cap	**FO100**	1	Ford Electronic Distributor
Ignition – Distributor Cap Base	**BC146**	1	Ford Electronic Distributor
Ignition – Distributor Rotor	**FO95**	1	Ford Electronic Distributor
Ignition – Module	**CM420**	1	
Ignition – Pickup / Trigger	**CSCA80**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Exhaust Oxygen	**COS761**	1	Direct Fit 1 Wire: To 5/1987
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire: From 5/1987
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: To 5/1987
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire: From 5/1987
Sensor – MAP	**CMS205**	1	

Ford	Part No	Qty	Notes
F150: F250: F350			
1/90-12/92 V8 Cyl 5.8L 351W OHV 16V EFi RWD & 4WD			
Ignition – Coil – Standard	**CC215**	1	Oil filled coil
Ignition – Coil – Standard	**CC205**	1	Transformer coil
Ignition – Distributor Cap	**FO100**	1	Ford Electronic Distributor
Ignition – Distributor Cap Base	**BC146**	1	Ford Electronic Distributor
Ignition – Distributor Rotor	**FO95**	1	Ford Electronic Distributor
Ignition – Module	**CM420**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Exhaust Oxygen	**COS765**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS205**	1	
F250 RM: F350 RM			
7/01-10/03 V8 Cyl 5.4L SOHC 16V MPFi RWD			
Sensor – Camshaft	**CSCA126**	1	
Sensor – Crankshaft	**CSCA144**	1	
Sensor – Crankshaft / Cam	**CSCA143**	1	Camshaft Timing
F350			
1/84-12/85 6 Cyl 4.1L OHV 12V Carb. 4WD			
Ignition – Distributor Cap	**BH118**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	
F350 RM Turbo Diesel			
7/01-10/03 V8 Cyl 7.3L OHV 16V Di RWD			
Sensor – Camshaft	**CSCA111**	1	
Fairlane ZA: ZB: ZC			
3/67-10/70 6 Cyl 200ci: 221ci OHV 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**FO91**	1	Ford Points Distributor
Ignition – Distributor Cap	**BH80**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC660**	1	Ford Points Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S80V**	1	Ford Points Distributor
Ignition – Distributor Points / Contact Set	**S1V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**FO74**	1	Ford Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Brake Light	**CSL37**	1	To 6/1969
Switch – Oil Pressure Warning Light	**CPS30**	1	
Fairlane ZA: ZB: ZC			
3/67-10/70 V8 Cyl 289ci 289W: 302ci 302W OHV 16V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**FO90**	1	Ford Points Distributor
Ignition – Distributor Condenser	**FC79**	1	Ford Points Distributor
Ignition – Distributor Points / Contact Set	**S82V**	1	Ford Points Distributor
Ignition – Distributor Rotor	**FO75**	1	Ford Points Distributor
Sensor – Temperature Gauge	**CTS120**	1	
Switch – Brake Light	**CSL37**	1	To 6/1969
Switch – Oil Pressure Warning Light	**CPS30**	1	

Ford	Part No	Qty	Notes
Fairlane ZD: ZF: ZG **11/70-5/76 6 Cyl 250ci: 4.1L OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Fairlane ZD: ZF: ZG **11/70-5/76 V8 Cyl 5.0L 302C: 5.8L 351C OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH84**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH87**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS120**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Fairlane ZH: ZJ: ZK **5/76-3/83 V8 Cyl 5.0L 302C: 5.8L 351C OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	Points ignition
Ignition – Coil – Standard	**CC215**	1	Electronic Ignition
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Points ignition
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Points ignition
Ignition – Distributor Cap	**BH84**	1	Bosch Points and Electronic Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH87**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS120**	1	
Switch – Brake Light	**CSL20**	1	From 5/1979
Switch – Oil Pressure Warning Light	**CPS30**	1	
Fairlane ZJ: ZK **10/79-9/84 6 Cyl 4.1L OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	Points ignition
Ignition – Coil – Standard	**CC215**	1	Electronic Ignition: To 3/1983
Ignition – Coil – Standard	**CC200**	1	Electronic Ignition: From 3/1983
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Points ignition
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Points ignition
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Cap	**BH118**	1	Bosch Electronic Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Brake Light	**CSL20**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	

Ford	Part No	Qty	Notes
Fairlane ZL **10/84-12/86 6 Cyl 4.1L OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH144**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH139**	1	Bosch Electronic Dist.: Leaded Fuel: To 1985
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor: Unleaded Fuel: From 1986
Ignition – Module	**CM418**	1	Leaded Fuel
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Fairlane ZL **10/84-5/88 6 Cyl 4.1L OHV 12V EFi RWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH144**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor
Ignition – Module	**CM420**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – MAP	**CMS205**	1	
Sensor – Temperature Gauge	**CTS122**	1	
Sensor – Throttle Position	**CTPS121**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Valve – Idle Speed Control	**CIA016**	1	
Fairlane NA: NA Series II: NC: NC Series II **6/88-4/92 6 Cyl 3.9L, 4.0L SOHC 12V MPFi RWD**			
Ignition – Coil – Standard	**CC236**	1	
Ignition – Distributor Cap	**BH144**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor
Ignition – Module	**CM420**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – MAP	**CMS205**	1	
Sensor – Temperature Gauge	**CTS144**	1	
Sensor – Temperature Gauge	**CTS131**	1	From 9/1989
Sensor – Throttle Position	**CTPS117**	1	Inner: 4 Speed Auto Transmission: From 10/1989 To 2/1992
Sensor – Throttle Position	**CTPS109**	1	Outer: 4 Speed Auto Transmission: From 10/1989 To 2/1992
Sensor – Throttle Position	**CTPS121**	1	From 2/1992
Switch – Brake Light	**CSL50**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Switch – Power Steering	**CP100**	1	Grey Insulator
Valve – Idle Speed Control	**CIA005**	1	With rectangular two pin connector

Ford	Part No	Qty	Notes
Fairlane NC: NC Series II: NF: NF Series II: NL **7/91-2/99 V8 Cyl 5.0L W OHV 16V MPFi RWD**			
Ignition – Coil – Standard	**CC205**	1	
Ignition – Distributor Cap	**FO100**	1	Ford Electronic Distributor
Ignition – Distributor Cap Base	**BC146**	1	Ford Electronic Distributor
Ignition – Distributor Rotor	**FO95**	1	Ford Electronic Distributor
Ignition – Module	**CM426**	1	
Ignition – Pickup / Trigger	**CSCA80**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS29**	1	To 3/1995
Sensor – Coolant Temperature	**CCS43**	1	From 3/1995
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – MAP	**CMS205**	1	
Sensor – Throttle Position	**CTPS110**	1	Upper
Sensor – Throttle Position	**CTPS100**	1	Lower
Switch – Brake Light	**CSL50**	1	To 3/1995
Switch – Brake Light	**CSL38**	1	Can Use CSL46: From 3/1995
Switch – Oil Pressure Warning Light	**CPS30**	1	To 3/1995
Switch – Oil Pressure Warning Light	**CPS34**	1	From 3/1995
Valve – Idle Speed Control	**CIA009**	1	
Fairlane NF: NF Series II: NL **3/95-2/99 6 Cyl 4.0L H SOHC 12V MPFi RWD**			
Ignition – Coil – Standard	**CC351**	1	To 10/1995
Ignition – Coil – Standard	**CC236**	1	From 10/1995
Ignition – Distributor Cap	**BH144**	1	From 10/1995
Ignition – Distributor Rotor	**BH231**	1	From 10/1995
Ignition – Module	**CM420**	1	From 10/1995
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Camshaft	**CSCA85**	1	To 10/1995
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Crankshaft	**CSCA41**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS102**	1	To 10/1995
Sensor – MAP	**CMS205**	1	
Sensor – Throttle Position	**CTPS121**	1	To 10/1995
Switch – Brake Light	**CSL38**	1	Can Use CSL46
Switch – Oil Pressure Warning Light	**CPS34**	1	
Switch – Power Steering	**CP100**	1	Grey Insulator
Valve – Idle Speed Control	**CIA011**	1	With oval two pin connector
Valve – Idle Speed Control	**CIA005**	1	With rectangular two pin connector
Fairlane AU: AU Series II **3/99-12/02 6 Cyl 4.0L Y SOHC 12V MPFi RWD**			
Ignition – Coil – Standard	**CC351**	1	To 6/2000
Ignition – Coil – Standard	**CC237**	1	From 7/2000
Sensor – Exhaust Oxygen	**COS802**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP and Inlet Air Temperature	**CMS217**	1	To 6/2000
Sensor – MAP and Inlet Air Temperature	**CMS216**	1	From 7/2000
Switch – Brake Light	**CSL38**	1	Can Use CSL46

Ford	Part No	Qty	Notes
Fairlane AU: AU Series II **3/99-12/02 V8 Cyl 5.0L X OHV 16V MPFi RWD**			
Ignition – Coil – Standard	**CC240**	2	
Sensor – Air Temperature – Inlet	**CAT018**	1	In Air Intake
Sensor – Air Temperature – Inlet	**CAT003**	1	In Manifold
Sensor – Camshaft	**CSCA92**	1	Synchroniser
Sensor – Coolant Temperature	**CCS43**	1	
Sensor – Exhaust Oxygen	**COS802**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Throttle Position	**CTPS110**	1	Upper
Sensor – Throttle Position	**CTPS100**	1	Lower
Switch – Brake Light	**CSL38**	1	Can Use CSL46
Switch – Oil Pressure Warning Light	**CPS34**	1	
Valve – Idle Speed Control	**CIA006**	1	
Fairlane BA: BA Series II: BF **7/03-12/07 6 Cyl 4.0L Barra 182: Barra 190 DOHC 24V ESPFI RWD**			
Ignition – Coil – Standard	**CC353**	6	
Sensor – Camshaft	**CSCA124**	1	LH Side: Inlet
Sensor – Camshaft	**CSCA125**	1	RH Side: Exhaust
Sensor – Crankshaft	**CSCA143**	1	
Sensor – Exhaust Oxygen	**COS802**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Brake Light	**CSL62**	1	
Switch – Power Steering	**CP101**	1	Green Insulator
Fairlane BA: BA Series II: BF **7/03-12/07 V8 Cyl 5.4L Barra 220: Barra 230 SOHC 24V ESPFI RWD**			
Sensor – Camshaft	**CSCA143**	2	
Sensor – Crankshaft	**CSCA144**	1	
Sensor – MAP and Inlet Air Temperature	**CMS216**	1	
Switch – Brake Light	**CSL62**	1	
Falcon XK: XL: XM: XP **1/60-8/66 6 Cyl 144ci: 170ci: 200ci OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**FO91**	1	Ford Points Distributor
Ignition – Distributor Condenser	**BC660**	1	Ford Points Distributor
Ignition – Distributor Points / Contact Set	**S80V**	1	Ford Points Distributor
Ignition – Distributor Rotor	**FO74**	1	Ford Points Distributor
Switch – Oil Pressure Warning Light	**CPS30**	1	
Falcon XR: XT: XW **9/66-11/70 6 Cyl 170ci: 188ci: 200ci: 221ci OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH80**	1	Bosch Points Distributor
Ignition – Distributor Cap	**FO91**	1	Ford Points Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC660**	1	Ford Points Distributor
Ignition – Distributor Points / Contact Set	**S1V**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S80V**	1	Ford Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**FO74**	1	Ford Points Distributor
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Brake Light	**CSL37**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	

Ford	Part No	Qty	Notes
Falcon XR: XT: XW Incl. GTHO Phase I & II			
9/66-11/70 V8 Cyl 289ci 289W: 302ci 302W OHV 16V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**FO90**	1	Ford Points Distributor
Ignition – Distributor Condenser	**FC79**	1	Ford Points Distributor
Ignition – Distributor Points / Contact Set	**S82V**	1	Ford Points Distributor
Ignition – Distributor Rotor	**FO75**	1	Ford Points Distributor
Sensor – Temperature Gauge	**CTS120**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Falcon XY			
11/70-3/72 6 Cyl 250ci OHV 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Falcon XY Incl. GTHO Phase III			
11/70-3/72 V8 Cyl 302ci 302C: 351ci 351C OHV 16V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH84**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH87**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS120**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Falcon XA: XB: XC			
3/72-2/79 6 Cyl 200ci 3.3L: 250ci 4.1L OHV 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Brake Light	**CSL20**	1	From 8/1976
Switch – Oil Pressure Warning Light	**CPS30**	1	

Ford	Part No	Qty	Notes
Falcon XA: XB: XC			
3/72-2/79 V8 Cyl 5.0L 302ci 302C: 5.8L 351ci 351C OHV Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	Points ignition
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Points ignition
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Points ignition
Ignition – Coil – Standard	**CC215**	1	Electronic Ignition
Ignition – Distributor Cap	**BH84**	1	Bosch Points and Electronic Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH87**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor: From 1/1979
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor: From 1/1979
Sensor – Temperature Gauge	**CTS120**	1	
Switch – Brake Light	**CSL20**	1	From 8/1976
Switch – Oil Pressure Warning Light	**CPS30**	1	
Falcon XD: XE			
3/79-9/84 6 Cyl 3.3L: 4.1L OHV 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	Points ignition
Ignition – Coil – Standard	**CC215**	1	Electronic Ignition
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Points ignition
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Points ignition
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Cap	**BH118**	1	Bosch Electronic Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Brake Light	**CSL20**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Falcon XD: XE			
3/79-10/83 V8 Cyl 5.0L 302C: 5.8L 351C OHV Carb. RWD			
Ignition – Coil – Standard	**CC215**	1	Electronic Ignition
Ignition – Distributor Cap	**BH84**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS120**	1	
Switch – Brake Light	**CSL20**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Falcon XE			
3/82-9/84 6 Cyl 4.1L OHV 12V EFi RWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH118**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Brake Light	**CSL20**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	

Ford	Part No	Qty	Notes
Falcon XF EFi **10/84-2/88 6 Cyl 4.1L OHV 12V MPFi RWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH144**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor
Ignition – Module	**CM420**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – MAP	**CMS205**	1	
Sensor – Throttle Position	**CTPS121**	1	
Valve – Idle Speed Control	**CIA016**	1	
Falcon XF Carb **10/84-3/93 6 Cyl 3.3L: 4.1L OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH144**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH139**	1	Bosch Electronic Dist.: Leaded Fuel: To 1985
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor: Unleaded Fuel: From 1986
Ignition – Module	**CM418**	1	Bosch Electronic Dist.: Leaded Fuel: To 1985
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Dist.: Leaded Fuel: To 1985
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Temperature Gauge	**CTS144**	1	
Switch – Brake Light	**CSL50**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	
Falcon EA: EA Series II: EB CFi **3/88-4/92 6 Cyl 3.2L: 3.9L SOHC 12V SPFi RWD**			
Ignition – Coil – Standard	**CC236**	1	
Ignition – Distributor Cap	**BH144**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor
Ignition – Module	**CM420**	1	Bosch Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – MAP	**CMS205**	1	
Sensor – Temperature Gauge	**CTS131**	1	
Sensor – Throttle Position	**CTPS117**	1	Inner
Sensor – Throttle Position	**CTPS109**	1	Outer
Switch – Brake Light	**CSL50**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	
Switch – Power Steering	**CP100**	1	Grey Insulator
Valve – Idle Speed Control	**CIA010**	1	

Ford	Part No	Qty	Notes
Falcon EA: EA Series II: EB: EB Series II: ED MPFi **3/88-8/94 6 Cyl 3.9L: 4.0L SOHC 12V MPFi RWD**			
Ignition – Coil – Standard	**CC236**	1	
Ignition – Distributor Cap	**BH144**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor
Ignition – Module	**CM420**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – MAP	**CMS205**	1	
Sensor – Temperature Gauge	**CTS144**	1	To 9/1989
Sensor – Temperature Gauge	**CTS131**	1	From 9/1989
Sensor – Throttle Position	**CTPS117**	1	Inner: From 9/1989 To 2/1992
Sensor – Throttle Position	**CTPS109**	1	Outer: From 9/1989 To 2/1992
Sensor – Throttle Position	**CTPS121**	1	From 2/1992
Switch – Brake Light	**CSL50**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	
Switch – Power Steering	**CP100**	1	Grey Insulator
Valve – Idle Speed Control	**CIA005**	1	With rectangular two pin connector
Falcon XF Ute & Van MPFi **1/91-3/93 6 Cyl 4.1L OHV 12V EFi RWD**			
Ignition – Coil – Standard	**CC236**	1	
Ignition – Distributor Cap	**BH144**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor
Ignition – Module	**CM420**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS131**	1	
Sensor – Throttle Position	**CTPS121**	1	
Switch – Brake Light	**CSL50**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	
Valve – Idle Speed Control	**CIA011**	1	With oval two pin connector
Falcon EB: EB Series II: ED **7/91-8/93 V8 Cyl 5.0L 302W OHV 16V MPFi RWD**			
Ignition – Coil – Standard	**CC205**	1	
Ignition – Distributor Cap	**FO100**	1	Ford Electronic Distributor
Ignition – Distributor Cap Base	**BC146**	1	Ford Electronic Distributor
Ignition – Distributor Rotor	**FO95**	1	Ford Electronic Distributor
Ignition – Module	**CM426**	1	
Ignition – Pickup / Trigger	**CSCA80**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – MAP	**CMS205**	1	
Sensor – Throttle Position	**CTPS110**	1	Upper
Sensor – Throttle Position	**CTPS100**	1	Lower:
Switch – Brake Light	**CSL50**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	
Valve – Idle Speed Control	**CIA009**	1	

Ford	Part No	Qty	Notes
Falcon XG Ute: Van Incl. XR6 MPFi **3/93-3/96 6 Cyl 4.0L SOHC 12V MPFi RWD**			
Ignition – Coil – Standard	**CC236**	1	
Ignition – Distributor Cap	**BH144**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor
Ignition – Module	**CM420**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS43**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – MAP	**CMS205**	1	
Sensor – Temperature Gauge	**CTS131**	1	
Sensor – Throttle Position	**CTPS121**	1	
Switch – Brake Light	**CSL50**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	
Valve – Idle Speed Control	**CIA011**	1	With oval two pin connector
Falcon EF: EF Series II: EL Incl. XR6 **8/94-8/98 6 Cyl 4.0L SOHC 12V MPFi RWD**			
Ignition – Coil – Standard	**CC351**	1	To 9/1996
Ignition – Coil – Standard	**CC236**	1	From 9/1996
Ignition – Distributor Cap	**BH144**	1	Bosch Electronic Distributor: From 9/1996
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor: From 9/1996
Ignition – Module	**CM420**	1	From 9/1996
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Camshaft	**CSCA85**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Crankshaft	**CSCA41**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS102**	1	
Sensor – MAP	**CMS205**	1	
Sensor – Temperature Gauge	**CTS131**	1	
Sensor – Throttle Position	**CTPS121**	1	
Switch – Brake Light	**CSL38**	1	Can Use CSL46
Switch – Oil Pressure Warning Light	**CPS34**	1	
Switch – Power Steering	**CP100**	1	Grey Insulator
Valve – Idle Speed Control	**CIA011**	1	With oval two pin connector
Valve – Idle Speed Control	**CIA005**	1	With rectangular two pin connector
Falcon EF: EF Series II: EL **8/94-8/98 V8 Cyl 5.0L 302W OHV 16V MPFi RWD**			
Ignition – Coil – Standard	**CC205**	1	
Ignition – Distributor Cap	**FO100**	1	Ford Electronic Distributor
Ignition – Distributor Cap Base	**BC146**	1	Ford Electronic Distributor
Ignition – Distributor Rotor	**FO95**	1	Ford Electronic Distributor
Ignition – Module	**CM426**	1	
Ignition – Pickup / Trigger	**CSCA80**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS43**	1	
Sensor – Exhaust Oxygen	**COS733**	2	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	2	Universal 3 Wire
Sensor – MAP	**CMS205**	1	
Switch – Brake Light	**CSL38**	1	Can Use CSL46
Switch – Oil Pressure Warning Light	**CPS34**	1	
Valve – Idle Speed Control	**CIA009**	1	

Ford	Part No	Qty	Notes
Falcon XH: XH Series II Ute & Van Incl. XR6 **3/96-6/99 6 Cyl 4.0L SOHC 12V MPFi RWD**			
Ignition – Coil – Standard	**CC236**	1	
Ignition – Distributor Cap	**BH144**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor
Ignition – Module	**CM420**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Camshaft	**CSCA85**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Crankshaft	**CSCA41**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS102**	1	
Sensor – MAP	**CMS205**	1	
Sensor – Throttle Position	**CTPS121**	1	
Switch – Brake Light	**CSL38**	1	Can Use CSL46
Switch – Oil Pressure Warning Light	**CPS34**	1	
Switch – Power Steering	**CP100**	1	Grey Insulator
Valve – Idle Speed Control	**CIA005**	1	With rectangular two pin connector
Falcon XH: XH Series II Ute & Van Incl. XR8 **10/97-5/99 V8 Cyl 5.0L 302W OHV 16V MPFi RWD**			
Ignition – Coil – Standard	**CC205**	1	
Ignition – Distributor Cap	**FO100**	1	
Ignition – Distributor Cap Base	**BC146**	1	
Ignition – Distributor Rotor	**FO95**	1	Ford Electronic Distributor
Ignition – Module	**CM426**	1	
Ignition – Pickup / Trigger	**CSCA80**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS43**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – MAP	**CMS205**	1	
Switch – Brake Light	**CSL38**	1	Can Use CSL46
Switch – Oil Pressure Warning Light	**CPS34**	1	
Valve – Idle Speed Control	**CIA009**	1	
Falcon AU: AU Series II: AU Series III Incl. XR6 **8/98-9/02 6 Cyl 4.0L SOHC 12V MPFi RWD**			
Ignition – Coil – Standard	**CC351**	1	Series I: To 4/2000
Ignition – Coil – Standard	**CC237**	1	Series II & Series III: From 4/2000
Sensor – Crankshaft	**CSCA41**	1	
Sensor – Exhaust Oxygen	**COS802**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS105**	1	
Sensor – MAP and Inlet Air Temperature	**CMS217**	1	To 2/2000
Sensor – MAP and Inlet Air Temperature	**CMS216**	1	From 3/2000
Sensor – Throttle Position	**CTPS121**	1	To 2/2000
Sensor – Throttle Position	**CTPS108**	1	From 3/2000
Switch – Brake Light	**CSL38**	1	Can Use CSL46
Switch – Oil Pressure Warning Light	**CPS34**	1	
Switch – Power Steering	**CP100**	1	Grey Insulator

Ford	Part No	Qty	Notes
Falcon AU: AU Series II: AU Series III Incl. XR8 **8/98-9/02 V8 Cyl 5.0L 302W OHV 16V MPFi RWD**			
Ignition – Coil – Standard	**CC240**	2	
Sensor – Air Temperature – Inlet	**CAT018**	1	In Air Intake
Sensor – Air Temperature – Inlet	**CAT003**	1	In Manifold
Sensor – Camshaft	**CSCA92**	1	
Sensor – Coolant Temperature	**CCS43**	1	
Sensor – Exhaust Oxygen	**COS802**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Throttle Position	**CTPS110**	1	Upper
Sensor – Throttle Position	**CTPS100**	1	Lower
Switch – Brake Light	**CSL38**	1	Can Use CSL46
Switch – Oil Pressure Warning Light	**CPS34**	1	
Valve – Idle Speed Control	**CIA006**	1	
Falcon BA: BA Series II: BF: BF Series II Incl. XR6: XR6T **9/02-5/08 6 Cyl 4.0L Barra 182: Barra 190: Barra 240T DOHC 24V MPFi RWD**			
Ignition – Coil – Standard	**CC353**	6	
Sensor – Camshaft	**CSCA124**	1	LH Side: Inlet
Sensor – Camshaft	**CSCA125**	1	RH Side: Exhaust
Sensor – Crankshaft	**CSCA126**	1	To 6/2003
Sensor – Crankshaft	**CSCA143**	1	From 7/2003
Sensor – Exhaust Oxygen	**COS802**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Brake Light	**CSL62**	1	
Switch – Power Steering	**CP101**	1	Green Insulator: Two Pin Switch
Falcon BA: BA Series II: BF: BF Series II **9/02-5/08 V8 Cyl 5.4L Barra 220: Barra 230 SOHC 24V MPFi RWD**			
Sensor – Camshaft	**CSCA126**	1	
Sensor – Camshaft	**CSCA143**	2	
Sensor – Coolant Temperature	**CCS43**	1	
Sensor – Crankshaft	**CSCA144**	1	
Sensor – Exhaust Oxygen	**COS765**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP and Inlet Air Temperature	**CMS216**	1	
Switch – Brake Light	**CSL62**	1	
Falcon BA: BA Series II: BF: BF Series II XR8 **1/03-5/08 V8 Cyl 5.4L Boss 260 DOHC 32V MPFi RWD**			
Sensor – Camshaft	**CSCA126**	1	
Sensor – Coolant Temperature	**CCS43**	1	
Sensor – Crankshaft	**CSCA144**	1	
Sensor – Exhaust Oxygen	**COS765**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP and Inlet Air Temperature	**CMS216**	1	
Switch – Brake Light	**CSL62**	1	
Falcon BF LPG **10/05-9/06 6 Cyl 4.0L Barra 156 DOHC 24V MPFi RWD**			
Ignition – Coil – Standard	**CC353**	6	
Sensor – Camshaft	**CSCA124**	1	LH Side: Inlet
Sensor – Camshaft	**CSCA125**	1	RH Side: Exhaust
Switch – Brake Light	**CSL62**	1	
Switch – Power Steering	**CP101**	1	Green Insulator

Ford	Part No	Qty	Notes
Festiva WA **10/91-3/94 4 Cyl 1.3L B3 SOHC 8V Carb. FWD**			
Ignition – Distributor Cap	**JP988**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Distributor
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS42**	1	
Festiva WB: WD (WBII) **4/94-12/97 4 Cyl 1.3L B3 SOHC 8V: 1.5L B5 SOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC249**	1	
Ignition – Distributor Cap	**BD132**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR133**	1	Mitsubishi Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT005**	1	
Sensor – Coolant Temperature	**CCS21**	1	To 10/1997
Sensor – Coolant Temperature	**CCS20**	1	From 10/1997
Sensor – Crankshaft	**CSCA68**	1	In Distributor
Sensor – Exhaust Oxygen	**COS777**	1	Direct Fit 1 Wire: 1.3L
Sensor – Exhaust Oxygen	**COS763**	1	Direct Fit 4 Wire: 1.5L
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: 1.3L
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: 1.5L
Switch – Brake Light	**CSL47**	1	
Switch – Radiator Fan	**CFS42**	1	To 12/1996
Switch – Radiator Fan	**CFS73**	1	From 1/1997
Festiva WF **1/98-4/01 4 Cyl 1.3L B3: 1.5L B5 SOHC 8V MPFi FWD**			
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR792**	1	Mitsubishi Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT005**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Crankshaft	**CSCA77**	1	In Distributor
Sensor – Exhaust Oxygen	**COS920**	1	Direct Fit 3 Wire: 1.5L
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: 1.3L
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire: 1.5L
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS100**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Fiesta WP **4/04-1/06 4 Cyl 1.6L Q100PS DOHC 16V ESPFI FWD**			
Ignition – Coil – Standard	**CC239**	1	
Sensor – Crankshaft	**CSCA154**	1	
Sensor – Exhaust Oxygen	**COS929**	1	Direct Fit 4 Wire: Manifold
Sensor – Exhaust Oxygen	**COS924**	1	Direct Fit 4 Wire: Engine Pipe
Sensor – Exhaust Oxygen	**COS930**	1	Direct Fit 4 Wire: Engine Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	3	Universal 4 Wire: Manifold and Engine Pipe
Switch – Brake Light	**CSL62**	1	To 11/2004
Fiesta WQ **2/06-on 4 Cyl 1.6L Q100PS DOHC 16V ESPFI FWD**			
Sensor – Camshaft	**CSCA200**	1	
Sensor – Crankshaft	**CSCA154**	1	
Switch – Oil Pressure Warning Light	**CPS41**	1	

Ford	Part No	Qty	Notes
Focus LR			
9/02-4/05 4 Cyl 1.8L EYDE: 2.0L EDDB DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC239**	1	
Sensor – Air Flow / MAF	**CAF029**	1	Excl. ST170
Sensor – Camshaft	**CSCA108**	1	
Sensor – Coolant Temperature	**CCS44**	1	
Sensor – Crankshaft	**CSCA44**	1	Excl. ST170
Sensor – Exhaust Oxygen	**COS836**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS151**	1	
Switch – Oil Pressure Warning Light	**CPS52**	1	
Focus LS			
5/05-6/07 4 Cyl 2.0L C307 DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC388**	4	
Sensor – Coolant Temperature	**CCS40**	1	
Sensor – Exhaust Oxygen	**COS888**	1	Direct Fit 4 Wire: Manifold
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Manifold
Focus LS: LT XR5 Turbo			
4/06-on 5 Cyl 2.5L B5254T3 DOHC 20V MPFi FWD			
Sensor – MAP and Inlet Air Temperature	**CMS226**	1	Intercooler Air
Focus LT Turbo Diesel			
7/07-on 4 Cyl 2.0L G6DD DOHC 16V Di FWD			
Sensor – Air Temperature – Inlet	**CAT028**	1	
Sensor – Coolant Temperature	**CCS57**	1	
Focus LT			
7/07-on 4 Cyl 2.0L C307 DOHC 16V MPFi FWD			
Sensor – Exhaust Oxygen	**COS888**	1	Direct Fit 4 Wire: Manifold
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Manifold
Focus PH Coupe Cabriolet			
11/07-on 4 Cyl 2.0L C307 DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC388**	4	
KA TA			
11/99-12/03 4 Cyl 1.3L Endura E OHV 8V MPSI FWD			
Ignition – Coil – Standard	**CC239**	1	
Sensor – Air Temperature – Inlet	**CAT027**	1	
Sensor – Coolant Temperature	**CCS43**	1	
Sensor – Crankshaft	**CSCA44**	1	
Sensor – Exhaust Oxygen	**COS767**	1	Direct Fit 4 Wire: To 8/2000
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: To 8/2000
Sensor – MAP and Inlet Air Temperature	**CMS216**	1	
Sensor – Temperature Gauge	**CTS148**	1	
KA2 TB			
1/01-12/03 4 Cyl 1.3L XJ OHV 8V MPSI FWD			
Ignition – Coil – Standard	**CC239**	1	
Sensor – Air Temperature – Inlet	**CAT027**	1	
Sensor – Coolant Temperature	**CCS43**	1	
Sensor – Exhaust Oxygen	**COS836**	1	Direct Fit 4 Wire: From 9/2000
Sensor – Exhaust Oxygen	**COS925**	1	Direct Fit 4 Wire: From 9/2000
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: From 9/2000
Sensor – Temperature Gauge	**CTS148**	1	

Ford	Part No	Qty	Notes
Laser KA: KB Incl. Turbo			
3/81-12/85 4 Cyl 1.3L E3: 1.5L E5 SOHC 8V Carb. FWD			
Ignition – Coil – Standard	**CIC32R**	1	Points Ignition: To 1982
Ignition – Coil – Standard	**CC259**	1	Electronic Ignition: From 1982
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Points Ignition: To 1982
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Points Ignition: To 1982
Ignition – Distributor Cap	**JP542**	1	Points Ignition: To 1982
Ignition – Distributor Cap	**JP568**	1	Electronic Ignition: From 1982
Ignition – Distributor Condenser	**MC417**	1	Points Ignition: To 1982
Ignition – Distributor Points / Contact Set	**S219VU**	1	Points Ignition: To 1982
Ignition – Distributor Rotor	**JR533**	1	Points Ignition: To 1982
Ignition – Distributor Rotor	**JR555**	1	Electronic Ignition: From 1982
Ignition – Module	**CM408**	1	Electronic Ignition: From 1982
Ignition – Pickup / Trigger	**CIT110**	1	Electronic Ignition: From 1982
Sensor – MAP	**CMS205**	1	Turbo Only
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS26**	1	
Laser KB *(NZ Market)*			
1983-85 4 Cyl 1.3L E3 SOHC 8V			
Ignition – Coil – Standard	**CIC32R**	1	Mitsubishi Electronic Distributor
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Mitsubishi Electronic Distributor
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP682**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Laser KC: KE			
10/85-3/89 4 Cyl 1.3L E3 SOHC 8V Carb. FWD			
Ignition – Coil – Standard	**CC259**	1	
Ignition – Distributor Cap	**JP682**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM408**	1	Mitsubishi Electronic Distributor
Ignition – Pickup / Trigger	**CIT114**	1	Mitsubishi Electronic Distributor
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS42**	2	One in head and in one in radiator
Laser KC: KE Carb.			
10/85-4/90 4 Cyl 1.6L B6 SOHC 8V Carb. FWD			
Ignition – Coil – Standard	**CC259**	1	
Ignition – Distributor Cap	**JP684**	1	
Ignition – Distributor Rotor	**JR619**	1	
Ignition – Module	**CM405**	1	
Ignition – Pickup / Trigger	**CIT111**	1	
Sensor – Temperature Gauge	**CTS111**	1	To 4/1989
Sensor – Temperature Gauge	**CTS115**	1	From 4/1989
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS42**	1	Mounted In Head
Switch – Radiator Fan	**CFS26**	1	Mounted In Radiator

Ford	Part No	Qty	Notes
Laser KC EFi **10/85-9/87 4 Cyl 1.6L B6 SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC222**	1	
Ignition – Distributor Cap	**JP684**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM405**	1	Mitsubishi Electronic Distributor
Ignition – Pickup / Trigger	**CIT111**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS736**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS42**	1	Mounted In Head
Switch – Radiator Fan	**CFS26**	1	Mounted In Radiator
Laser KE EFi *(NZ Market)* **1987-89 4 Cyl 1.3L B3 SOHC 8V**			
Ignition – Distributor Cap	**BD107**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Distributor
Laser KE Carb. *(NZ Market)* **1987-89 4 Cyl 1.5L E5 SOHC 8V**			
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Laser KE Ghia **10/87-4/90 4 Cyl 1.6L B6 SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC219**	1	
Ignition – Distributor Cap	**JP680**	1	
Ignition – Distributor Rotor	**JR617**	1	
Ignition – Module	**CM405**	1	
Ignition – Pickup / Trigger	**CIT106**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Temperature Gauge	**CTS111**	1	To 4/1989
Sensor – Temperature Gauge	**CTS115**	1	From 4/1989
Laser KE TX3 **10/87-2/90 4 Cyl 1.6L B6 SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC219**	1	
Ignition – Distributor Cap	**JP680**	1	
Ignition – Distributor Rotor	**JR617**	1	
Ignition – Module	**CM405**	1	
Ignition – Pickup / Trigger	**CIT106**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS736**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS111**	1	To 4/1989
Sensor – Temperature Gauge	**CTS115**	1	From 4/1989
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS42**	1	Mounted In Head

Ford	Part No	Qty	Notes
Laser KE TX3 Turbo: FWD & 4WD **10/87-4/90 4 Cyl 1.6L B6T DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC219**	1	
Ignition – Distributor Cap	**JP706**	1	
Ignition – Distributor Rotor	**JR625**	1	
Ignition – Module	**CM425**	1	Cylinder Identifier
Ignition – Pickup / Trigger	**CIT106**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS736**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS111**	1	To 4/1989
Sensor – Temperature Gauge	**CTS115**	1	From 4/1989
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS42**	1	Mounted In Head
Switch – Radiator Fan	**CFS26**	1	Mounted In Radiator
Laser BF5PF: KF *(NZ Market)* **1987-94 4 Cyl 1.5L E5: B5 SOHC 8V Carb.**			
Ignition – Coil – Standard	**CC259**	1	Mitsubishi Electronic Distributor
Laser KF Carb. *(NZ Market)* **1990-92 4 Cyl 1.3L B3 SOHC 16V**			
Ignition – Distributor Cap	**JP718**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR641**	1	Mitsubishi Electronic Distributor
Laser KE Series II: KF: KH: KH Series II **3/90-10/94 4 Cyl 1.6L B6 SOHC 16V Carb. FWD**			
Ignition – Coil – Standard	**CC350**	1	
Ignition – Distributor Cap	**JP718**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR641**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM411**	1	
Ignition – Pickup / Trigger	**CIT113**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS65**	1	
Laser KF: KH: KH Series II Incl. TX3 **3/90-10/94 4 Cyl 1.8L BP SOHC 16V: DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC226**	1	
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR792**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM421**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Crankshaft	**CSCA08**	1	
Sensor – Exhaust Oxygen	**COS766**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS104**	1	Manual Transmission
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS65**	1	Mounted In Head
Switch – Radiator Fan	**CFS67**	1	Mounted In Radiator

Ford	Part No	Qty	Notes
Laser KF: KH Series II TX3 Turbo			
6/90-7/93 4 Cyl 1.8L BPD DOHC 16V EFi 4WD			
Ignition – Coil – Standard	**CC226**	1	
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR792**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM421**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	Push On Terminal
Switch – Oil Pressure Warning Light	**CPS24**	1	Without Push On Terminal
Switch – Radiator Fan	**CFS59**	1	Mounted In Head
Switch – Radiator Fan	**CFS67**	1	Mounted In Radiator
Laser *(NZ Market)*			
1991-96 4 Cyl 1.5L Z5-DE DOHC EFi			
Ignition – Distributor Rotor	**DR133**	1	Mitsubishi Electronic Distributor
Laser KJ			
10/94-12/96 4 Cyl 1.6L B6 DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC253**	1	
Ignition – Distributor Cap	**BD132**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR133**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA67**	1	
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL69**	1	
Laser KJ			
10/94-12/96 4 Cyl 1.8L BP DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC241**	1	
Ignition – Distributor Cap	**BD132**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR133**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA67**	1	
Sensor – Exhaust Oxygen	**COS837**	1	Direct Fit 4 Wire: To 7/1995
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL69**	1	
Laser KJ Series II (KL): KJ Series III (KM)			
12/96-3/99 4 Cyl 1.6L B6 DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC242**	1	
Ignition – Distributor Cap	**BD132**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR133**	1	Mitsubishi Electronic Distributor
Sensor – Crankshaft	**CSCA65**	1	
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	

Ford	Part No	Qty	Notes
Laser KJ Series II (KL): KJ Series III (KM) **12/96-3/99 4 Cyl 1.8L BP: BPE DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC242**	1	
Ignition – Distributor Cap	**BD132**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR133**	1	Mitsubishi Electronic Distributor
Sensor – Crankshaft	**CSCA65**	1	
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Laser KN: KQ **3/99-8/02 4 Cyl 1.6L ZM DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC316**	2	
Sensor – Camshaft	**CSCA91**	1	
Sensor – Coolant Temperature	**CCS21**	1	From 7/1999
Sensor – Crankshaft	**CSCA155**	1	
Sensor – Exhaust Oxygen	**COS908**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Throttle Position	**CTPS143**	1	
Switch – Brake Light	**CSL47**	1	
Laser KN: KQ **3/99-8/02 4 Cyl 1.8L FP DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC311**	1	From 4/2001
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Camshaft	**CSCA91**	1	
Sensor – Camshaft	**CSCA93**	1	
Sensor – Coolant Temperature	**CCS21**	1	From 7/1999
Sensor – Crankshaft	**CSCA47**	1	
Sensor – Exhaust Oxygen	**COS909**	1	Direct Fit 4 Wire: Auto Transmission
Sensor – Exhaust Oxygen	**COS922**	1	Direct Fit 4 Wire: Manual Transmission
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Throttle Position	**CTPS147**	1	
Switch – Brake Light	**CSL47**	1	
Laser KQ **4/01-8/02 4 Cyl 2.0L FS DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC311**	1	
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Camshaft	**CSCA93**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA47**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Brake Light	**CSL47**	1	
LTD FA: FB: FC **1973-2/82 V8 Cyl 351 ci 5.8L C OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	Bosch Points Distributor: To 6/1978
Ignition – Coil – Standard	**CC215**	1	Bosch Electronic Distributor: From 6/1978
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Bosch Points Distributor: To 6/1978
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Bosch Points Distributor: To 6/1978
Ignition – Distributor Cap	**BH84**	1	Bosch Points and Electronic Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor: To 6/1978
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor: To 6/1978
Ignition – Distributor Rotor	**BH87**	1	Bosch Points Distributor: To 6/1978
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor: From 6/1978
Ignition – Module	**CM418**	1	Bosch Electronic Distributor: From 1/1979
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor: From 1/1979
Sensor – Temperature Gauge	**CTS120**	1	
Switch – Brake Light	**CSL20**	1	From 6/1979
Switch – Oil Pressure Warning Light	**CPS34**	1	From 6/1979

Ford	Part No	Qty	Notes
LTD FC: FD Carb. **10/79-2/83 6 Cyl 4.1L OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH118**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	From 6/1980
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Brake Light	**CSL20**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
LTD FD **3/82-2/83 V8 Cyl 5.0L C: 5.8L C OHV Carb. RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH84**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS120**	1	
Switch – Brake Light	**CSL20**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	
LTD FD EFi **3/83-9/84 6 Cyl 4.1L OHV 12V EFi RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH118**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH101**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Brake Light	**CSL20**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
LTD FE **10/84-5/88 6 Cyl 4.1L OHV 12V EFi RWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH144**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor
Ignition – Module	**CM420**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – MAP	**CMS205**	1	
Sensor – Temperature Gauge	**CTS122**	1	
Sensor – Throttle Position	**CTPS121**	1	
Switch – Brake Light	**CSL50**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	
Valve – Idle Speed Control	**CIA016**	1	

Ford	Part No	Qty	Notes
LTD DA: DA Series II: DC: DC Series II **6/88-3/95 6 Cyl 3.9L SOHC 12V MPFi RWD**			
Ignition – Coil – Standard	**CC236**	1	
Ignition – Distributor Cap	**BH144**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor
Ignition – Module	**CM420**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – MAP	**CMS205**	1	
Sensor – Temperature Gauge	**CTS144**	1	To 9/1989
Sensor – Temperature Gauge	**CTS131**	1	From 10/1989
Sensor – Throttle Position	**CTPS117**	1	Inner: To 1/1992
Sensor – Throttle Position	**CTPS109**	1	Outer: To 1/1992
Sensor – Throttle Position	**CTPS121**	1	From 2/1992
Switch – Brake Light	**CSL50**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	
Switch – Power Steering	**CP100**	1	Grey Insulator
Valve – Idle Speed Control	**CIA005**	1	With rectangular two pin connector
LTD DC: DC Series II **7/91-3/95 V8 Cyl 5.0L W OHV 16V MPFi RWD**			
Ignition – Coil – Standard	**CC205**	1	
Ignition – Distributor Cap	**FO100**	1	Ford Electronic Distributor
Ignition – Distributor Cap Base	**BC146**	1	Ford Electronic Distributor
Ignition – Distributor Rotor	**FO95**	1	Ford Electronic Distributor
Ignition – Module	**CM426**	1	
Ignition – Pickup / Trigger	**CSCA80**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – MAP	**CMS205**	1	
Sensor – Temperature Gauge	**CTS122**	1	
Sensor – Throttle Position	**CTPS110**	1	Upper
Sensor – Throttle Position	**CTPS100**	1	Lower
Switch – Brake Light	**CSL50**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	
Valve – Idle Speed Control	**CIA009**	1	
LTD DF: DF Series II **3/95-9/96 6 Cyl 4.0L SOHC 12V MPFi RWD**			
Ignition – Coil – Standard	**CC351**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS131**	1	
Switch – Brake Light	**CSL38**	1	Can Use CSL46
Switch – Oil Pressure Warning Light	**CPS34**	1	
Switch – Power Steering	**CP100**	1	Grey Insulator

Ford	Part No	Qty	Notes
LTD DF: DF Series II: DL **3/95-6/99 V8 Cyl 5.0L W OHV 16V MPFi RWD**			
Ignition – Coil – Standard	**CC205**	1	
Ignition – Distributor Cap	**FO100**	1	Ford Electronic Distributor
Ignition – Distributor Cap Base	**BC146**	1	Ford Electronic Distributor
Ignition – Distributor Rotor	**FO95**	1	Ford Electronic Distributor
Ignition – Module	**CM426**	1	
Ignition – Pickup / Trigger	**CSCA80**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Exhaust Oxygen	**COS733**	2	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	2	Universal 3 Wire
Sensor – Throttle Position	**CTPS110**	1	Upper
Sensor – Throttle Position	**CTPS100**	1	Lower
Switch – Brake Light	**CSL38**	1	Can Use CSL46
Switch – Oil Pressure Warning Light	**CPS34**	1	
LTD DL **9/96-6/99 6 Cyl 4.0L SOHC 12V MPFi RWD**			
Ignition – Coil – Standard	**CC236**	1	From 9/1996
Ignition – Distributor Cap	**BH144**	1	Bosch Electronic Distributor: From 9/1996
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor: From 9/1996
Ignition – Module	**CM420**	1	
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Sensor – Crankshaft	**CSCA41**	1	
Sensor – Exhaust Oxygen	**COS733**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS102**	1	
Sensor – MAP	**CMS205**	1	
Sensor – Temperature Gauge	**CTS131**	1	
Sensor – Throttle Position	**CTPS121**	1	
Switch – Brake Light	**CSL38**	1	Can Use CSL46
Switch – Oil Pressure Warning Light	**CPS34**	1	
Switch – Power Steering	**CP100**	1	Grey Insulator
Valve – Idle Speed Control	**CIA011**	1	With oval two pin connector
Valve – Idle Speed Control	**CIA005**	1	With rectangular two pin connector
LTD AU: AU Series II **6/99-12/02 6 Cyl 4.0L SOHC 12V MPFi RWD**			
Ignition – Coil – Standard	**CC351**	1	Series I: To 4/2000
Ignition – Coil – Standard	**CC237**	1	Series II: From 4/2000
Sensor – Crankshaft	**CSCA41**	1	
Sensor – Exhaust Oxygen	**COS802**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS105**	1	
Sensor – MAP and Inlet Air Temperature	**CMS217**	1	To 2/2000
Sensor – MAP and Inlet Air Temperature	**CMS216**	1	From 3/2000
Sensor – Throttle Position	**CTPS121**	1	To 2/2000
Sensor – Throttle Position	**CTPS108**	1	From 3/2000
Switch – Brake Light	**CSL38**	1	Can Use CSL46
Switch – Oil Pressure Warning Light	**CPS34**	1	
Switch – Power Steering	**CP100**	1	Grey Insulator

Ford	Part No	Qty	Notes
LTD AU: AU Series II			
6/99-12/02 V8 Cyl 5.0L W OHV 16V MPFi RWD			
Ignition – Coil – Standard	**CC240**	1	
Sensor – Air Temperature – Inlet	**CAT018**	1	In Air Intake
Sensor – Air Temperature – Inlet	**CAT003**	1	In Manifold
Sensor – Camshaft	**CSCA92**	1	
Sensor – Exhaust Oxygen	**COS802**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Throttle Position	**CTPS110**	1	Upper
Sensor – Throttle Position	**CTPS100**	1	Lower
Switch – Brake Light	**CSL38**	1	Can Use CSL46
Switch – Oil Pressure Warning Light	**CPS34**	1	
Valve – Idle Speed Control	**CIA006**	1	
LTD BA: BA Series II: BF			
7/03-12/07 V8 Cyl 5.4L Barra 220: Barra 230 SOHC 24V ESPFI RWD			
Sensor – Camshaft	**CSCA126**	1	
Sensor – Coolant Temperature	**CCS43**	1	
Sensor – Crankshaft	**CSCA144**	1	
Sensor – Crankshaft / Cam	**CSCA143**	2	Camshaft Timing
Sensor – Exhaust Oxygen	**COS765**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP and Inlet Air Temperature	**CMS216**	1	
Switch – Brake Light	**CSL62**	1	
Maverick			
2/88-9/93 6 Cyl 4.2L TB42 OHV Carb. 4WD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD810**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Switch – Oil Pressure Warning Light	**CPS28**	1	
Meteor GA: GB			
4/82-9/85 4 Cyl 1.5L E5 SOHC 8V Carb. & Twin Carb. FWD			
Ignition – Coil – Standard	**CIC32R**	1	Points Ignition: To 1982
Ignition – Coil – Standard	**CC259**	1	Electronic Ignition: From 1982
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Points Ignition: To 1982
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Points Ignition: To 1982
Ignition – Distributor Cap	**JP542**	1	Points Ignition: To 1982
Ignition – Distributor Cap	**JP568**	1	Electronic Ignition: From 1982
Ignition – Distributor Condenser	**MC417**	1	Points Ignition: To 1982
Ignition – Distributor Points / Contact Set	**S219VU**	1	Points Ignition: To 1982
Ignition – Distributor Rotor	**JR533**	1	Points Ignition: To 1982
Ignition – Distributor Rotor	**JR555**	1	Electronic Ignition: From 1982
Ignition – Module	**CM408**	1	Electronic Ignition: From 1982
Ignition – Pickup / Trigger	**CIT110**	1	Electronic Ignition: From 1982
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS26**	1	

Ford	Part No	Qty	Notes
Meteor GC **10/85-9/87 4 Cyl 1.6L B6 SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CC259**	1	
Ignition – Distributor Cap	**JP684**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR619**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM405**	1	
Ignition – Pickup / Trigger	**CIT111**	1	
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS42**	1	Mounted In Head
Meteor GC **10/85-9/87 4 Cyl 1.6L B6 SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC222**	1	
Ignition – Distributor Cap	**JP684**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM408**	1	To 4/1987
Ignition – Module	**CM405**	1	From 4/1987
Ignition – Pickup / Trigger	**CIT111**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS736**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS111**	1	
Sensor – Throttle Position	**CTPS104**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS42**	1	Mounted In Head
Switch – Radiator Fan	**CFS26**	1	Mounted In Radiator
Mondeo HA: HB: HC **7/95-12/98 4 Cyl 2.0L HA (Zetec) DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC240**	1	
Sensor – Air Flow / MAF	**CAF031**	1	
Sensor – Camshaft	**CSCA108**	1	
Sensor – Coolant Temperature	**CCS43**	1	
Sensor – Crankshaft	**CSCA44**	1	
Sensor – Exhaust Oxygen	**COS767**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS151**	1	To 12/1997
Switch – Brake Light	**CSL62**	1	
Switch – Oil Pressure Warning Light	**CPS41**	1	
Mondeo HD: HE **1/99-12/00 4 Cyl 2.0L HA (Zetec) DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC239**	1	
Sensor – Air Flow / MAF	**CAF031**	1	
Sensor – Camshaft	**CSCA108**	1	
Sensor – Coolant Temperature	**CCS40**	1	
Sensor – Crankshaft	**CSCA44**	1	
Switch – Oil Pressure Warning Light	**CPS41**	1	
Mondeo HE **2/00-12/00 V6 Cyl 2.5L Duratec DOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC210**	1	
Sensor – Air Temperature – Inlet	**CAT027**	1	
Sensor – Coolant Temperature	**CCS43**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Brake Light	**CSL62**	1	4 Speed Auto Transmission

Ford	Part No	Qty	Notes
Mondeo MA TDCi Turbo Diesel			
10/07-on 4 Cyl 2.0L Duratorq DOHC 16V Di FWD			
Sensor – Air Temperature – Inlet	**CAT028**	1	
Mustang			
10/65-12/73 V8 Cyl 4.7L W OHV 16V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**FO90**	1	Ford Points Distributor: To 1970
Ignition – Distributor Condenser	**FC79**	1	Ford Points Distributor: To 1970
Ignition – Distributor Points / Contact Set	**S82V**	1	Ford Points Distributor: To 1970
Ignition – Distributor Rotor	**FO75**	1	Ford Points Distributor: To 1970
Mustang Cobra			
2/01-12/03 V8 Cyl 4.6L XF DOHC 32V MPFi RWD			
Sensor – Camshaft	**CSCA126**	1	
Sensor – Crankshaft	**CSCA144**	1	
Probe ST: SU: SV			
7/94-1/98 V6 Cyl 2.5L KL DOHC 24V EFi FWD			
Ignition – Coil – Standard	**CC252**	1	
Ignition – Distributor Cap	**JP726**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR647**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CSCA59**	1	Mitsubishi Distributor: From 11/1994
Ignition – Pickup / Trigger	**CSCA10**	1	Mitsubishi Electronic Distributor: To 10/1994
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA49**	1	
Sensor – Exhaust Oxygen	**COS764**	1	Direct Fit 4 Wire: Front
Sensor – Exhaust Oxygen	**COS763**	1	Direct Fit 4 Wire: Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear
Sensor – Knock Control	**CKS119**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS149**	1	
Switch – Brake Light	**CSL70**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Raider UV			
8/91-7/97 4 Cyl 2.6L G6 SOHC 12V EFi 4WD			
Ignition – Coil – Standard	**CC209**	1	
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR792**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM421**	1	
Sensor – Air Temperature – Inlet	**CAT013**	1	
Sensor – Coolant Temperature	**CCS46**	1	
Sensor – Crankshaft	**CSCA53**	1	In Distributor
Sensor – Exhaust Oxygen	**COS763**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Temperature Gauge	**CTS115**	1	
Sensor – Throttle Position	**CTPS148**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Sierra S/W *(NZ Market)*			
1984-88 4 Cyl 2.0L TL20H SOHC			
Ignition – Distributor Cap	**FO92**	1	Autolite Distributor
Ignition – Distributor Cap	**BH100**	1	Bosch Distributor
Ignition – Distributor Rotor	**FO77**	1	Autolite Distributor
Ignition – Distributor Rotor	**DR127**	1	Bosch Distributor

Ford	Part No	Qty	Notes
Spectron **1/83-5/84 4 Cyl 1.6L NA SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	Points Ignition
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP564**	1	Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Points Distributor
Spectron **5/84-12/86 4 Cyl 1.8L F8 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	Points Ignition: To 11/1986
Ignition – Coil – Standard	**CC209**	1	Electronic Ignition: From 11/1986
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Points Ignition
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Points Ignition
Ignition – Distributor Cap	**JP564**	1	Manual Transmission: Points Dist.: To 11/1986
Ignition – Distributor Cap	**JP680**	1	Manual Transmission: Electronic Distributor: From 11/1986
Ignition – Distributor Condenser	**MC413**	1	Manual Transmission: Points Dist.: To 11/1986
Ignition – Distributor Points / Contact Set	**S219VU**	1	Manual Transmission: Points Dist.: To 11/1986
Ignition – Distributor Rotor	**JR533**	1	Manual Transmission: Points Dist.: To 11/1986
Ignition – Distributor Rotor	**JR617**	1	Manual Transmission: Electronic Distributor: From 11/1986
Ignition – Module	**CM405**	1	Manual Transmission: Electronic Distributor: From 11/1986
Ignition – Pickup / Trigger	**CIT106**	1	Manual Transmission: Electronic Distributor: From 11/1986
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
Spectron Incl.4WD **3/86-4/90 4 Cyl 2.0L FE SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC209**	1	
Ignition – Distributor Cap	**JP680**	1	Electronic Distributor
Ignition – Distributor Rotor	**JR617**	1	Electronic Distributor
Ignition – Module	**CM405**	1	Electronic Distributor
Ignition – Pickup / Trigger	**CIT106**	1	Electronic Distributor: To 7/1989
Ignition – Pickup / Trigger	**CIT107**	1	Electronic Distributor: From 7/1989
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
Taurus DN: DP **3/96-9/98 V6 Cyl 3.0L Duratec DOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC210**	1	
Sensor – Camshaft	**CSCA106**	1	
Sensor – Coolant Temperature	**CCS43**	1	
Sensor – Exhaust Oxygen	**COS802**	4	Direct Fit 4 Wire: LH & RH Side Before & After Catalyst
Sensor – Exhaust Oxygen	**COS765**	2	Direct Fit 4 Wire: LH & RH Side In Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	6	Universal 4 Wire: LH & RH Side: All
Sensor – Throttle Position	**CTPS119**	1	
Switch – Oil Pressure Warning Light	**CPS41**	1	

Ford	Part No	Qty	Notes
Telstar AR: AS **5/83-9/87 4 Cyl 2.0L FE SOHC 8V Carb. FWD**			
Ignition – Distributor Cap	**BH122**	1	Bosch Electronic Distributor
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**BH121**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Module	**CM408**	1	Mitsubishi Electronic Distributor
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS26**	1	
Telstar *(NZ Market)* **1983-88 4 Cyl 2.0L FE SOHC**			
Ignition – Coil – Standard	**CC259**	1	
Telstar GE5PF *(NZ Market)* **1983-88 V6 Cyl 2.5L KL DOHC**			
Ignition – Distributor Rotor	**DR135**	1	
Telstar AS TX5 Turbo **1/86-9/87 4 Cyl 2.0L FE SOHC 8V SPFI FWD**			
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS736**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
Switch – Radiator Fan	**CFS26**	1	
Telstar AT **10/87-10/89 4 Cyl 2.0L FE SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CC259**	1	
Ignition – Distributor Cap	**JP680**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM405**	1	Mitsubishi Electronic Distributor
Ignition – Pickup / Trigger	**CIT106**	1	Mitsubishi Electronic Distributor: To 7/1989
Ignition – Pickup / Trigger	**CIT107**	1	Mitsubishi Electronic Distributor: From 7/1989
Sensor – Temperature Gauge	**CTS111**	1	To 10/1988
Sensor – Temperature Gauge	**CTS115**	1	From 10/1988
Telstar AT: AV **10/87-1/92 4 Cyl 2.2L F2 SOHC 12V MPFi FWD**			
Ignition – Coil – Standard	**CC202**	1	Hanshin
Ignition – Coil – Standard	**CC219**	1	Mitsubishi
Ignition – Distributor Cap	**JP710**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR625**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM405**	1	Mitsubishi Electronic Distributor: To 2/1990
Ignition – Pickup / Trigger	**CIT107**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS736**	1	Direct Fit 1 Wire: To 9/1989
Sensor – Exhaust Oxygen	**COS768**	1	Direct Fit 1 Wire: From 1/1990
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: All
Sensor – Temperature Gauge	**CTS111**	1	To 10/1988
Sensor – Temperature Gauge	**CTS115**	1	From 10/1988
Switch – Brake Light	**CSL47**	1	To 9/1989
Switch – Brake Light	**CSL71**	1	From 1/1990
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS26**	1	

Ford	Part No	Qty	Notes
Telstar AT: AV TX5 Turbo **10/87-1/92 4 Cyl 2.2L F2 SOHC 12V MPFi FWD**			
Ignition – Coil – Standard	**CC219**	1	
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR627**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS736**	1	Direct Fit 1 Wire: To 9/1989
Sensor – Exhaust Oxygen	**COS768**	1	Direct Fit 1 Wire: From 1/1990
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS111**	1	To 10/1988
Sensor – Temperature Gauge	**CTS115**	1	From 10/1988 To 9/1989
Sensor – Temperature Gauge	**CTS110**	1	From 1/1990
Switch – Brake Light	**CSL47**	1	To 9/1989
Switch – Brake Light	**CSL71**	1	From 1/1990
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS26**	1	
Telstar AX: AY **1/92-11/96 4 Cyl 2.0L FS DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC250**	1	Hitachi Electronic Distributor: From 7/1994
Ignition – Coil – Standard	**CC245**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP736**	1	Hitachi Electronic Distributor: To 6/1994
Ignition – Distributor Cap	**JP404**	1	Hitachi Electronic Distributor: From 7/1994
Ignition – Distributor Rotor	**JR653**	1	Hitachi Electronic Distributor: To 6/1994
Ignition – Distributor Rotor	**JR820**	1	Hitachi Electronic Distributor: From 7/1994
Sensor – Air Temperature – Inlet	**CAT012**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA09**	1	In Distributor: Check which one required
Sensor – Crankshaft	**CSCA63**	1	In Distributor: Check which one required
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS147**	1	
Switch – Brake Light	**CSL71**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Telstar AX **1/92-8/94 V6 Cyl 2.5L KL DOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC248**	1	
Ignition – Distributor Cap	**JP726**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR647**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CSCA59**	1	From 7/1994
Ignition – Pickup / Trigger	**CSCA10**	1	To 6/1994
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA49**	1	
Sensor – Exhaust Oxygen	**COS764**	1	Direct Fit 4 Wire: Front
Sensor – Exhaust Oxygen	**COS763**	1	Direct Fit 4 Wire: Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS149**	1	
Switch – Brake Light	**CSL71**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Ford	Part No	Qty	Notes
Telstar AY **8/94-11/96 V6 Cyl 2.5L KL DOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC252**	1	
Ignition – Distributor Cap	**BD134**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR135**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CSCA59**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA49**	1	
Sensor – Exhaust Oxygen	**COS764**	1	Direct Fit 4 Wire: Front
Sensor – Exhaust Oxygen	**COS763**	1	Direct Fit 4 Wire: Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear
Sensor – Knock Control	**CKS119**	1	From 1995
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS149**	1	
Switch – Brake Light	**CSL71**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Territory SX: SY **5/04-9/05 6 Cyl 4.0L Barra 182: Barra 190 DOHC 24V MPFi RWD & AWD**			
Ignition – Coil – Standard	**CC353**	6	
Sensor – Camshaft	**CSCA124**	1	LH Side: Inlet
Sensor – Camshaft	**CSCA125**	1	RH Side: Exhaust
Sensor – Crankshaft	**CSCA126**	1	
Sensor – Crankshaft / Cam	**CSCA143**	1	Crankshaft
Sensor – Exhaust Oxygen	**COS802**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Trader 0409 **6/79-12/81 4 Cyl 2.0L VA Carb. 4x2**			
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Transit **5/73-12/81 6 Cyl 4.1L Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS122**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Transit VE Diesel **6/94-5/96 4 Cyl 2.5L 4D OHV 8V Di RWD**			
Sensor – Temperature Gauge	**CTS149**	1	
Transit VF: VG **1/96-11/00 4 Cyl 2.0L N9K: NSJ DOHC EFi RWD**			
Ignition – Coil – Standard	**CC238**	2	
Sensor – Air Flow / MAF	**CAF031**	1	
Sensor – Air Temperature – Inlet	**CAT025**	1	To 7/1997
Sensor – Air Temperature – Inlet	**CAT003**	1	From 7/1997
Sensor – Coolant Temperature	**CCS29**	1	2 Round Pin Connector
Sensor – Coolant Temperature	**CCS43**	1	2 Flat Pin Connector
Sensor – Exhaust Oxygen	**COS808**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS151**	1	
Switch – Oil Pressure Warning Light	**CPS45**	1	

Ford	Part No	Qty	Notes
Transit VF: VG Turbo Diesel **5/96-11/00 4 Cyl 2.5L Di RWD**			
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS43**	1	
Transit VH: VJ **12/00-10/06 4 Cyl 2.3L DOHC 16V MPFi RWD**			
Sensor – Air Temperature – Inlet	**CAT003**	1	
Sensor – Coolant Temperature	**CCS43**	1	
Sensor – Crankshaft	**CSCA195**	1	
Switch – Oil Pressure Warning Light	**CPS45**	1	
Transit VH Turbo Diesel **12/00-4/04 4 Cyl 2.4L DOHC 16V Di RWD**			
Sensor – Crankshaft	**CSCA44**	1	
Sensor – Temperature Gauge	**CTS149**	1	
Switch – Oil Pressure Warning Light	**CPS45**	1	
Ford FTE			
TE50: TL50: TS50: AU: AU Series II: AU Series III **10/99-12/02 V8 Cyl 5.0L 302W: 5.6L OHV 16V MPFi RWD**			
Sensor – Air Temperature – Inlet	**CAT018**	1	In Air Intake
Sensor – Air Temperature – Inlet	**CAT003**	1	In Manifold
Hillman			
Arrow **5/67-11/68 4 Cyl 1.7L OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD278**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor
Hunter HC: HE **5/67-10/70 4 Cyl 1.7L OHV Carb. & 2xCarb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD278**	1	Lucas Points Distributor: To 1972
Ignition – Distributor Cap	**BD276**	1	Lucas Points Distributor: From 1972
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor: To 1972
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor: From 1972
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Husky **1/60-12/62 4 Cyl 1.4L OHV Carb. RWD**			
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	

Hillman	Part No	Qty	Notes
Imp			
12/64-12/69 4 Cyl 875cc Carb. RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD268**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Minx			
1/60-12/67 4 Cyl 1.5L: 1.6L Carb. RWD			
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Holden			
Adventra VY Series II CX8: LX8			
10/03-10/04 V8 Cyl 5.7L GEN III OHV 16V MPFi 4WD			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS124**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Adventra VZ CX8: LX8			
11/04-2/05 V8 Cyl 5.7L GEN III OHV 16V MPFi 4WD			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Crankshaft	**CSCA45**	1	
Sensor – Exhaust Oxygen	**COS873**	1	Direct Fit 4 Wire: Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear
Sensor – MAP	**CMS210**	1	
Adventra VZ CX6: SX6: LX6			
3/05-8/07 V6 Cyl 3.6L Alloytec 190 DOHC 24V MPFi AWD			
Sensor – Camshaft	**CSCA113**	1	
Sensor – Crankshaft	**CSCA131**	1	
Apollo JK			
8/89-6/91 4 Cyl 2.0L 3SFC DOHC 16V Carb. FWD			
Ignition – Coil – Standard	**CC216**	1	
Ignition – Distributor Cap	**DR895**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT103**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL67**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS32**	1	

Holden	Part No	Qty	Notes
Apollo JK: JL **5/91-2/93 4 Cyl 2.0L 3SFE DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Distributor Cap and Leads	**JP805**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Ignition – Module	**CM437**	1	Computer Controlled Distributor
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS104**	1	Auto Transmission
Switch – Brake Light	**CSL67**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS32**	1	
Apollo JM: JP **3/93-5/97 4 Cyl 2.2L 5SFE DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC263**	1	
Ignition – Distributor Cap	**JP822**	1	Denso Electronic Distributor: To 9/1993
Ignition – Distributor Cap	**BD131**	1	Denso Electronic Distributor: From 10/1993
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor: From 10/1993
Ignition – Module	**CM436**	1	
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS150**	1	
Sensor – Throttle Position	**CTPS111**	1	From 10/1994
Switch – Brake Light	**CSL59**	1	2 Terminals
Switch – Brake Light	**CSL60**	1	4 Terminal
Switch – Oil Pressure Warning Light	**CPS51**	1	
Switch – Radiator Fan	**CFS55**	1	
Apollo JM **3/93-8/95 V6 Cyl 3.0L 3VZFE DOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC276**	1	
Ignition – Distributor Cap	**BD138**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**BD139**	1	Denso Electronic Distributor
Ignition – Module	**CM438**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL59**	1	2 Terminals
Switch – Brake Light	**CSL60**	1	4 Terminal
Switch – Oil Pressure Warning Light	**CPS51**	1	
Apollo JP **9/95-5/97 V6 Cyl 3.0L 3VZFE DOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC276**	1	
Ignition – Distributor Cap	**BD138**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**BD139**	1	Denso Electronic Distributor
Ignition – Module	**CM438**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL59**	1	2 Terminals
Switch – Brake Light	**CSL60**	1	4 Terminal
Switch – Oil Pressure Warning Light	**CPS51**	1	

Holden	Part No	Qty	Notes
Astra LB: LC			
8/84-7/87 4 Cyl 1.5L E15: 1.6L E16 SOHC 8V Carb. FWD			
Ignition – Coil – Standard	**CIC32R**	1	Points ignition: To 1/1985
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Points ignition: To 1/1985
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Points ignition: To 1/1985
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor: To 1/1985
Ignition – Distributor Cap	**JP594**	1	Hitachi Electronic Distributor: From 2/1985
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor: To 1/1985
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor: To 1/1985
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor: To 1/1985
Ignition – Distributor Rotor	**JR535**	1	Hitachi Electronic Distributor: From 2/1985
Ignition – Module & Pickup / Trigger	**CM417**	1	Hitachi Electronic Distributor: From 2/1985
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS20**	1	
Astra LD			
7/87-7/89 4 Cyl 1.6L 16LF: 1.8L 18LE SOHC 8V SPFi & MPFi FWD			
Ignition – Coil – Standard	**CC207**	1	
Ignition – Distributor Cap	**DR114**	1	Delco Electronic Distributor
Ignition – Distributor Rotor	**DR73**	1	Delco Electronic Distributor
Ignition – Module	**CM415**	1	Delco Electronic Distributor
Ignition – Pickup / Trigger	**CIT100**	1	Delco Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT009**	1	1.8L MPFi
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS127**	1	
Sensor – Throttle Position	**CTPS132**	1	1.6L SPFi
Sensor – Throttle Position	**CTPS131**	1	1.8L MPFi
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS57**	1	
Switch – Radiator Fan	**CFS28**	1	
Valve – Idle Speed Control	**CIA004**	1	1.6L SPFi
Valve – Idle Speed Control	**CIA008**	1	1.8L MPFi
Astra TR			
9/96-9/98 4 Cyl 1.6L C16SE SOHC 8V MPFi FWD			
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA16**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS127**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Brake Light	**CSL55**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Radiator Fan	**CFS92**	1	Code WM: With A/C Manual Control
Switch – Radiator Fan	**CFS58**	1	Code WR: Excl A/C: Manual Control
Switch – Radiator Fan	**CFS49**	1	Code XC: With A/C Manual Control
Switch – Radiator Fan	**CFS46**	1	Code XD: With A/C Manual Control
Valve – Idle Speed Control	**CIA017**	1	

Holden	Part No	Qty	Notes
Astra TR **9/96-9/98 4 Cyl 1.8L C18SE: 2.0L X20XE DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC270**	1	
Sensor – Air Flow / MAF	**CAF004**	1	2.0L X20XE Engine
Sensor – Camshaft	**CSCA82**	1	
Sensor – Coolant Temperature	**CCS48**	1	
Sensor – Crankshaft	**CSCA21**	1	
Sensor – Knock Control	**CKS112**	1	2.0L X20XE Engine: To Engine T8---
Sensor – Temperature Gauge	**CTS127**	1	
Sensor – Throttle Position	**CTPS100**	1	Switch
Switch – Brake Light	**CSL55**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Radiator Fan	**CFS95**	1	Code WG: Excl A/C Manual Control
Switch – Radiator Fan	**CFS92**	1	Code WM: With A/C Manual Control
Switch – Radiator Fan	**CFS93**	1	Code WQ: With A/C Manual Control
Switch – Radiator Fan	**CFS49**	1	Code XC: With A/C Manual Control
Switch – Radiator Fan	**CFS46**	1	Code XD: With A/C Manual Control
Valve – Idle Speed Control	**CIA018**	1	
Astra TS **9/98-12/00 4 Cyl 1.8L X18XE1 DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC356**	1	
Sensor – Air Flow / MAF	**CAF005**	1	
Sensor – Air Temperature – Ambient	**CAT019**	1	
Sensor – Camshaft	**CSCA83**	1	
Sensor – Coolant Temperature	**CCS42**	1	
Sensor – Crankshaft	**CSCA50**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS117**	1	
Sensor – MAP	**CMS210**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Astra TS: AH **1/01-3/07 4 Cyl 1.8L Z18XE DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC356**	1	
Sensor – Air Flow / MAF	**CAF005**	1	
Sensor – Air Temperature – Ambient	**CAT019**	1	
Sensor – Camshaft	**CSCA83**	1	
Sensor – Coolant Temperature	**CCS42**	1	
Sensor – Crankshaft	**CSCA23**	1	
Sensor – Exhaust Oxygen	**COS884**	1	Direct Fit 4 Wire: Manifold
Sensor – Exhaust Oxygen	**COS883**	1	Direct Fit 4 Wire: Engine Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Manifold and Engine Pipe
Sensor – Knock Control	**CKS114**	1	
Sensor – Speed / RPM	**CSCA204**	1	4 Speed Auto Transmission: Input
Switch – Oil Pressure Warning Light	**CPS48**	1	
Astra TS **10/01-1/07 4 Cyl 2.2L Z22SE DOHC 16V ESFI FWD**			
Ignition – Coil and Igniter	**CC386**	1	
Sensor – Air Temperature – Ambient	**CAT019**	1	
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA130**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Engine Pipe and After Catalyst
Sensor – MAP	**CMS210**	1	

Holden	Part No	Qty	Notes
Astra TS Turbo **5/03-7/04 4 Cyl 2.0L Z20LET DOHC 16V ESFI FWD**			
Sensor – Air Temperature – Ambient	**CAT019**	1	
Sensor – Camshaft	**CSCA156**	1	
Sensor – Coolant Temperature	**CCS41**	1	
Sensor – Crankshaft	**CSCA157**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Engine Pipe and After Catalyst
Sensor – MAP	**CMS224**	1	Boost Pressure
Sensor – MAP and Inlet Air Temperature	**CAT022**	1	Intercooler
Switch – Oil Pressure Warning Light	**CPS48**	1	
Astra AH Turbo Diesel **6/06-on 4 Cyl 1.9L Z19DT4: Z19DTH4 SOHC 8V Di FWD**			
Sensor – Air Temperature – Ambient	**CAT019**	1	
Sensor – Camshaft	**CSCA174**	1	Z19DT4 Engine
Sensor – Camshaft	**CSCA175**	1	Z19DTH4 Engine
Sensor – Coolant Temperature	**CCS49**	1	
Sensor – Crankshaft	**CSCA177**	1	
Sensor – MAP	**CMS225**	1	
Switch – Oil Pressure Warning Light	**CPS58**	1	
Astra AH Turbo **6/06-on 4 Cyl 2.0L Z20LER DOHC 16V MPFi FWD**			
Sensor – Air Temperature – Ambient	**CAT019**	1	
Sensor – Camshaft	**CSCA156**	1	
Sensor – Coolant Temperature	**CCS41**	1	
Sensor – Crankshaft	**CSCA157**	1	
Sensor – MAP	**CMS224**	1	Boost Pressure
Sensor – MAP and Inlet Air Temperature	**CAT022**	1	Intercooler
Astra AH **12/06-on 4 Cyl 2.2L Z22YH DOHC 16V MPFi FWD**			
Sensor – Air Flow / MAF	**CAF030**	1	
Sensor – Air Temperature – Ambient	**CAT019**	1	
Sensor – Camshaft	**CSCA173**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA130**	1	
Sensor – MAP	**CMS210**	1	
Sensor – Speed / RPM	**CSCA204**	1	4 Speed Auto Transmission: Input
Astra AH **4/07-on 4 Cyl 1.8L Z18XER DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC357**	1	
Sensor – Air Temperature – Ambient	**CAT019**	1	
Sensor – Camshaft	**CSCA173**	1	
Sensor – Coolant Temperature	**CCS47**	1	
Sensor – Speed / RPM	**CSCA204**	1	4 Speed Auto Transmission: Input
Barina MB: ML **2/85-1/89 4 Cyl 1.3L G13A SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CC201**	1	To 8/1986
Ignition – Coil – Standard	**CC284**	1	From 9/1986
Ignition – Distributor Cap	**JP654**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**DR128**	1	Denso Electronic Distributor
Ignition – Module	**CM478**	1	
Ignition – Pickup / Trigger	**CIT105**	1	
Sensor – Temperature Gauge	**CTS142**	1	
Switch – Brake Light	**CSL31**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS45**	1	

Holden	Part No	Qty	Notes
Barina MF: MH **2/89-5/94 4 Cyl 1.3L G13B SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CC309**	1	
Ignition – Distributor Cap	**BD107**	1	Mitsubishi Electronic Distributor (A): To Vin G6800148087 / S7700141225
Ignition – Distributor Cap	**JP718**	1	Mitsubishi Electronic Distributor (B): From Vin G6800148088 / S7700141226
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Distributor (A): To Vin G6800148087 / S7700141225
Ignition – Distributor Rotor	**JR641**	1	Mitsubishi Electronic Distributor (B): From Vin G6800148088 / S7700141226
Ignition – Module	**CM405**	1	To 12/1992: To Vin JSAE8MG6800148087 & JSAE8MS7700141225
Ignition – Module	**CM411**	1	From 1/1993: From Vin JSAE8MG6800148088 & JSAE8MS7700141226
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS86**	1	MF: 3 Door
Switch – Radiator Fan	**CFS85**	1	MF: 5 Door: To Vin JSAE8MG6800101893
Switch – Radiator Fan	**CFS86**	1	MF: 5 Door: From Vin JSAE8MG6800101894
Switch – Radiator Fan	**CFS91**	1	MH
Barina SB **4/94-7/97 4 Cyl 1.2L C12NZ: 1.4L C14NZ SOHC 8V SPFI FWD**			
Ignition – Coil – Standard	**CC279**	1	
Ignition – Distributor Cap	**BD123**	1	Bosch Electronic Distributor
Ignition – Distributor Cap	**JP820**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**DR127**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**JR807**	1	Lucas Electronic Distributor
Ignition – Module	**CM427**	1	
Sensor – Air Temperature – Ambient	**CAT019**	1	
Sensor – Air Temperature – Inlet	**CAT020**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS134**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Radiator Fan	**CFS49**	1	Oval Shaped Connector
Switch – Radiator Fan	**CFS78**	1	Round Shaped Connector
Valve – Idle Speed Control	**CIA004**	1	Auto Transmission
Barina SB **4/94-3/95 4 Cyl 1.6L C16XE DOHC 16V MPFi FWD**			
Sensor – Air Temperature – Ambient	**CAT019**	1	
Sensor – Camshaft	**CSCA95**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA15**	1	
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Brake Light	**CSL41**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Radiator Fan	**CFS49**	1	Oval Shaped Connector
Switch – Radiator Fan	**CFS78**	1	Round Shaped Connector
Valve – Idle Speed Control	**CIA017**	1	

Holden	Part No	Qty	Notes
Barina SB **3/95-9/98 4 Cyl 1.6L X16XE DOHC 16V MPFi FWD**			
Sensor – Air Temperature – Ambient	**CAT019**	1	
Sensor – Air Temperature – Inlet	**CAT020**	1	
Sensor – Camshaft	**CSCA95**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA17**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire: With Air Pump
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire: Without Air Pump
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: With Air Pump
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Without Air Pump
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Brake Light	**CSL41**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Radiator Fan	**CFS49**	1	Oval Shaped Connector
Switch – Radiator Fan	**CFS78**	1	Round Shaped Connector
Valve – Idle Speed Control	**CIA017**	1	
Barina SB **8/97-2/01 4 Cyl 1.4L C14SE SOHC 8V MPFi FWD**			
Ignition – Module	**CM427**	1	
Sensor – Air Temperature – Inlet	**CAT020**	1	
Sensor – Coolant Temperature	**CCS41**	1	
Sensor – Crankshaft	**CSCA16**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS134**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Radiator Fan	**CFS49**	1	Oval Shaped Connector
Switch – Radiator Fan	**CFS78**	1	Round Shaped Connector
Valve – Idle Speed Control	**CIA017**	1	
Barina XC **2/01-12/05 4 Cyl 1.4L Z14XE DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC355**	1	To 1/2003
Sensor – Air Temperature – Inlet	**CAT020**	1	
Sensor – Camshaft	**CSCA158**	1	To 2004
Sensor – Camshaft	**CSCA94**	1	From 2005
Sensor – Coolant Temperature	**CCS41**	1	
Sensor – Crankshaft	**CSCA176**	1	To 2004
Sensor – Crankshaft	**CSCA24**	1	From 2005
Sensor – Exhaust Oxygen	**COS917**	1	Direct Fit 4 Wire: In Pipe
Sensor – Exhaust Oxygen	**COS899**	1	Direct Fit 4 Wire: In Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: In Pipe and In Catalyst
Sensor – MAP	**CMS210**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	M14x1.5 Thread
Switch – Radiator Fan	**CFS49**	1	Oval Shaped Connector
Switch – Radiator Fan	**CFS78**	1	Round Shaped Connector

Holden	Part No	Qty	Notes
Barina XC **9/01-12/05 4 Cyl 1.8L Z18XE DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC356**	1	
Sensor – Air Flow / MAF	**CAF005**	1	
Sensor – Air Temperature – Ambient	**CAT019**	1	
Sensor – Camshaft	**CSCA83**	1	
Sensor – Coolant Temperature	**CCS42**	1	
Sensor – Crankshaft	**CSCA24**	1	
Sensor – Exhaust Oxygen	**COS883**	1	Direct Fit 4 Wire: After Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Engine Pipe and After Catalyst
Sensor – Knock Control	**CKS114**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Barina XC **12/03-12/05 4 Cyl 1.4L Z14XEP DOHC 16V ESPFI FWD**			
Ignition – Coil and Igniter	**CC355**	1	
Sensor – Air Temperature – Inlet	**CAT020**	1	From Vin 54000001
Sensor – Camshaft	**CSCA158**	1	
Sensor – Coolant Temperature	**CCS41**	1	
Sensor – Crankshaft	**CSCA176**	1	
Sensor – Exhaust Oxygen	**COS883**	1	Direct Fit 4 Wire: Front Exhaust Pipe: Z14XEP Code BZ
Sensor – Exhaust Oxygen	**COS917**	1	Direct Fit 4 Wire: Front Exhaust Pipe: To Vin 14999999
Sensor – Exhaust Oxygen	**COS901**	1	Direct Fit 4 Wire: Front Exhaust Pipe: From Vin 24000001
Sensor – Exhaust Oxygen	**COS899**	1	Direct Fit 4 Wire: In Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Univ. 4 Wire: Front Exhaust Pipe and Catalyst
Sensor – MAP	**CMS210**	1	
Barina XC SRi **12/03-12/05 4 Cyl 1.8L Z18XE1 DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC356**	1	
Sensor – Air Flow / MAF	**CAF005**	1	
Sensor – Air Temperature – Inlet	**CAT020**	1	
Sensor – Camshaft	**CSCA83**	1	
Sensor – Coolant Temperature	**CCS42**	1	
Sensor – Crankshaft	**CSCA23**	1	
Sensor – Exhaust Oxygen	**COS883**	1	Direct Fit 4 Wire: Engine Pipe
Sensor – Exhaust Oxygen	**COS884**	1	Direct Fit 4 Wire: Before Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Engine Pipe and Before Catalyst
Sensor – Knock Control	**CKS114**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Barina TK **12/05-on 4 Cyl 1.6L F16D3 DOHC 16V MPFi FWD**			
Sensor – Air Temperature – Inlet	**CAT023**	1	
Sensor – Coolant Temperature	**CCS31**	1	Coolant Sensor and Gauge Sender
Sensor – Crankshaft	**CSCA178**	1	
Sensor – Exhaust Oxygen	**COS873**	1	Direct Fit 4 Wire: Manifold and Engine Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Manifold and Engine Pipe
Sensor – Throttle Position	**CTPS131**	1	

Holden	Part No	Qty	Notes
Calibra YE **10/91-7/95 4 Cyl 2.0L C20NE SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC262**	1	
Ignition – Distributor Cap	**JP821**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**JR817**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA13**	1	
Sensor – Exhaust Oxygen	**COS755**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS100**	1	
Switch – Brake Light	**CSL61**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Radiator Fan	**CFS46**	1	
Calibra YE: YE95 Incl. Turbo **10/91-7/98 4 Cyl 2.0L C20XE: C20LET DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC262**	1	
Ignition – Coil – Standard	**CC271**	1	Bosch: From Vin P1000001 or P9000001
Ignition – Distributor Cap	**JP821**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR127**	1	Bosch Electronic Distributor
Sensor – Air Flow / MAF	**CAF014**	1	From Engine 14002935
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA13**	1	
Sensor – Exhaust Oxygen	**COS755**	1	Direct Fit 3 Wire: C20XE Engine
Sensor – Exhaust Oxygen	**COS898**	1	Direct Fit 3 Wire: C20LET Engine
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS108**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS146**	1	To Vin N1999999 or N9999999
Sensor – Throttle Position	**CTPS100**	1	From Vin P1000001 & P9000001
Switch – Brake Light	**CSL58**	1	3 Terminal
Switch – Brake Light	**CSL61**	1	2 Terminal
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Radiator Fan	**CFS93**	1	C20XE Engine
Switch – Radiator Fan	**CFS46**	1	C20LET Engine
Calibra YE95 **8/95-7/98 4 Cyl 2.0L X20XEV DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC271**	1	
Sensor – Air Flow / MAF	**CAF004**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA21**	1	From Vin 14142430 & T9004512
Sensor – Oil Pressure Gauge	**CPS54**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS100**	1	
Switch – Brake Light	**CSL61**	1	
Switch – Radiator Fan	**CFS93**	1	
Valve – Idle Speed Control	**CIA018**	1	

Holden	Part No	Qty	Notes
Calibra YE95			
8/95-7/98 V6 Cyl 2.5L C25XE DOHC 24V MotroniCarb. FWD			
Sensor – Air Flow / MAF	**CAF014**	1	
Sensor – Camshaft	**CSCA179**	1	To Vin S1035178
Sensor – Camshaft	**CSCA114**	1	From Vin S1035179
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS755**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Oil Pressure Gauge	**CPS54**	1	
Sensor – Temperature Gauge	**CTS134**	1	
Switch – Brake Light	**CSL61**	1	
Switch – Radiator Fan	**CFS94**	1	
Camira JB: JD			
8/82-2/86 4 Cyl 1.6L 16JH SOHC 8V Carb. FWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH86**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH107**	1	Bosch Electronic Distributor
Ignition – Module	**CM409**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS127**	1	
Switch – Oil Pressure Warning Light	**CPS21**	1	
Switch – Radiator Fan	**CFS10**	1	
Switch – Reverse Light	**CRS100**	1	4 Speed Transmission
Camira JD			
11/84-1/86 4 Cyl 1.8L 18JU SOHC 8V MPFi FWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH86**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH107**	1	Bosch Electronic Distributor
Ignition – Module	**CM472**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS127**	1	
Camira JD: JE			
2/86-8/89 4 Cyl 1.8L 18JC: 2.0L 20JD SOHC 8V SPFI FWD			
Ignition – Coil – Standard	**CC207**	1	
Ignition – Distributor Cap	**DR114**	1	Delco Electronic Distributor
Ignition – Distributor Rotor	**DR73**	1	Delco Electronic Distributor
Ignition – Module	**CM415**	1	Delco Electronic Distributor
Ignition – Pickup / Trigger	**CIT100**	1	Delco Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT009**	1	20JD Engine
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS127**	1	
Sensor – Throttle Position	**CTPS131**	1	20JD Engine
Switch – Oil Pressure Warning Light	**CPS21**	1	
Switch – Radiator Fan	**CFS10**	1	
Switch – Reverse Light	**CRS100**	1	4 Speed Transmission
Caprice VQ: VQ Series II			
3/90-2/94 V8 Cyl 5.0L VU OHV 16V MPFi RWD			
Ignition – Coil – Standard	**CC200**	1	Oil Filled
Ignition – Distributor Cap	**BH84**	1	
Ignition – Distributor Rotor	**BH231**	1	
Sensor – Temperature Gauge	**CTS127**	1	

Holden	Part No	Qty	Notes
Caprice WH: WH Series II: WK: WL			
6/99-1/06 V8 Cyl 5.7L GEN III OHV 16V MPFi RWD			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA45**	1	
Sensor – Exhaust Oxygen	**COS744**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS124**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Caprice WL: WM			
8/04-on V6 Cyl 3.6L Alloytec 190 DOHC 24V MPFi RWD			
Sensor – Camshaft	**CSCA113**	4	
Sensor – Coolant Temperature	**CCS41**	1	
Sensor – Crankshaft	**CSCA131**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear
Caprice WL: WM			
2/06-on V8 Cyl 6.0L L76 OHV 16V MPFi RWD			
Sensor – Camshaft	**CSCA112**	1	
Sensor – Crankshaft	**CSCA45**	1	
Sensor – MAP	**CMS210**	1	
Combo SB			
3/96-7/97 4 Cyl 1.4L C14NZ SOHC 8V SPFI FWD			
Ignition – Coil – Standard	**CC279**	1	
Ignition – Distributor Cap	**BD123**	1	Bosch Electronic Distributor
Ignition – Distributor Cap	**JP820**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**DR127**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**JR807**	1	Lucas Electronic Distributor
Ignition – Module	**CM427**	1	
Sensor – Air Temperature – Ambient	**CAT019**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS134**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Radiator Fan	**CFS49**	1	Oval Shaped Connector
Switch – Radiator Fan	**CFS78**	1	Round Shaped Connector
Combo SB			
8/97-9/02 4 Cyl 1.4L C14SE SOHC 8V MPFi FWD			
Sensor – Air Temperature – Inlet	**CAT020**	1	
Sensor – Crankshaft	**CSCA16**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS134**	1	
Sensor – Throttle Position	**CTPS131**	1	
Valve – Idle Speed Control	**CIA017**	1	

Holden	Part No	Qty	Notes
Combo XC **9/02-4/05 4 Cyl 1.6L Z16SE SOHC 8V MPFi FWD**			
Sensor – Air Temperature – Inlet	**CAT020**	1	
Sensor – Crankshaft	**CSCA24**	1	
Sensor – Exhaust Oxygen	**COS901**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Oil Pressure Warning Light	**CPS48**	1	
Combo XC **5/05-on 4 Cyl 1.4L Z14XE DOHC16V MPFi FWD**			
Sensor – Air Temperature – Inlet	**CAT020**	1	
Sensor – Camshaft	**CSCA158**	1	
Sensor – Crankshaft	**CSCA176**	1	
Sensor – Exhaust Oxygen	**COS883**	3	Direct Fit 4 Wire: Manifold, Eng Pipe and After Catalyst: To Vin 53999999
Sensor – Exhaust Oxygen – Universal	**COS724**	3	Universal 4 Wire: Manifold, Engine Pipe and After Catalyst: To Vin 53999999
Switch – Oil Pressure Warning Light	**CPS48**	1	
Commodore VB **11/78-2/80 6 Cyl 2.8L VD: 3.3L VL OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH79**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS127**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS30**	1	
Switch – Reverse Light	**CRS100**	1	4 Speed Transmission
Commodore VB **11/78-2/80 V8 Cyl 4.2L VR: 5.0L VT OHV 16V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH84**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH87**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS127**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS30**	1	
Switch – Reverse Light	**CRS100**	1	4 Speed Transmission
Commodore VC: VH **3/80-2/84 4 Cyl 1.9L VN OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH90**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS30**	1	
Switch – Reverse Light	**CRS100**	1	4 Speed Transmission

Holden	Part No	Qty	Notes
Commodore VC: VH: VK Incl. EST **3/80-2/86 6 Cyl 2.8L VD: 3.3L VL OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH116**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH105**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH222**	1	Bosch Electronic Dist.: 3.3L EST: From 3/1984
Ignition – Module	**CM418**	1	Bosch Electronic Dist.: Excl 3.3L EST: To 2/1984
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Dist.: Excl 3.3L EST: To 2/1984
Sensor – Coolant Temperature	**CCS26**	1	3.3L EST: From 3/1984
Sensor – Temperature Gauge	**CTS125**	1	To 9/1981
Sensor – Temperature Gauge	**CTS152**	1	Without Air Pump: From 10/1981
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS30**	1	
Switch – Reverse Light	**CRS100**	1	4 Speed Transmission
Commodore VC: VH: VK Incl. SS **3/80-2/86 V8 Cyl 4.2L VR: 5.0L VT OHV 16V Carb. RWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH112**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH103**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS127**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS30**	1	
Switch – Reverse Light	**CRS100**	1	4 Speed Transmission
Commodore VK **3/84-2/86 6 Cyl 3.3L VK OHV 12V EFi RWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH116**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH105**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS30**	1	
Switch – Reverse Light	**CRS100**	1	4 Speed Transmission
Commodore VL Incl. Turbo **3/86-8/88 6 Cyl 3.0L RB30E: RB30ET SOHC 12V EFi RWD**			
Ignition – Coil – Standard	**CC221**	1	
Ignition – Distributor Cap	**JP694**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR621**	1	Hitachi Electronic Distributor
Ignition – Module	**CM474**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Crankshaft	**CSCA01**	1	Hitachi Distributor
Sensor – Crankshaft	**CSCA01B**	1	Hitachi Distributor: Kit supplied with bearing
Sensor – Exhaust Oxygen	**COS737**	1	Direct Fit 3 Wire: Titania
Sensor – Temperature Gauge	**CTS130**	1	
Sensor – Throttle Position	**CTPS129**	1	Auto Transmission
Sensor – Throttle Position	**CTPS103**	1	Manual Transmission
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS28**	1	

Holden	Part No	Qty	Notes
Commodore VL **10/86-8/88 V8 Cyl 5.0L VJ OHV 16V Carb. RWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH112**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH103**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS152**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS30**	1	
Switch – Reverse Light	**CRS100**	1	4 Speed Transmission
Commodore VL *(NZ Market)* **1987-90 6 Cyl 2.0L RB20E SOHC 12V**			
Ignition – Coil – Standard	**CC223**	1	
Ignition – Distributor Cap	**JP694**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**BD136**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR621**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR137**	1	Mitsubishi Electronic Distributor
Commodore VN Series I: VG **8/88-10/90 V6 Cyl 3.8L VH OHV 12V EFi RWD**			
Ignition – Coil – Standard	**CC206**	1	
Ignition – Coil & Module Kit	**CCMLK**	1	With Ignition Leads
Ignition – Coil & Module Kit	**CCMK**	1	Without Ignition Leads
Ignition – Module	**CM407**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA03**	1	Sensor only
Sensor – Crankshaft	**CSCA02**	1	Complete Assembly
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
Commodore VN: VG: VP **3/89-7/93 V8 Cyl 5.0L VU OHV 16V EFi RWD**			
Ignition – Coil – Standard	**CC200**	1	Oil Filled
Ignition – Distributor Cap	**BH84**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Knock Control	**CKS103**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	

Holden	Part No	Qty	Notes
Commodore VN Series II: VG: VP **11/90-7/93 V6 Cyl 3.8L VH OHV 12V EFi RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Coil & Module Kit	**CCMLK**	1	With Ignition Leads
Ignition – Coil & Module Kit	**CCMK**	1	Without Ignition Leads
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Exhaust Oxygen	**COS734**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Knock Control	**CKS103**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
Commodore VR: VR Series II **7/93-4/95 V6 Cyl 3.8L VH OHV 12V EFi RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Coil & Module Kit	**CCMLK**	1	With Ignition Leads
Ignition – Coil & Module Kit	**CCMK**	1	Without Ignition Leads
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Camshaft	**CSCA81**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS103**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
Commodore VR: VR Series II **7/93-4/95 V8 Cyl 5.0L VU OHV 16V EFi RWD**			
Ignition – Coil – Standard	**CC200**	1	Oil Filled
Ignition – Distributor Cap	**BH84**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS750**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Knock Control	**CKS103**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	

Holden	Part No	Qty	Notes
Commodore VS: VS Series II: VS Series III **4/95-12/00 V6 Cyl 3.8L VH OHV 12V EFi RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT002**	1	
Sensor – Camshaft	**CSCA81**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Exhaust Oxygen	**COS750**	1	Direct Fit 2 Wire: To 5/1995
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire: From 5/1995
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire: To 5/1995
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: From 5/1995
Sensor – Knock Control	**CKS101**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
Commodore VS: VS Series II: VS Series III **4/95-12/00 V8 Cyl 5.0L VU OHV 16V EFi RWD**			
Ignition – Distributor Cap	**BH84**	1	
Ignition – Distributor Rotor	**BH231**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS750**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
Commodore VT: VT Series II **9/97-6/99 V6 Cyl 3.8L VH OHV 12V SMPFI RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT002**	1	
Sensor – Camshaft	**CSCA81**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Exhaust Oxygen	**COS734**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	

Holden	Part No	Qty	Notes
Commodore VT: VT Series II S S/charged **9/97-9/00 V6 Cyl 3.8L VS-L67 OHV 12V PFI RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT002**	1	
Sensor – Camshaft	**CSCA81**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
Commodore VT: Incl. SS **9/97-6/99 V8 Cyl 5.0L VM OHV 16V SMPFI RWD**			
Sensor – Air Temperature – Inlet	**CAT002**	1	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Commodore VX: VX Series II **10/00-9/02 V6 Cyl 3.8L VH OHV 12V SMPFI RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT002**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Exhaust Oxygen	**COS734**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Commodore VX: VX Series II S/charged **10/00-9/02 V6 Cyl 3.8L L67 OHV 12V SMPFI RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT002**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	

Holden	Part No	Qty	Notes
Commodore VX: VX Series II **10/00-9/02 V8 Cyl 5.7L GEN III OHV 12V SMPFI RWD**			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA45**	1	
Sensor – Exhaust Oxygen	**COS744**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS124**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Commodore VU: VU Series II Utility **12/00-9/02 V6 Cyl 3.8L VH OHV 12V SMPFI RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT002**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Knock Control	**CKS101**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Commodore VU: VU Series II Utility: Incl. SS **12/00-9/02 V8 Cyl 5.7L GEN III OHV 16V MPFi RWD**			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA45**	1	
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS124**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Commodore VY: VY Series II **9/02-7/04 V6 Cyl 3.8L VH OHV 12V SMPFI RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT002**	1	
Sensor – Camshaft	**CSCA81**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Exhaust Oxygen	**COS734**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Commodore VY: VY Series II Incl. SS: SV8 **9/02-7/04 V8 Cyl 5.7L GEN III OHV 16V SMPFI RWD**			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS124**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	

Holden	Part No	Qty	Notes
Commodore VY: VY Series II S/charged **10/02-7/04 V6 Cyl 3.8L L67 OHV 12V SMPFI RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT002**	1	
Sensor – Camshaft	**CSCA81**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Commodore VY Series II SS **8/03-7/04 V8 Cyl 5.7L GEN III OHV 16V MPFi RWD**			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS124**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Commodore VZ Incl. S: SV6: SVZ **8/04-7/06 V6 Cyl 3.6L Alloytec DOHC 24V ESPFI RWD**			
Sensor – Camshaft	**CSCA113**	2	
Sensor – Coolant Temperature	**CCS41**	1	
Sensor – Crankshaft	**CSCA131**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear
Commodore VZ Incl. SS: SSZ: SV8 **8/04-8/07 V8 Cyl 5.7L GEN III OHV 16V MPFi RWD**			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA45**	1	
Sensor – MAP	**CMS210**	1	
Commodore VZ SS: SV8 **2/06-7/06 V8 Cyl 6.0L GEN IV / L76 OHV 16V MPFi RWD**			
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA45**	1	LS2 Engine
Sensor – MAP	**CMS210**	1	
Commodore VE Incl. Dual Fuel & SV6 **8/06-on V6 Cyl 3.6L Alloytec DOHC 24V MPFi RWD**			
Sensor – Camshaft	**CSCA113**	4	
Sensor – Coolant Temperature	**CCS41**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: After Catalyst
Commodore VE: SS & SSV **8/06-on V8 Cyl 6.0L GEN IV / L98 OHV 16V MPFi RWD**			
Sensor – Exhaust Oxygen	**COS873**	1	Direct Fit 4 Wire: LH Side
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: LH & RH Side
Sensor – MAP	**CMS210**	1	

Holden	Part No	Qty	Notes
Crewman VY Series II Incl. S **9/03-7/04 V6 Cyl 3.8L VH OHV 12V MPFi RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT002**	1	
Sensor – Camshaft	**CSCA81**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Crewman VY Series II Cross 8: SS: SSZ **9/03-10/04 V8 Cyl 5.7L GEN III OHV 16V MPFi RWD**			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS124**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Crewman VZ Cross 8: SS: SSZ **8/04-1/06 V8 Cyl 5.7L GEN III OHV 16V MPFi RWD**			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA45**	1	
Sensor – MAP	**CMS210**	1	
Crewman VZ Cross 6 **4/05-7/06 V6 Cyl 3.6L Alloytec DOHC 24V MPFi 4WD**			
Sensor – Camshaft	**CSCA113**	2	
Sensor – Coolant Temperature	**CCS41**	1	
Sensor – Crankshaft	**CSCA131**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear
Drover QB **3/85-12/87 4 Cyl 1.3L G13A SOHC 8V Carb. 4WD**			
Ignition – Coil – Standard	**CC283**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR645**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS23**	1	
Sensor – Temperature Gauge	**CTS142**	1	
Switch – Brake Light	**CSL31**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Epica EP **3/07-6/08 4 Cyl 2.0L X20D1 DOHC 24V MPFi FWD**			
Sensor – Coolant Temperature	**CCS51**	1	
Sensor – Knock Control	**CKS113**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Epica EP **3/07-6/08 6 Cyl 2.5L X25D1 DOHC 24V MPFi FWD**			
Sensor – Coolant Temperature	**CCS51**	1	
Sensor – Knock Control	**CKS113**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	

Holden	Part No	Qty	Notes
Frontera M7 **10/95-3/99 4 Cyl 2.0L X20SE SOHC 8V PFI 4WD**			
Ignition – Coil – Standard	**CC271**	1	
Sensor – Air Flow / MAF	**CAF024**	1	
Sensor – Air Temperature – Inlet	**CAT021**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA13**	1	
Sensor – Exhaust Oxygen	**COS918**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS107**	1	
Sensor – Oil Pressure Gauge	**CPS54**	1	
Sensor – Temperature Gauge	**CTS134**	1	
Switch – Brake Light	**CSL55**	1	
Switch – Radiator Fan	**CFS77**	1	
Frontera MX **2/99-7/02 4 Cyl 2.2L X22SE DOHC 16V MPFi 4WD**			
Ignition – Coil and Igniter	**CC348**	1	
Sensor – Camshaft	**CSCA84**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Exhaust Oxygen	**COS918**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS127**	1	
Switch – Brake Light	**CSL54**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Frontera MX **2/99-1/04 V6 Cyl 3.2L 6VD1-W DOHC 24V MPFi 4WD**			
Sensor – Camshaft	**CSCA117**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Crankshaft	**CSCA48**	1	To 8/2001
Sensor – Crankshaft	**CSCA132**	1	From 9/2001
Sensor – Exhaust Oxygen	**COS744**	2	Direct Fit 4 Wire: To 12/2000
Sensor – Exhaust Oxygen	**COS873**	2	Direct Fit 4 Wire: From 1/2001 To 8/2001
Sensor – Exhaust Oxygen	**COS855**	2	Direct Fit 4 Wire: From 9/2001
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL54**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Gemini TX: TC: TD: TE: TF: TG **3/75-5/85 4 Cyl 1.6L G161Z SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S214V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS139**	1	
Switch – Brake Light	**CSL30**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Holden	Part No	Qty	Notes
Gemini RB: RB2			
5/85-6/87 4 Cyl 1.5L 4XC1 SOHC 8V Carb. FWD			
Ignition – Distributor Cap	**JP574**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Ignition – Module	**CM477**	1	
Ignition – Pickup / Trigger	**CIT139**	1	
Sensor – Temperature Gauge	**CTS138**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS38**	1	
Holden FX (48: 50 Series)			
1948-53 6 Cyl 133ci Grey OHV Carb. RWD			
Ignition – Distributor Cap	**DR86**	1	Delco Points Distributor
Ignition – Distributor Condenser	**UC11E**	1	Delco Points Distributor
Ignition – Distributor Points / Contact Set	**S778A**	1	Delco Points Distributor
Ignition – Distributor Rotor	**RE85**	1	Delco Points Distributor
Switch – Coolant Temperature Warning Light	**CTS124**	1	
Switch – Oil Pressure Warning Light	**CPS36**	1	
Holden FJ: FE: FC: FB: EK: EJ			
1953-8/63 6 Cyl 133ci: 138ci Grey OHV Carb. RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S4V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
Switch – Coolant Temperature Warning Light	**CTS124**	1	
Switch – Oil Pressure Warning Light	**CPS33**	1	
Holden EH: HD			
8/63-4/66 6 Cyl 149ci: 179ci Red OHV 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH80**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC63**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**S4V**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BH79**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS123**	1	
Switch – Coolant Temperature Warning Light	**CTS124**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Holden HR: HK			
5/66-4/69 6 Cyl 161ci: 186ci Red OHV 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH80**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC63**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S4V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH79**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS123**	1	
Switch – Coolant Temperature Warning Light	**CTS124**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	

Holden	Part No	Qty	Notes
Holden HK: HT: HG			
3/68-6/71 V8 Cyl 307ci: 350ci Chevrolet OHV 16V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**DR102**	1	Delco Points Distributor
Ignition – Distributor Condenser	**DC10**	1	Delco Points Distributor
Ignition – Distributor Points / Contact Set	**S143V**	1	Delco Points Distributor
Ignition – Distributor Rotor	**DR65**	1	Delco Points Distributor: Standard Rotor
Ignition – Distributor Rotor	**DR1670**	1	Delco Points Distributor: Performance Rotor
Sensor – Temperature Gauge	**CTS123**	1	
Switch – Oil Pressure Warning Light	**CPS32**	1	
Holden HT: HG			
5/69-6/71 6 Cyl 161ci: 186ci Red OHV 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH79**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS123**	1	
Switch – Coolant Temperature Warning Light	**CTS124**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Holden HT: HG			
5/69-6/71 V8 Cyl 253ci: 308ci Holden OHV 16V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH84**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH87**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS123**	1	
Switch – Coolant Temperature Warning Light	**CTS124**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Holden HQ: HJ			
7/71-6/76 6 Cyl 173ci: 202ci OHV 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BH79**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS125**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	

Holden	Part No	Qty	Notes
Holden HQ: HJ **7/71-6/76 V8 Cyl 253ci: 308ci OHV 16V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH84**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH87**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS125**	1	
Switch – Brake Light	**CSL20**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Holden HQ **7/71-9/74 V8 Cyl 350ci OHV 16V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**DR102**	1	Delco Points Distributor
Ignition – Distributor Condenser	**DC10**	1	Delco Points Distributor
Ignition – Distributor Points / Contact Set	**S143V**	1	Delco Points Distributor
Ignition – Distributor Rotor	**DR65**	1	Delco Points Distributor: Standard Rotor
Ignition – Distributor Rotor	**DR1670**	1	Delco Points Distributor: Performance Rotor
Sensor – Temperature Gauge	**CTS123**	1	
Switch – Oil Pressure Warning Light	**CPS32**	1	
Holden HX: HZ **7/76-3/80 6 Cyl 3.3L OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH79**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS125**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Holden HX: HZ **7/76-3/80 V8 Cyl 4.2L: 5.0L OHV 16V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH84**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH87**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS125**	1	
Switch – Brake Light	**CSL20**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Holden WB **4/80-12/85 6 Cyl 3.3L SOHC 12V Carb. RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH116**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH105**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS125**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	

Holden	Part No	Qty	Notes
Holden WB **4/80-12/85 V8 Cyl 4.2L: 5.0L OHV 16V Carb. RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH112**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH103**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS125**	1	
Switch – Brake Light	**CSL20**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Jackaroo UBS13 **11/81-7/85 4 Cyl 2.0L G200Z SOHC 8V Carb. 4WD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S214V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS139**	1	
Switch – Brake Light	**CSL30**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Jackaroo UBS52 Diesel **11/81-12/83 4 Cyl 2.2L C223 OHV 8V Di 4WD**			
Sensor – Temperature Gauge	**CTS139**	1	
Jackaroo UBS52 Turbo Diesel **7/84-12/88 4 Cyl 2.2L C223T OHV 8V Di 4WD**			
Sensor – Temperature Gauge	**CTS139**	1	
Switch – Brake Light	**CSL54**	1	With Cruise Control
Switch – Brake Light	**CSL43**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS23**	1	
Jackaroo UBS16 **8/85-12/88 4 Cyl 2.3L 4ZD1 SOHC 8V Carb. 4WD**			
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL54**	1	With Cruise Control
Switch – Brake Light	**CSL43**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS23**	1	
Jackaroo UBS17 **7/88-3/92 4 Cyl 2.6L 4ZE1 SOHC 8V EFi 4WD**			
Ignition – Coil – Standard	**CC319**	1	
Ignition – Distributor Cap	**JP734**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR651**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA01**	1	
Sensor – Crankshaft	**CSCA01B**	1	Kit supplied with bearing
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS107**	1	Auto Transmission
Sensor – Throttle Position	**CTPS105**	1	Manual Transmission
Switch – Brake Light	**CSL54**	1	With Cruise Control
Switch – Brake Light	**CSL43**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS47**	1	

Holden	Part No	Qty	Notes
Jackaroo UBS55 Turbo Diesel **7/88-3/92 4 Cyl 2.8L 4JB1T OHV Di 4WD**			
Sensor – Temperature Gauge	**CTS139**	1	
Switch – Brake Light	**CSL54**	1	With Cruise Control
Switch – Brake Light	**CSL43**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS23**	1	
Jackaroo UBS69 Turbo Diesel **4/92-2/98 4 Cyl 3.1L 4JG2 OHV Di 4WD**			
Sensor – Temperature Gauge	**CTS139**	1	
Switch – Brake Light	**CSL54**	1	With Cruise Control
Switch – Brake Light	**CSL43**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS23**	1	
Jackaroo UBS25 **4/92-2/98 V6 Cyl 3.2L 6VD1-V SOHC 24V EFi 4WD**			
Ignition – Coil – Standard	**CC208**	3	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Exhaust Oxygen	**COS784**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL54**	1	With Cruise Control
Switch – Brake Light	**CSL43**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS22**	1	
Jackaroo U8 **2/98-9/04 V6 Cyl 3.5L 6VE1 DOHC 24V MPFi 4WD**			
Sensor – Camshaft	**CSCA117**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Crankshaft	**CSCA48**	1	
Sensor – MAP	**CMS210**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Jackaroo U8 Turbo Diesel **3/98-9/04 4 Cyl 3.0L 4JX1 DOHC 16V Di 4WD**			
Sensor – MAP	**CMS207**	1	
Sensor – Temperature Gauge	**CTS139**	1	
Monaro HK GTS **3/68-4/69 V8 Cyl 327ci Chevrolet OHV 16V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**DR102**	1	Delco Points Distributor
Ignition – Distributor Condenser	**DC10**	1	Delco Points Distributor
Ignition – Distributor Points / Contact Set	**S143V**	1	Delco Points Distributor
Ignition – Distributor Rotor	**DR65**	1	Delco Points Distributor: Standard Rotor
Ignition – Distributor Rotor	**DR1670**	1	Delco Points Distributor: Performance Rotor
Sensor – Temperature Gauge	**CTS123**	1	
Switch – Oil Pressure Warning Light	**CPS32**	1	

Holden	Part No	Qty	Notes
Monaro V2: V2 Series II CV6 S/charged			
12/01-8/03 V6 Cyl 3.8L VS OHV 12V ESPFI RWD			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – Throttle Position	**CTPS131**	1	
Monaro V2: V2 Series II: V2 Series III: VZ CV8			
12/01-7/06 V8 Cyl 5.7L GENIII OHV ESPFI RWD			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA45**	1	
Sensor – Exhaust Oxygen	**COS744**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS124**	1	
Nova LE			
8/89-8/91 4 Cyl 1.4L 6AFC: 1.6L 4AFC DOHC 16V Carb. FWD			
Ignition – Coil – Standard	**CC216**	1	Denso Electronic Distributor: To 2/1990
Ignition – Coil – Standard	**CC215**	1	Bosch Electronic Distributor: From 3/1990
Ignition – Distributor Cap	**DR895**	1	Denso Electronic Distributor: To 2/1990
Ignition – Distributor Cap	**BH178**	1	Bosch Electronic Distributor: From 3/1990
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor: To 2/1990
Ignition – Distributor Rotor	**BH121**	1	Bosch Electronic Distributor: From 3/1990
Ignition – Module	**CM418**	1	Bosch Electronic Distributor: From 3/1990
Ignition – Pickup / Trigger	**CIT103**	1	Denso Electronic Distributor: To 2/1990
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS32**	1	
Nova LF			
9/91-10/94 4 Cyl 1.4L 6AFC: 1.6L 4AFC DOHC 16V Carb. FWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH178**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH121**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS154**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS24**	1	
Nova LF			
9/91-10/94 4 Cyl 1.6L 4AFE DOHC 16V EFi FWD			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Distributor Cap and Leads	**JP801**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS778**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS154**	1	
Sensor – Throttle Position	**CTPS102**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS24**	1	

Holden	Part No	Qty	Notes
Nova LF **10/92-10/94 4 Cyl 1.8L 7AFE DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC216**	1	
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS778**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS154**	1	
Sensor – Throttle Position	**CTPS111**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
Switch – Radiator Fan	**CFS63**	1	
Nova LG **10/94-4/97 4 Cyl 1.6L 4AFE: 1.8L 7AFE DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC216**	1	
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS775**	1	Direct Fit 2 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS725**	1	Universal 2 Wire With Flange
Sensor – Temperature Gauge	**CTS154**	1	
Sensor – Throttle Position	**CTPS111**	1	
Switch – Brake Light	**CSL59**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
Switch – Radiator Fan	**CFS63**	1	
Piazza YB Turbo **4/86-11/87 4 Cyl 2.0L 4ZC1T SOHC 8V EFi RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL54**	1	
Switch – Oil Pressure Warning Light	**CPS46**	1	
Switch – Radiator Fan	**CFS66**	1	
Rodeo KB25: KB40 **1/78-12/80 4 Cyl 1.6L G161Z SOHC 8V Carb. RWD & 4WD**			
Sensor – Temperature Gauge	**CTS139**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Rodeo KB26: KB41 **1/81-12/82 4 Cyl 1.6L G161Z SOHC 8V Carb. RWD & 4WD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S214V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS139**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Holden	Part No	Qty	Notes
Rodeo KB27: KB42 **1/83-12/83 4 Cyl 1.8L G180Z SOHC 8V Carb. RWD & 4WD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S214V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Rodeo KBD27: KBD42 Diesel **1/83-12/83 4 Cyl 2.2L C223 OHV 8V Di RWD & 4WD**			
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Rodeo KB28: KB43 **1/84-3/87 4 Cyl 1.9L G200Z SOHC 8V Carb. RWD & 4WD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor: From 1985
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor: From 1985
Ignition – Distributor Points / Contact Set	**S214V**	1	Denso Points Distributor: From 1985
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: From 1985
Sensor – Temperature Gauge	**CTS139**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Rodeo KBD28: KBD43 Diesel **1/84-6/88 4 Cyl 2.2L C223 OHV 8V Di RWD & 4WD**			
Sensor – Temperature Gauge	**CTS125**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Rodeo KBD47 Diesel **7/85-6/88 4 Cyl 2.2L C223 OHV 8V Di 4WD**			
Sensor – Temperature Gauge	**CTS139**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Rodeo KB29: KB49 **4/87-6/88 4 Cyl 2.3L 4ZD1 SOHC 8V Carb. RWD & 4WD**			
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Ignition – Module	**CM478**	1	From 1988
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Rodeo TFR54: TFS54 Diesel **6/88-12/92 4 Cyl 2.5L 4JA1 SOHC 8V Di RWD & 4WD**			
Sensor – Temperature Gauge	**CTS139**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Holden	Part No	Qty	Notes
Rodeo TFR17: TFS17 **7/88-4/90 4 Cyl 2.6L 4ZE1 SOHC 8V EFi RWD & 4WD**			
Ignition – Coil – Standard	**CC319**	1	
Ignition – Distributor Cap	**BD124**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR651**	1	Denso Electronic Distributor
Sensor – Crankshaft	**CSCA01**	1	
Sensor – Crankshaft	**CSCA01B**	1	Kit supplied with bearing
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS107**	1	Auto Transmission
Sensor – Throttle Position	**CTPS105**	1	Manual
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS46**	1	
Rodeo TFR16 **5/90-3/93 4 Cyl 2.3L 4ZD1 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC285**	1	To 10/1992
Ignition – Distributor Cap	**BD109**	1	
Ignition – Distributor Rotor	**JR645**	1	
Ignition – Module	**CM478**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Rodeo TFS55: Turbo Diesel **5/90-12/01 4 Cyl 2.8L 4JB1T OHV 8V Di 4WD**			
Sensor – Temperature Gauge	**CTS139**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Rodeo TFR17: TFS17 **5/90-5/98 4 Cyl 2.6L 4ZE1 SOHC 8V EFi RWD & 4WD**			
Ignition – Coil – Standard	**CC319**	1	
Ignition – Distributor Cap	**BD124**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR651**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA01**	1	
Sensor – Crankshaft	**CSCA01B**	1	Kit supplied with bearing
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS106**	1	
Switch – Brake Light	**CSL43**	1	
Rodeo TFR25 **2/98-2/03 V6 Cyl 3.2L 6VD1-W DOHC 24V MPF RWD**			
Sensor – Camshaft	**CSCA117**	1	
Sensor – Crankshaft	**CSCA48**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS139**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Rodeo TFR30 **6/98-2/03 4 Cyl 2.2L C22NE SOHC 8V MPFi RWD**			
Sensor – Crankshaft	**CSCA25**	1	
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS131**	1	
Rodeo TFS55 Turbo Diesel **8/99-2/03 4 Cyl 2.8L 4JB1T OHV 8V Di 4WD**			
Sensor – Temperature Gauge	**CTS139**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Holden	Part No	Qty	Notes
Rodeo TFR77: TFS77 Turbo Diesel **1/02-2/03 4 Cyl 3.0L 4JH1TC OHV 8V Di RWD & 4WD**			
Sensor – Crankshaft	**CSCA194**	1	Top Dead Centre
Sensor – Temperature Gauge	**CTS139**	1	
Rodeo TFR32: TFS32 **3/03-1/07 4 Cyl 2.4L Y24SE SOHC 8V EFi RWD & 4WD**			
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS210**	1	
Rodeo TFR85: TFS85 Turbo Diesel **3/03-1/07 4 Cyl 3.0L 4JH1TC OHV 8V Di RWD & 4WD**			
Sensor – Crankshaft	**CSCA194**	1	Top Dead Centre
Sensor – Temperature Gauge	**CTS139**	1	Denso
Switch – Oil Pressure Warning Light	**CPS48**	1	
Rodeo TFR26: TFS26 **3/03-11/05 V6 Cyl 3.5L 6VE1 DOHC 24V EFi RWD**			
Sensor – Camshaft	**CSCA117**	1	
Sensor – Crankshaft	**CSCA132**	1	
Sensor – Exhaust Oxygen	**COS855**	1	Direct Fit
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Rodeo TFR27 **12/05-on V6 Cyl 3.6L HFV6 Euro 3 DOHC 24V EFi RWD**			
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Engine Pipe
Rodeo TFR32: TFS32 **1/07-on 4 Cyl 2.4L Y24SE SOHC 8V EFi RWD & 4WD**			
Sensor – Air Temperature – Inlet	**CAT006**	1	
Scurry NB **7/85-12/87 4 Cyl 970cc F10A SOHC 8V Carb. RWD**			
Ignition – Distributor Cap	**JP642**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS142**	1	
Switch – Brake Light	**CSL31**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Shuttle WFR **3/82-3/87 4 Cyl 1.8L 4ZB1 Carb RWD**			
Ignition – Coil – Standard	**CC285**	1	
Ignition – Distributor Rotor	**JR577**	1	Denso Elect Dist
Shuttle WFR **4/87-12/91 4 Cyl 2.0L 4ZC1 Carb. RWD**			
Ignition – Coil – Standard	**CC285**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor: To 1990
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor: To 1990
Sensor – Coolant Temperature	**CCS25**	1	
Sensor – Temperature Gauge	**CTS139**	1	
Switch – Brake Light	**CSL30**	1	
Switch – Oil Pressure Warning Light	**CPS46**	1	

Holden	Part No	Qty	Notes
Statesman WB **5/80-7/85 V8 Cyl 5.0L WT OHV 16V Carb. RWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH112**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH103**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Distributor
Sensor – Temperature Gauge	**CTS125**	1	
Statesman VQ: VQ Series II **3/90-10/91 V8 Cyl 5.0L VU OHV 16V EFi RWD**			
Ignition – Coil – Standard	**CC200**	1	Oil Filled
Ignition – Distributor Cap	**BH84**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire: Series I
Sensor – Exhaust Oxygen	**COS750**	1	Direct Fit 2 Wire: Series II
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: Series I
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire: Series II
Sensor – Knock Control	**CKS103**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS127**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
Statesman VQ Series II **11/91-2/94 V6 Cyl 3.8L VH OHV 12V EFi RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Coil & Module Kit	**CCMLK**	1	With Ignition Leads
Ignition – Coil & Module Kit	**CCMK**	1	Without Ignition Leads
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Exhaust Oxygen	**COS734**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS127**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
Statesman VR **3/94-4/95 V6 Cyl 3.8L VH OHV 12V EFi RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Coil & Module Kit	**CCMLK**	1	With Ignition Leads
Ignition – Coil & Module Kit	**CCMK**	1	Without Ignition Leads
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Camshaft	**CSCA81**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	

Holden	Part No	Qty	Notes
Statesman VR **3/94-4/95 V8 Cyl 5.0L VU OHV 16V EFi RWD**			
Ignition – Coil – Standard	**CC200**	1	Oil Filled
Ignition – Distributor Cap	**BH84**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH231**	1	Bosch Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS750**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Knock Control	**CKS103**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
Statesman VS: VS Series II **4/95-6/99 V6 Cyl 3.8L VH OHV 12V EFi RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT002**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Exhaust Oxygen	**COS750**	1	Direct Fit 2 Wire: To Vin L823094
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire: From Vin L823095
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire: To Vin L823094
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: From Vin L823095
Sensor – Temperature Gauge	**CTS152**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Statesman VS: VS Series II: VS Series III **4/95-6/99 V8 Cyl 5.0L VU OHV 16V EFi RWD**			
Ignition – Distributor Cap	**BH84**	1	
Ignition – Distributor Rotor	**BH231**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS750**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Statesman VS Series II: VS Series III S/charged **10/96-6/99 V6 Cyl 3.8L L67 OHV 12V EFi RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT002**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Exhaust Oxygen	**COS750**	1	Direct Fit 2 Wire: To Vin L823094
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire: From Vin L823095
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire: To Vin L823094
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: From Vin L823095
Switch – Oil Pressure Warning Light	**CPS38**	1	

Holden	Part No	Qty	Notes
Statesman WH: WH Series II **6/99-4/03 V6 Cyl 3.8L VH OHV 12V MPFi RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Camshaft	**CSCA81**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Exhaust Oxygen	**COS734**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – MAP	**CMS210**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Statesman WH: WH Series II S/charged **6/99-4/03 V6 Cyl 3.8L VS-L67 OHV 12V MPFi RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Exhaust Oxygen	**COS744**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Sensor – Temperature Gauge	**CTS152**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Statesman WH: WH Series II **10/00-4/03 V8 Cyl 5.7L GEN III OHV 16V MPFi RWD**			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA45**	1	
Sensor – Exhaust Oxygen	**COS744**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS124**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Statesman WK **5/03-7/04 V6 Cyl 3.8L VH OHV 12V MPFi RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Camshaft	**CSCA81**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Knock Control	**CKS101**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Statesman WK S/charged **5/03-7/04 V6 Cyl 3.8L VS-L67 OHV 12V MPFi RWD**			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Camshaft	**CSCA81**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Knock Control	**CKS101**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	

Holden	Part No	Qty	Notes
Statesman WK **5/03-7/04 V8 Cyl 5.7L GEN III OHV 16V MPFi RWD**			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA45**	1	
Sensor – Exhaust Oxygen	**COS744**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS124**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Statesman WL: WM **8/04-on V6 Cyl 3.6L Alloytec DOHC 24V ESPFI RWD**			
Sensor – Camshaft	**CSCA113**	4	
Sensor – Crankshaft	**CSCA131**	1	
Sensor – Coolant Temperature	**CCS41**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Statesman WL **8/04-7/06 V8 Cyl 5.7L GEN III OHV 16V MPFi RWD**			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA45**	1	
Sensor – MAP	**CMS210**	1	
Statesman WL: WM **2/06-on V8 Cyl 6.0L L76 OHV 16V MPFi RWD**			
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – MAP	**CMS210**	1	
Suburban 1500 K8 **2/98-1/01 V8 Cyl 5.7L L31 OHV 16V MPFi 4WD**			
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire: Before Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Before and After Catalyst
Sensor – Throttle Position	**CTPS124**	1	
Suburban 2500 K8 Turbo Diesel **2/98-1/01 V8 Cyl 6.5L FCWG OHV 16V Di 4WD**			
Sensor – Throttle Position	**CTPS124**	1	
Sunbird LX: UC **8/77-12/78 4 Cyl 1.9L OPEL OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH86**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH89**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS125**	1	
Switch – Oil Pressure Warning Light	**CPS21**	1	

Holden	Part No	Qty	Notes
Sunbird UC **9/78-12/80 4 Cyl 1.9L Starfire OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH90**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Switch – Oil Pressure Warning Light	**CPS30**	1	
Tigra XC **9/05-9/07 4 Cyl 1.8L Z18XE DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC356**	1	
Sensor – Air Flow / MAF	**CAF005**	1	
Sensor – Camshaft	**CSCA83**	1	
Sensor – Crankshaft	**CSCA23**	1	
Sensor – Exhaust Oxygen	**COS883**	1	Universal 4 Wire: Front Eng Pipe
Sensor – Exhaust Oxygen	**COS884**	1	Direct Fit 4 Wire: In Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front Eng Pipe and Catalyst
Sensor – Knock Control	**CKS114**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Reverse Light	**CRS102**	1	5 Speed Manual
Torana HB: LC **5/67-2/72 4 Cyl 1.2L OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**DR101**	1	Delco Points Distributor
Ignition – Distributor Condenser	**UC11E**	1	Delco Points Distributor
Ignition – Distributor Points / Contact Set	**S52**	1	Denso Points Distributor
Ignition – Distributor Rotor	**RE85**	1	Delco Points Distributor
Sensor – Temperature Gauge	**CTS125**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	
Torana LC: LJ: LH: LX: UC Incl. GTR-XU1 **11/69-12/79 6 Cyl 138ci: 161ci: 173ci: 186ci: 202ci OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH82**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: To 2/1978
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor: To 2/1978
Ignition – Distributor Rotor	**BH79**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor: To 2/1978
Sensor – Temperature Gauge	**CTS123**	1	To LJ: To 3/1974
Sensor – Temperature Gauge	**CTS125**	1	From LH: From 3/1974
Switch – Coolant Temperature Warning Light	**CTS124**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Torana LC **6/71-1/72 4 Cyl 1.6L OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**UC11E**	1	Delco Points Distributor
Ignition – Distributor Points / Contact Set	**S50**	1	Delco Points Distributor
Switch – Coolant Temperature Warning Light	**CTS124**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	

Holden	Part No	Qty	Notes
Torana LJ **2/72-12/73 4 Cyl 1.2L OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Sensor – Temperature Gauge	**CTS125**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	
Torana LJ: TA **2/72-3/75 4 Cyl 1.3L OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**DR101**	1	Delco Points Distributor
Ignition – Distributor Condenser	**UC11E**	1	Delco Points Distributor
Ignition – Distributor Points / Contact Set	**S52**	1	Delco Points Distributor
Ignition – Distributor Rotor	**RE85**	1	Delco Points Distributor
Torana LJ: TA **2/72-3/75 4 Cyl 1.8L SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**UC11E**	1	Delco Points Distributor
Ignition – Distributor Points / Contact Set	**S50**	1	Delco Points Distributor
Switch – Coolant Temperature Warning Light	**CTS124**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	
Torana LH **3/74-2/76 4 Cyl 1.9L OPEL SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Points / Contact Set	**S63**	1	Delco Points Distributor
Sensor – Temperature Gauge	**CTS125**	1	
Switch – Oil Pressure Warning Light	**CPS21**	1	
Torana LH: LX **3/74-2/78 V8 Cyl 253ci: 308ci OHV 16V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH84**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC70**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH87**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS123**	1	
Switch – Coolant Temperature Warning Light	**CTS124**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
Torana LX **3/76-12/76 4 Cyl 1.9L OPEL Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH86**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S63**	1	Delco Points Distributor
Ignition – Distributor Rotor	**BH89**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS125**	1	
Switch – Oil Pressure Warning Light	**CPS21**	1	

Holden	Part No	Qty	Notes
Vectra JR: JS: JS Series II **6/97-11/00 4 Cyl 2.0L C20SE DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC270**	1	
Sensor – Air Flow / MAF	**CAF004**	1	
Sensor – Camshaft	**CSCA82**	1	
Sensor – Coolant Temperature	**CCS48**	1	To Vin V5999999
Sensor – Crankshaft	**CSCA21**	1	
Sensor – Temperature Gauge	**CTS127**	1	
Sensor – Throttle Position	**CTPS100**	1	
Switch – Brake Light	**CSL64**	1	2 Terminal: To Vin XL396308
Switch – Brake Light	**CSL73**	1	4 Terminal: With Cruise Control
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Radiator Fan	**CFS79**	1	
Switch – Reverse Light	**CRS102**	1	
Vectra JR: JS: JS Series II **6/97-11/00 V6 Cyl 2.5L X25XE DOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC360**	1	With Oval Shape Connector
Ignition – Coil – Standard	**CC359**	1	With Rectangle Shape Connector
Sensor – Air Flow / MAF	**CAF014**	1	To Vin V5999999
Sensor – Air Flow / MAF	**CAF022**	1	From Vin W5000001
Sensor – Air Temperature – Inlet	**CAT021**	1	To Vin V5999999
Sensor – Camshaft	**CSCA114**	1	
Sensor – Coolant Temperature	**CCS41**	1	
Sensor – Crankshaft	**CSCA19**	1	
Sensor – Exhaust Oxygen	**COS898**	1	Direct Fit 3 Wire: Front: To Vin V5141892
Sensor – Exhaust Oxygen	**COS755**	1	Direct Fit 3 Wire: Front: From Vin V5141893
Sensor – Exhaust Oxygen	**COS918**	1	Direct Fit 3 Wire: Rear: To Vin V5141892
Sensor – Exhaust Oxygen	**COS755**	1	Direct Fit 3 Wire: Rear: From Vin V5141893
Sensor – Exhaust Oxygen – Universal	**COS721**	2	Universal 3 Wire: Front and Rear
Sensor – Temperature Gauge	**CTS134**	1	
Sensor – Throttle Position	**CTPS108**	1	From Vin W5000001
Switch – Brake Light	**CSL64**	1	2 Terminal: To Vin XL396308
Switch – Brake Light	**CSL73**	1	4 Terminal: With Cruise Control
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Radiator Fan	**CFS80**	1	
Vectra JS: JS Series II **8/98-12/02 4 Cyl 2.2L C22SEL DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC270**	1	
Sensor – Air Flow / MAF	**CAF004**	1	
Sensor – Camshaft	**CSCA82**	1	
Sensor – Crankshaft	**CSCA21**	1	
Sensor – Temperature Gauge	**CTS127**	1	
Sensor – Throttle Position	**CTPS100**	1	
Switch – Brake Light	**CSL64**	1	2 Terminal
Switch – Brake Light	**CSL73**	1	4 Terminal: With Cruise Control
Switch – Oil Pressure Warning Light	**CPS48**	1	
Switch – Radiator Fan	**CFS49**	1	Code XY
Switch – Radiator Fan	**CFS79**	1	Code XP (brown)

Holden	Part No	Qty	Notes
Vectra JS Series II **11/00-12/02 V6 Cyl 2.6L Y26SE DOHC 24V MPFi FWD**			
Sensor – Camshaft	**CSCA172**	1	
Sensor – Coolant Temperature	**CCS41**	1	
Sensor – Exhaust Oxygen	**COS883**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen	**COS884**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS134**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Vectra ZC **3/03-12/06 4 Cyl 2.2L Z22SE DOHC 16V ESPFI FWD**			
Ignition – Coil and Igniter	**CC358**	1	
Sensor – Air Temperature – Ambient	**CAT019**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA130**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS210**	1	
Switch – Oil Pressure Warning Light	**CPS48**	1	
Vectra ZC **3/03-12/06 V6 Cyl 3.2L Z32SE DOHC 24V ESPFI FWD**			
Sensor – Air Temperature – Ambient	**CAT019**	1	
Sensor – Camshaft	**CSCA172**	1	
Sensor – Coolant Temperature	**CCS41**	1	
Sensor – Exhaust Oxygen	**COS883**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Oil Pressure Warning Light	**CPS48**	1	
Viva JF **9/05-on 4 Cyl 1.8L F18D DOHC 16V ESPFI FWD**			
Sensor – Crankshaft	**CSCA178**	1	
Sensor – Exhaust Oxygen	**COS904**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS113**	1	
Zafira TT **6/01-5/06 4 Cyl 2.2L Z22SE DOHC 16V MPFi FWD**			
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA130**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear
Switch – Brake Light	**CSL65**	1	4 Terminal: With Cruise Control
Holden HDT			
Commodore VL SS Group A **11/86-12/87 V8 Cyl 5.0L OHV 16V Carb. RWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH112**	1	
Ignition – Distributor Rotor	**BH103**	1	
Ignition – Module	**CM418**	1	
Ignition – Pickup / Trigger	**CIT116**	1	

Holden HSV	Part No	Qty	Notes
Astra LD SV1800 Stage 1: Stage 2 **9/88-8/89 4 Cyl 1.8L 18LE SOHC EFi FWD**			
Ignition – Coil – Standard	**CC207**	1	
Ignition – Distributor Cap	**DR114**	1	Delco Electronic Distributor
Ignition – Distributor Rotor	**DR73**	1	Delco Electronic Distributor
Ignition – Module	**CM415**	1	Delco Electronic Distributor
Ignition – Pickup / Trigger	**CIT100**	1	Delco Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS127**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS57**	1	
Switch – Radiator Fan	**CFS28**	1	
Valve – Idle Speed Control	**CIA008**	1	
Avalanche VY Series II **10/03-4/06 V8 Cyl 5.7L LS1 OHV 16V MPFi AWD**			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS124**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Calais VL SV88 **5/88-11/88 V8 Cyl 5.0L OHV 16V Carb. RWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH112**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH103**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS152**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS30**	1	
Switch – Reverse Light	**CRS100**	1	4 Speed Transmission
Caprice VS: VS Series II 215i **4/95-6/99 V8 Cyl 5.7L VU OHV 16V MPFi RWD**			
Ignition – Distributor Cap	**BH84**	1	
Ignition – Distributor Rotor	**BH231**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS750**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	

Holden HSV	Part No	Qty	Notes
Clubsport VP Series II: VR **5/93-4/95 V8 Cyl 5.0L OHV 16V MPFi RWD**			
Ignition – Coil – Standard	**CC200**	1	Oil Filled
Ignition – Distributor Cap	**BH84**	1	
Ignition – Distributor Rotor	**BH231**	1	
Sensor – Temperature Gauge	**CTS127**	1	
Clubsport VS: VS Series II **4/95-8/97 V8 Cyl 5.0L OHV 16V MPFi RWD**			
Ignition – Distributor Cap	**BH84**	1	
Ignition – Distributor Rotor	**BH231**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Clubsport VT Series II **7/99-10/00 V8 Cyl 5.7L GENIII OHV 16V MPFi RWD**			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA45**	1	
Sensor – Exhaust Oxygen	**COS744**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS124**	1	
Clubsport VX: VX Series II: VY: VY Series II **9/00-9/04 V8 Cyl 5.7L GENIII OHV 16V MPFi RWD**			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Air Temperature – Inlet	**CAT006**	1	
Commodore VL SS Grp A Walkinshaw **3/88-3/89 V8 Cyl 5.0L VP OHV 16V MPFi RWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH112**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH103**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Ignition – Pickup / Trigger	**CIT116**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS152**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS30**	1	
Switch – Reverse Light	**CRS100**	1	4 Speed Transmission
Commodore VN: VN Series II: VP: VP Series II **10/88-6/93 V6 Cyl 3.8L OHV 12V MPFi RWD**			
Ignition – Coil – Standard	**CC206**	1	To 11/1990
Ignition – Coil – Standard	**CC208**	3	From 11/1990
Ignition – Coil & Module Kit	**CCMLK**	1	With Ignition Leads
Ignition – Coil & Module Kit	**CCMK**	1	Without Ignition Leads
Ignition – Module	**CM407**	1	To 11/1990
Ignition – Module	**CM414**	1	From 11/1990
Commodore VN **3/89-7/91 V8 Cyl 5.0L OHV 16V MPFi RWD**			
Ignition – Coil – Standard	**CC200**	1	Oil Filled
Ignition – Distributor Cap	**BH84**	1	
Ignition – Distributor Rotor	**BH231**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	

Holden HSV	Part No	Qty	Notes
Grange VS Series II **10/96-12/98 V8 Cyl 5.0L: 5.7L Holden OHV 16V MPFi RWD**			
Ignition – Distributor Cap	**BH84**	1	
Ignition – Distributor Rotor	**BH231**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS750**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
GTS VP: VS: VS Series II: VT **8/92-6/99 V8 Cyl 5.0L: 5.7L Holden OHV 16V MPFi RWD**			
Ignition – Distributor Cap	**BH84**	1	
Ignition – Distributor Rotor	**BH231**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS750**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
GTS VT Series II: VX: VY: VY Series II **4/00-9/04 V8 Cyl 5.7L GENIII OHV 16V MPFi RWD**			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Crankshaft	**CSCA45**	1	
Sensor – Exhaust Oxygen	**COS744**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS124**	1	
Maloo VG: VP: VR: VS: VS Series II: VS Series III **10/90-10/00 V8 Cyl 5.0L OHV 16V MPFi RWD**			
Ignition – Coil – Standard	**CC200**	1	Oil Filled: To 3/1995
Ignition – Distributor Cap	**BH84**	1	
Ignition – Distributor Rotor	**BH231**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	

Holden HSV	Part No	Qty	Notes
Maloo VY: VY Series II Incl R8			
10/02-9/04 V8 Cyl 5.7L LS1 OHV 16V MPFi RWD			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS124**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Manta VS: VS Series II			
4/95-8/97 V8 Cyl 5.0L VU OHV 16V MPFi RWD			
Ignition – Distributor Cap	**BH84**	1	
Ignition – Distributor Rotor	**BH231**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Senator VP: VR			
3/92-4/95 V8 Cyl 5.0L OHV 16V MPFi RWD			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH84**	1	
Ignition – Distributor Rotor	**BH231**	1	
Sensor – Temperature Gauge	**CTS127**	1	
Senator VS: VS Series II: VT			
4/95-6/99 V8 Cyl 5.0L: 5.7L Holden OHV 16V MPFi RWD			
Ignition – Distributor Cap	**BH84**	1	
Ignition – Distributor Rotor	**BH231**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	To 8/1997
Sensor – Air Temperature – Inlet	**CAT002**	1	From 9/1997
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS750**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
Senator VT Series II: VX: VX Series II: VY: VY Series II			
7/99-9/04 V8 Cyl 5.7L LS1 OHV 16V MPFi RWD			
Ignition – Coil and Igniter	**CC354**	8	
Sensor – Air Temperature – Inlet	**CAT006**	1	
Sensor – Camshaft	**CSCA112**	1	
Sensor – Coolant Temperature	**CCS31**	1	
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS210**	1	
Sensor – Throttle Position	**CTPS124**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	

Holden HSV	Part No	Qty	Notes
Statesman VQ: VQ Series II: VR: VS: VS Series II			
4/91-9/96 V8 Cyl 5.0L: 5.7L Holden OHV 16V MPFi RWD			
Ignition – Coil – Standard	**CC200**	1	To 4/1993
Ignition – Distributor Cap	**BH84**	1	
Ignition – Distributor Rotor	**BH231**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	To 8/1997
Sensor – Air Temperature – Inlet	**CAT002**	1	From 9/1997
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS750**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
XU6 VT: VT Series II S/charged			
3/98-10/02 V6 Cyl 3.8L VH OHV 12V MPFi RWD			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT002**	1	
Sensor – Camshaft	**CSCA81**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Crankshaft	**CSCA04**	1	
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS131**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
XU8 VT			
1/99-6/99 V8 Cyl 5.0L VN OHV 16V MPFi RWD			
Ignition – Distributor Cap	**BH84**	1	
Ignition – Distributor Rotor	**BH231**	1	
Sensor – Air Temperature – Inlet	**CAT002**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS750**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Knock Control	**CKS101**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS152**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Brake Light	**CSL41**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	

Honda	Part No	Qty	Notes
Accord SJ **3/77-12/78 4 Cyl 1.6L EG SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP544**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR535**	1	Hitachi Points Distributor
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS12**	1	
Accord SY: SZ **1/82-12/83 4 Cyl 1.6L EL SOHC 8V Carb. FWD**			
Ignition – Distributor Cap	**JP562**	1	TEC Distributor: To Engine L1800000
Ignition – Distributor Cap	**JP630**	1	Hitachi Electronic Distributor: To 1982
Ignition – Distributor Cap	**JP562**	1	Hitachi Electronic Distributor: From 1982
Ignition – Distributor Rotor	**DR782**	1	TEC Distributor: To Engine L1800000
Ignition – Distributor Rotor	**JR513**	1	Hitachi Electronic Distributor: To 1982
Ignition – Distributor Rotor	**JR517**	1	Hitachi Electronic Distributor: From 1982
Ignition – Module	**CM401**	1	
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS12**	1	
Accord AD **1/84-12/85 4 Cyl 1.8L ET SOHC 8V Carb. FWD**			
Ignition – Distributor Cap	**JP660**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CM417**	1	Hitachi Distributor
Ignition – Module	**CM400**	1	TEC Distributor
Sensor – Temperature Gauge	**CTS115**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS12**	1	
Accord EP: MT: EQ: AT *(NZ Market)* **1984-86 4 Cyl 1.6L EZ SOHC**			
Ignition – Distributor Cap	**JP630**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
Accord AC: AD *(NZ Market)* **1984-86 4 Cyl 1.8L ET SOHC 12V**			
Ignition – Coil – Standard	**CC224**	1	
Ignition – Distributor Cap	**JP660**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
Accord CA2 *(NZ Market)* **1985-89 4 Cyl 1.8L B18A1 DOHC 2xCarb.**			
Ignition – Distributor Cap	**JP660**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
Accord CA3 Carb. *(NZ Market)* **1985-89 4 Cyl 2.0L B20A DOHC 16V Carb.**			
Ignition – Coil – Standard	**CC224**	1	
Ignition – Distributor Cap	**JP660**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor

Honda	Part No	Qty	Notes
Accord CA3 EFi *(NZ Market)* **1985-89 4 Cyl 2.0L B20A DOHC 16V EFi**			
Ignition – Coil – Standard	**CC224**	1	
Ignition – Distributor Cap	**JP600**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
Accord CA1 *(NZ Market)* **1985-91 4 Cyl 1.8L A18A SOHC 12V Carb.**			
Ignition – Coil – Standard	**CC224**	1	
Ignition – Distributor Cap	**JP660**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
Accord CA5 **1/86-5/89 4 Cyl 2.0L A20A2 SOHC 12V Carb. FWD**			
Ignition – Coil – Standard	**CC224**	1	
Ignition – Distributor Cap	**JP662**	1	TEC Electronic Distributor: From 1988
Ignition – Distributor Rotor	**DR782**	1	TEC Electronic Distributor: From 1988
Ignition – Module	**CM400**	1	TEC Electronic Distributor
Sensor – Temperature gauge	**CTS115**	1	To Engine 2800000
Switch – Oil Pressure Warning Light	**CPS22**	1	
Accord CA5: CA6 *(NZ Market)* **1986-91 4 Cyl 2.0L A20A SOHC 12V**			
Ignition – Coil – Standard	**CC224**	1	
Ignition – Distributor Cap	**JP600**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
Accord CA5 **1/87-12/89 4 Cyl 2.0L A20A4 SOHC 12V EFi FWD**			
Ignition – Coil – Standard	**CC224**	1	
Ignition – Distributor Cap	**JP662**	1	TEC Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	TEC Electronic Distributor
Ignition – Module	**CM400**	1	NEC Distributor
Sensor – Coolant Temperature	**CCS23**	1	
Sensor – Exhaust Oxygen	**COS745**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS115**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS14**	1	
Accord CB3 EXL-1: Si *(NZ Market)* **1989-92 4 Cyl 2.0L F20A DOHC 16V**			
Ignition – Coil – Standard	**CC225**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Accord CB3 EXL *(NZ Market)* **1989-92 4 Cyl 2.0L F20A DOHC 16V**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR992**	1	Hitachi Electronic Distributor
Ignition – Module	**CM429**	1	Hitachi Electronic Distributor

Honda	Part No	Qty	Notes
Accord CB7: CB9 Incl. 4WS			
11/89-6/94 4 Cyl 2.2L F22A5: F22A6: F22A9 SOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC225**	1	
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor: To 10/1990
Ignition – Distributor Rotor	**JR992**	1	Hitachi Electronic Distributor: To 10/1990
Ignition – Module	**CM429**	1	
Sensor – Air Temperature – Inlet	**CAT015**	1	To 12/1990
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS769**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS219**	1	
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Brake Light	**CSL54**	1	With Cruise Control
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS57**	1	
Accord CB1 *(NZ Market)*			
1990-94 4 Cyl 1.8L F18A SOHC			
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Accord CB7: CB9 *(NZ Market)*			
1991-94 4 Cyl 2.2L F22A SOHC 16V			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
Accord CB4 *(NZ Market)*			
1992-94 4 Cyl 2.0L F20A SOHC			
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Accord CD4 *(NZ Market)*			
1993-97 4 Cyl 2.0L F20B			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
Accord CD5: CY *(NZ Market)*			
1993-97 4 Cyl 2.2L F22B SOHC 16V			
Ignition – Distributor Cap	**JP968**	1	
Accord CE1 *(NZ Market)*			
1993-97 4 Cyl 2.2L F22B SOHC			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
Accord CD5: CE1			
10/93-12/97 4 Cyl 2.2L F22B1 SOHC 16V EFi FWD			
Ignition – Coil – Standard	**CC277**	1	
Ignition – Distributor Cap	**JP402**	1	Hitachi Electronic Distributor
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS831**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Brake Light	**CSL54**	1	With Cruise Control
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS53**	1	
Switch – Radiator Fan	**CFS57**	1	CE1: V-TEC
Accord CD5			
4/96-12/97 4 Cyl 2.2L F22B3 SOHC 16V EFi FWD			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Sensor – Exhaust Oxygen	**COS831**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire

Honda	Part No	Qty	Notes
Accord CG5			
12/97-4/99 4 Cyl 2.3L F23A1 SOHC 16V EFi FWD			
Ignition – Coil – Standard	**CC277**	1	
Ignition – Distributor Cap	**JP402**	1	
Ignition – Distributor Rotor	**JR402**	1	
Sensor – Exhaust Oxygen	**COS831**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Accord CG1			
12/97-5/03 V6 Cyl 3.0L J30A1 SOHC 24V EFi FWD			
Ignition – Distributor Rotor	**JR403**	1	
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Radiator Fan	**CFS62**	1	
Ascot CB1: CB4 *(NZ Market)*			
1989-95 4 Cyl 1.8:2.0L F18A: F20A			
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
City VF			
1/84-6/86 4 Cyl 1.2L ER SOHC 8V Carb. FWD			
Ignition – Distributor Rotor	**DR782**	1	TEC Electronic Distributor
Ignition – Module	**CM400**	1	
Sensor – Temperature Gauge	**CTS115**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS12**	1	
City FA: FH: FC: FD *(NZ Market)*			
1984-89 4 Cyl 1.2L ER1: ER4			
Ignition – Distributor Cap	**JP630**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
City GA1 *(NZ Market)*			
1987-89 4 Cyl 1.2L D12A			
Ignition – Distributor Cap	**JP630**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
City GA2 *(NZ Market)*			
1989-94 4 Cyl 1.3L D13C SOHC 16V			
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Civic SB			
3/73-8/76 4 Cyl 1.2L EB1 SOHC 8V Carb. FWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor: To 1975
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor: To 1975
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor: To 1975
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor: To 1975
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS12**	1	

Honda	Part No	Qty	Notes
Civic **10/74-6/78 4 Cyl 1.5L EC SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP544**	1	Hitachi Points Distributor: From 1975
Ignition – Distributor Condenser	**NC213**	1	Hitachi Points Distributor: From 1975
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor: From 1975
Ignition – Distributor Rotor	**JR535**	1	Hitachi Points Distributor: From 1975
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS12**	1	
Civic SL **11/79-12/83 4 Cyl 1.3L EN1 SOHC 8V Carb. FWD**			
Ignition – Distributor Cap	**JP562**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Electronic Distributor
Ignition – Module	**CM401**	1	
Civic AN: AK: AH **1/84-10/87 4 Cyl 1.5L EW2 SOHC 12V Carb. FWD**			
Ignition – Distributor Cap	**JP660**	1	TEC Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	TEC Electronic Distributor
Ignition – Module	**CM400**	1	TEC Electronic Distributor
Sensor – Temperature Gauge	**CTS115**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS12**	1	
Civic AG, AJ *(NZ Market)* **1984-88 4 Cyl 1.3L EV SOHC 12V**			
Ignition – Distributor Cap	**JP660**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
Ignition – Module	**CM401**	1	Hitachi Electronic Distributor
Civic PT, PR *(NZ Market)* **1984-88 4 Cyl 1.5L EW SOHC 12V**			
Ignition – Distributor Cap	**JP660**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
Civic AT: AU *(NZ Market)* **1985-87 4 Cyl 1.6L ZC DOHC 16V**			
Ignition – Distributor Cap	**JP660**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
Civic EF4 *(NZ Market)* **1987-89 4 Cyl 1.5L D15B SOHC 16V 4WD**			
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Civic EF3 *(NZ Market)* **1987-89 4 Cyl 1.6L ZC DOHC 16V**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Civic EF1 *(NZ Market)* **1987-91 4 Cyl 1.3L D13B SOHC 16V**			
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Civic EF2 Carb. *(NZ Market)* **1987-91 4 Cyl 1.5L D15B SOHC 16V**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor

Honda	Part No	Qty	Notes
Civic ED: EE: EG3: EG4			
11/87-10/93 4 Cyl 1.3L D13B2 Carb: 1.5L D15B4 2xCarb. SOHC 16V FWD			
Ignition – Coil – Standard	**CC267**	1	
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Sensor – Coolant Temperature	**CCS22**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS12**	1	
Civic CK: CR *(NZ Market)*			
1988-91 4 Cyl 1.3L D13B SOHC 16V			
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Civic EG5: EH9			
10/91-10/93 4 Cyl 1.6L D16A8 DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC225**	1	
Ignition – Module	**CM429**	1	
Sensor – Air Temperature – Inlet	**CAT015**	1	From 1992
Civic EG3: EG7 *(NZ Market)*			
1991-95 4 Cyl 1.3L D13B SOHC 16V			
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Civic EG4: EG8 *(NZ Market)*			
1991-95 4 Cyl 1.5L D15B SOHC 16V			
Ignition – Coil – Standard	**CC225**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Civic EG5: EH9 *(NZ Market)*			
1992-94 4 Cyl 1.6L B16A DOHC 16V			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Civic GU: HF *(NZ Market)*			
1992-96 4 Cyl 1.5L D15B SOHC 16V			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
Civic EG			
10/93-9/95 4 Cyl 1.5L D15B7 SOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC225**	1	
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT015**	1	
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS890**	1	Direct Fit 2 Wire
Sensor – MAP	**CMS218**	1	CX: Manual Transmission
Sensor – MAP	**CMS219**	1	DX
Switch – Oil Pressure Warning Light	**CPS22**	1	
Civic EG Breeze			
10/93-9/95 4 Cyl 1.5L D15Z2 SOHC 16V Carb. FWD			
Ignition – Coil – Standard	**CC267**	1	
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT015**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS62**	1	

Honda	Part No	Qty	Notes
Civic EH9 **10/93-9/95 4 Cyl 1.6L D16Y1 SOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC225**	1	TEC Distributor
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS745**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – MAP	**CMS218**	1	
Civic EJ1: EJ3 *(NZ Market)* **1993-97 4 Cyl 1.6L ZC: D16A**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
Civic EK2 *(NZ Market)* **1995-97 4 Cyl 1.3L D13B SOHC 16V**			
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Civic EK **10/95-3/99 4 Cyl 1.6L B16A2 DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC225**	1	TEC Electronic Distributor
Ignition – Distributor Cap	**JP968**	1	TEC Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	TEC Electronic Distributor
Sensor – Exhaust Oxygen	**COS769**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS219**	1	
Civic EK **10/95-9/00 4 Cyl 1.6L D16Y4 SOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC277**	1	
Ignition – Distributor Cap	**JP402**	1	
Civic EK1 *(NZ Market)* **1996-99 4 Cyl 1.6L D16Y SOHC 16V**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Civic EM1 **3/99-9/00 4 Cyl 1.6L B16A2 DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC225**	1	TEC Electronic Distributor
Ignition – Distributor Cap	**JP968**	1	TEC Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	TEC Electronic Distributor
Sensor – MAP	**CMS218**	1	
Concerto MA1 *(NZ Market)* **1988-92 4 Cyl 1.5L D15B SOHC 16V**			
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Concerto MA2: MA3 *(NZ Market)* **1988-93 4 Cyl 1.6L ZC**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
Concerto MA2 *(NZ Market)* **1988-93 4 Cyl 1.6L D16Z1 SOHC 16V**			
Ignition – Distributor Cap	**JP660**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
Ignition – Module	**CM429**	1	Hitachi Electronic Distributor

Honda	Part No	Qty	Notes
Concerto MA **11/88-1/93 4 Cyl 1.6L D16Z2 SOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC228**	1	TEC Distributor TD-03U: From 1990
Ignition – Distributor Cap	**JP969**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR982**	1	Hitachi Electronic Dist.: To Chassis 1300000
Ignition – Module	**CM429**	1	
Sensor – Air Temperature – Inlet	**CAT015**	1	
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS745**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS54**	1	
Crossroad LJJ *(NZ Market)* **1993-96 V8 Cyl 3.9L**			
Ignition – Distributor Cap	**BD280**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**DR71**	1	Lucas Points Distributor
CRV RD1 **9/97-12/01 4 Cyl 2.0L B20B3 DOHC 16V MPFi 4WD**			
Ignition – Coil – Standard	**CC225**	1	TEC Electronic Distributor
Ignition – Distributor Cap	**JP968**	1	TEC Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	
Sensor – Exhaust Oxygen	**COS831**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS218**	1	
CRV RD2 **12/01-1/07 4 Cyl 2.4L K24A1 DOHC 16V ESPFI 4WD**			
Ignition – Coil – Standard	**CC381**	1	
Sensor – Exhaust Oxygen	**COS831**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
CRX EF6 *(NZ Market)* **1987-91 4 Cyl 1.5L D15B SOHC 16V**			
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
CRX ED9 **11/87-5/92 4 Cyl 1.6L D16A8 DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC228**	1	
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
Ignition – Module	**CM429**	1	
Sensor – Air Temperature – Inlet	**CAT015**	1	
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS745**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS12**	1	
CRX EF7 *(NZ Market)* **1987-92 4 Cyl 1.6L ZC**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
CRX EF8 *(NZ Market)* **1989-94 4 Cyl 1.6L B16A DOHC 16V**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor

Honda	Part No	Qty	Notes
CRX EG1: EG2 *(NZ Market)* **1992-96 4 Cyl 1.5:1.6L D15B:B16A SOHC 16V**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
CRX EG2 **6/92-9/98 4 Cyl 1.6L B16A2 DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC225**	1	
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
Ignition – Module	**CM429**	1	
Sensor – Air Temperature – Inlet	**CAT015**	1	
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS769**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS219**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS62**	1	
Domani MA7 *(NZ Market)* **1994-98 4 Cyl 1.5L D15B SOHC 16V**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
HRV GH1: GH2 *(NZ Market)* **1999-01 4 Cyl 1.6L D16A SOHC**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
HRV GH2: GH4 **1/99-7/02 4 Cyl 1.6L D16W1 SOHC 16V MPFi 4WD**			
Ignition – Coil – Standard	**CC225**	1	
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS831**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Integra AV: DA1 *(NZ Market)* **1985-88 4 Cyl 1.6L ZC DOHC 16V**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
Integra DA **5/86-5/89 4 Cyl 1.6L D16A3 DOHC 16V EFi FWD**			
Ignition – Distributor Cap	**JP660**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Electronic Distributor
Ignition – Module	**CM400**	1	
Sensor – Coolant Temperature	**CCS27**	1	
Sensor – Exhaust Oxygen	**COS745**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS115**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS12**	1	
Integra DA2 *(NZ Market)* **1986-89 4 Cyl 1.5L EW SOHC 12V**			
Ignition – Distributor Cap	**JP660**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
Integra DA5: DA7 *(NZ Market)* **1988-93 4 Cyl 1.6L ZC SOHC 12V**			
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor

Honda	Part No	Qty	Notes
Integra DA6 *(NZ Market)* **4 Cyl 1.6L B16A DOHC 16V**			
Ignition – Distributor Cap	**JP980**	1	Hitachi Electronic Distributor: To Vin 1200000
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Dist.: From Vin 1200001
Ignition – Distributor Rotor	**JR997**	1	Hitachi Electronic Distributor: To Vin 1200000
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Dist.: From Vin 1200001
Integra DA9 **6/89-7/93 4 Cyl 1.8L B18A1 DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC230**	1	To 1991
Ignition – Coil – Standard	**CC225**	1	From 1992
Ignition – Distributor Cap	**JP968**	1	TEC Electronic Distributor: To 1990
Ignition – Distributor Cap	**JP980**	1	TEC Electronic Distributor: From 1991 To 1991
Ignition – Distributor Cap	**JP968**	1	TEC Electronic Distributor: From 1992
Ignition – Distributor Rotor	**JR982**	1	TEC Electronic Distributor: To 1990
Ignition – Distributor Rotor	**JR997**	1	TEC Electronic Distributor: From 1991 To 1991
Ignition – Distributor Rotor	**JR995**	1	TEC Electronic Distributor: From 1992
Ignition – Module	**CM429**	1	
Sensor – Air Temperature – Inlet	**CAT015**	1	
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS745**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – MAP	**CMS219**	1	
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Integra DC1 *(NZ Market)* **4 Cyl 1.6L ZC**			
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Integra DC2 **7/93-11/99 4 Cyl 1.8L B18C2 DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC225**	1	
Ignition – Distributor Cap	**JP986**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS769**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS218**	1	
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS12**	1	
Integra DC4 **7/93-7/01 4 Cyl 1.8L B18B2 DOHC 16V PGMFI FWD**			
Ignition – Coil – Standard	**CC225**	1	
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
Ignition – Module	**CM429**	1	
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS769**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS218**	1	
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS62**	1	

Honda	Part No	Qty	Notes
Legend KA2 **5/86-12/87 V6 Cyl 2.5L C25A1 SOHC 24V EFi FWD**			
Ignition – Coil – Standard	**CC266**	1	
Ignition – Module	**CM400**	1	
Sensor – Coolant Temperature	**CCS23**	1	
Sensor – Exhaust Oxygen	**COS745**	2	Direct Fit 1 Wire: Front & Rear
Sensor – Exhaust Oxygen – Universal	**COS720**	2	Universal 1 Wire: Front & Rear
Sensor – Temperature Gauge	**CTS115**	1	
Switch – Brake Light	**CSL54**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS47**	1	
Legend KA4 **11/87-3/91 V6 Cyl 2.7L C27A1 SOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC266**	1	Auto Transmission: To 12/1989
Ignition – Coil – Standard	**CC274**	1	Auto Transmission: From 1/1990
Ignition – Distributor Cap	**BD560**	1	TEC Electronic Distributor
Ignition – Distributor Rotor	**DR561**	1	TEC Electronic Distributor
Sensor – Coolant Temperature	**CCS23**	1	
Sensor – Exhaust Oxygen	**COS745**	2	Direct Fit 1 Wire: Front & Rear
Sensor – Exhaust Oxygen – Universal	**COS720**	2	Universal 1 Wire: Front & Rear
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Brake Light	**CSL54**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
Switch – Radiator Fan	**CFS47**	1	
Legend KA7 **4/91-4/96 V6 Cyl 3.2L C32A3 SOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC307**	6	
Legend KA8 **4/91-3/96 V6 Cyl 3.2L C32A3 SOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC307**	6	
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS823**	2	Direct Fit 4 Wire: Front & Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front & Rear
Sensor – MAP	**CMS219**	1	
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Brake Light	**CSL54**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS87**	1	
Legend KA9 **5/96-1/05 V6 Cyl 3.5L C35A3 SOHC 24V PGMFI FWD**			
Ignition – Coil – Standard	**CC307**	6	
Sensor – Exhaust Oxygen	**COS830**	2	Direct Fit 4 Wire: Front & Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front & Rear
Logo GA3 *(NZ Market)* **1996-99 4 Cyl 1.3L D13B**			
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
NSX NA **1/91-1/05 V6 Cyl 3.0L C30A3 DOHC 24V EFi RWD**			
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS823**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	

Honda	Part No	Qty	Notes
Odyssey RA1 *(NZ Market)* **1994-95 4 Cyl 2.2L F22B SOHC**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
Odyssey RA1 **6/95-12/97 4 Cyl 2.2L F22B6 SOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC225**	1	
Sensor – Exhaust Oxygen	**COS831**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Radiator Fan	**CFS62**	1	
Odyssey RA3 **1/98-4/00 4 Cyl 2.3L F23A7 SOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC277**	1	Hitachi Distributor
Ignition – Distributor Rotor	**JR402**	1	Hitachi Distributor
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS831**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS114**	1	
Prelude SNF **5/79-12/82 4 Cyl 1.6L EL SOHC 8V Carb. FWD**			
Ignition – Distributor Cap	**JP630**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP562**	1	Hitachi Electronic Distributor: From 1/1982
Ignition – Distributor Rotor	**JR517**	1	Hitachi Electronic Distributor
Ignition – Module	**CM401**	1	
Ignition – Module & Pickup / Trigger	**CM417**	1	
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Brake Light	**CSL52**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS12**	1	
Prelude AB7 **1/83-12/85 4 Cyl 1.8L ES SOHC 12V 2xCarb. FWD**			
Ignition – Distributor Cap	**JP600**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
Ignition – Module	**CM401**	1	
Sensor – Temperature Gauge	**CTS115**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS13**	1	
Prelude AB *(NZ Market)* **1983-87 4 Cyl 1.8L ET SOHC 12V**			
Ignition – Distributor Cap	**BD708**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
Prelude BA1: BA2: BA3 *(NZ Market)* **1985-87 4 Cyl 2.0L B20A DOHC 16V**			
Ignition – Distributor Cap	**BD708**	1	Hitachi Electronic Distributor
Prelude BA3 **1/86-9/87 4 Cyl 2.0L A20A4 SOHC 12V EFi FWD**			
Ignition – Distributor Cap	**JP662**	1	TEC Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	TEC Electronic Distributor
Ignition – Module	**CM400**	1	
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS745**	2	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	2	Universal 1 Wire
Sensor – Temperature Gauge	**CTS115**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS14**	1	

Honda	Part No	Qty	Notes
Prelude BA4 **10/87-12/91 4 Cyl 2.0L B20A6 DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC224**	1	
Ignition – Distributor Cap	**JP401**	1	
Ignition – Distributor Rotor	**JR401**	1	
Sensor – Air Temperature – Inlet	**CAT015**	1	
Prelude BA4: BA5 *(NZ Market)* **1987-91 4 Cyl 2.0L B20A DOHC 16V**			
Ignition – Coil – Standard	**CC224**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**BD708**	1	Hitachi Electronic Distributor
Prelude BA4 4WS **8/91-12/91 4 Cyl 2.0L B20A6 DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC224**	1	
Ignition – Distributor Cap	**JP662**	1	TEC Electronic Distributor
Ignition – Distributor Rotor	**JR517**	1	TEC Electronic Distributor
Ignition – Module	**CM400**	1	Suits (TEC TD-13V) Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT015**	1	
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS745**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS115**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
Switch – Radiator Fan	**CFS14**	1	
Prelude BA8: BA9 *(NZ Market)* **1991-94 4 Cyl 2.0L F20A OHC**			
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Prelude BB1: BB4 4WS *(NZ Market)* **1991-95 4 Cyl 2.2L H22A DOHC 16V**			
Ignition – Coil – Standard	**CC225**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
Prelude BA8 **12/91-12/96 4 Cyl 2.2L F22A1 DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC272**	1	
Ignition – Distributor Cap	**JP976**	1	TEC Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	TEC Electronic Distributor
Ignition – Module	**CM429**	1	
Sensor – Air Temperature – Inlet	**CAT015**	1	
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS769**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS219**	1	
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS57**	1	In Thermostat Cover
Switch – Radiator Fan	**CFS53**	1	In Engine Hose Connector
Prelude BA9 4WS *(NZ Market)* **1991-96 4 Cyl 2.2L F22B3 DOHC 16V**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor

Honda	Part No	Qty	Notes
Prelude BB2 **12/91-12/96 4 Cyl 2.3L H23A1 DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC225**	1	TEC Electronic Distributor
Ignition – Distributor Cap	**JP968**	1	TEC Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	TEC Electronic Distributor
Ignition – Module	**CM429**	1	TEC Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT015**	1	
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS769**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS219**	1	
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Brake Light	**CSL54**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
Switch – Radiator Fan	**CFS53**	1	TEC: On at 97°C Off at 87°C
Switch – Radiator Fan	**CFS57**	1	Uchiya: On at 112°C Off at 107°C
Prelude BB1 **2/94-12/96 4 Cyl 2.2L H22A1 DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC272**	1	
Ignition – Distributor Cap	**JP976**	1	TEC Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	TEC Electronic Distributor
Sensor – Coolant Temperature	**CCS22**	1	
Sensor – Exhaust Oxygen	**COS832**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS114**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS53**	1	
Prelude BB5 **1/97-7/02 4 Cyl 2.2L F22Z6 DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC225**	1	
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Switch – Radiator Fan	**CFS53**	1	
Prelude BB6 **1/97-7/02 4 Cyl 2.2L H22A4 DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC225**	1	
Ignition – Distributor Cap	**JP976**	1	Hitachi Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT015**	1	
Sensor – Exhaust Oxygen	**COS859**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Radiator Fan	**CFS53**	1	
Shuttle AN: AK *(NZ Market)* **1984-88 4 Cyl 1.5L EW SOHC 12V**			
Ignition – Distributor Cap	**JP660**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
Shuttle EY2 *(NZ Market)* **1987-91 4 Cyl 1.3L D13B SOHC 16V**			
Ignition – Distributor Cap	**JP971**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor
Shuttle EY4 *(NZ Market)* **1987-95 4 Cyl 1.5L D15B SOHC 12V**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR981**	1	Hitachi Electronic Distributor

Honda	Part No	Qty	Notes
Vigor CA1: CA3 *(NZ Market)* **1985-89 4 Cyl 1.8:2.0L A18A: B20A**			
Ignition – Distributor Cap	**JP660**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR782**	1	Hitachi Electronic Distributor
Hyundai			
Accent X3A *(NZ Market)* **1994-00 4 Cyl 1.5L G4EK SOHC 12V**			
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Accent LC: LS **6/00-4/06 4 Cyl 1.5L G4ECX: 1.6L G4ED2 DOHC 16V EPFI FWD**			
Ignition – Coil – Standard	**CC320**	1	
Sensor – Camshaft	**CSCA99**	1	
Sensor – Crankshaft	**CSCA20**	1	
Sensor – Exhaust Oxygen	**COS860**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS211**	1	
Sensor – Throttle Position	**CTPS108**	1	
Switch – Brake Light	**CSL67**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Accent MC **5/06-on 4 Cyl 1.6L G4ED DOHC 16V MPFi FWD**			
Sensor – Air Flow / MAF	**CAF026**	1	
Sensor – Camshaft	**CSCA99**	1	
Sensor – Crankshaft	**CSCA20**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Exhaust Oxygen	**COS860**	1	Direct Fit 4 Wire: Manifold
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Manifold
Switch – Oil Pressure Warning Light	**CPS37**	1	
Elantra XD Incl. Lavita **10/00-6/04 4 Cyl 1.8L G4GBX DOHC 16V EPFI FWD**			
Ignition – Coil – Standard	**CC321**	1	To 12/2001
Ignition – Coil – Standard	**CC339**	1	From 12/2001 To 9/2002
Ignition – Coil – Standard	**CC340**	1	From 9/2002
Sensor – Camshaft	**CSCA116**	1	
Sensor – Crankshaft	**CSCA31**	1	
Sensor – Exhaust Oxygen	**COS869**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS211**	1	
Sensor – Throttle Position	**CTPS108**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Elantra XD **10/00-9/03 4 Cyl 2.0L G4GCX DOHC 16V EPFI FWD**			
Ignition – Coil – Standard	**CC321**	1	To 12/2001
Ignition – Coil – Standard	**CC339**	1	From 12/2001 To 9/2002
Ignition – Coil – Standard	**CC340**	1	From 9/2002
Sensor – Camshaft	**CSCA116**	1	
Sensor – Crankshaft	**CSCA31**	1	
Sensor – Exhaust Oxygen	**COS869**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS211**	1	
Sensor – Throttle Position	**CTPS108**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	

Hyundai	Part No	Qty	Notes
Elantra XD **10/03-9/07 4 Cyl 2.0L G4GCX DOHC 16V EPFI FWD**			
Ignition – Coil – Standard	**CC340**	1	
Sensor – Air Flow / MAF	**CAF026**	1	
Sensor – Crankshaft	**CSCA31**	1	
Sensor – Exhaust Oxygen	**COS869**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS211**	1	
Sensor – Throttle Position	**CTPS108**	1	
Excel X1 **2/86-12/89 4 Cyl 1.5L G4AJ SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CC202**	1	To 11/1986
Ignition – Coil – Standard	**CC344**	1	From 11/1986
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CM404**	1	
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Brake Light	**CSL57**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS41**	1	
Excel, Pony *(NZ Market)* **1986-90 4 Cyl 1.5l 4G15 SOHC 8V**			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Excel X2 **1/90-11/94 4 Cyl 1.5L G4DJ SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC220**	1	
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR611**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Air Temperature – Inlet	**CAT005**	1	
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Crankshaft	**CSCA54**	1	With Triangle Shaped Connector: To 7/1992
Sensor – Crankshaft	**CSCA06**	1	With Square Connector: To 7/1992
Sensor – Exhaust Oxygen	**COS757**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – MAP	**CMS206**	1	From 7/1992
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS100**	1	From 7/1991 To 9/1992
Switch – Brake Light	**CSL57**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS31**	1	
Valve – Idle Speed Control	**CIA002**	1	To 7/1992

Hyundai	Part No	Qty	Notes
Excel X3			
9/94-4/98 4 Cyl 1.5L G4EK SOHC 12V EFi FWD			
Ignition – Coil – Standard	**CC328**	1	
Sensor – Air Flow / MAF	**CAF021**	1	
Sensor – Air Temperature – Inlet	**CAT005**	1	To 12/1996
Sensor – Air Temperature – Inlet	**CAT004**	1	From 12/1996
Sensor – Camshaft	**CSCA115**	1	No 1 Top Dead Centre
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA18**	1	
Sensor – Exhaust Oxygen	**COS801**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS107**	1	
Sensor – MAP	**CMS209**	1	Kefico: From 9/1996 To 5/1998
Sensor – MAP	**CMS212**	1	Kefico: From 5/1998
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS100**	1	
Switch – Clutch Pedal	**CSL66**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS41**	1	
Excel X3			
1/98-6/00 4 Cyl 1.5L G4FKV DOHC 16V EFi FWD			
Ignition – Coil – Standard	**CC341**	1	
Sensor – Air Flow / MAF	**CAF021**	1	
Sensor – Air Temperature – Inlet	**CAT005**	1	
Sensor – Camshaft	**CSCA115**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA18**	1	
Sensor – Exhaust Oxygen	**COS911**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS115**	1	
Sensor – MAP	**CMS209**	1	Kefico: To 5/1998
Sensor – MAP	**CMS212**	1	Kefico: From 5/1998
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS100**	1	
Switch – Brake Light	**CSL67**	1	
Switch – Clutch Pedal	**CSL66**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS41**	1	
Valve – Idle Speed Control	**CIA012**	1	
Coupe FX: SFX: SX RD: RD Series II			
7/96-4/02 4 Cyl 1.8L G4GMR: 2.0L G4GF DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC333**	1	
Sensor – Air Temperature – Inlet	**CAT004**	1	
Sensor – Camshaft	**CSCA96**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA18**	1	
Sensor – Exhaust Oxygen	**COS905**	1	Direct Fit 4 Wire: From 12/1996
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS115**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS100**	1	
Switch – Brake Light	**CSL63**	1	With Cruise Control
Switch – Brake Light	**CSL67**	1	Without Cruise Control
Switch – Clutch Pedal	**CSL68**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	

Hyundai	Part No	Qty	Notes
Getz TB			
9/02-9/05 4 Cyl 1.5L G4EC2 DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC320**	1	
Sensor – Camshaft	**CSCA99**	1	Top Dead Centre
Sensor – Crankshaft	**CSCA20**	1	
Sensor – Exhaust Oxygen	**COS860**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS211**	1	
Sensor – Throttle Position	**CTPS108**	1	
Switch – Brake Light	**CSL67**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Getz TB			
3/03-9/05 4 Cyl 1.3L G4EA2 SOHC 12V MPFi FWD			
Ignition – Coil – Standard	**CC346**	1	
Sensor – Camshaft	**CSCA99**	1	Top Dead Centre
Sensor – Crankshaft	**CSCA20**	1	
Sensor – Exhaust Oxygen	**COS860**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS211**	1	
Sensor – Throttle Position	**CTPS108**	1	
Switch – Brake Light	**CSL67**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Getz TB			
10/05-2/07 4 Cyl 1.4L G4EE DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC320**	1	
Sensor – Camshaft	**CSCA99**	1	Top Dead Centre
Sensor – Crankshaft	**CSCA20**	1	
Sensor – Exhaust Oxygen	**COS860**	1	Direct Fit 4 Wire: Manifold and Engine Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Manifold and Engine Pipe
Sensor – MAP	**CMS211**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Getz TB			
10/05-2/07 4 Cyl 1.6L G4ED DOHC 16V MPFi FWD			
Sensor – Crankshaft	**CSCA20**	1	
Sensor – Exhaust Oxygen	**COS860**	2	Direct Fit 4 Wire: Manifold and Engine Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Manifold and Engine Pipe
Sensor – MAP	**CMS211**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Grandeur FT4			
9/99-1/04 V6 Cyl 3.0L G6CT DOHC 24V MPFi FWD			
Ignition – Coil and Igniter	**CC336**	3	
Sensor – Crankshaft	**CSCA32**	1	
Sensor – Crankshaft	**CSCA90**	1	Position
Sensor – Exhaust Oxygen	**COS868**	2	Direct Fit 4 Wire: LH & RH Side
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: LH & RH Side

Hyundai	Part No	Qty	Notes
Lantra KF2: KF3			
5/91-8/95 4 Cyl 1.6L G4CR: 1.8L G4CN DOHC 16V EFi FWD			
Ignition – Coil – Standard	**CC233**	1	
Sensor – Coolant Temperature	**CCS33**	1	
Sensor – Exhaust Oxygen	**COS762**	1	Direct Fit 4 Wire: 1.6L: To 8/1995: 1.8L: To 5/1993
Sensor – Exhaust Oxygen	**COS856**	1	Direct Fit 4 Wire: 1.8L: From 5/1993
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL63**	1	With Cruise Control
Switch – Brake Light	**CSL57**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS31**	1	1.6L
Switch – Radiator Fan	**CFS41**	1	1.8L
Lantra J2: J3			
8/95-10/00 4 Cyl 1.8L G4GM: 2.0L G4GFV DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC333**	1	
Sensor – Air Temperature – Inlet	**CAT004**	1	
Sensor – Camshaft	**CSCA96**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA18**	1	
Sensor – Exhaust Oxygen	**COS905**	1	Direct Fit 4 Wire: From 12/1996
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: From 8/1995
Sensor – Knock Control	**CKS115**	1	
Sensor – MAP	**CMS206**	1	To 4/1997
Sensor – MAP	**CMS213**	1	From 4/1997
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS100**	1	
Switch – Brake Light	**CSL67**	1	Without Cruise Control
Switch – Brake Light	**CSL63**	1	Auto Transmission: With Cruise Control
Switch – Brake Light	**CSL57**	1	Manual Transmission: With Cruise Control
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS30**	1	
Pony *(NZ Market)*			
1982-89 4 Cyl 1.2:1.4L 4G33: 4G36			
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Santa Fe			
11/00-4/06 V6 Cyl 2.7L G6EAY DOHC 24V EPFI 4WD			
Sensor – Air Flow / MAF	**CAF025**	1	
Sensor – Air Temperature – Inlet	**CAT005**	1	
Sensor – Camshaft	**CSCA97**	1	Top Dead Centre: From Vin KMHSC81DR1U000001
Sensor – Crankshaft	**CSCA33**	1	From Vin KMHSC81DR1U000001
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Valve – Idle Speed Control	**CIA012**	1	
Santa Fe GL			
1/01-9/03 4 Cyl 2.4L G4JS DOHC 16V MPFi 4WD			
Ignition – Coil and Igniter	**CC343**	2	
Sensor – Camshaft	**CSCA98**	1	From Vin KMHSC81DR1U000001
Sensor – Crankshaft	**CSCA36**	1	From Vin KMHSC81DR1U000001
Valve – Idle Speed Control	**CIA012**	1	

Hyundai	Part No	Qty	Notes
S Coupe **7/90-8/91 4 Cyl 1.5L G4DJ SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC220**	1	
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR611**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Exhaust Oxygen	**COS757**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS31**	1	
S Coupe Incl. Turbo **9/91-3/96 4 Cyl 1.5L G4EK SOHC 12V EFi FWD**			
Ignition – Coil – Standard	**CC367**	1	To 4/1994
Ignition – Distributor Cap	**BD126**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR127**	1	Bosch Electronic Distributor
Sensor – Camshaft	**CSCA115**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Crankshaft	**CSCA14**	1	
Sensor – Exhaust Oxygen	**COS757**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Knock Control	**CKS107**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS100**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS31**	1	
Sonata **3/89-2/92 4 Cyl 2.4L G4CS SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC232**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor: To 5/1989
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor: From 5/1989
Ignition – Distributor Rotor	**JR611**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Exhaust Oxygen	**COS746**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Oil Pressure Gauge	**CPS55**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL63**	1	With Cruise Control
Switch – Brake Light	**CSL57**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS30**	1	
Valve – Idle Speed Control	**CIA002**	1	From 7/1990

Hyundai	Part No	Qty	Notes
Sonata **4/90-8/98 V6 Cyl 3.0L G6AT SOHC 12V EFi FWD**			
Ignition – Coil – Standard	**CC327**	1	
Ignition – Distributor Cap	**JP728**	1	Mitsubishi Electronic Distributor: To 10/1993
Ignition – Distributor Rotor	**JR639**	1	Mitsubishi Electronic Distributor: To 10/1993
Ignition – Module	**CM422**	1	Hyundai
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Crankshaft	**CSCA51**	1	In Distributor
Sensor – Exhaust Oxygen	**COS806**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL63**	1	
Switch – Clutch Pedal	**CSL66**	1	
Switch – Oil Pressure Warning Light	**CPS50**	1	
Switch – Radiator Fan	**CFS70**	1	
Sonata **10/93-8/98 4 Cyl 2.0L G4CP DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC233**	1	
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Crankshaft	**CSCA34**	1	
Sensor – Exhaust Oxygen	**COS762**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Oil Pressure Gauge	**CPS55**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL63**	1	
Switch – Clutch Pedal	**CSL66**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS41**	1	
Sonata EF **8/98-4/00 4 Cyl 2.0L G4JPV DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC343**	2	
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA35**	1	
Sensor – Exhaust Oxygen	**COS856**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS71**	1	
Valve – Idle Speed Control	**CIA012**	1	
Sonata EF **8/98-9/01 V6 Cyl 2.5L G6BVV DOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC342**	1	
Sensor – Air Flow / MAF	**CAF016**	1	
Sensor – Air Temperature – Inlet	**CAT005**	1	
Sensor – Crankshaft	**CSCA33**	1	
Sensor – Exhaust Oxygen	**COS868**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Valve – Idle Speed Control	**CIA012**	1	

Hyundai	Part No	Qty	Notes
Sonata EFB **10/01-5/05 4 Cyl 2.4L G4JSY DOHC 16V EPFI FWD**			
Ignition – Coil and Igniter	**CC343**	2	
Sensor – Camshaft	**CSCA98**	1	From Vin KMHEM41DR1A000001
Sensor – Crankshaft	**CSCA35**	1	From Vin KMHEM41DR1A000001
Sensor – Temperature Gauge	**CTS110**	1	
Valve – Idle Speed Control	**CIA012**	1	
Sonata EFB **10/01-5/05 V6 Cyl 2.7L G6BAY DOHC 24V EPFI FWD**			
Ignition – Coil – Standard	**CC342**	1	
Sensor – Air Flow / MAF	**CAF025**	1	
Sensor – Camshaft	**CSCA97**	1	Top Dead Centre: From Vin KMHEM41FR1A000001
Sensor – Crankshaft	**CSCA33**	1	From Vin KMHEM41FR1A000001
Valve – Idle Speed Control	**CIA012**	1	
Sonata NF **6/05-on 4 Cyl 2.4L G4KC DOHC 16V EPFI FWD**			
Sensor – Exhaust Oxygen	**COS886**	1	Direct Fit 4 Wire: Front
Sensor – Exhaust Oxygen	**COS885**	1	Direct Fit 4 Wire: Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear
Stellar Prima *(NZ Market)* **1984-89 4 Cyl 1.6L 4G32 SOHC**			
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Stellar Prima *(NZ Market)* **1986-89 4 Cyl 2.0L 4G33 SOHC**			
Ignition – Distributor Cap	**JP558**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Terracan Incl. Highlander **11/01-1/07 V6 Cyl 3.5L G6CU DOHC 24V EPFI 4WD**			
Sensor – Air Flow / MAF	**CAF023**	1	
Sensor – Exhaust Oxygen	**COS938**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Terracan CRDi **1/05-on 4 Cyl 2.9L J3 DOHC 16V CRDi 4WD**			
Sensor – Air Flow / MAF	**CAF017**	1	
Tiburon **3/02-4/04 4 Cyl 2.0L Beta/G4GC DOHC 16V EPFI FWD**			
Ignition – Coil – Standard	**CC333**	1	
Sensor – Air Flow / MAF	**CAF026**	1	
Sensor – Exhaust Oxygen	**COS869**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Tiburon **3/02-1/07 V6 Cyl 2.7L Delta/G6BA DOHC 24V EPFI FWD**			
Sensor – Air Flow / MAF	**CAF025**	1	
Sensor – Air Temperature – Inlet	**CAT005**	1	
Trajet **5/00-on V6 Cyl 2.7L G6BAX DOHC 24V EPFI FWD**			
Sensor – Air Flow / MAF	**CAF025**	1	
Sensor – Air Temperature – Inlet	**CAT005**	1	
Sensor – Camshaft	**CSCA97**	1	Top Dead Centre
Sensor – Crankshaft	**CSCA33**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Valve – Idle Speed Control	**CIA012**	1	

Hyundai	Part No	Qty	Notes
Tucson **8/04-on V6 Cyl 2.7L G6BA3 DOHC 24V EPFI FT4WD**			
Sensor – Air Flow / MAF	**CAF025**	1	
Sensor – Air Temperature – Inlet	**CAT005**	1	
Sensor – Camshaft	**CSCA97**	1	Top Dead Centre
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA33**	1	
Valve – Idle Speed Control	**CIA012**	1	
Tucson City **10/05-on 4 Cyl 2.0L G4GC DOHC 16V EPFI 4WD**			
Ignition – Coil – Standard	**CC340**	1	
Sensor – Air Flow / MAF	**CAF025**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA31**	1	
Sensor – Exhaust Oxygen	**COS869**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Throttle Position	**CTPS108**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
International			
Acco A Series: B Series **1972-79 V8 Cyl**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**FO90**	1	Holley Points Distributor
Ignition – Distributor Condenser	**BC660**	1	Holley Points Distributor
Ignition – Distributor Points / Contact Set	**S84V**	1	Holley Points Distributor
Ignition – Distributor Rotor	**FO75**	1	Holley Points Distributor
Acco C Series **1980-84 V8 Cyl**			
Ignition – Distributor Cap	**BD162**	1	Autolite Electronic Distributor
Ignition – Distributor Rotor	**DR163**	1	Autolite Electronic Distributor
D Line **1972-79 6 Cyl 4.6L**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
D Line **1978-79 V8 Cyl**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**FO90**	1	Holley Points Distributor
Ignition – Distributor Condenser	**BC660**	1	Holley Points Distributor
Ignition – Distributor Points / Contact Set	**S84V**	1	Holley Points Distributor
Ignition – Distributor Rotor	**FO75**	1	Holley Points Distributor

International	Part No	Qty	Notes
V Series Truck V345: V392			
1978-83 V8 Cyl 345ci: 392ci			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD162**	1	Autolite Points Distributor
Ignition – Distributor Condenser	**BC868**	1	Autolite Points Distributor
Ignition – Distributor Points / Contact Set	**S85V**	1	Autolite Points Distributor
Ignition – Distributor Rotor	**DR163**	1	Autolite Points Distributor
V Series Truck V304: V345: V392: V404: V446: V537			
1980-on V8 Cyl 345ci: 392ci			
Ignition – Distributor Cap	**BD162**	1	Autolite Electronic Distributor
Ignition – Distributor Rotor	**DR163**	1	Autolite Electronic Distributor
Isuzu			
Bellet			
9/64-1/71 4 Cyl 1.5L: 1.6L Carb. RWD			
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**NC203**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Big Horn UBS13 *(NZ Market)*			
1981-87 4 Cyl 2.0L G200Z			
Ignition – Coil – Standard	**CC211**	1	Denso Points Distributor
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S214V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Big Horn UBS17 *(NZ Market)*			
7/88-3/92 4 Cyl 2.6L 4ZE1			
Ignition – Distributor Cap	**JP734**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR651**	1	Denso Electronic Distributor
Florain			
12/68-1/71 4 Cyl 1.6L Carb. RWD			
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**NC203**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
LUV KB20			
1972-77 4 Cyl 1.6L G161Z SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor: To 1974
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor: From 1974
Ignition – Distributor Condenser	**MC418**	1	Denso and Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor: To 1974
Ignition – Distributor Points / Contact Set	**S214V**	1	Denso Points Distributor: From 1974
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor: To 1974
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: From 1974
Sensor – Temperature Gauge	**CTS138**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
MU UCS17 *(NZ Market)*			
1989-93 4 Cyl 2.6L 4ZE1			
Ignition – Distributor Cap	**JP574**	1	Denso Electronic Distributor

Jaguar	Part No	Qty	Notes
420 **1966-71 6 Cyl 4.2L Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD250**	1	Lucas Points Distributor
E Type Series II **3/69-5/72 6 Cyl 4.2L DOHC Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD250**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS35**	1	
E Type Series III **6/72-10/74 V12 Cyl 5.3L SOHC Carb. RWD**			
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS35**	1	
Mk.10 **8/65-10/66 6 Cyl 4.2L Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD250**	1	Lucas Points Distributor
Sovereign **1/83-3/87 6 Cyl 4.2L 8L DOHC EFi RWD**			
Ignition – Module	**CM410**	1	
Sovereign **3/87-9/89 6 Cyl 3.6L 9DPBP DOHC 24V EFi RWD**			
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
V12 **11/89-1/93 V12 Cyl 5.3L 7P SOHC 24V EFi RWD**			
Sensor – Exhaust Oxygen	**COS748**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
XJ6 *(NZ Market)* **1968-87 6 Cyl 4.2L XK**			
Ignition – Coil – Standard	**CC211**	1	Lucas Points Distributor
Ignition – Distributor Cap	**BD286**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD250**	1	Lucas Points Distributor
XJ6 **4/69-11/73 6 Cyl 2.8L 7G DOHC 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD286**	1	Lucas Points Distributor: Std lead towers
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD250**	1	Lucas Points Distributor
Switch – Oil Pressure Warning Light	**CPS35**	1	

Jaguar	Part No	Qty	Notes
XJ6 Series I **1969-74 6 Cyl 4.2L DOHC Carb. RWD**			
Switch – Oil Pressure Warning Light	**CPS35**	1	
XJ6 Series II **1974-7/79 6 Cyl 4.2L Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD286**	1	Lucas Points Distributor: To 1976
Ignition – Distributor Cap	**BD290**	1	Lucas Points Distributor: From 1975
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: To 1976
Ignition – Distributor Condenser	**LC104**	1	Lucas Points Distributor: From 1975
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD250**	1	Lucas Points Distributor: To 1976
Ignition – Distributor Rotor	**BD287**	1	Lucas Points Distributor: From 1975
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS35**	1	
XJ6 Series III **8/79-3/87 6 Cyl 4.2L 8L DOHC EFi RWD**			
Ignition – Distributor Cap	**BD740**	1	Lucas Electronic Distributor: From 1980
Ignition – Distributor Rotor	**BD287**	1	Lucas Electronic Distributor: From 1980
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS35**	1	
XJ12 Series I: Series II **3/73-76 V12 Cyl 5.3L 7P SOHC 24V 4 x Carb. RWD**			
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS35**	1	
XJ12: XJR-S **11/92-10/94 V12 Cyl 6.0L 8C SOHC 24V EFi RWD**			
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS35**	1	
XJS **9/76-9/93 V12 Cyl 5.3L 7P SOHC 24V EFi RWD**			
Ignition – Module	**CM410**	1	From 11/1982
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS35**	1	
XJS Sport **2/92-10/95 6 Cyl 4.0L DOHC 24V EFi RWD**			
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
XJS **10/93-10/95 V12 Cyl 6.0L 8S SOHC 24V MPFi RWD**			
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
XJS *(NZ Market)* **1977-96 V12 Cyl**			
Ignition – Coil – Standard	**CC215**	1	Lucas Electronic Distributor
Ignition – Distributor Cap	**BD294**	1	Lucas Electronic Distributor

Jeep	Part No	Qty	Notes
Cherokee **3/79-4/85 V8 Cyl 5.9L OHV 16V Carb. 4WD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**DR102**	1	Delco Points Distributor
Ignition – Distributor Condenser	**DC10**	1	Delco Points Distributor
Ignition – Distributor Points / Contact Set	**S143V**	1	Delco Points Distributor
Ignition – Distributor Rotor	**DR65**	1	Delco Points Distributor: Standard Rotor
Ignition – Distributor Rotor	**DR1670**	1	Delco Points Distributor: Performance Rotor
Ignition – Distributor Rotor	**DR157**	1	Ford Electronic Distributor: From 1982
Cherokee JF4N *(NZ Market)* **1993-on 6 Cyl 4.0L MX**			
Ignition – Distributor Cap	**BD30**	1	Mopar – Electronic Distributor
Ignition – Distributor Rotor	**DR31**	1	Mopar – Electronic Distributor
Cherokee XJ **4/94-1/98 6 Cyl 4.0L MX OHV 12V EFi 4WD**			
Ignition – Distributor Cap	**BD30**	1	Mopar Electronic Distributor
Ignition – Distributor Rotor	**DR31**	1	Mopar Electronic Distributor
Sensor – Crankshaft	**CSCA27**	1	
Sensor – Exhaust Oxygen	**COS803**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS206**	1	To 1995
Grand Cherokee J4GZ *(NZ Market)* **1994-on 6 Cyl 4.0L MX**			
Ignition – Distributor Cap	**BD30**	1	Mopar – Electronic Distributor
Ignition – Distributor Rotor	**DR31**	1	Mopar – Electronic Distributor
Grand Cherokee ZG **3/96-7/99 6 Cyl 4.0L MX OHV 12V EFi 4WD**			
Ignition – Distributor Cap	**BD30**	1	Mopar Electronic Distributor
Ignition – Distributor Rotor	**DR31**	1	Mopar Electronic Distributor
Grand Cherokee WJ: WG **7/99-5/05 V8 Cyl 4.7L 8N SOHC 16V MPFi 4WD**			
Sensor – Camshaft	**CSCA105**	1	
Wrangler TJ **10/96-1/05 6 Cyl 4.0L MX OHV 12V MPFi 4WD**			
Ignition – Distributor Cap	**BD30**	1	Mopar Electronic Distributor
Ignition – Distributor Rotor	**DR31**	1	Mopar Electronic Distributor
Sensor – Exhaust Oxygen	**COS827**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Kia			
Carnival **9/99-12/01 V6 Cyl 2.5L KV6 DOHC 24V MPFi FWD**			
Sensor – Air Flow / MAF	**CAF016**	1	From 9/2000 To 7/2001
Sensor – Camshaft	**CSCA73**	1	
Sensor – Crankshaft	**CSCA74**	1	4 Speed Auto Transmission
Sensor – Throttle Position	**CTPS100**	1	
Switch – Brake Light	**CSL47**	1	To 7/2001

Kia	Part No	Qty	Notes
Credos			
5/98-4/01 4 Cyl 2.0L FE K2114 DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC335**	1	
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR792**	1	Mitsubishi Electronic Distributor
Sensor – Crankshaft	**CSCA12**	1	
Sensor – Exhaust Oxygen	**COS896**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Switch – Brake Light	**CSL47**	1	
Mentor			
12/96-5/98 4 Cyl 1.5L B5 SOHC 8V MPFi FWD			
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR792**	1	Mitsubishi Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT005**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Crankshaft	**CSCA77**	1	In Distributor
Sensor – Exhaust Oxygen	**COS906**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS59**	1	
Mentor			
5/98-6/00 4 Cyl 1.5L BF DOHC 16V MPFi FWD			
Sensor – Crankshaft	**CSCA192**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS100**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Mentor			
5/98-6/00 4 Cyl 1.8L TE DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC385**	4	
Sensor – Air Temperature – Inlet	**CAT005**	1	To 1/2001
Optima			
5/01-2/03 V6 Cyl 2.5L G6BV DOHC 24V ESPFI FWD			
Sensor – Air Flow / MAF	**CAF025**	1	
Pregio Diesel			
7/02-6/04 4 Cyl 2.7L J2 SOHC 8V Di RWD			
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Rio			
7/00-12/02 4 Cyl 1.5L A5D DOHC 16V MPFi FWD			
Sensor – Exhaust Oxygen	**COS926**	1	Direct Fit 4 Wire: Manifold
Sensor – Exhaust Oxygen	**COS927**	1	Direct Fit 4 Wire: Engine Pipe: To 7/2002
Sensor – Exhaust Oxygen	**COS915**	1	Direct Fit 4 Wire: Engine Pipe: From 7/2002
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Manifold and Engine Pipe
Sensor – Throttle Position	**CTPS100**	1	
Switch – Brake Light	**CSL47**	1	4 Speed Auto Transmission
Switch – Oil Pressure Warning Light	**CPS37**	1	
Shuma			
1/00-4/01 4 Cyl 1.8L TE DOHC 16V MPFi FWD			
Sensor – Air Temperature – Inlet	**CAT005**	1	To 1/2001
Sensor – Throttle Position	**CTPS100**	1	

Kia	Part No	Qty	Notes
Sorento **2/03-on V6 Cyl 3.5L G6CU DOHC 24V MPFi 4WD**			
Sensor – Air Flow / MAF	**CAF023**	1	
Sensor – Exhaust Oxygen	**COS938**	1	Direct Fit 4 Wire: LH and RH Side Front
Sensor – Exhaust Oxygen – Universal	**COS724**	4	Universal 4 Wire: LH and RH Side Front & Rear
Sportage **12/96-6/04 4 Cyl 2.0L FED DOHC 16V MPFi 4WD**			
Ignition – Coil – Standard	**CC334**	2	
Sensor – Camshaft	**CSCA100**	1	To 12/2002
Sensor – Crankshaft	**CSCA14**	1	To 3/1998
Sensor – Crankshaft	**CSCA12**	1	From 4/1998
Sensor – Knock Control	**CKS115**	1	To 12/2002
Sensor – Throttle Position	**CTPS100**	1	To 12/2002
Switch – Brake Light	**CSL47**	1	To 12/2002
Switch – Oil Pressure Warning Light	**CPS37**	1	To 12/2002
Switch – Radiator Fan	**CFS59**	1	
Sportage KM **4/05-on V6 Cyl 2.7L G6BA DOHC 24V EPFI 4WD**			
Sensor – Air Temperature – Inlet	**CAT005**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Valve – Idle Speed Control	**CIA012**	1	
Lada			
Niva 2121 *(NZ Market)* **1983-88 4 Cyl 1.6L**			
Ignition – Distributor Cap	**BD201**	1	UDS Points Distributor
Ignition – Distributor Rotor	**DR204**	1	UDS Points Distributor
Niva Carb **7/83-12/95 4 Cyl 1.6L SOHC Carb. 4WD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD201**	1	UDS Points Distributor: To 1987
Ignition – Distributor Condenser	**MC40**	1	UDS Points Distributor: To 1987
Ignition – Distributor Points / Contact Set	**S152V**	1	UDS Points Distributor: To 1987
Ignition – Module	**CM409**	1	
Niva 2105 *(NZ Market)* **1986-91 4 Cyl 1.5L**			
Ignition – Distributor Cap	**BD201**	1	UDS Points Distributor
Ignition – Distributor Rotor	**DR204**	1	UDS Points Distributor
Niva 2106 *(NZ Market)* **1988-89 4 Cyl 1.6L**			
Ignition – Distributor Cap	**BD201**	1	UDS Points Distributor
Ignition – Distributor Rotor	**DR204**	1	UDS Points Distributor
Niva EFi **9/90-6/95 4 Cyl 1.6L SOHC EFi 4WD**			
Ignition – Module	**CM409**	1	
Sensor – Temperature Gauge	**CTS132**	1	
Switch – Oil Pressure Warning Light	**CPS21**	1	
Switch – Radiator Fan	**CFS33**	1	
Samara 2104 *(NZ Market)* **1986-94 4 Cyl 1.5L VAZ21083**			
Ignition – Distributor Cap	**BD201**	1	UDS Points Distributor
Ignition – Distributor Rotor	**DR204**	1	UDS Points Distributor

Lada	Part No	Qty	Notes
Samara 2109 *(NZ Market)* **1986-96 4 Cyl 1.5L VAZ21083**			
Ignition – Distributor Cap	**BD201**	1	UDS Points Distributor
Ignition – Distributor Rotor	**DR204**	1	UDS Points Distributor
Samara 2108 *(NZ Market)* **1988-89 4 Cyl 1.5L VAZ21083**			
Ignition – Coil – Standard	**CC215**	1	UDS Points Distributor
Ignition – Distributor Cap	**BD201**	1	UDS Points Distributor
Ignition – Distributor Rotor	**DR204**	1	UDS Points Distributor
Samara **7/88-5/91 4 Cyl 1.3L 2108 SOHC Carb. FWD**			
Ignition – Distributor Rotor	**DR204**	1	UDS Electronic Distributor
Sensor – Temperature Gauge	**CTS132**	1	
Switch – Oil Pressure Warning Light	**CPS21**	1	
Switch – Radiator Fan	**CFS33**	1	
Lancia			
Beta **3/74-12/76 4 Cyl 1.8L DOHC Carb. FWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor: To 1975
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor: To 1975
Ignition – Distributor Rotor	**DR460**	1	Bosch Points Distributor: To 1975
Beta **6/76-5/82 4 Cyl 2.0L DOHC Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor: To 1977
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor: To 1977
Ignition – Distributor Rotor	**BH89**	1	Bosch Points Distributor: To 1977
Beta HPE **3/77-9/85 4 Cyl 2.0L 828BC1000 DOHC 2xCarb. FWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH136**	1	Bosch Electronic Distributor: From 1982
Ignition – Distributor Condenser	**DC10**	1	Marelli Points Distributor: From 1978 To 1982
Ignition – Distributor Points / Contact Set	**S156**	1	Marelli Points Distributor: From 1978 To 1982
Ignition – Distributor Rotor	**BH95**	1	Bosch Electronic Distributor: From 1982
Ignition – Module	**CM410**	1	From 1982
Landrover			
3.5 **3/81-12/91 V8 Cyl 3.5L Carb. 4WD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD280**	1	Lucas Points Distributor: To 1984
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: To 1984
Ignition – Distributor Points / Contact Set	**S261**	1	Lucas Points Distributor: To 1984
Ignition – Distributor Rotor	**DR71**	1	Lucas Points Distributor: To 1984

Landrover	Part No	Qty	Notes
110 **11/84-85 V8 Cyl 3.5L OHV Carb. 4WD**			
Ignition – Distributor Cap	**BD280**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD299**	1	Lucas Electronic Distributor
Sensor – Temperature Gauge	**CTS119**	1	
Defender 110 Turbo Diesel **3/92-3/99 4 Cyl 2.5L 11L OHV Di 4WD**			
Switch – Radiator Fan	**CFS84**	1	
Discovery **4/91-10/93 V8 Cyl 3.5L 22D OHV 16V EFi 4WD**			
Ignition – Distributor Cap	**JP832**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD299**	1	Lucas Electronic Distributor
Sensor – Coolant Temperature	**CCS35**	1	
Sensor – Temperature Gauge	**CTS119**	1	
Discovery *(NZ Market)* **1991-on V8 Cyl 3.5:3.9L 22D**			
Ignition – Distributor Cap	**BD280**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**DR71**	1	Lucas Points Distributor
Discovery Turbo Diesel **3/92-3/99 4 Cyl 2.5L 12L OHV 8V Di 4WD**			
Switch – Radiator Fan	**CFS84**	1	
Discovery **11/93-3/99 V8 Cyl 3.9L 38D OHV 16V MPFi 4WD**			
Ignition – Module	**CM476**	1	
Freelander **2/98-on 4 Cyl 1.8L K DOHC 16V MPFi 4WD**			
Ignition – Distributor Cap	**BD896**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD897**	1	Lucas Electronic Distributor
Series 1: 2: 2A: 3 **1956-12/80 4 Cyl 2.3L 4WD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD270**	1	Lucas Points Distributor: Series 2 & 2A
Ignition – Distributor Cap	**BD276**	1	Lucas Points Distributor: Series 3
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor
Series 2 **1968-70 6 Cyl 2.6L 4WD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: To 1969
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor: To 1969
Ignition – Distributor Rotor	**BD250**	1	Lucas Points Distributor: To 1969
Series 3 **6/72-12/80 6 Cyl 2.6L 4WD**			
Ignition – Distributor Cap	**BD286**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD250**	1	Lucas Points Distributor: To 1977
Sensor – Temperature Gauge	**CTS119**	1	

Lexus	Part No	Qty	Notes
ES300 VCV10R			
6/92-10/96 V6 Cyl 3.0L 3VZFE DOHC 24V EFi FWD			
Ignition – Coil – Standard	**CC276**	1	
Ignition – Module	**CM438**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS110**	1	
ES300 MCV20R			
10/96-9/01 V6 Cyl 3.0L 1MZFE DOHC 24V EFi FWD			
Ignition – Coil and Igniter	**CC384**	6	
Sensor – Camshaft	**CSCA159**	1	
Sensor – Crankshaft	**CSCA133**	1	
Sensor – Temperature Gauge	**CTS154**	1	
Sensor – Throttle Position	**CTPS154**	1	From 5/2000 To 7/2001
ES300 MCV30R			
10/01-on V6 Cyl 3.0L 1MZFE DOHC 24V EPFI FWD			
Ignition – Coil and Igniter	**CC384**	6	
Sensor – Camshaft	**CSCA103**	1	RH Side No 1
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA133**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: No 1 & No 2
Switch – Radiator Fan	**CFS69**	1	
GS300 JZS160R			
11/97-3/05 6 Cyl 3.0L 2JZGE DOHC 24V EFi RWD			
Ignition – Coil – Standard	**CC290**	3	
Sensor – Air Flow / MAF	**CAF034**	1	
Sensor – Exhaust Oxygen	**COS838**	1	Direct Fit 4 Wire: Manifold 1
Sensor – Exhaust Oxygen	**COS853**	1	Direct Fit 4 Wire: Pipe 1 and 2
Sensor – Exhaust Oxygen – Universal	**COS724**	4	Universal 4 Wire: Manifold and Pipe
GS300 GRS190R			
3/05-on V6 Cyl 3.0L 3GRFSE DOHC 24V EDPI RWD			
Sensor – Exhaust Oxygen	**COS894**	2	Direct Fit 4 Wire
Sensor – Knock Control	**CKS121**	1	
GS430 UZS190R			
3/05-on V8 Cyl 4.3L 3UZFE DOHC 32V ESPFI RWD			
Sensor – Air Flow / MAF	**CAF034**	1	
Sensor – Camshaft	**CSCA109**	1	
Sensor – Crankshaft	**CSCA135**	1	
Sensor – Exhaust Oxygen	**COS844**	1	Direct Fit 4 Wire: LH Side Manifold
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: LH and RH Side Manifold
Sensor – Knock Control	**CKS121**	1	
GS450h GWS191R Hybrid			
5/06-on V6 Cyl 3.5L 2GRFSE DOHC 24V MPFi RWD			
Sensor – Air Flow / MAF	**CAF034**	1	
Sensor – Camshaft	**CSCA147**	3	Rear
Sensor – Crankshaft	**CSCA138**	1	
Sensor – Exhaust Oxygen	**COS894**	1	Direct Fit 4 Wire: LH and RH Side
Sensor – Knock Control	**CKS121**	1	
IS200 GXE10R			
3/99-10/05 6 Cyl 2.0L 1GFE DOHC 24V ESPFI RWD			
Ignition – Coil and Igniter	**CC293**	6	
Sensor – Exhaust Oxygen	**COS858**	1	Direct Fit 4 Wire: Rear Manifold
Sensor – Exhaust Oxygen	**COS853**	1	Direct Fit 4 Wire: Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	3	Universal 4 Wire: Front & Rear Manifold & Pipe

Lexus	Part No	Qty	Notes
IS250 GSE20R			
11/05-on V6 Cyl 2.5L 4GRFSE DOHC 24V ESPFI RWD			
Sensor – Crankshaft	**CSCA138**	1	
Sensor – Exhaust Oxygen	**COS894**	2	Direct Fit 4 Wire: LH and RH Side Manifold
Sensor – Knock Control	**CKS121**	1	
IS300 JCE10R			
8/01-10/05 6 Cyl 3.0L 2JZGE DOHC 24V ESPFI RWD			
Ignition – Coil – Standard	**CC290**	3	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	4	Universal 4 Wire: Manifold and Exhaust Pipe
LS400 UCF10R			
5/90-10/94 V8 Cyl 4.0L 1UZFE DOHC 32V EFi RWD			
Ignition – Coil – Standard	**CC231**	2	Twin Distributor
Ignition – Module	**CM437**	2	Twin Distributor: To 11/1991
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS847**	1	Direct Fit 4 Wire: Front
Sensor – Exhaust Oxygen	**COS780**	1	Direct Fit 2 Wire: Rear: To 8/1992
Sensor – Exhaust Oxygen	**COS781**	1	Direct Fit 2 Wire With Flange: Rear: From 8/1992
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Front
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire: Rear: To 8/1992
Sensor – Exhaust Oxygen – Universal	**COS725**	1	Univ. 2 Wire With Flange: Rear: From 8/1992
Sensor – Temperature Gauge	**CTS110**	1	To 8/1992
Sensor – Temperature Gauge	**CTS154**	1	From 8/1992
LS400 UCF20R			
11/94-11/97 V8 Cyl 4.0L 1UZFE DOHC 32V EFi RWD			
Ignition – Coil – Standard	**CC231**	2	Twin Distributor
Ignition – Module	**CM436**	2	To 7/1997
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS844**	1	Direct Fit 4 Wire: Front
Sensor – Exhaust Oxygen	**COS853**	1	Direct Fit 4 Wire: Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear
Sensor – Temperature Gauge	**CTS154**	1	
Sensor – Throttle Position	**CTPS111**	1	Denso: To 7/1997
LS430 UCF30R			
11/00-on V8 Cyl 4.3L 3UZFE DOHC 32V MPFi RWD			
Ignition – Coil and Igniter	**CC293**	8	
Sensor – Camshaft	**CSCA118**	1	
Sensor – Crankshaft	**CSCA135**	1	
Sensor – Exhaust Oxygen	**COS844**	1	Direct Fit 4 Wire: LH Side Front
Sensor – Exhaust Oxygen	**COS871**	1	Direct Fit 4 Wire: Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	3	Universal 4 Wire: LH and RH Side Front: Rear
LS460 USF40R			
4/07-on V8 Cyl 4.6L 1URFSE DOHC 32V MPFi RWD			
Sensor – Camshaft	**CSCA147**	4	No.1
Sensor – Exhaust Oxygen	**COS894**	1	Direct Fit 4 Wire: LH and RH Side
Sensor – Knock Control	**CKS121**	1	

Lexus	Part No	Qty	Notes
LX470 UZJ100R			
5/98-on V8 Cyl 4.7L 2UZFE DOHC 32V MPFi 4WD			
Ignition – Coil and Igniter	**CC293**	8	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA135**	1	
Sensor – Exhaust Oxygen	**COS844**	1	Direct Fit 4 Wire: Front
Sensor – Exhaust Oxygen	**COS843**	1	Direct Fit 4 Wire With Flange: Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Front
Sensor – Exhaust Oxygen – Universal	**COS726**	1	Universal 4 Wire With Flange: Rear
Sensor – Temperature Gauge	**CTS154**	1	
RX330 MCU38R			
4/03-1/06 V6 Cyl 3.4L 3MZFE DOHC 24V MPFi 4WD			
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS895**	1	Direct Fit 4 Wire: Front and Rear Manifold
Sensor – Exhaust Oxygen	**COS867**	1	Direct Fit 4 Wire: Front Eng Pipe
Sensor – Exhaust Oxygen	**COS881**	1	Direct Fit 4 Wire: Rear Eng Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear Eng Pipe
Sensor – Knock Control	**CKS121**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
RX350 GSU35R			
2/06-on V6 Cyl 3.5L 2GRFE DOHC 24V MPFi 4WD			
Sensor – Camshaft	**CSCA147**	1	
Sensor – Coolant Temperature	**CCS52**	1	
Sensor – Crankshaft	**CSCA138**	1	
Sensor – Knock Control	**CKS121**	2	
Switch – Oil Pressure Warning Light	**CPS51**	1	
RX400h MHU38R Hybrid			
10/06-on V6 Cyl 3.3L 3MZFE DOHC 24V MPFi 4WD			
Sensor – Air Flow / MAF	**CAF034**	1	
SC430 UZZ40R			
10/01-on V8 Cyl 4.3L 3UZFE DOHC 32V MPFi RWD			
Ignition – Coil and Igniter	**CC293**	8	
Leyland			
Marina			
4/72-12/75 4 Cyl 1.5L: 1.7L SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD278**	1	Lucas Points Distributor: To 1974
Ignition – Distributor Cap	**BD276**	1	Lucas Points Distributor: From 1973 To 1974
Ignition – Distributor Cap	**BD288**	1	Lucas Points Distributor: From 1974
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: To 1974
Ignition – Distributor Condenser	**LC104**	1	Lucas Points Distributor: From 1974
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor: To 1974
Ignition – Distributor Points / Contact Set	**L24V**	1	Lucas Points Distributor: From 1974
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor: To 1974
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor: From 1973 To 1974
Ignition – Distributor Rotor	**BD287**	1	Lucas Points Distributor: From 1974
Sensor – Temperature Gauge	**CTS128**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	

Leyland	Part No	Qty	Notes
Marina			
4/72-12/75 6 Cyl 2.6L SOHC 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: To 1974
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor: To 1974
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor: To 1974
Sensor – Temperature Gauge	**CTS128**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Mini & Mini Moke Incl. Clubman			
3/66-12/83 4 Cyl 998cc: 1.1L: 1.3L OHV 8V Carb. FWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD278**	1	Lucas Points Distributor: From 1967 To 1974
Ignition – Distributor Cap	**BD276**	1	Lucas Points Distributor: From 1973 To 1974
Ignition – Distributor Cap	**BD288**	1	Lucas Points Distributor: From 1974
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: From 1967 To 1974
Ignition – Distributor Condenser	**LC104**	1	Lucas Points Distributor: From 1974
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor: From 1967 To 1974
Ignition – Distributor Points / Contact Set	**L24V**	1	Lucas Points Distributor: From 1974
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor: From 1967 To 1974
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor: From 1973 To 1974
Ignition – Distributor Rotor	**BD287**	1	Lucas Points Distributor: From 1974
Sensor – Temperature Gauge	**CTS128**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
P76			
1972-74 6 Cyl 2.6L Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS128**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
P76			
1972-74 V8 Cyl 4.4L Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD280**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD257**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS123**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	

Mallory Performance Distributors	Part No	Qty	Notes
YC: ZC Series Twin Point Distributor 6 Cyl with 3 LOBE DISTRIBUTOR CAM			
Ignition – Distributor Cap	**BD6**	1	
Ignition – Distributor Condenser	**UC11E**	1	
Ignition – Distributor Points / Contact Set	**S9100**	2	
Ignition – Distributor Rotor	**DR7**	1	
YC: ZC Series Twin Point Distributor V8 Cyl with 4 LOBE DISTRIBUTOR CAM			
Ignition – Distributor Condenser	**UC11E**	1	
Ignition – Distributor Points / Contact Set	**S9100**	2	
Ignition – Distributor Rotor	**DR7**	1	
YD: YL: ZD Series Twin Point Distributor 6 Cyl with 6 LOBE DISTRIBUTOR CAM			
Ignition – Distributor Cap	**AL105A**	1	
Ignition – Distributor Condenser	**BC3**	1	
Ignition – Distributor Points / Contact Set	**S9000**	2	
Ignition – Distributor Rotor	**DR105**	1	
YD: YL: ZD Series Twin Point Distributor V8 Cyl with 8 LOBE DISTRIBUTOR CAM			
Ignition – Distributor Cap	**BD2**	1	
Ignition – Distributor Cap	**BD65**	1	Inboard Marine Applications
Ignition – Distributor Condenser	**BC3**	1	
Ignition – Distributor Points / Contact Set	**S9000**	2	
Ignition – Distributor Rotor	**DR6500**	1	
Ignition – Distributor Rotor	**DR66**	1	Inboard Marine Applications
Mazda			
2 DY: DE 12/02-on 4 Cyl 1.5L ZY DOHC 16V EPFI FWD			
Sensor – Air Flow / MAF	**CAF033**	1	
3 BK 1/04-on 4 Cyl 2.0L MZR DOHC 16V EPFI FWD			
Sensor – Air Flow / MAF	**CAF033**	1	
Sensor – Camshaft	**CSCA160**	1	
Sensor – Coolant Temperature	**CCS40**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Manifold and Engine Pipe
3 BK SP23 1/04-on 4 Cyl 2.3L MZR DOHC 16V EPFI FWD			
Sensor – Air Flow / MAF	**CAF033**	1	
6 GY: GG 8/02-on 4 Cyl 2.3L LF DOHC 16V ESPFI FWD			
Sensor – Air Flow / MAF	**CAF033**	1	
Sensor – Camshaft	**CSCA160**	1	
6 GG Turbo 10/05-on 4 Cyl 2.3L L3 DOHC 16V ESPFI FWD			
Sensor – Camshaft	**CSCA160**	1	
30X EC (Eunos) 6/96-10/97 V6 Cyl 1.8L K8 DOHC 24V EFi FWD			
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	

Mazda	Part No	Qty	Notes
121 CD2: CD5			
3/76-12/80 4 Cyl 1.8L VC: 2.0L MA SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC412**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
121 DA			
3/87-11/90 4 Cyl 1.3L B3 SOHC 8V Carb. FWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Distributor Cap	**BD107**	1	Mitsubishi Electronic Distributor: To 3/1989
Ignition – Distributor Cap	**JP718**	1	Mitsubishi Electronic Distributor: From 4/1989
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Distributor: To 3/1989
Ignition – Distributor Rotor	**JR641**	1	Mitsubishi Electronic Distributor: From 4/1989
Ignition – Module	**CM405**	1	To 3/1989
Ignition – Module	**CM411**	1	From 4/1989
121 DA26: DA58: DA86 *(NZ Market)*			
1987-91 4 Cyl 1.1L B1: 1.3L B3			
Ignition – Distributor Cap	**JP680**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Distributor
121 DB3P *(NZ Market)*			
1990-94 4 Cyl 1.3L B3			
Ignition – Coil – Standard	**CC226**	1	Mitsubishi Electronic Distributor
121 DB: DW			
11/90-12/02 4 Cyl 1.3L B3: 1.5L B5 SOHC 16V EFi FWD			
Ignition – Distributor Cap	**JP403**	1	Mitsubishi Electronic Distributor: To 12/2000
Ignition – Distributor Rotor	**JR653**	1	Mitsubishi Electronic Distributor: To 12/2000
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS770**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS21**	1	
Switch – Radiator Fan	**CFS42**	1	DB Series
Switch – Radiator Fan	**CFS65**	1	DW Series
323 FA4			
3/77-12/81 4 Cyl 1.3L TC: 1.4L UC SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC409**	1	Mitsubishi Points Distributor: 1.3L
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor: 1.4L
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS112**	1	To Vin FA4PS516639 & FA4TS595883
Sensor – Temperature Gauge	**CTS159**	1	From Vin FA4PS516639 & F4TS595882
Switch – Oil Pressure Warning Light	**CPS23**	1	

Mazda	Part No	Qty	Notes
323 BD			
10/80-10/85 4 Cyl 1.3L E3: 1.5L E5 SOHC 8V Carb. & 2xCarb. FWD			
Ignition – Coil – Standard	**CIC32R**	1	Points ignition: To 12/1982
Ignition – Coil – Standard	**CC259**	1	Electronic ignition: From 12/1982
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Points ignition: To 12/1982
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Points ignition: To 12/1982
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor: To 1981
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor: From 1982
Ignition – Distributor Condenser	**MC417**	1	Mitsubishi Points Distributor: To 1981
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor: To 1981
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor: To 1981
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor: From 1982
Ignition – Module	**CM408**	1	Mitsubishi Electronic Distributor: From 12/1982
Ignition – Pickup / Trigger	**CIT110**	1	
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS26**	1	
323 BF			
10/85-10/89 4 Cyl 1.6L B6 SOHC 8V Carb. FWD			
Ignition – Coil – Standard	**CC259**	1	
Ignition – Distributor Cap	**JP684**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR619**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM405**	1	Mitsubishi Electronic Distributor
Ignition – Pickup / Trigger	**CIT111**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Temperature Gauge	**CTS111**	1	Leaded Fuel
Sensor – Temperature Gauge	**CTS110**	1	Unleaded Fuel
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS42**	1	
323 BF			
10/85-10/89 4 Cyl 1.6L B6 SOHC 8V MPFi FWD			
Ignition – Coil – Standard	**CC219**	1	
Ignition – Distributor Cap	**BD107**	1	
Ignition – Distributor Rotor	**JR617**	1	
Ignition – Module	**CM405**	1	
Ignition – Pickup / Trigger	**CIT106**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS736**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS111**	1	To 9/1987
Sensor – Temperature Gauge	**CTS110**	1	From 10/1987
Sensor – Throttle Position	**CTPS104**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS42**	1	
323 BF5P: BF5R: BFSP: BFSR: BT7J: BW6P *(NZ Market)*			
1985-93 4 Cyl 1.5L E5: B5 SOHC			
Ignition – Coil – Standard	**CC259**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
323 BFTP *(NZ Market)*			
1986-88 4 Cyl 1.3L B3 SOHC			
Ignition – Distributor Cap	**JP680**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Distributor

Mazda	Part No	Qty	Notes
323 BFMS: BFMP *(NZ Market)* **1987-89 4 Cyl 1.6L B6 DOHC EFi**			
Ignition – Distributor Cap	**JP718**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR627**	1	Mitsubishi Electronic Distributor
323 BWMR S/W *(NZ Market)* **1987-89 4 Cyl 1.6L B6 SOHC**			
Ignition – Distributor Cap	**JP680**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Distributor
323 BFMR Turbo *(NZ Market)* **1987-89 4 Cyl 1.6L B6T DOHC 4WD**			
Ignition – Distributor Cap	**JP684**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR619**	1	Mitsubishi Electronic Distributor
323 BF Turbo: Incl. 4WD **10/87-8/89 4 Cyl 1.6L B6T DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC219**	1	
Ignition – Distributor Cap	**JP706**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR625**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM425**	1	Mitsubishi Electronic Distributor
Ignition – Pickup / Trigger	**CIT106**	1	Mitsubishi Electronic Distributor: To 12/1988
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS736**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS111**	1	To 9/1988
Sensor – Temperature Gauge	**CTS115**	1	From 10/1988
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS42**	1	
323 BG *(NZ Market)* **1989-92 4 Cyl 1.3L B3 SOHC 16V**			
Ignition – Distributor Cap	**JP718**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR792**	1	Mitsubishi Electronic Distributor
323 Astina BG5P *(NZ Market)* **1989-93 4 Cyl 1.5L B5 DOHC 16V EFi**			
Ignition – Coil – Standard	**CC259**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
323 BG6R: BG6Z *(NZ Market)* **1989-93 4 Cyl 1.6L B6 SOHC 4WD**			
Ignition – Distributor Cap	**JP684**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR619**	1	Mitsubishi Electronic Distributor
323 BG3P: BG3S *(NZ Market)* **1989-94 4 Cyl 1.3L B3 SOHC 16V**			
Ignition – Coil – Standard	**CC226**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP680**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR133**	1	Mitsubishi Electronic Distributor
323 BG6P: BG6S *(NZ Market)* **1989-94 4 Cyl 1.6L B6 DOHC EFi**			
Ignition – Coil – Standard	**CC226**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP718**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR627**	1	Mitsubishi Electronic Distributor

Mazda	Part No	Qty	Notes
323 BG8P: BG8S *(NZ Market)* **1989-94 4 Cyl 1.8L BP DOHC EFi**			
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR627**	1	Mitsubishi Electronic Distributor
323 BG: BA **10/89-5/96 4 Cyl 1.6L B6 SOHC16V Carb. FWD**			
Ignition – Coil – Standard	**CC350**	1	
Ignition – Distributor Cap	**JP718**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR641**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM411**	1	Mitsubishi Electronic Distributor
Ignition – Pickup / Trigger	**CIT113**	1	Mitsubishi Electronic Distributor
Sensor – Temperature Gauge	**CTS110**	1	
323 BG **10/89-8/94 4 Cyl 1.8L BP DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC226**	1	
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR792**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM421**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS766**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
323 Astina BG8P Turbo *(NZ Market)* **1990-94 4 Cyl 1.8L BPT DOHC**			
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR627**	1	Mitsubishi Electronic Distributor
323 BG EFi *(NZ Market)* **1991-94 4 Cyl 1.3L B3 SOHC 16V**			
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR792**	1	Mitsubishi Electronic Distributor
323 BHA5P *(NZ Market)* **1993-96 4 Cyl 1.5L E5 DOHC 16V**			
Ignition – Distributor Cap	**BD132**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR133**	1	Mitsubishi Electronic Distributor
323 BA **7/94-9/98 4 Cyl 1.6L B6: 1.8L BP DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC253**	1	
Ignition – Distributor Cap	**BD132**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR133**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM411**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA67**	1	In Distributor
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	

Mazda	Part No	Qty	Notes
323 BA **7/94-9/98 V6 Cyl 2.0L KF DOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC252**	1	
Ignition – Distributor Cap	**BD134**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR135**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA49**	1	
Sensor – Exhaust Oxygen	**COS799**	1	Direct Fit 3 Wire: Front: To 8/1995
Sensor – Exhaust Oxygen	**COS907**	1	Direct Fit 3 Wire: Front: From 9/1995
Sensor – Exhaust Oxygen	**COS837**	1	Direct Fit 4 Wire: Rear: From 9/1995
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire: Front All and rear to 8/1995
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Rear: From 9/1995
Sensor – Knock Control	**CKS119**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS149**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
323 BJ10 **9/98-2/01 4 Cyl 1.6L ZMD DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC316**	2	
Sensor – Exhaust Oxygen	**COS908**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
323 BJ10 **9/98-2/01 4 Cyl 1.8L FPD DOHC 16V MPFi FWD**			
Sensor – Exhaust Oxygen	**COS909**	1	Direct Fit 4 Wire: Auto Transmission
Sensor – Exhaust Oxygen	**COS922**	1	Direct Fit 4 Wire: Manual Transmission
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
323 BJ20 **2/01-5/02 4 Cyl 1.6L ZM DOHC 16V MPFi FWD**			
Sensor – Camshaft	**CSCA91**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA155**	1	
Sensor – Exhaust Oxygen	**COS908**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
323 BJ20 **2/01-5/02 4 Cyl 1.8L FP DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC311**	1	
Sensor – Camshaft	**CSCA93**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA47**	1	
Sensor – Exhaust Oxygen	**COS909**	1	Direct Fit 4 Wire: Auto Transmission
Sensor – Exhaust Oxygen	**COS922**	1	Direct Fit 4 Wire: Manual Transmission
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	

Mazda	Part No	Qty	Notes
323 BJ20			
2/01-12/03 4 Cyl 2.0L FSD DOHC 16V MPFi FWD			
Ignition – Coil and Igniter	**CC311**	1	From 9/2002
Sensor – Camshaft	**CSCA93**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA47**	1	
Sensor – Exhaust Oxygen	**COS910**	1	Direct Fit 4 Wire: Before Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Before Catalyst
Switch – Oil Pressure Warning Light	**CPS37**	1	
500 GAEP *(NZ Market)*			
1992-95 V6 Cyl 2.0L KF			
Ignition – Distributor Cap	**BD134**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR135**	1	Mitsubishi Electronic Distributor
500 CA (Eunos)			
6/96-9/99 V6 Cyl 2.0L KF DOHC 24V MPFi FWD			
Ignition – Distributor Cap	**JP408**	1	
Ignition – Distributor Rotor	**JR405**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA49**	1	
Sensor – Exhaust Oxygen	**COS764**	1	Direct Fit 4 Wire: Front
Sensor – Exhaust Oxygen	**COS763**	1	Direct Fit 4 Wire: Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
626 CB			
12/78-2/83 4 Cyl 2.0L MA SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
626 GC			
2/83-10/87 4 Cyl 2.0L FE SOHC 8V Carb. FWD			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM408**	1	Mitsubishi Electronic Distributor
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS42**	1	
626 GG: GT: GV88 *(NZ Market)*			
1983-92 4 Cyl 1.8:2.0L F8: FE SOHC			
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor

Mazda	Part No	Qty	Notes
626 GC Turbo **1/86-10/87 4 Cyl 2.0L FE SOHC 8V SPFI FWD**			
Ignition – Pickup / Trigger	**CIT110**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS736**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS42**	1	
626 GD Turbo: 2WS & 4WS **10/87-12/91 4 Cyl 2.2L F2 SOHC 12V MPFi FWD**			
Ignition – Coil – Standard	**CC219**	1	
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR627**	1	Mitsubishi Electronic Distributor: To Chassis 8210
Ignition – Distributor Rotor	**DR792**	1	Mitsubishi Electronic Distributor: From Chassis 8210
Ignition – Module	**CM405**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Crankshaft	**CSCA69**	1	In Distributor
Sensor – Exhaust Oxygen	**COS736**	1	Direct Fit 1 Wire: To 12/1989
Sensor – Exhaust Oxygen	**COS768**	1	Direct Fit 1 Wire: From 1/1990
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS111**	1	To 10/1988
Sensor – Temperature Gauge	**CTS115**	1	From 10/1988 To 12/1989
Sensor – Temperature Gauge	**CTS110**	1	From 12/1989
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS61**	1	
626 GD **10/87-6/92 4 Cyl 2.2L F2 SOHC 12V MPFi FWD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP710**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR625**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM405**	1	From 6/1988
Ignition – Pickup / Trigger	**CIT107**	1	Mitsubishi Electronic Distributor: From 11/1989
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS768**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS42**	1	
626 GV90 *(NZ Market)* **1988-92 4 Cyl 2.0L FE DOHC EFi**			
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR627**	1	Mitsubishi Electronic Distributor

Mazda	Part No	Qty	Notes
626 GE **1/92-6/97 4 Cyl 2.0L FS DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC219**	1	External Coil
Ignition – Coil – Standard	**CC250**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP736**	1	Hitachi Electronic Distributor: To 5/1994
Ignition – Distributor Cap	**JP404**	1	Hitachi Electronic Distributor: From 6/1994
Ignition – Distributor Rotor	**JR653**	1	Hitachi Electronic Distributor: To 5/1994
Ignition – Distributor Rotor	**JR820**	1	Hitachi Electronic Distributor: From 6/1994
Ignition – Module	**CM421**	1	External Module
Ignition – Pickup / Trigger	**CIT107**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA09**	1	
Sensor – Exhaust Oxygen	**COS764**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS147**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
626 GE **1/92-6/97 V6 Cyl 2.5L KL DOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC250**	1	
Ignition – Distributor Cap	**JP726**	1	Mitsubishi Electronic Distributor: To 5/1994
Ignition – Distributor Cap	**BD134**	1	Mitsubishi Electronic Distributor: From 6/1994
Ignition – Distributor Rotor	**JR647**	1	Mitsubishi Electronic Distributor: To 5/1994
Ignition – Distributor Rotor	**DR135**	1	Mitsubishi Electronic Distributor: From 6/1994
Ignition – Module & Pickup / Trigger	**CSCA59**	1	From 3/1993
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS764**	1	Direct Fit 4 Wire: Front Pipe
Sensor – Exhaust Oxygen	**COS763**	1	Direct Fit 4 Wire: Rear Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear Pipe
Sensor – Knock Control	**CKS119**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS149**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS61**	1	
626 GESR: GFEP: GT5 *(NZ Market)* **1992-99 4 Cyl 2.0L FSDE DOHC EFi**			
Ignition – Distributor Rotor	**JR653**	1	Mitsubishi Electronic Distributor
626 GW72 S/W *(NZ Market)* **1993-97 4 Cyl 2.0L FE SOHC 12V**			
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
626 GT5JMN1 *(NZ Market)* **1995-99 V6 Cyl 2.5L KL SOHC 24V EFi**			
Ignition – Distributor Cap	**JP726**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR135**	1	Mitsubishi Electronic Distributor

Mazda	Part No	Qty	Notes
626 GF			
7/97-8/02 4 Cyl 2.0L FSD DOHC 16V SMPFI FWD			
Ignition – Coil – Standard	**CC240**	1	
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR627**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA09**	1	
Sensor – Exhaust Oxygen	**COS909**	1	Direct Fit 4 Wire: Auto Transmission
Sensor – Exhaust Oxygen	**COS922**	1	Direct Fit 4 Wire: Manual Transmission
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS147**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
808			
3/72-12/78 4 Cyl 1.3L TC: 1.6L NA SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor: To 1977
Ignition – Distributor Condenser	**MC412**	1	Mitsubishi Points Distributor: To 1977
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor: To 1977
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor: To 1977
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
929 LA: HB			
8/73-12/83 4 Cyl 1.8L VC: 2.0L MA SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC412**	1	Mitsubishi Points Distributor: 1.8L
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor: 2.0L
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS126**	1	2.0L: To 2/1982
Sensor – Temperature Gauge	**CTS112**	1	2.0L: From 3/1982
Switch – Oil Pressure Warning Light	**CPS23**	1	
929 HB			
2/84-6/87 4 Cyl 2.0L FE SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	To 1985
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	To 1985
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	To 1985
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor: To 1985
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor: From 1986
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor: To 1985
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor: From 1986
Ignition – Module	**CM408**	1	From 1986
Ignition – Pickup / Trigger	**CIT101**	1	From 1986
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS42**	1	
929 HB Turbo			
7/86-6/87 4 Cyl 2.0L FE SOHC 8V SPFI RWD			
Ignition – Module	**CM408**	1	
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS126**	1	

Mazda	Part No	Qty	Notes
929 HCFS *(NZ Market)* **1986-91 V6 Cyl 2.0L JF DOHC 18V EFi**			
Ignition – Distributor Cap	**JP678**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Denso Electronic Distributor
929 HC10E1: HC10E2 **6/87-8/91 V6 Cyl 3.0L JE SOHC 18V MPFi RWD**			
Ignition – Coil – Standard	**CC219**	1	
Ignition – Distributor Cap	**JP678**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR575**	1	Denso Electronic Distributor
Ignition – Module	**CM405**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS796**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	To 12/1989
Switch – Oil Pressure Warning Light	**CPS24**	1	From 1/1990
Switch – Radiator Fan	**CFS26**	1	
929 HC10E2 **1/90-8/91 V6 Cyl 3.0L JE41 DOHC 24V MPFi RWD**			
Ignition – Coil – Standard	**CC350**	1	
Ignition – Distributor Cap	**JP829**	1	
Ignition – Distributor Rotor	**JR804**	1	
Sensor – Air Temperature – Inlet	**CAT013**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS828**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL71**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
929 HD10E2: HE10E1 4WS **7/91-11/97 V6 Cyl 3.0L JE55: JEZE DOHC 24V MPFi RWD**			
Ignition – Coil – Standard	**CC350**	1	
Ignition – Module	**CM421**	1	
Sensor – Air Temperature – Inlet	**CAT013**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS763**	1	Direct Fit 4 Wire: LH Side
Sensor – Exhaust Oxygen	**COS764**	1	Direct Fit 4 Wire: RH Side
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: LH and RH Side
Switch – Brake Light	**CSL71**	1	
1200 **11/68-7/70 4 Cyl 1.2L TB SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**JP524**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S208**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR521**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Mazda	Part No	Qty	Notes
1300			
7/70-2/77 4 Cyl 1.3L TC SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Mitsubishi Points Distributor: To 1973
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor: From 1973
Ignition – Distributor Condenser	**MC418**	1	Mitsubishi Points Distributor: To 1973
Ignition – Distributor Condenser	**MC412**	1	Mitsubishi Points Distributor: From 1973
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor: From 1973
Ignition – Distributor Rotor	**JR517**	1	Mitsubishi Points Distributor: To 1973
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor: From 1973
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
1500			
10/66-10/71 4 Cyl 1.5L UB SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**MC418**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR521**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
1800			
9/69-7/73 4 Cyl 1.8L VB SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Mitsubishi Points Distributor
Autozam AZ3 EC5S *(NZ Market)*			
1991-95 4 Cyl 1.5L B5			
Ignition – Distributor Cap	**JP698**	1	
Ignition – Distributor Rotor	**DR792**	1	
B1600			
7/71-12/77 4 Cyl 1.6L NA SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
B1600 BNA61N, PE2 *(NZ Market)*			
1972-85 4 Cyl 1.6L NA SOHC			
Ignition – Coil – Standard	**CC211**	1	Mitsubishi Points Distributor
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor

Mazda	Part No	Qty	Notes
B1800 **10/77-11/82 4 Cyl 1.8L VC SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
B2000 **12/82-5/85 4 Cyl 2.0L MA SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
B2000 UT32 *(NZ Market)* **1982-85 4 Cyl 2.0L MA SOHC**			
Ignition – Coil – Standard	**CC211**	1	Mitsubishi Points Distributor
Ignition – Distributor Cap	**JP524**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR521**	1	Mitsubishi Points Distributor
B2000 **6/85-7/88 4 Cyl 2.0L FE SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
B2200 Diesel **1/81-5/85 4 Cyl 2.2L S2: 2.2L R2 SOHC 8V Di RWD**			
Sensor – Temperature Gauge	**CTS126**	1	To 5/1985
Sensor – Temperature Gauge	**CTS111**	1	From 1/1986
B2200 **3/88-2/93 4 Cyl 2.2L F2 SOHC 12V Carb. RWD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP680**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM405**	1	
Ignition – Pickup / Trigger	**CIT106**	1	To Vin 9701
Ignition – Pickup / Trigger	**CIT107**	1	From Vin 9701
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Mazda	Part No	Qty	Notes
B2500 Bravo Diesel: Turbo Diesel			
4/96-11/06 4 Cyl 2.5L WL: 2.5L WLT SOHC 12V Di RWD & 4WD			
Sensor – Temperature Gauge	**CTS110**	1	
B2600			
3/87-10/91 4 Cyl 2.6L 4G54 SOHC 8V Carb. 4WD			
Ignition – Coil – Standard	**CC202**	1	To 11/1989
Ignition – Coil – Standard	**CC209**	1	From 11/1989
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CM404**	1	
Sensor – Coolant Temperature	**CCS46**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
B2600 Bravo			
12/90-11/06 4 Cyl 2.6L G6: 2.6L G6E SOHC 12V EFi RWD & 4WD			
Ignition – Coil – Standard	**CC209**	1	
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR792**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM421**	1	
Sensor – Air Temperature – Inlet	**CAT013**	1	
Sensor – Coolant Temperature	**CCS46**	1	
Sensor – Crankshaft	**CSCA52**	1	
Sensor – Exhaust Oxygen	**COS779**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Temperature Gauge	**CTS115**	1	
Sensor – Throttle Position	**CTPS148**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Bongo SREAV *(NZ Market)*			
1985-90 4 Cyl 2.0L FE			
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Bongo SRE9W *(NZ Market)*			
1983-87 4 Cyl 2.0L FE			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
BT50 Turbo Diesel			
11/06-on 4 Cyl 2.5L WLAT: 3.0L WEAT DOHC 16V Di RWD			
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Capella			
10/70-12/78 4 Cyl 1.6L NA SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Mitsubishi Points Distributor: To 1973
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor: From 1973
Ignition – Distributor Condenser	**TC205**	1	Mitsubishi Points Distributor: To 1973
Ignition – Distributor Condenser	**MC418**	1	Mitsubishi Points Dist.: From 1973 To 1976
Ignition – Distributor Condenser	**MC412**	1	Mitsubishi Points Distributor: From 1976
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Mitsubishi Points Distributor: To 1973
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor: From 1973
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Mazda	Part No	Qty	Notes
Capella GC8P *(NZ Market)* **1982-87 4 Cyl 1.8L F8 SOHC 8V**			
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor
Capella GD8P *(NZ Market)* **1985-87 4 Cyl 1.8L F8 SOHC 8V**			
Ignition – Distributor Cap	**JP710**	1	Mitsubishi Electronic Distributor
Capella GD6P *(NZ Market)* **1987-91 4 Cyl 1.6L B6 SOHC**			
Ignition – Distributor Cap	**JP680**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR619**	1	Mitsubishi Electronic Distributor
Capella GDEP *(NZ Market)* **1987-91 4 Cyl 2.0L FE SOHC**			
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Capella GV8W Wagon *(NZ Market)* **1987-93 4 Cyl 1.8L F8 SOHC 8V**			
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Capella Van GV6V *(NZ Market)* **1988-92 4 Cyl 1.6L B6**			
Ignition – Distributor Cap	**JP718**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR641**	1	Mitsubishi Electronic Distributor
Capella GESR *(NZ Market)* **1991-94 4 Cyl 2.0L FS DOHC 4WD**			
Ignition – Distributor Rotor	**JR653**	1	Mitsubishi Electronic Distributor
Capella CG2SP *(NZ Market)* **1994-97 4 Cyl 2.0L FS DOHC**			
Ignition – Distributor Rotor	**JR653**	1	Mitsubishi Electronic Distributor
Cronos: MS6 GE8P *(NZ Market)* **1991-95 V6 Cyl 1.8L K8 DOHC**			
Ignition – Distributor Cap	**JP726**	1	Mitsubishi Electronic Distributor
Cronos: MS6 GEEP *(NZ Market)* **1991-95 V6 Cyl 2.0L KF DOHC 16V**			
Ignition – Distributor Cap	**BD134**	1	Mitsubishi Electronic Distributor
Cronos GE5P *(NZ Market)* **1992-94 V6 Cyl 2.5L KL DOHC EFi**			
Ignition – Distributor Cap	**JP726**	1	Mitsubishi Electronic Distributor
E1300: E1400 **5/78-12/83 4 Cyl 1.3L TC: 1.4L UC SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S217**	1	Mitsubishi Points Distributor: One of each required: 1.3L
Ignition – Distributor Points / Contact Set	**S367A**	1	Mitsubishi Points Distributor: One of each required: 1.3L
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor: 1.4L
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Mazda	Part No	Qty	Notes
E1600			
5/78-12/83 4 Cyl 1.6L NA SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC412**	1	Mitsubishi Points Distributor: To 1980
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor: From 1980
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
E1800			
2/84-1/88 4 Cyl 1.8L F8 SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
E1800			
11/90-12/96 4 Cyl 1.8L F8 SOHC 8V Carb. RWD			
Ignition – Distributor Cap	**JP680**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR617**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM405**	1	
Ignition – Pickup / Trigger	**CIT107**	1	
Sensor – Temperature Gauge	**CTS115**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
E1800			
2/03-7/06 4 Cyl 1.8L F8 SOHC 8V MPFi FWD			
Ignition – Coil – Standard	**CC209**	1	
Ignition – Distributor Cap	**JP698**	1	
Ignition – Distributor Rotor	**DR792**	1	
Ignition – Module	**CM421**	1	
Sensor – Air Temperature – Inlet	**CAT013**	1	
Sensor – Coolant Temperature	**CCS46**	1	
Sensor – Exhaust Oxygen	**COS902**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
E2000			
1/74-12/81 4 Cyl 2.0L VA SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP524**	1	Mitsubishi Points Distributor: To 1975
Ignition – Distributor Condenser	**TC205**	1	Mitsubishi Points Distributor: To 1975
Ignition – Distributor Points / Contact Set	**S360A**	1	Mitsubishi Points Distributor: To 1975
Ignition – Distributor Rotor	**JR521**	1	Mitsubishi Points Distributor: To 1975
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Mazda	Part No	Qty	Notes
E2000 **2/84-2/03 4 Cyl 2.0L FE SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Points Distributor: To 1988
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor: To 1988
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor: To 1988
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor: To 1988
Sensor – Temperature Gauge	**CTS111**	1	To 1/1990
Sensor – Temperature Gauge	**CTS115**	1	From 1/1990 To 11/1996
Sensor – Temperature Gauge	**CTS110**	1	From 11/1996
Switch – Oil Pressure Warning Light	**CPS25**	1	
E2000 **2/03-7/06 4 Cyl 2.0L FE SOHC 8V MPFi FWD**			
Ignition – Coil – Standard	**CC209**	1	
Ignition – Distributor Cap	**JP698**	1	
Ignition – Distributor Rotor	**DR792**	1	
Ignition – Module	**CM421**	1	
Sensor – Air Temperature – Inlet	**CAT013**	1	
Sensor – Coolant Temperature	**CCS46**	1	
Sensor – Exhaust Oxygen	**COS902**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
E2200 Diesel **5/81-8/97 4 Cyl 2.2L S2: 2.2L R2 SOHC 8V Di RWD**			
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
F1000 Bongo **1969-78 4 Cyl 1.0L PB Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP524**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S360A**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR521**	1	Mitsubishi Points Distributor
Familia BG5PS *(NZ Market)* **1989-93 4 Cyl 1.5L B5 DOHC 16V**			
Ignition – Distributor Cap	**JP710**	1	Mitsubishi Electronic Distributor
Familia BHALP *(NZ Market)* **1998-89 4 Cyl 1.5L Z5DE DOHC 16V**			
Ignition – Distributor Cap	**BD132**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR133**	1	Mitsubishi Electronic Distributor
Luce HBES: HBEP *(NZ Market)* **1983-88 4 Cyl 2.0L FE**			
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor

Mazda	Part No	Qty	Notes
MPV LV **10/93-8/99 V6 Cyl 3.0L JE SOHC 18V EFi RWD**			
Ignition – Coil – Standard	**CC219**	1	
Ignition – Distributor Cap	**JP813**	1	Mitsubishi Electronic Distributor: To 3/1996
Ignition – Distributor Rotor	**JR803**	1	Mitsubishi Electronic Distributor: To 3/1996
Ignition – Distributor Rotor	**DR135**	1	Mitsubishi Electronic Distributor: From 4/1996
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS826**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS149**	1	
Switch – Radiator Fan	**CFS61**	1	
MPV LW **8/99-6/02 V6 Cyl 2.5L GY DOHC 24V EFi RWD**			
Sensor – Crankshaft	**CSCA145**	1	
MS8 MB5A: MB5P *(NZ Market)* **1992-95 V6 Cyl 2.5L KL DOHC EFi**			
Ignition – Distributor Cap	**JP726**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR135**	1	Mitsubishi Electronic Distributor
MX5 NA **10/89-11/93 4 Cyl 1.6L B6 DOHC 16V MPFi RWD**			
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Crankshaft	**CSCA76**	1	From 8/1992
Sensor – Exhaust Oxygen	**COS766**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS104**	1	From 8/1992
Switch – Radiator Fan	**CFS65**	1	
MX5 NA **11/93-9/97 4 Cyl 1.8L BPD DOHC 16V MPFi RWD**			
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA76**	1	
Sensor – Exhaust Oxygen	**COS837**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Radiator Fan	**CFS65**	1	
MX5 NA: NB **3/98-8/05 4 Cyl 1.8L BPD DOHC 16V MPFi RWD**			
Sensor – Crankshaft	**CSCA75**	1	
Sensor – Exhaust Oxygen	**COS837**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
MX6 GD Turbo: 2WS & 4WS **10/87-9/91 4 Cyl 2.2L F2 SOHC 12V MPFi FWD**			
Ignition – Coil – Standard	**CC219**	1	
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR627**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM405**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS768**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS111**	1	To Vin 8B01
Sensor – Temperature Gauge	**CTS115**	1	From Vin 8B01
Switch – Oil Pressure Warning Light	**CPS25**	1	
Switch – Radiator Fan	**CFS61**	1	Auto Transmission
Switch – Radiator Fan	**CFS59**	1	Manual Transmission

Mazda	Part No	Qty	Notes
MX6 GE 4WS **11/91-9/97 V6 Cyl 2.5L KL DOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC252**	1	
Ignition – Distributor Cap	**JP726**	1	Mitsubishi Electronic Distributor: From 7/1994 To 10/1994
Ignition – Distributor Rotor	**JR647**	1	Mitsubishi Electronic Distributor: From 7/1994 To 10/1994
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA49**	1	
Sensor – Exhaust Oxygen	**COS764**	1	Direct Fit 4 Wire: Front Pipe
Sensor – Exhaust Oxygen	**COS763**	1	Direct Fit 4 Wire: Rear Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear Pipes
Sensor – Knock Control	**CKS119**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS149**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS61**	1	
MX6 GE 2WS **9/94-9/97 V6 Cyl 2.5L KL DOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC252**	1	
Ignition – Distributor Cap	**BD134**	1	
Ignition – Distributor Rotor	**DR135**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA49**	1	
Sensor – Exhaust Oxygen	**COS764**	1	Direct Fit 4 Wire: Front
Sensor – Exhaust Oxygen	**COS763**	1	Direct Fit 4 Wire: Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear
Sensor – Knock Control	**CKS119**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS149**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Premacy CP **2/01-6/03 4 Cyl 1.8L FP: 2.0L FSD DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC311**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA93**	1	Front
Sensor – Crankshaft	**CSCA47**	1	Rear
Sensor – Exhaust Oxygen	**COS910**	1	Direct Fit 4 Wire: Manifold
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Manifold
Sensor – Throttle Position	**CTPS147**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Proceed UV66R: UV66M *(NZ Market)* **1990-94 4 Cyl 2.6L G6**			
Ignition – Distributor Cap	**JP698**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR627**	1	Mitsubishi Electronic Distributor
R100 **6/69-12/71 2 Rotor 982cc 10A ROTARY Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**MC405**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S208**	1	Mitsubishi Points Distributor
Switch – Oil Pressure Warning Light	**CPS24**	1	

Mazda	Part No	Qty	Notes
RX2			
10/70-4/76 2 Rotor 1.1L 12A ROTARY Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	Use with resistor
Ignition – Coil – Standard	**CIC31**	1	Use without resistor
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	Use without resistor
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Use with resistor
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Use with resistor
Ignition – Distributor Cap	**JP540**	1	Mitsubishi Points Distributor: From 1974
Ignition – Distributor Condenser	**MC405**	2	Mitsubishi Points Distributor: Leading & Trailing Distributors: To 1973
Ignition – Distributor Condenser	**MC410**	1	Mitsubishi Points Distributor: From 1974
Ignition – Distributor Points / Contact Set	**S208**	2	Mitsubishi Points Distributor
Switch – Oil Pressure Warning Light	**CPS24**	1	
RX3			
3/72-3/76 2 Rotor 1.1L 12A ROTARY Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**JP540**	1	Mitsubishi Points Distributor: From 1973
Ignition – Distributor Condenser	**MC405**	2	Mitsubishi Points Distributor: Leading and Trailing Distributor: To 1973
Ignition – Distributor Condenser	**MC410**	1	Mitsubishi Points Distributor: From 1973
Ignition – Distributor Points / Contact Set	**S208**	2	Mitsubishi Points Distributor: Leading and Trailing Distributor: To 1973
Ignition – Distributor Points / Contact Set	**S217**	2	Mitsubishi Points Distributor: From 1973
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
RX4			
4/73-4/76 2 Rotor 1.1L 12A ROTARY Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	2	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	2	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	2	
Ignition – Distributor Condenser	**MC405**	2	Mitsubishi Points Distributor: To 1975
Ignition – Distributor Points / Contact Set	**S208**	2	Mitsubishi Points Distributor: To 1975
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
RX4			
4/73-6/79 2 Rotor 1.3L 13B ROTARY Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	2	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	2	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	2	
Ignition – Distributor Cap	**JP540**	1	Mitsubishi Points Distributor: From 1975
Ignition – Distributor Condenser	**MC411**	1	Mitsubishi Points Distributor: One of each required: From 1975
Ignition – Distributor Condenser	**MC410**	1	Mitsubishi Points Distributor: One of each required: From 1975
Ignition – Distributor Points / Contact Set	**S217**	2	Mitsubishi Points Distributor: From 1975
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	

Mazda	Part No	Qty	Notes
RX5 **7/76-6/79 2 Rotor 1.3L 13B ROTARY Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	2	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	2	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	2	
Ignition – Distributor Cap	**JP540**	1	Mitsubishi Twin Points Distributor: To 1978
Ignition – Distributor Condenser	**MC411**	1	Mitsubishi Twin Points Distributor: One of each required: To 1978
Ignition – Distributor Condenser	**MC410**	1	Mitsubishi Twin Points Distributor: One of each required: To 1978
Ignition – Distributor Points / Contact Set	**S217**	2	Mitsubishi Twin Points Distributor: To 1978
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
RX7 SA22 Series I: SA22 Series II: SA22 Series III **3/79-12/85 2 Rotor 1.1L 12A ROTARY Carb. RWD**			
Ignition – Distributor Cap	**JP570**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR557**	1	Mitsubishi Electronic Distributor
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS26**	1	
RX7 FC1032 Series IV Incl. Turbo **1/86-2/89 2 Rotor 1.3L 13B ROTARY MPFi RWD**			
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS115**	1	
RX7 FC1032 Series V Incl. Turbo **3/89-12/91 2 Rotor 1.3L 13B ROTARY MPFi RWD**			
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
RX7 FD1031 Series VI: FD1032 Series VII: FD1032 Series VIII Twin Turbo **1/92-2/99 2 Rotor 1.3L 13B ROTARY MPFi RWD**			
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA93**	1	
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL71**	1	
Switch – Radiator Fan	**CFS61**	1	
T2600 **4/85-12/88 4 Cyl 2.6L 4G54 SOHC 8V Carb. RWD**			
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
T3000 Diesel **1/84-10/84 4 Cyl 3.0L HA OHV 8V Di RWD**			
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
T3500 Diesel **5/84-4/97 4 Cyl 3.5L SL OHV 8V Di RWD**			
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
T4100 Diesel **1/84-12/91 6 Cyl 4.1L ZB OHV 12V Di RWD**			
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Mazda	Part No	Qty	Notes
Traveller			
1/83-5/84 4 Cyl 1.6L NA SOHC 8V Carb. RWD			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
Traveller			
6/84-12/87 4 Cyl 1.8L F8 SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Sensor – Temperature Gauge	**CTS112**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Traveller			
8/86-3/88 4 Cyl 2.0L FE SOHC 8V Carb. RWD			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Sensor – Temperature Gauge	**CTS111**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
Tribute			
2/01-1/04 4 Cyl 2.0L YF DOHC 16V MPFi 4WD			
Ignition – Coil – Standard	**CC239**	1	
Sensor – Camshaft	**CSCA108**	1	
Mercedes			
180E W201			
10/91-3/94 4 Cyl 1.8L 102.910 SOHC 8V EFi RWD			
Ignition – Coil – Standard	**CC364**	1	
Sensor – Exhaust Oxygen	**COS794**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
190E W201			
12/84-12/90 4 Cyl 2.0L 102.962 SOHC 8V EFi RWD			
Ignition – Coil – Standard	**CC364**	1	
Ignition – Distributor Cap	**BH126**	1	Bosch Electronic Distributor: To 1985
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor: To 1985
Sensor – Exhaust Oxygen	**COS795**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
190E W201			
6/87-3/91 6 Cyl 2.6L 103.942 SOHC 12V EFi RWD			
Ignition – Coil – Standard	**CC364**	1	
Sensor – Exhaust Oxygen	**COS795**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
190E W201			
9/90-12/92 4 Cyl 1.8L 102.910 SOHC 8V EFi RWD			
Ignition – Coil – Standard	**CC364**	1	
Sensor – Exhaust Oxygen	**COS794**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire

Mercedes	Part No	Qty	Notes
190E W201			
9/90-12/92 4 Cyl 2.3L 102.985 SOHC 8V EFi RWD			
Ignition – Coil – Standard	**CC364**	1	
Sensor – Exhaust Oxygen	**COS794**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
190E W201			
11/92-1/94 4 Cyl 2.0L 102.962 SOHC 8V EFi RWD			
Ignition – Coil – Standard	**CC364**	1	
Sensor – Exhaust Oxygen	**COS795**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
220E W124			
3/93-8/93 4 Cyl 2.2L DOHC 16V EFi RWD			
Sensor – Exhaust Oxygen	**COS814**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
230 W123			
11/76-7/81 4 Cyl 2.3L 115.954 SOHC Carb. RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC147**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S4V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
230.4 W115			
1974-76 4 Cyl 2.3L SOHC Carb. RWD			
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor
230.6 W114			
11/73-11/76 6 Cyl 2.3L 180.954 SOHC 2xCarb. RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC147**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S4V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
230E W123			
7/81-12/85 4 Cyl 2.3L 102.980 SOHC EFi RWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH126**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor
230E W124			
2/86-2/93 4 Cyl 2.3L 102.982 SOHC 8V EFi RWD			
Ignition – Coil – Standard	**CC364**	1	
Ignition – Distributor Cap	**BH126**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor
Sensor – Exhaust Oxygen	**COS758**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
230GE			
5/86-12/89 4 Cyl 2.3L 102.981/988 SOHC EFi 4WD			
Ignition – Distributor Cap	**BH126**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor

Mercedes	Part No	Qty	Notes
230TE W123			
12/83-7/86 4 Cyl 2.3L SOHC EFi RWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH126**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
230TE W124			
8/86-4/89 4 Cyl 2.3L SOHC EFi RWD			
Ignition – Coil – Standard	**CC364**	1	
Ignition – Distributor Cap	**BH126**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor
Sensor – Exhaust Oxygen	**COS758**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
250: 250C W114			
6/68-3/72 6 Cyl 2.5L 114.92SOHC Carb: 2.5L 130.923 SOHC 2xCarb. RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC63**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S4V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
250			
9/72-10/76 6 Cyl 2.8L SOHC 2xCarb. RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH140**	1	Bosch Points Distributor: From 1975
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor: From 1974
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor: From 1975
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor: From 1974
Ignition – Distributor Rotor	**BH177**	1	Bosch Points Distributor: From 1975
250CE			
6/69-3/72 6 Cyl 2.5L SOHC Fi RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC63**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S4V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
260E W124			
8/88-3/91 6 Cyl 2.6L 103.94 SOHC 12V EFi RWD			
Ignition – Coil – Standard	**CC364**	1	
Sensor – Exhaust Oxygen	**COS758**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
280			
10/72-12/76 6 Cyl 2.7L DOHC Carb. RWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH128**	1	Bosch Points Distributor: From 1975
Ignition – Distributor Rotor	**BH129**	1	Bosch Points Distributor: From 1975
280C			
10/72-12/73 6 Cyl 2.8L DOHC Carb. RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH128**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC842**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH129**	1	Bosch Points Distributor

Mercedes	Part No	Qty	Notes
280CE **10/72-10/73 6 Cyl 2.8L DOHC Fi RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC147**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S3**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
280CE **11/73-10/76 6 Cyl 2.8L DOHC Fi RWD**			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH128**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC842**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH129**	1	Bosch Points Distributor
280CE W123 **11/77-2/86 6 Cyl 2.8L DOHC 24V EFi RWD**			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH166**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH177**	1	Bosch Electronic Distributor
280E W123 **11/76-2/86 6 Cyl 2.8L 110.984/985 DOHC 24V EFi RWD**			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH128**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH129**	1	Bosch Points Distributor
280S **3/68-12/73 6 Cyl 2.8L SOHC Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC147**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S3**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
280SE W126 & 280TE S123 **6/80-3/86 6 Cyl 2.8L DOHC 24V EFi RWD**			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH166**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH177**	1	Bosch Electronic Distributor
300E W124 & 300CE C124 **3/86-2/93 6 Cyl 3.0L SOHC 12V EFi RWD**			
Ignition – Coil – Standard	**CC364**	1	
Sensor – Air Flow / MAF	**CAF010**	1	
Sensor – Exhaust Oxygen	**COS758**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
300E W124 **3/93-8/93 6 Cyl 2.8L DOHC EFi RWD**			
Sensor – Exhaust Oxygen	**COS814**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
300SE W126 **4/86-4/92 6 Cyl 3.0L SOHC 12V EFi RWD**			
Ignition – Coil – Standard	**CC364**	1	

Mercedes	Part No	Qty	Notes
300SE W140 **3/92-9/93 6 Cyl 3.2L DOHC 24V EFi RWD**			
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
300SEb: 300SEL **1/66-6/68 6 Cyl 3.0L Fi RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
300SEL **1/70-12/73 V8 Cyl 3.5L SOHC Fi RWD**			
Ignition – Distributor Cap	**BH150**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH153**	1	Bosch Points Distributor
300SEL W126 **3/87-3/92 6 Cyl 3.0L SOHC 12V EFi RWD**			
Sensor – Air Flow / MAF	**CAF010**	1	
Sensor – Exhaust Oxygen	**COS758**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
300TE W124 **3/93-8/93 6 Cyl 2.8L DOHC 24V EFi RWD**			
Sensor – Exhaust Oxygen	**COS814**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
320E W124 **2/93-8/93 6 Cyl 3.2L M104 DOHC 24V EFi RWD**			
Sensor – Exhaust Oxygen	**COS814**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
380SE W126 & 380SEC C126 & 380SEL W126 & 380SL **12/80-3/86 V8 Cyl 3.9L SOHC 16V EFi RWD**			
Ignition – Coil – Standard	**CC364**	1	
Ignition – Distributor Cap	**BH130**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH153**	1	Bosch Electronic Distributor
400SE: 400SEL W140 **3/92-8/93 V8 Cyl 4.2L DOHC 32V EFi RWD**			
Sensor – Exhaust Oxygen	**COS816**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
450SE: 450SEL: 450SL: 450SLC W116 **1/73-12/80 V8 Cyl 4.5L SOHC 16V EFi RWD**			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH130**	1	Bosch Points and Electronic Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor: To 1975
500SEL W140 **3/92-8/93 V8 Cyl 5.0L DOHC 32V EFi RWD**			
Sensor – Exhaust Oxygen	**COS816**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
600 **1/63-12/78 V8 Cyl 6.3L OHC Fi RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Standard	**CC212**	1	From 1971 To 1976
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH150**	1	Bosch Points Distributor: From 1965 To 1976
Ignition – Distributor Rotor	**BH153**	1	Bosch Points Distributor: From 1965 To 1976

Mercedes	Part No	Qty	Notes
600SEL W140			
3/92-8/93 V12 Cyl 6.0L M120.080 DOHC 48V EFi RWD			
Sensor – Exhaust Oxygen	**COS816**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
A140 W168			
2/00-6/01 4 Cyl 1.4L M166 SOHC 8V MPFi FWD			
Sensor – Exhaust Oxygen	**COS870**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
A160 W168			
10/98-4/05 4 Cyl 1.6L M166 SOHC 8V MPFi RWD			
Sensor – Exhaust Oxygen	**COS870**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
A190 W168			
9/99-4/05 4 Cyl 1.9L SOHC 8V MPFi FWD			
Sensor – Exhaust Oxygen	**COS870**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
C36 AMG W202			
10/95-7/97 6 Cyl 3.6L M104 DOHC 24V MPFi RWD			
Sensor – Air Flow / MAF	**CAF010**	1	
Sensor – Air Flow / MAF	**CAF003**	1	
C180 W202			
2/94-11/00 4 Cyl 1.8L M111 DOHC 16V MPFi RWD			
Sensor – Air Flow / MAF	**CAF008**	1	
Sensor – Exhaust Oxygen	**COS846**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
C180 W203: C180 CL203			
11/00-9/02 4 Cyl 2.0L DOHC 16V EPFI RWD			
Sensor – Exhaust Oxygen	**COS870**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
C200T W202			
10/96-10/00 4 Cyl 2.0L M111 DOHC 16V EFi RWD			
Sensor – Air Flow / MAF	**CAF008**	1	
C230 W202			
11/96-8/97 4 Cyl 2.3L M111 DOHC 16V EFi RWD			
Sensor – Air Flow / MAF	**CAF008**	1	
C280 W202			
3/94-10/00 6 Cyl 2.8L M104.941 DOHC 24V MPFi RWD			
Sensor – Air Flow / MAF	**CAF010**	1	To 9/1997
Sensor – Air Flow / MAF	**CAF003**	1	From 9/1997
Sensor – Exhaust Oxygen	**COS818**	1	Direct Fit 4 Wire: Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear
CL55 C215 AMG			
7/01-2/03 V8 Cyl 5.5L DOHC 24V MPFi RWD			
Sensor – Exhaust Oxygen	**COS870**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
CL500 C215			
3/00-3/07 V8 Cyl 5.0L SOHC 24V MPFi RWD			
Sensor – Exhaust Oxygen	**COS816**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
CLK200 A208			
10/00-1/04 4 Cyl 2.0L M111.940 DOHC 16V MPFi RWD			
Sensor – Air Flow / MAF	**CAF008**	1	

Mercedes	Part No	Qty	Notes
E36 S210			
5/96-7/97 6 Cyl 3.6L M104.992 DOHC 24V MPFi RWD			
Sensor – Air Flow / MAF	**CAF003**	1	
Sensor – Air Flow / MAF	**CAF010**	1	
Sensor – Exhaust Oxygen	**COS814**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
E220 W124			
9/93-2/96 4 Cyl 2.2L M111.960 DOHC 16V EFi RWD			
Sensor – Exhaust Oxygen	**COS814**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
E230 W210			
2/96-5/98 4 Cyl 2.3L M111.970 DOHC 16V MPFi RWD			
Sensor – Exhaust Oxygen	**COS876**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
E240 S210: W210			
11/99-8/02 V6 Cyl 2.4L M112.911 SOHC 18V MPFi RWD			
Sensor – Air Flow / MAF	**CAF003**	1	
E320 W124			
9/93-2/96 6 Cyl 3.2L M104.992 DOHC 24V EFi RWD			
Sensor – Exhaust Oxygen	**COS814**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
E320 W210			
2/96-6/98 6 Cyl 3.2L M104.992 DOHC 24V MPFi RWD			
Sensor – Exhaust Oxygen	**COS864**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
E320 W210			
8/97-8/02 V6 Cyl 3.2L M112.941 SOHC 18V MPFi RWD			
Sensor – Air Flow / MAF	**CAF003**	1	
Sensor – Exhaust Oxygen	**COS864**	1	Direct Fit 4 Wire: LH Side Before Catalyst
Sensor – Exhaust Oxygen	**COS841**	1	Direct Fit 4 Wire: RH Side Before Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: LH Side Before Catalyst
E320 S210: S211 & E320T S210			
7/97-8/02 V6 Cyl 3.2L M112.941 SOHC 18V MPFi RWD			
Sensor – Air Flow / MAF	**CAF003**	1	
E430 W210			
1/98-8/02 V8 Cyl 4.3L SOHC 24V MPFi RWD			
Sensor – Air Flow / MAF	**CAF011**	1	
ML320 W163			
9/98-4/03 V6 Cyl 3.2L M112 SOHC 18V MPFi RWD			
Sensor – Air Flow / MAF	**CAF003**	1	
Sensor – Exhaust Oxygen	**COS875**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
ML430 W163			
3/99-10/01 V8 Cyl 4.3L M113 SOHC 24V EPFI FT4WD			
Sensor – Exhaust Oxygen	**COS870**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
ML500 W164			
9/05-10/07 V8 Cyl 5.0L SOHC 24V MPFi 4WD			
Sensor – Exhaust Oxygen	**COS870**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire

Mercedes	Part No	Qty	Notes
S280 W140			
10/95-4/99 6 Cyl 2.8L M104.944 DOHC 24V MPFi RWD			
Sensor – Air Flow / MAF	**CAF010**	1	
S350 W220			
3/03-2/06 V6 Cyl 3.7L SOHC 18V MPFi RWD			
Sensor – Exhaust Oxygen	**COS870**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
S600L W140			
9/93-4/99 V12 Cyl 6.0L DOHC 48V MPFi RWD			
Sensor – Exhaust Oxygen	**COS816**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
S600L W220 Turbo			
3/03-2/06 V12 Cyl 5.5L SOHC 36V MPFi RWD			
Sensor – Exhaust Oxygen	**COS870**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
SL280 R129			
11/95-4/99 6 Cyl 2.8L M104.943 DOHC 24V MPFi RWD			
Sensor – Air Flow / MAF	**CAF010**	1	
Sensor – Exhaust Oxygen	**COS816**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
SL320 R129			
3/99-7/02 V6 Cyl 3.2L SOHC 18V MPFi RWD			
Sensor – Air Flow / MAF	**CAF003**	1	
Sensor – Exhaust Oxygen	**COS840**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
SL350 R230			
10/03-4/06 V6 Cyl 3.8L M119 SOHC 18V MPFi RWD			
Sensor – Exhaust Oxygen	**COS870**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
SL500 R230			
7/02-4/06 V8 Cyl 5.0L SOHC 24V MPFi RWD			
Sensor – Exhaust Oxygen	**COS875**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
SLK200 W170			
11/97-11/00 4 Cyl 2.0L M111.946 DOHC 16V MPFi RWD			
Sensor – Air Flow / MAF	**CAF008**	1	
Sensor – Exhaust Oxygen	**COS839**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
SLK200 W202 S/Charged			
7/00-7/04 4 Cyl 2.0L DOHC 16V MPFi RWD			
Sensor – Air Flow / MAF	**CAF008**	1	
SLK230 W170: W202 S/Charged			
2/97-7/04 4 Cyl 2.3L M111.973 DOHC 16V MPFi RWD			
Sensor – Air Flow / MAF	**CAF008**	1	
Sensor – Exhaust Oxygen	**COS839**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Vito 113 V638			
2/98-3/04 4 Cyl 2.0L M111.948 DOHC 16V EPFI FWD			
Sensor – Exhaust Oxygen	**COS841**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire

Mercedes	Part No	Qty	Notes
Vito 119 V639 **4/04-on V6 Cyl 3.2L SOHC 18V EFi RWD**			
Sensor – Exhaust Oxygen	**COS870**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
MG			
MGA **1956-63 4 Cyl 1.6L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD268**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor
Switch – Oil Pressure Warning Light	**CPS35**	1	
MGB Mk.I **1963-68 4 Cyl 1.8L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD268**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor
MGB Mk.II **9/68-6/70 4 Cyl 1.8L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD278**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS128**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
MGB GT V8 **8/73-12/76 V8 Cyl 3.5L OHV 16V 2xCarb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD280**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**DR71**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
MGF 1.8i **3/97-11/00 4 Cyl 1.8L DOHC 16V MPFi RWD**			
Ignition – Distributor Cap	**BD896**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD897**	1	Lucas Electronic Distributor

MG	Part No	Qty	Notes
Midget Mk.III **1968-72 4 Cyl 1.3L OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD268**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor: To 1970
Ignition – Distributor Rotor	**BD287**	1	Lucas Points Distributor: From 1971
Switch – Oil Pressure Warning Light	**CPS31**	1	
Midget Mk.III **12/74-79 4 Cyl 1.5L RWD**			
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Mini			
Cooper R50 **3/02-2/07 4 Cyl 1.6L W10B SOHC 16V MPFI FWD**			
Sensor – MAP	**CMS227**	1	In Suction Pipe
Cooper S R50 S/Charged **5/02-8/04 4 Cyl 1.6L W11B SOHC 16V MPFI FWD**			
Sensor – MAP	**CMS230**	1	In Manifold
Sensor – MAP	**CMS227**	1	In Suction Pipe
Mitsubishi			
380 DB Incl. Series II: Series III **9/05-4/08 V6 Cyl 3.8L 6G75 SOHC 24V ESPFI FWD**			
Sensor – Crankshaft	**CSCA161**	1	
Switch – Brake Light	**CSL71**	1	
Switch – Clutch Pedal	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
3000GT JF **10/92-3/98 V6 Cyl 3.0L 6G72 DOHC 24V EFi 4WD**			
Ignition – Coil – Standard	**CC382**	3	Coil only
Sensor – Coolant Temperature	**CCS33**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS29**	1	
Canter FC212 **1/84-3/86 4 Cyl 2.6L 4G54 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC414**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Canter FC432 **4/86-7/92 4 Cyl 2.6L 4G54 SOHC 8V Carb. RWD**			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC414**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor

Mitsubishi	Part No	Qty	Notes
Challenger K96 *(NZ Market)* **1996-on V6 Cyl 3.0L 6G72**			
Ignition – Distributor Cap	**BD100**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR639**	1	Mitsubishi Electronic Distributor
Challenger PA **3/98-3/07 V6 Cyl 3.0L 6G72 SOHC 24V MPFi 4WD**			
Ignition – Coil – Standard	**CC314**	2	With Black Connector
Ignition – Coil – Standard	**TBA**	1	With White Connector
Sensor – Camshaft	**CSCA110**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA37**	1	To 5/2003
Sensor – Crankshaft	**CSCA162**	1	From 6/2003
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Auto Transmission
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS151**	1	With Cruise Control
Sensor – Throttle Position	**CTPS150**	1	Without Cruise Control: To 6/2001
Sensor – Throttle Position	**CTPS152**	1	With & Without Cruise Control: From 6/2001
Switch – Oil Pressure Warning Light	**CPS50**	1	
Switch – Radiator Fan	**CFS22**	1	
Valve – Idle Speed Control	**CIA015**	1	
Chariot DX3: DX4: D05W *(NZ Market)* **1984-91 4 Cyl 1.75L 4G37 SOHC 8V**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP564**	1	
Ignition – Distributor Rotor	**JR533**	1	
Chariot DO8W *(NZ Market)* **1984-93 4 Cyl 2.0L 4G63B 4WD**			
Ignition – Distributor Cap	**JP648**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Chariot N33W *(NZ Market)* **3/91-5/92 4 Cyl 2.0L 4G63 SOHC 8V**			
Ignition – Distributor Cap	**JP718**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR806**	1	Mitsubishi Electronic Distributor
Chariot N33W *(NZ Market)* **6/92-1/95 4 Cyl 2.0L 4G63 SOHC 8V**			
Ignition – Distributor Cap	**JP815**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR814**	1	Mitsubishi Electronic Distributor
Chariot N34W: N44W *(NZ Market)* **1993-98 4 Cyl 2.4L 4G64**			
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR611**	1	Mitsubishi Electronic Distributor
Chariot N33W *(NZ Market)* **1/95-4/96 4 Cyl 2.0L 4G63 SOHC 8V**			
Ignition – Distributor Cap	**JP815**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR814**	1	Mitsubishi Electronic Distributor

Mitsubishi	Part No	Qty	Notes
Colt RA **1/81-10/82 4 Cyl 1.4L 4G12 SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS22**	1	
Colt RB: RC: RD: RE **10/82-6/90 4 Cyl 1.4L 4G33: 1.6L 4G32 SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH90**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC100**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS22**	1	
Colt Z2 **8/04-on 4 Cyl 1.5L 4G15 DOHC 16V MPFi FWD**			
Sensor – Coolant Temperature	**CCS39**	1	
Colt RG **9/04-2/06 4 Cyl 1.5L 4G15 DOHC 16V MPFi FWD**			
Sensor – Camshaft	**CSCA148**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA163**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: LH & RH Side Manifold
Switch – Oil Pressure Warning Light	**CPS50**	1	
Colt RG **3/06-3/07 4 Cyl 1.5L 4A91 DOHC 16V MPFi FWD**			
Sensor – Camshaft	**CSCA151**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Colt RG Turbo **7/06-on 4 Cyl 1.5L 4A91 DOHC 16V MPFi FWD**			
Sensor – Camshaft	**CSCA148**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA163**	1	
Colt RZ Turbo **11/06-on 4 Cyl 1.5L 4G15 DOHC 16V MPFi FWD**			
Sensor – Camshaft	**CSCA148**	1	
Sensor – Crankshaft	**CSCA163**	1	
Sensor – Exhaust Oxygen	**COS887**	1	Direct Fit 4 Wire: After Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: After Catalyst
Colt RZ **11/06-on 4 Cyl 1.5L 4A91 DOHC 16V MPFi FWD**			
Sensor – Camshaft	**CSCA151**	1	

Mitsubishi	Part No	Qty	Notes
Cordia AA **4/83-10/84 4 Cyl 1.6L 4G32 SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC423**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS108**	1	
Cordia 3H24: 5Z24 Incl. Turbo *(NZ Market)* **1983-87 4 Cyl 1.6L 4G32**			
Ignition – Coil – Standard	**CC211**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP558**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Cordia AA: AB: AC Turbo **3/84-7/89 4 Cyl 1.8L 4G62 SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Ignition – Pickup / Trigger	**CIT122**	1	
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Exhaust Oxygen	**COS746**	1	Direct Fit 1 Wire: From 12/1985
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: From 12/1985
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Radiator Fan	**CFS22**	1	
Cordia AB: AC **11/84-7/89 4 Cyl 1.8L 4G37 SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CM404**	1	
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Radiator Fan	**CFS22**	1	
Cordia CX: CY: CZ *(NZ Market)* **1985-87 4 Cyl 1.8L 4G37**			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Delica PO4W: PO24W *(NZ Market)* **1988-96 4 Cyl 2.4L 4G64**			
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR611**	1	Mitsubishi Electronic Distributor
Diamante F36A *(NZ Market)* **1995-99 4 Cyl 3.0L 6G72 DOHC 16V**			
Ignition – Distributor Cap	**BD100**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR639**	1	Mitsubishi Electronic Distributor
Eterna E12A *(NZ Market)* **1983-85 4 Cyl 1.8L 4G37B**			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR517**	1	Mitsubishi Electronic Distributor

Mitsubishi	Part No	Qty	Notes
Express SF: SG: SH Carb **10/86-9/94 4 Cyl 2.0L 4G63 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC232**	1	
Ignition – Distributor Cap	**JP652**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT109**	1	Denso Electronic Distributor
Sensor – Temperature Gauge	**CTS110**	1	
Express SF: SG: SH EFi **10/86-9/94 4 Cyl 2.4L 4G64 SOHC 8V EFi RWD & 4WD**			
Ignition – Coil – Standard	**CC220**	1	To 5/1994
Ignition – Coil – Standard	**CC281**	1	From 6/1994
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR611**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Exhaust Oxygen	**COS757**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS100**	1	To 5/1994
Sensor – Throttle Position	**CTPS150**	1	From 6/1994
Switch – Coolant Temperature Warning Light	**CTS163**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Express SF: SG: SH: SJ Diesel **1/88-9/03 4 Cyl 2.5L 4D56 SOHC 8V Di RWD**			
Sensor – Temperature Gauge	**CTS162**	1	
Express WA EFi **9/94-2/06 4 Cyl 2.4L 4G64 SOHC 16V EFi RWD**			
Ignition – Distributor Cap	**JP816**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR806**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Coolant Temperature Warning Light	**CTS163**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Express SJ Carb **10/94-10/03 4 Cyl 2.0L 4G63 SOHC 16V Carb. RWD**			
Ignition – Coil – Standard	**CC281**	1	To 6/1995
Ignition – Coil – Standard	**CC232**	1	From 7/1995 To 6/1996
Ignition – Coil – Standard	**CC281**	1	From 7/1996
Ignition – Distributor Cap	**JP816**	1	Mitsubishi Electronic Distributor: To 6/1995
Ignition – Distributor Cap	**JP652**	1	Denso Electronic Dist.: From 7/1995 To 6/1996
Ignition – Distributor Cap	**JP816**	1	Mitsubishi Electronic Distributor: From 7/1995
Ignition – Distributor Rotor	**JR641**	1	Mitsubishi Electronic Distributor: To 6/1995
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Dist.: From 7/1995 To 6/1996
Ignition – Distributor Rotor	**JR641**	1	Mitsubishi Electronic Distributor: From 7/1995
Ignition – Module	**CM475**	1	Mitsubishi Electronic Distributor
Ignition – Pickup / Trigger	**CIT109**	1	Denso Electronic Distributor
Sensor – Temperature Gauge	**CTS110**	1	
Express SJ EFi 4WD **10/94-2/01 4 Cyl 2.4L 4G64 SOHC 16V EFi 4WD**			
Ignition – Module	**CM475**	1	
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Temperature Gauge	**CTS110**	1	

Mitsubishi	Part No	Qty	Notes
Express SJ EFi RWD			
10/94-10/03 4 Cyl 2.4L 4G64 SOHC 16V EFi RWD			
Ignition – Coil – Standard	**CC281**	1	
Ignition – Distributor Cap	**JP816**	1	Mitsubishi Electronic Distributor: To 9/2000
Ignition – Distributor Rotor	**JR806**	1	Mitsubishi Electronic Distributor: To 9/2000
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS100**	1	
Sensor – Throttle Position	**CTPS150**	1	
Switch – Coolant Temperature Warning Light	**CTS163**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Express SJ EFi			
11/03-2/06 4 Cyl 2.0L 4G63 SOHC 16V EFi RWD			
Ignition – Coil – Standard	**CC281**	1	
Ignition – Module	**CM422**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Express SJ EFi			
3/06-on 4 Cyl 2.4L 4G64 SOHC 16V EFi RWD			
Sensor – Camshaft	**CSCA87**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS150**	1	
Galant E15A Turbo *(NZ Market)*			
1983-85 4 Cyl 2.0L 4G63BT			
Ignition – Coil – Standard	**CC211**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP558**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Galant E12A *(NZ Market)*			
1983-86 4 Cyl 1.8L 4G37B			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Galant E31A *(NZ Market)*			
1987-92 4 Cyl 1.6L 4G32 SOHC 8V			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Galant E32A *(NZ Market)*			
1988-91 4 Cyl 1.8L 4G37 SOHC 8V			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Galant E33A *(NZ Market)*			
1989-91 4 Cyl 2.0L 4G63 DOHC 16V			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Galant SB1M41G *(NZ Market)*			
1988-93 4 Cyl 1.6L 4G32 SOHC 8V			
Ignition – Distributor Cap	**JP648**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Galant SB3: SC3 *(NZ Market)*			
1988-93 4 Cyl 1.8L 4G37 SOHC 8V			
Ignition – Coil – Standard	**CC259**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP648**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor

Mitsubishi	Part No	Qty	Notes
Galant SB541G: SB6P41G *(NZ Market)* **6/88-93 4 Cyl 2.0L 4G63 SOHC 8V**			
Ignition – Coil – Standard	**CC202**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Galant HG SOHC **5/89-8/90 4 Cyl 2.0L 4G63 SOHC 8V MPFi FWD**			
Ignition – Coil – Standard	**CC220**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR611**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Exhaust Oxygen	**COS742**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS48**	1	
Galant HG: HH Incl. Turbo: DOHC **5/89-3/93 4 Cyl 2.0L 4G63 DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC233**	1	
Ignition – Module	**CM441**	1	From 6/1990
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Exhaust Oxygen	**COS762**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS100**	1	
Switch – Brake Light	**CSL54**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS48**	1	
Galant HH SOHC **9/90-12/92 4 Cyl 2.0L 4G63 SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC220**	1	
Ignition – Distributor Cap	**JP718**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR806**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Crankshaft	**CSCA01**	1	Module inside Crank Sensor: From 5/1992 To 10/1992
Sensor – Exhaust Oxygen	**COS742**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS100**	1	From 1991
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS48**	1	
Galant HJ **4/93-3/95 4 Cyl 2.0L 4G63 SOHC 16V EFi FWD**			
Ignition – Distributor Cap	**JP831**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR814**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Exhaust Oxygen	**COS783**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL54**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	

Mitsubishi	Part No	Qty	Notes
Galant HJ **4/93-10/96 V6 Cyl 2.0L 6A12 DOHC 24V EFi FWD**			
Ignition – Coil – Standard	**CC312**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Exhaust Oxygen	**COS752**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Grandis BA **5/04-6/06 4 Cyl 2.4L 4G69 SOHC 16V EFi FWD**			
Sensor – Camshaft	**CSCA148**	1	
Sensor – Crankshaft	**CSCA153**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: LH and RH Side Manifold:
From 6/2005			
GTO Z16 Incl. Turbo *(NZ Market)* **1990-94 6 Cyl 3.0L 6G72**			
Ignition – Distributor Cap	**BD100**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR639**	1	Mitsubishi Electronic Distributor
L200 Express MA: MB: MC **3/80-8/84 4 Cyl 1.6L 4G32 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC423**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
L200 Express MA: MB **7/81-9/82 4 Cyl 2.0L 4G52 SOHC 8V Carb. RWD & 4WD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor: To 1981
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor: To 1981
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
L200 Express MC **10/82-9/84 4 Cyl 2.0L 4G63 SOHC 8V Carb. RWD & 4WD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP568**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Denso Electronic Distributor
Ignition – Module	**CM408**	1	
Ignition – Pickup / Trigger	**CIT112**	1	
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
L200 Express MD **9/84-10/86 4 Cyl 2.0L 4G63 SOHC 8V Carb. RWD & 4WD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Ignition – Module	**CM408**	1	
Ignition – Pickup / Trigger	**CIT112**	1	
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Mitsubishi	Part No	Qty	Notes
L200 K13T *(NZ Market)* **1986-92 4 Cyl 2.6L 4G54 SOHC 8V**			
Ignition – Coil – Standard	**CC202**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
L200 JNK *(NZ Market)* **1993-01 V6 Cyl 3.0L 6G72**			
Ignition – Distributor Rotor	**JR639**	1	Mitsubishi Electronic Distributor
L200 K65 *(NZ Market)* **1997-on 4 Cyl 2.4L 4G64**			
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR611**	1	Mitsubishi Electronic Distributor
L300 Express SA: SB: SC: SD: SE **4/80-10/86 4 Cyl 1.6L 4G32 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC423**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
L300 Express SB: SC: SD **10/82-6/85 4 Cyl 1.8L 4G62 SOHC 8V Carb. RWD & 4WD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP648**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
L300 LO32PV *(NZ Market)* **1982-87 4 Cyl 1.6L 4G32 SOHC 8V**			
Ignition – Coil – Standard	**CC211**	1	Mitsubishi Points Distributor
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC423**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
L300 LO65 *(NZ Market)* **1983-87 4 Cyl 1.8L 4G62**			
Ignition – Coil – Standard	**CC211**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP558**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
L300 Express SE **7/85-10/86 4 Cyl 2.0L 4G63 SOHC 8V Carb. RWD & 4WD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP652**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT109**	1	
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	

Mitsubishi	Part No	Qty	Notes
L300 P Series 2WD & 4WD *(NZ Market)* **1987-92 4 Cyl 2.0L 4G63 SOHC 8V**			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor: Clip Down Cap
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Dist.: Screw Down Cap
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor: Clip Down Cap
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Dist.: Screw Down Cap
L300 PG5P *(NZ Market)* **1992-97 4 Cyl 2.4L 4G64 SOHC 8V**			
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Lancer C11A *(NZ Market)* **1984-88 4 Cyl 1.3L 4G13B**			
Ignition – Distributor Cap	**JP558**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Lancer C12A *(NZ Market)* **1984-88 4 Cyl 1.5L 4G15B**			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR517**	1	Mitsubishi Electronic Distributor
Lancer S/W C37V.W 4WD *(NZ Market)* **1986-92 4 Cyl 1.8L 4G37**			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Lancer CA **9/88-8/90 4 Cyl 1.5L 4G15 SOHC 12V Carb. FWD**			
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CM404**	1	To 5/1990
Lancer C62A *(NZ Market)* **1988-91 4 Cyl 1.5L 4G15 SOHC 12V**			
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Lancer CA **4/89-8/90 4 Cyl 1.5L 4G15 SOHC 12V EFi FWD**			
Ignition – Coil – Standard	**CC220**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR611**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Exhaust Oxygen	**COS746**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS100**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS29**	1	
Lancer LB3M41 *(NZ Market)* **1989-92 4 Cyl 1.3L 4G13**			
Ignition – Distributor Cap	**JP558**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor

Mitsubishi	Part No	Qty	Notes
Lancer LB5H41 *(NZ Market)* **1989-92 4 Cyl 1.5L 4G15 SOHC 8V**			
Ignition – Coil – Standard	**CIC32R**	1	Mitsubishi Points Distributor
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Mitsubishi Points Distributor
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Mitsubishi Points Distributor
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC409**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Lancer C12W: C32V *(NZ Market)* **1990-92 4 Cyl 1.5L 4G15**			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Lancer CB: CC **9/90-7/96 4 Cyl 1.5L 4G15 SOHC 12V Carb. FWD**			
Ignition – Distributor Cap	**JP830**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR641**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM428**	1	
Ignition – Pickup / Trigger	**CIT113**	1	
Lancer CB **9/90-9/92 4 Cyl 1.5L 4G15 SOHC 12V EFi FWD**			
Ignition – Coil – Standard	**CC246**	1	
Ignition – Distributor Cap	**JP814**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR886**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS33**	1	
Sensor – Crankshaft	**CSCA78**	1	In Distributor: Optic Type
Sensor – Crankshaft	**CSCA11**	1	In Distributor: Hall Type
Sensor – Exhaust Oxygen	**COS783**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS100**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS29**	1	
Lancer CB **9/90-9/92 4 Cyl 1.6L 4G61 DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC233**	1	
Ignition – Module	**CM441**	1	
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Crankshaft	**CSCA01**	1	
Sensor – Crankshaft	**CSCA01B**	1	Kit Supplied With Bearing
Sensor – Exhaust Oxygen	**COS742**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS100**	1	To 5/1992
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS29**	1	

Mitsubishi	Part No	Qty	Notes
Lancer CC **9/92-7/96 4 Cyl 1.6L 4G92 SOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC246**	1	
Ignition – Distributor Cap	**JP815**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR814**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM441**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA62**	1	In Distributor
Sensor – Exhaust Oxygen	**COS783**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS29**	1	Automatic Transmission
Switch – Radiator Fan	**CFS11**	1	Manual Transmission
Lancer CC **9/92-7/96 4 Cyl 1.8L 4G93 SOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC246**	1	
Ignition – Distributor Cap	**JP815**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR814**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA62**	1	In Distributor
Sensor – Exhaust Oxygen	**COS783**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Radiator Fan	**CFS29**	1	Automatic Transmission
Switch – Radiator Fan	**CFS11**	1	Manual Transmission
Lancer CC Turbo **11/92-7/96 4 Cyl 1.8L 4G93 DOHC 16V EFi 4WD**			
Ignition – Coil – Standard	**CC244**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA01**	1	
Sensor – Crankshaft	**CSCA01B**	1	Kit Supplied With Bearing
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Radiator Fan	**CFS29**	1	Automatic Transmission
Switch – Radiator Fan	**CFS11**	1	Manual Transmission
Lancer CE **7/96-1/03 4 Cyl 1.5L 4G15 SOHC 12V MPFi FWD**			
Ignition – Coil – Standard	**CC242**	1	
Ignition – Distributor Cap	**JP817**	1	Mitsubishi Electronic Distributor: To 8/2001
Ignition – Distributor Rotor	**JR815**	1	Mitsubishi Electronic Distributor: To 8/2001
Ignition – Module & Pickup / Trigger	**CSCA58**	1	In Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Exhaust Oxygen	**COS783**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – MAP	**CMS214**	1	To 5/1998
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Radiator Fan	**CFS29**	1	
Lancer CE **7/96-1/03 4 Cyl 1.8L 4G93 SOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC315**	2	To 8/2001
Sensor – Camshaft	**CSCA87**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA40**	1	
Sensor – Temperature Gauge	**CTS110**	1	

Mitsubishi	Part No	Qty	Notes
Lancer CG			
7/02-9/03 4 Cyl 2.0L 4G94 SOHC 16V EPFI FWD			
Ignition – Coil and Igniter	**CC315**	2	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA152**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Lancer CZ EVO VIII Turbo			
6/04-6/05 4 Cyl 2.0L 4G63T DOHC 16V MPFi AWD			
Sensor – Camshaft	**CSCA87**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Manifold
Sensor – Temperature Gauge	**CTS110**	1	
Lancer CY EVO IX Turbo			
8/05-9/07 4 Cyl 2.0L 4G63T DOHC 16V MPFi AWD			
Sensor – Camshaft	**CSCA87**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Lancer CH			
8/05-on 4 Cyl 2.4L 4G69 DOHC 16V MPFi FWD			
Sensor – Camshaft	**CSCA148**	1	
Sensor – Crankshaft	**CSCA153**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Magna TM: TN: TP: TR: TS Carb			
5/85-3/96 4 Cyl 2.6L 4G54 SOHC 8V Carb. FWD			
Ignition – Coil – Standard	**CC215**	1	Oil Filled Coil
Ignition – Coil – Standard	**CC218**	1	Transformer Coil
Ignition – Distributor Cap	**BH122**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH121**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL54**	1	With Cruise Control
Switch – Brake Light	**CSL47**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS22**	1	To 3/1994
Switch – Radiator Fan	**CFS29**	1	From 3/1994
Magna TN: TP: TR: TS			
4/87-3/96 4 Cyl 2.6L 4G54 SOHC 8V MPFi FWD			
Ignition – Coil – Standard	**CC218**	1	Transformer coil
Ignition – Distributor Cap	**BH122**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH227**	1	Bosch Electronic Distributor
Ignition – Module	**CM422**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS746**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS113**	1	From 4/1991
Switch – Brake Light	**CSL54**	1	With Cruise Control
Switch – Brake Light	**CSL47**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS22**	1	To 4/1991
Switch – Radiator Fan	**CFS48**	1	From 4/1991 To 3/1994
Switch – Radiator Fan	**CFS29**	1	From 3/1994

Mitsubishi	Part No	Qty	Notes
Magna TR: TS **4/93-3/96 V6 Cyl 3.0L 6G72 SOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC218**	1	
Ignition – Distributor Cap	**BD100**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR639**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS33**	1	
Sensor – Crankshaft	**CSCA51**	1	In Distributor
Sensor – Exhaust Oxygen	**COS752**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS113**	1	
Switch – Brake Light	**CSL54**	1	With Cruise Control
Switch – Brake Light	**CSL47**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS48**	1	To 3/1994
Switch – Radiator Fan	**CFS29**	1	From 3/1994
Magna TF2M4 *(NZ Market)* **1994-99 4 Cyl 2.4L 4G64**			
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR611**	1	Mitsubishi Electronic Distributor
Magna TE: TF **4/96-3/99 4 Cyl 2.4L 4G64S4 SOHC 16V MPFi FWD**			
Ignition – Distributor Cap	**JP837**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR815**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA60**	1	Mitsubishi Electronic Distributor
Sensor – Exhaust Oxygen	**COS752**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL54**	1	With Cruise Control
Switch – Brake Light	**CSL47**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS37**	1	
Magna TE: TF: TH: TJ **4/96-8/02 V6 Cyl 3.0L 6G72S4 SOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC352**	1	Mitsubishi Electronic Distributor: To 5/1997
Ignition – Coil – Standard	**CC242**	1	Mitsubishi Electronic Distributor: From 6/1997
Ignition – Distributor Cap	**JP819**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR135**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CSCA66**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA38**	1	From 3/1999
Sensor – Exhaust Oxygen	**COS752**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS151**	1	
Switch – Brake Light	**CSL54**	1	With Cruise Control
Switch – Brake Light	**CSL47**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS37**	1	
Valve – Idle Speed Control	**CIA015**	1	

Mitsubishi	Part No	Qty	Notes
Magna TH: TJ: TJ Series II **3/99-7/03 V6 Cyl 3.5L 6G74S4 SOHC 24V MPFi FWD & AWD**			
Ignition – Coil – Standard	**CC242**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP819**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR135**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CSCA66**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA38**	1	
Sensor – Exhaust Oxygen	**COS752**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS152**	1	With Cruise
Sensor – Throttle Position	**CTPS151**	1	LPG
Switch – Oil Pressure Warning Light	**CPS37**	1	
Valve – Idle Speed Control	**CIA015**	1	
Magna TL Incl. LPG **6/03-9/04 V6 Cyl 3.5L 6G74 SOHC 24V MPFi FWD & AWD**			
Ignition – Coil – Standard	**CC242**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP819**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR135**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CSCA66**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS152**	1	With Cruise Control
Sensor – Throttle Position	**CTPS151**	1	Without Cruise Control
Switch – Brake Light	**CSL71**	1	With Cruise Control
Switch – Brake Light	**CSL72**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS37**	1	
Magna TW **10/04-9/05 V6 Cyl 3.5L 6G74 SOHC 24V MPFi FWD**			
Ignition – Coil – Standard	**CC242**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP819**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR135**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CSCA66**	1	Mitsubishi Electronic Distributor
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS152**	1	With Cruise Control
Sensor – Throttle Position	**CTPS151**	1	Without Cruise Control
Mirage C13A Turbo *(NZ Market)* **1982-87 4 Cyl 1.6L 4G32BT**			
Ignition – Coil – Standard	**CC211**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR517**	1	Mitsubishi Electronic Distributor
Mirage C11A: C51A *(NZ Market)* **1982-90 4 Cyl 1.3L 4G13**			
Ignition – Distributor Cap	**JP558**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Mirage MA3L *(NZ Market)* **1984-88 4 Cyl 1.3L 4G13**			
Ignition – Coil – Standard	**CC211**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP558**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Mirage C52A: C62A *(NZ Market)* **1987-90 4 Cyl 1.5L 4G15**			
Ignition – Coil – Standard	**CC220**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor

Mitsubishi	Part No	Qty	Notes
Mirage MA3L45: MH3L *(NZ Market)* **1988-93 4 Cyl 1.3L 4G13**			
Ignition – Distributor Cap	**JP558**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Mirage MB5: MC5: MF5 *(NZ Market)* **1989-92 4 Cyl 1.5L 4G15 SOHC**			
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Mirage CA: CB: CC: LJ: LK *(NZ Market)* **1991-95 4 Cyl 1.3L 4G13 SOHC 12V**			
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor
Mirage CJ1A: CK1A *(NZ Market)* **1995-99 4 Cyl 1.3L 4G13**			
Ignition – Distributor Cap	**JP558**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Mirage CE **7/96-8/04 4 Cyl 1.5L 4G15 SOHC 12V MPFi FWD**			
Ignition – Distributor Cap	**JP817**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR815**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CSCA58**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Exhaust Oxygen	**COS783**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – MAP	**CMS214**	1	To 5/1998
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Nimbus UA: UB **5/84-8/87 4 Cyl 1.8L 4G37 SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CC215**	1	To 12/1985
Ignition – Coil – Standard	**CC202**	1	From 12/1985
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CM404**	1	
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS22**	1	
Nimbus UC **9/87-1/92 4 Cyl 2.0L 4G63 SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP652**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT109**	1	Denso Electronic Distributor
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS22**	1	

Mitsubishi	Part No	Qty	Notes
Nimbus UF **2/92-11/98 4 Cyl 2.4L 4G64 SOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC220**	1	To 5/1992
Ignition – Coil – Standard	**CC246**	1	From 5/1992
Ignition – Distributor Cap	**JP718**	1	Mitsubishi Electronic Distributor (A): To 5/1992
Ignition – Distributor Cap	**JP815**	1	Mitsubishi Electronic Distributor (B): To 5/1995
Ignition – Distributor Rotor	**JR806**	1	Mitsubishi Electronic Distributor (A): To 5/1992
Ignition – Distributor Rotor	**JR814**	1	Mitsubishi Electronic Distributor (B): To 5/1995
Ignition – Distributor Rotor	**JR815**	1	Mitsubishi Electronic Dist. (C): From 6/1995
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Crankshaft	**CSCA62**	1	
Sensor – Exhaust Oxygen	**COS783**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS29**	1	
Nimbus UG **11/98-4/04 4 Cyl 2.4L 4G64 SOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC315**	2	
Sensor – Camshaft	**CSCA87**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Outlander ZE **2/03-7/04 4 Cyl 2.4L 4G64 SOHC 16V MPFi 4WD**			
Ignition – Coil and Igniter	**CC315**	2	
Sensor – Camshaft	**CSCA87**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Outlander ZF **8/04-10/06 4 Cyl 2.4L 4G69 SOHC 16V MPFi 4WD**			
Sensor – Camshaft	**CSCA148**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA153**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL71**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Outlander ZG **11/06-on 4 Cyl 2.4L 4B12 DOHC 16V MPFi 4WD**			
Sensor – Coolant Temperature	**CCS39**	1	
Outlander ZG **11/06-on V6 Cyl 3.0L 6B31 SOHC 24V MPFi 4WD**			
Sensor – Coolant Temperature	**CCS39**	1	
Pajero NA: NB: NC Turbo Diesel **1/83-10/86 4 Cyl 2.3L 4D55 SOHC 8V Di 4WD**			
Sensor – Temperature Gauge	**CTS108**	1	
Sensor – Temperature Gauge	**CTS162**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Mitsubishi	Part No	Qty	Notes
Pajero NA: NB: NC Carb **1/83-9/86 4 Cyl 2.6L 4G54 SOHC 8V Carb. 4WD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Dist.: To Engine DT8639
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Dist.: From Engine DT8640
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Dist.: To Engine DT8639
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Dist.: From Engine DT8640
Ignition – Module	**CM408**	1	To Engine DT8639
Ignition – Module & Pickup / Trigger	**CM404**	1	From Engine DT8640
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Pajero LO42: LO47 *(NZ Market)* **1984-90 4 Cyl 2.6L 4G54**			
Ignition – Coil – Standard	**CC211**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Pajero ND: NE: NF: NH Turbo Diesel **10/86-10/93 4 Cyl 2.5L 4D56 SOHC 8V Di 4WD**			
Sensor – Temperature Gauge	**CTS162**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Pajero ND: NE: NF: NG: NH Carb **10/86-10/93 4 Cyl 2.6L 4G54 SOHC 8V Carb. 4WD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CM404**	1	Mitsubishi Electronic Distributor
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Pajero L141G: L141GW *(NZ Market)* **1988-90 V6 Cyl 3.0L 6G72**			
Ignition – Distributor Rotor	**JR639**	1	Mitsubishi Electronic Distributor
Pajero NF: NG: NH: NJ: NK **5/88-7/97 V6 Cyl 3.0L 6G72 SOHC 24V MPFi 4WD**			
Ignition – Coil – Standard	**CC218**	1	
Ignition – Distributor Cap	**JP714**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR639**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS24**	1	To 5/1991
Sensor – Coolant Temperature	**CCS33**	1	From 5/1991 To 10/1996
Sensor – Coolant Temperature	**CCS39**	1	From 10/1996
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS150**	1	From 1/1997 To 5/1997
Switch – Coolant Temperature Warning Light	**CTS163**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Pajero V23: V43 *(NZ Market)* **1990-95 V6 Cyl 3.0L 6G72 SOHC 24V**			
Ignition – Distributor Rotor	**JR639**	1	Mitsubishi Electronic Distributor
Pajero NJ: NK: NL Diesel & Turbo Diesel **11/93-6/00 4 Cyl 2.8L 4M40: 4M40T SOHC 8V Di 4WD**			
Sensor – Temperature Gauge	**CTS162**	1	

Mitsubishi	Part No	Qty	Notes
Pajero NJ: NK **9/95-6/97 V6 Cyl 3.5L 6G74 DOHC 24V MPFi 4WD**			
Ignition – Coil – Standard	**CC332**	3	
Sensor – Camshaft	**CSCA101**	1	To 5/1997
Sensor – Coolant Temperature	**CCS39**	1	To 5/1994
Sensor – Coolant Temperature	**CCS33**	1	From 6/1994
Sensor – Crankshaft	**CSCA39**	1	To 5/1997
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS150**	1	
Switch – Coolant Temperature Warning Light	**CTS163**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Valve – Idle Speed Control	**CIA015**	1	
Pajero NL: NM **8/97-10/02 V6 Cyl 3.5L 6G74 SOHC 24V MPFi 4WD**			
Ignition – Coil – Standard	**CC314**	2	With Black Connector
Ignition – Coil – Standard	**TBA**	1	With White Connector
Sensor – Camshaft	**CSCA110**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA37**	1	
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS150**	1	
Switch – Coolant Temperature Warning Light	**CTS163**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Valve – Idle Speed Control	**CIA015**	1	
Pajero NM Turbo Diesel **5/00-7/02 4 Cyl 2.8L 4M40T SOHC 8V Di 4WD**			
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS162**	1	
Pajero NM: NP Turbo Diesel **5/02-10/06 4 Cyl 3.2L 4M41A DOHC 16V Di 4WD**			
Sensor – Temperature Gauge	**CTS110**	1	
Pajero NP **11/02-7/04 V6 Cyl 3.5L 6G74 SOHC 24V EPFI 4WD**			
Ignition – Coil – Standard	**CC314**	2	With Black Connector
Ignition – Coil – Standard	**TBA**	1	With White Connector
Sensor – Crankshaft	**CSCA164**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Pajero NP: NS **10/03-on V6 Cyl 3.8L 6G75 SOHC 24V EPFI 4WD**			
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA164**	1	
Sensor – Exhaust Oxygen	**COS852**	1	Direct Fit 4 Wire: LH Side Eng Pipe: From 6/2005
Sensor – Exhaust Oxygen	**COS850**	1	Direct Fit 4 Wire: RH Side Eng Pipe and LH Side After Catalyst: From 6/2005
Sensor – Exhaust Oxygen	**COS851**	1	Direct Fit 4 Wire: RH Side After Catalyst: From 6/2005
Sensor – Exhaust Oxygen – Universal	**COS724**	4	From 6/2005
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL71**	1	
Switch – Clutch Pedal	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	To 10/2006
Switch – Oil Pressure Warning Light	**CPS59**	1	From 11/2006

Mitsubishi	Part No	Qty	Notes
Pajero NS Turbo Diesel **11/06-on 4 Cyl 3.2L 4M41 DOHC 16V Di 4WD**			
Sensor – Camshaft	**CSCA151**	1	
Pajero iO QA **3/99-9/01 4 Cyl 1.6L 4G18 SOHC 16V MPFi FT4WD**			
Ignition – Coil and Igniter	**CC315**	2	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Pajero iO QA **3/99-9/03 4 Cyl 1.8L 4G93: 2.0L 4G94 SOHC 16V MPFi 4WD**			
Ignition – Coil and Igniter	**CC315**	2	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA152**	1	From 6/2000
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
RVR N11W: N21W *(NZ Market)* **5/91-4/95 4 Cyl 1.8L 4G93**			
Ignition – Distributor Cap	**JP815**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR814**	1	Mitsubishi Electronic Distributor
RVR N11W: N21W *(NZ Market)* **5/95-10/95 4 Cyl 1.8L 4G93**			
Ignition – Distributor Cap	**JP815**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR802**	1	Mitsubishi Electronic Distributor
RVR N11W: N21W *(NZ Market)* **11/95-3/96 4 Cyl 1.8L 4G93**			
Ignition – Distributor Cap	**JP815**	1	
Ignition – Distributor Rotor	**JR815**	1	
RVR N11W: N21W *(NZ Market)* **4/96-3/97 4 Cyl 1.8L 4G93**			
Ignition – Distributor Cap	**JP817**	1	
Ignition – Distributor Rotor	**JR815**	1	
Scorpion GE **3/78-6/79 4 Cyl 2.0L 4G52 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	Auto Transmission
Ignition – Coil – Standard	**CC211**	1	Manual Transmission
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC414**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Brake Light	**CSL27**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Scorpion GH: GJ **7/79-9/82 4 Cyl 2.6L 4G54 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC202**	1	Electronic Distributor
Ignition – Distributor Cap	**JP558**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM406**	1	Mitsubishi Electronic Distributor
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Mitsubishi	Part No	Qty	Notes
Scorpion GK: GL			
2/82-9/85 4 Cyl 2.6L 4G54 SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CC202**	1	Electronic Distributor
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM408**	1	Mitsubishi Electronic Distributor
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Sigma GE			
10/77-5/80 4 Cyl 1.6L 4G32 SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC409**	1	Mitsubishi Points Distributor: To Engine JA31
Ignition – Distributor Condenser	**MC418**	1	Mitsubishi Points Distributor: From Engine JB1
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Brake Light	**CSL27**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Sigma GE: GH			
10/77-2/82 4 Cyl 2.0L 4G52 SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CC259**	1	
Ignition – Distributor Cap	**BH90**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Brake Light	**CSL27**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Sigma GE			
9/78-79 4 Cyl 1.85L 4G51 SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH90**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Brake Light	**CSL27**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Sigma GE			
1980 4 Cyl 2.6L 4G54 SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CC259**	1	
Ignition – Distributor Cap	**BH90**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Electronic Distributor
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS108**	1	52mm Long
Switch – Brake Light	**CSL27**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	

Mitsubishi	Part No	Qty	Notes
Sigma GH: GJ: GK			
5/80-9/85 4 Cyl 1.6L 4G32 SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH90**	1	Bosch Points Distributor
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**BC100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**MC409**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Sigma GH: GJ			
5/80-2/84 4 Cyl 2.6L 4G54 SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CC259**	1	To 4/1982
Ignition – Coil – Standard	**CC200**	1	From 5/1982
Ignition – Distributor Cap	**BH90**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Electronic Distributor
Ignition – Module	**CM406**	1	
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS108**	1	52mm Long
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Sigma GJ			
3/82-2/84 4 Cyl 2.0L 4G52 SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH90**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Electronic Distributor
Ignition – Module	**CM406**	1	
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Sigma GK: GN			
3/84-12/85 4 Cyl 2.0L 4G52 SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH122**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH121**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Sigma GK: GN			
3/84-12/87 4 Cyl 2.6L 4G54 SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH122**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH121**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Mitsubishi	Part No	Qty	Notes
Starion JA Turbo **5/82-8/84 4 Cyl 2.0L 4G63T SOHC 8V EFi RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM408**	1	External Module From 1983
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Starion JB Turbo **9/84-11/85 4 Cyl 2.0L 4G63T SOHC 8V EFi RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Starion JD Turbo **12/85-8/87 4 Cyl 2.0L 4G63T SOHC 8V EFi RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP568**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS108**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Starwagon SF: SG: SH **10/86-9/94 4 Cyl 2.0L 4G63 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC232**	1	
Ignition – Distributor Cap	**JP652**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Coolant Temperature Warning Light	**CTS163**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Starwagon SF: SG: SH **10/86-9/94 4 Cyl 2.4L 4G64 SOHC 16V EFi RWD & 4WD**			
Ignition – Coil – Standard	**CC220**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR611**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Exhaust Oxygen	**COS757**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Coolant Temperature Warning Light	**CTS163**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	

Mitsubishi	Part No	Qty	Notes
Starwagon WA **9/94-4/04 4 Cyl 2.0L 4G63 SOHC 16V Carb. RWD**			
Ignition – Coil – Standard	**CC281**	1	
Ignition – Distributor Cap	**JP816**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR641**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM475**	1	To 5/1998
Ignition – Module	**CM422**	1	From 6/1998
Sensor – Coolant Temperature	**CCS24**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS150**	1	From 6/1998
Switch – Oil Pressure Warning Light	**CPS37**	1	
Starwagon WA **9/94-4/04 4 Cyl 2.4L 4G64 SOHC 16V EFi RWD**			
Ignition – Coil – Standard	**CC281**	1	
Ignition – Distributor Cap	**JP816**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR806**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA37**	1	Front
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS150**	1	
Starwagon WA **9/94-12/96 V6 Cyl 3.0L 6G72 SOHC 24V EFi RWD**			
Ignition – Coil – Standard	**CC313**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA37**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS150**	1	
Valve – Idle Speed Control	**CIA015**	1	To 7/1996
Starwagon SJ Carb. **10/95-11/97 4 Cyl 2.0L 4G63 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC232**	1	To 9/1997
Ignition – Module	**CM475**	1	
Sensor – Coolant Temperature	**CCS33**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Starwagon SJ EFi **11/97-6/01 4 Cyl 2.0L 4G63 SOHC 16V EFi RWD**			
Ignition – Coil – Standard	**CC281**	1	
Ignition – Module	**CM475**	1	
Sensor – Coolant Temperature	**CCS33**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS150**	1	
Tredia TT: TV: TX: TY: TZ *(NZ Market)* **1982-87 4 Cyl 1.6L 4G32 SOHC**			
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Tredia A215A *(NZ Market)* **1984-87 4 Cyl 1.8L 4G37B**			
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Points Distributor
Tredia TX: TY: TZ *(NZ Market)* **1985-87 4 Cyl 1.8L 4G37**			
Ignition – Coil – Standard	**CC211**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP558**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR555**	1	Mitsubishi Electronic Distributor

Mitsubishi	Part No	Qty	Notes
Triton ME: MF: MG: MH: MJ **10/86-10/96 4 Cyl 2.6L 4G54 SOHC 8V Carb. RWD & 4WD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP542**	1	Mitsubishi Electronic Distributor: To 10/1986
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor: From 11/1986
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CM404**	1	Mitsubishi Electronic Distributor
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Triton ME: MF: MG: MH: MJ Diesel & Turbo Diesel **12/86-10/96 4 Cyl 2.5L 4D56 SOHC 8V Di RWD & 4WD**			
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS162**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Triton MH: MJ **9/90-10/96 V6 Cyl 3.0L 6G72 SOHC 24V EFi 4WD**			
Ignition – Coil – Standard	**CC218**	1	
Ignition – Distributor Cap	**JP714**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR639**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS33**	1	
Sensor – Crankshaft	**CSCA51**	1	In Distributor: Optic Trigger
Sensor – Exhaust Oxygen	**COS835**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Triton MK **10/96-12/06 4 Cyl 2.4L 4G64 SOHC16V MPFi RWD**			
Ignition – Coil – Standard	**CC281**	1	
Ignition – Distributor Cap	**JP816**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR806**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA57**	1	
Sensor – Exhaust Oxygen	**COS849**	1	Direct Fit 4 Wire: From 9/2003 To 12/2006
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: From 9/2003 To 12/2006
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS150**	1	
Switch – Coolant Temperature Warning Light	**CTS163**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Triton MK Diesel & Turbo Diesel **10/96-6/06 4 Cyl 2.8L 4M40 SOHC 8V Di RWD & 4WD**			
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS162**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	

Mitsubishi	Part No	Qty	Notes
Triton MK **10/96-10/06 V6 Cyl 3.0L 6G72 SOHC 24V MPFi RWD & 4WD**			
Ignition – Coil – Standard	**CC313**	1	To 8/2003
Ignition – Coil – Standard	**CC314**	2	With Black Connector: From 9/2003
Ignition – Coil – Standard	**TBA**	1	With White Connector: From 9/2003
Sensor – Camshaft	**CSCA110**	1	
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA37**	1	To 8/2003
Sensor – Crankshaft	**CSCA162**	1	From 9/2003
Sensor – Oil Pressure Gauge	**CPS27**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS150**	1	
Switch – Coolant Temperature Warning Light	**CTS163**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Valve – Idle Speed Control	**CIA015**	1	
Triton ML Turbo Diesel **7/06-on 4 Cyl 3.2L 4M41A SOHC 16V Di 4WD**			
Sensor – Camshaft	**CSCA151**	1	
Sensor – Temperature Gauge	**CTS162**	1	
Triton ML **7/06-on V6 Cyl 3.5L 6G74 SOHC 24V MPFi RWD & 4WD**			
Ignition – Coil – Standard	**CC314**	2	With Black Connector
Ignition – Coil – Standard	**TBA**	1	With White Connector
Sensor – Crankshaft	**CSCA164**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Triton ML **3/07-on 4 Cyl 2.4L 4G64B SOHC 16V MPFi RWD**			
Sensor – Temperature Gauge	**CTS110**	1	
V3000 EA: KS5: KS6 *(NZ Market)* **4/88-6/91 V6 Cyl 3.0L 6G72 SOHC 24V**			
Ignition – Distributor Cap	**BD100**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR639**	1	Mitsubishi Electronic Distributor
Verada KR: KS **7/91-9/96 V6 Cyl 3.0L 6G72 SOHC 12V MPFi FWD**			
Ignition – Coil – Standard	**CC218**	1	
Ignition – Distributor Cap	**BD100**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR639**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS33**	1	
Sensor – Crankshaft	**CSCA51**	1	In Distributor: From 1993
Sensor – Exhaust Oxygen	**COS752**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS113**	1	
Switch – Brake Light	**CSL54**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS48**	1	

Mitsubishi	Part No	Qty	Notes
Verada KE: KF: KH: KJ: KJ Series II			
10/96-5/03 V6 Cyl 3.5L 6G74 SOHC 24V MPFi FWD			
Ignition – Coil – Standard	**CC352**	1	Mitsubishi Coil in Distributor
Ignition – Distributor Cap	**JP819**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR135**	1	Mitsubishi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CSCA66**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA38**	1	
Sensor – Exhaust Oxygen	**COS752**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS151**	1	To 3/1999
Sensor – Throttle Position	**CTPS152**	1	From 3/1999 To 6/2000
Switch – Oil Pressure Warning Light	**CPS37**	1	
Valve – Idle Speed Control	**CIA015**	1	
Verada KL			
6/03-9/04 V6 Cyl 3.5L 6G74 SOHC 24V MPFi FWD & AWD			
Ignition – Coil – Standard	**CC352**	1	Mitsubishi Coil in Distributor
Ignition – Distributor Cap	**JP819**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR135**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA38**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS152**	1	With Cruise / Traction or LPG
Sensor – Throttle Position	**CTPS151**	1	Without Cruise / Traction or LPG
Switch – Brake Light	**CSL71**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Valve – Idle Speed Control	**CIA015**	1	
Verada KW			
10/04-9/05 V6 Cyl 3.5L 6G74 SOHC 24V MPFi FWD & AWD			
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS152**	1	With Cruise / Traction or LPG
Sensor – Throttle Position	**CTPS151**	1	Without Cruise / Traction or LPG
Morris			
1100			
1960-69 4 Cyl 1.1L Carb. FWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD268**	1	Lucas Points Distributor: To 1968
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: To 1968
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor: To 1968
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor: To 1968
Nomad			
1969-72 4 Cyl 1.5L Carb. FWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD268**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor
Niki			
650			
1989-93 2 Cyl 652cc Carb. RWD			
Ignition – Distributor Condenser	**MC41**	1	Marelli Points Distributor

Nissan	Part No	Qty	Notes
120Y B210 **3/74-3/79 4 Cyl 1.2L A12 OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	
Ignition – Distributor Condenser	**MC418**	1	
Ignition – Distributor Points / Contact Set	**S219VU**	1	
Ignition – Distributor Rotor	**JR517**	1	
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL28**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
180B 610 Incl. SSS **9/72-10/77 4 Cyl 1.8L L18 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD278**	1	Lucas Points Distributor: To 1975
Ignition – Distributor Cap	**JP520**	1	Mitsubishi and Hitachi Points Distributor:
Ignition – Distributor Cap	**JP544**	1	Hitachi Twin Points Distributor: From 1976
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: To 1975
Ignition – Distributor Condenser	**MC418**	1	Mitsubishi and Hitachi Points Distributor:
Ignition – Distributor Condenser	**NC203**	1	Hitachi Twin Points Distributor: From 1976
Ignition – Distributor Condenser	**NC207**	1	Hitachi Twin Points Distributor: From 1976
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor: To 1975
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi and Hitachi Points Distributor:
Ignition – Distributor Points / Contact Set	**S217**	2	Hitachi Twin Points Distributor: From 1976
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor: To 1975
Ignition – Distributor Rotor	**JR517**	1	Mitsubishi and Hitachi Points Distributor
Ignition – Distributor Rotor	**JR535**	1	Hitachi Twin Point Distributor: From 1976
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
180SX S13 Turbo **1/89-12/91 4 Cyl 1.8L CA18DET DOHC 16V MPFi RWD**			
Sensor – Crankshaft	**CSCA30**	1	To 1/1991
180SX S13 Incl. Turbo **1/91-12/97 4 Cyl 2.0L SR20DE DOHC 16V EFi RWD**			
Sensor – Knock Control	**CKS120**	1	From 1/1991
200B 810 Incl. SSS **10/77-5/81 4 Cyl 2.0L L20B SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH90**	1	Bosch Points Distributor
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor: To 1978
Ignition – Distributor Cap	**JP544**	1	Hitachi Twin Points Distributor: To 1980
Ignition – Distributor Cap	**JP520**	1	Mitsubishi Points Distributor: To 1980
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor: To 1978
Ignition – Distributor Condenser	**NC203**	1	Hitachi Twin Points Distributor: To 1980
Ignition – Distributor Condenser	**NC207**	1	Hitachi Twin Points Distributor: To 1980
Ignition – Distributor Condenser	**MC418**	1	Mitsubishi Points Distributor: To 1980
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor

Nissan	Part No	Qty	Notes
200B 810 Incl. SSS *(Continued)*			
10/77-5/81 4 Cyl 2.0L L20B SOHC 8V Carb. RWD			
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor: To 1978
Ignition – Distributor Points / Contact Set	**S217**	2	Hitachi Twin Points Distributor: To 1980
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor: To 1980
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor: To 1978
Ignition – Distributor Rotor	**JR535**	1	Hitachi Twin Points Distributor: To 1980
Ignition – Distributor Rotor	**JR517**	1	Mitsubishi Points Distributor: To 1980
Sensor – Temperature Gauge	**CTS100**	1	Imported Models
Sensor – Temperature Gauge	**CTS102**	1	Australian Assembled Models
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL28**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
200SX S14 Turbo			
10/94-11/00 4 Cyl 2.0L SR20DET DOHC 16V PFI RWD			
Ignition – Coil and Igniter	**CC303**	4	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS772**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS120**	1	
Sensor – Temperature Gauge	**CTS155**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	
200SX S15 Turbo			
11/00-12/03 4 Cyl 2.0L SR20DET DOHC 16V EPFI RWD			
Sensor – Exhaust Oxygen	**COS772**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS120**	1	
240C: 240K: 240Z			
10/70-3/78 6 Cyl 2.4L L24 SOHC 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP526**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
260C: 260Z			
1/73-12/78 6 Cyl 2.6L L26 SOHC 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP526**	1	Hitachi Points Distributor: To 1975
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor: To 1975
Ignition – Distributor Rotor	**JR535**	1	Hitachi Points Distributor: From 1975
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	

Nissan	Part No	Qty	Notes
280C			
3/78-2/83 6 Cyl 2.8L L28 SOHC 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor: To 1979
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor: To 1979
Ignition – Distributor Rotor	**JR535**	1	Hitachi Points Distributor: To 1979
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
280ZX			
3/79-5/84 6 Cyl 2.8L L28E SOHC 12V EFi RWD			
Ignition – Distributor Cap	**JP738**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR655**	1	Hitachi Electronic Distributor
Ignition – Module	**CM416**	1	
Sensor – Coolant Temperature	**CCS25**	1	
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Sensor – Throttle Position	**CTPS142**	1	To 11/1980
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
300C			
5/84-5/86 V6 Cyl 3.0L VG30E SOHC 12V EFi RWD			
Ignition – Coil – Standard	**CC221**	1	
Ignition – Distributor Cap	**BD741**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR761**	1	Hitachi Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS737**	1	Direct Fit 3 Wire: Titania
Sensor – Exhaust Oxygen	**COS772**	1	Direct Fit 3 Wire: Zirconia
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire: Zirconia
Sensor – Temperature Gauge	**CTS141**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	
300ZX Z31			
5/84-12/85 V6 Cyl 3.0L VG30E SOHC 12V EFi RWD			
Ignition – Coil – Standard	**CC221**	1	
Ignition – Distributor Cap	**BD741**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR761**	1	Hitachi Electronic Distributor
Sensor – Coolant Temperature	**CCS25**	1	
Sensor – Exhaust Oxygen	**COS737**	1	Direct Fit 3 Wire: Titania
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Sensor – Throttle Position	**CTPS133**	1	Auto Transmission: From 2/1987
Sensor – Throttle Position	**CTPS103**	1	Manual Transmission
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
300ZX Z31 Turbo			
1/86-12/89 V6 Cyl 3.0L VG30ET SOHC 12V EFi RWD			
Ignition – Coil – Standard	**CC221**	1	
Ignition – Distributor Cap	**BD741**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR761**	1	Hitachi Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS737**	1	Direct Fit 3 Wire: Titania
Sensor – Throttle Position	**CTPS133**	1	Auto Transmission: From 2/1987
Sensor – Throttle Position	**CTPS103**	1	Manual Transmission
Switch – Brake Light	**CSL43**	1	

Nissan	Part No	Qty	Notes
300ZX Z32 Incl. Turbo *(NZ Market)* **1989-93 V6 Cyl 3.0L VG30DE: VG30DETT**			
Ignition – Distributor Cap	**BD741**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR761**	1	Hitachi Electronic Distributor
300ZX Z32 **12/89-3/97 V6 Cyl 3.0L VG30DE DOHC 24V EFi RWD**			
Sensor – Camshaft	**CSCA05**	1	Mitsubishi: To 1/1994
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS797**	1	Direct Fit 3 Wire: LH and RH Side
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire: LH and RH Side
Sensor – Knock Control	**CKS120**	1	
Sensor – Throttle Position	**CTPS133**	1	To 10/1992
Switch – Brake Light	**CSL43**	1	
520 1 Tonne **1/71-12/78 4 Cyl 1.5L J15 OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor: To 1972
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor: To 1972
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor: To 1972
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor: To 1972
620 1 Tonne **7/72-12/79 4 Cyl 1.5L J15 OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi & Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi & Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi & Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi & Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
720 **1/80-12/85 4 Cyl 1.8L L18 Carb. RWD & 4WD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
720 **1/80-9/84 4 Cyl 2.2L SD22 Di RWD**			
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	

Nissan	Part No	Qty	Notes
720 PG72OU: MGY720TU *(NZ Market)* **1980-86 4 Cyl 1.8:2.2L L18: Z22**			
Ignition – Coil – Standard	**CC211**	1	Hitachi Points Distributor
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
720 **6/83-12/85 4 Cyl 2.3L SD23: 2.5L SD25 Di RWD**			
Sensor – Temperature Gauge	**CTS158**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
720 **1/85-12/85 4 Cyl 2.2L Z22 Carb. 4WD**			
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
1000 **1967-70 4 Cyl 1.0L A10 Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Switch – Oil Pressure Warning Light	**CPS20**	1	
1200 B110: B120 **6/70-12/85 4 Cyl 1.2L A12 OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor
Ignition – Distributor Cap	**BD278**	1	Lucas Points Distributor: To 1978
Ignition – Distributor Cap	**JP520**	1	Mitsubishi Points Distributor: From 1978
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: To 1978
Ignition – Distributor Condenser	**MC418**	1	Mitsubishi Points Distributor: From 1978
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor: To 1978
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor: From 1978
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor: To 1978
Ignition – Distributor Rotor	**JR517**	1	Mitsubishi Points Distributor: From 1978
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL28**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	

Nissan	Part No	Qty	Notes
1600 **1965-73 4 Cyl 1.6L L16 Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor
Ignition – Distributor Cap	**BD278**	1	Lucas Points Distributor: From 1971
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: From 1971
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor: From 1971
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor: From 1971
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
2400 **7/70-8/71 6 Cyl 2.4L L24 Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP526**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Bluebird 910 Series I **5/81-8/83 4 Cyl 2.0L L20B SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH90**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL28**	1	Bullet Terminals
Switch – Oil Pressure Warning Light	**CPS22**	1	
Bluebird 910 Series II **9/83-4/85 4 Cyl 2.0L L20B SOHC 8V Carb. RWD**			
Ignition – Distributor Cap	**BH122**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH121**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	Blade Terminals
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS16**	1	
Bluebird U11 *(NZ Market)* **1983-87 4 Cyl 1.8L CA18 SOHC 8V**			
Ignition – Distributor Cap	**JP666**	1	Hitachi Electronic Distributor
Bluebird U11: U12 *(NZ Market)* **1983-91 4 Cyl 2.0L CA20 SOHC**			
Ignition – Coil – Standard	**CC200**	2	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP666**	1	Hitachi Electronic Distributor: With Vent
Ignition – Distributor Cap	**JP672**	1	Hitachi Electronic Distributor: Without Vent
Ignition – Distributor Rotor	**JR655**	1	Hitachi Electronic Distributor

Nissan	Part No	Qty	Notes
Bluebird 910 Series III **4/85-6/86 4 Cyl 2.0L CA20S SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC200**	2	
Ignition – Distributor Cap	**BH176**	1	Bosch Electronic Distributor
Ignition – Distributor Cap	**JP716**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**BH229**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**JR623**	1	Hitachi Electronic Distributor
Ignition – Module	**CM471**	1	Hitachi
Ignition – Module	**CM419**	1	Bosch
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	Blade Terminals
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS16**	1	
Bluebird U13 *(NZ Market)* **1989-96 4 Cyl 2.0L SR18: SR20DE DOHC**			
Ignition – Coil – Standard	**CC223**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR643**	1	Hitachi Electronic Distributor
Bluebird U12: U13 *(NZ Market)* **1991-95 4 Cyl 2.4L KA24E: KA24DE**			
Ignition – Distributor Cap	**JP672**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR535**	1	Hitachi Electronic Distributor
Bluebird U13 **10/93-12/97 4 Cyl 2.4L KA24DE DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC229**	1	
Ignition – Distributor Cap	**JP825**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR808**	1	Hitachi Electronic Distributor
Ignition – Module	**CM428**	1	Hanshin
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Crankshaft	**CSCA168**	1	
Sensor – Exhaust Oxygen	**COS748**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Knock Control	**CKS120**	1	To 5/1997
Sensor – Temperature Gauge	**CTS141**	1	
Sensor – Throttle Position	**CTPS139**	1	Auto Transmission
Sensor – Throttle Position	**CTPS138**	1	Manual Transmission: To 1/1995
Sensor – Throttle Position	**CTPS140**	1	Manual Transmission: From 1/1995
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	
Brougham V30E **6/86-1/88 V6 Cyl 3.0L VG30E SOHC 12V EFi RWD**			
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS737**	1	Direct Fit 3 Wire: Titania
Sensor – Exhaust Oxygen	**COS772**	1	Direct Fit 3 Wire: Zirconia
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire: Zirconia
Caball **1969-81 4 Cyl 2.0L H20 OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor: From 1975
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor: From 1975
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor: From 1975
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor: From 1975

Nissan	Part No	Qty	Notes
Cabstar F22 **4/84-12/87 4 Cyl 2.0L Z20 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC423**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Cabstar H40 **10/84-12/87 4 Cyl 2.2L Z22 Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC423**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Switch – Brake Light	**CSL28**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Cefiro A31 *(NZ Market)* **9/88-7/90 6 Cyl 2.0L RB20E SOHC 8V**			
Ignition – Coil – Standard	**CC233**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP694**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR621**	1	Hitachi Electronic Distributor
Cefiro A31 Turbo *(NZ Market)* **1988-94 6 Cyl 2.0L RB20DET**			
Ignition – Distributor Cap	**JP694**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR621**	1	Hitachi Electronic Distributor
EXA KEN13 *(NZ Market)* **1986-90 4 Cyl 1.6L CA16DE DOHC**			
Ignition – Coil – Standard	**CC207**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP594**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR607**	1	Hitachi Electronic Distributor
EXA KN13 **2/87-12/87 4 Cyl 1.6L CA16DE DOHC 16V EFi FWD**			
Ignition – Coil and Igniter	**CC235**	4	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Crankshaft	**CSCA30**	1	
Sensor – Exhaust Oxygen	**COS737**	1	Direct Fit 3 Wire: Titania
Sensor – Oil Pressure Gauge	**CPS56**	1	
Sensor – Throttle Position	**CTPS134**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Radiator Fan	**CFS28**	1	
EXA KN13 **1/88-10/91 4 Cyl 1.8L CA18DE DOHC 16V EFi FWD**			
Ignition – Coil and Igniter	**CC235**	4	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS738**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Oil Pressure Gauge	**CPS56**	1	
Sensor – Throttle Position	**CTPS135**	1	
Switch – Radiator Fan	**CFS28**	1	

Nissan	Part No	Qty	Notes
Gazelle S12 **1/84-11/88 4 Cyl 2.0L CA20E SOHC 8V EFi RWD**			
Ignition – Distributor Cap	**JP696**	1	Hitachi Electronic Distributor: To 1986
Ignition – Distributor Cap	**JP716**	1	Hitachi Electronic Distributor: From 1986
Ignition – Distributor Rotor	**JR623**	1	Hitachi Electronic Distributor
Ignition – Module	**CM471**	1	To 1986
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS748**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Homer F20 **4/76-12/81 4 Cyl 2.0L H20 OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor: To 1979
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor: To 1979
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor: To 1979
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor: To 1979
Infiniti Q45 **9/93-12/96 V8 Cyl 4.5L VH45DE DOHC 32V MPFI RWD**			
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire: LH Side
Langley N13 *(NZ Market)* **1986-88 4 Cyl 1.5L E15S**			
Ignition – Distributor Cap	**JP594**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR535**	1	Hitachi Electronic Distributor
Laurel C32: C33: C34 *(NZ Market)* **1986-93 6 Cyl 2.0L RB20E: RB20DE**			
Ignition – Distributor Cap	**JP694**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR621**	1	Hitachi Electronic Distributor
Maxima J30 *(NZ Market)* **1988-94 V6 Cyl 3.0L VG30E: VG30DE**			
Ignition – Distributor Cap	**BD741**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR761**	1	Hitachi Electronic Distributor
Maxima J30 **5/90-12/92 V6 Cyl 3.0L VG30E SOHC 12V MPFI FWD**			
Ignition – Coil – Standard	**CC223**	1	
Ignition – Distributor Cap	**BD841**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR841A**	1	Hitachi Electronic Distributor
Ignition – Module	**CM428**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS771**	1	Direct Fit 3 Wire: Titania
Sensor – Temperature Gauge	**CTS141**	1	
Sensor – Throttle Position	**CTPS133**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	

Nissan	Part No	Qty	Notes
Maxima A32 **2/95-12/99 V6 Cyl 3.0L VQ30DE DOHC 24V MPFI FWD**			
Ignition – Coil and Igniter	**CC302**	3	Front Only
Sensor – Coolant Temperature	**CCS37**	1	
Sensor – Crankshaft	**CSCA28**	1	Mitsubishi: Crank Reference
Sensor – Exhaust Oxygen	**COS800**	1	Direct Fit 3 Wire: Before Catalyst
Sensor – Exhaust Oxygen – Universal	**COS721**	2	Universal 3 Wire: Before and After Catalyst
Sensor – Knock Control	**CKS120**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	
Maxima A33 **11/99-11/03 V6 Cyl 3.0L VQ30DE DOHC 24V MPFI FWD**			
Sensor – Air Flow / MAF	**CAF032**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	
Micra K11E **5/95-12/97 4 Cyl 1.3L CG13DE MPFI FWD**			
Ignition – Distributor Cap	**JP405**	1	
Ignition – Distributor Rotor	**JR404**	1	
Sensor – Coolant Temperature	**CCS37**	1	
Sensor – Exhaust Oxygen	**COS772**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Navara D21 *(NZ Market)* **1985-89 4 Cyl 1.6L Z16**			
Ignition – Distributor Cap	**JP672**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR535**	1	Hitachi Electronic Distributor
Navara D21 **1/86-10/95 4 Cyl 2.0L Z20 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP672**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**BC301**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR615**	1	Hitachi Points Distributor
Sensor – Oil Pressure Gauge	**CPS26**	1	
Sensor – Temperature Gauge	**CTS158**	1	
Switch – Brake Light	**CSL43**	1	
Navara D21 **1/86-5/92 4 Cyl 2.4L Z24 SOHC 12V Carb. RWD & 4WD**			
Ignition – Coil – Standard	**CIC32R**	1	To 10/1989
Ignition – Module	**CM471**	1	
Sensor – Oil Pressure Gauge	**CPS26**	1	
Sensor – Temperature Gauge	**CTS158**	1	
Switch – Brake Light	**CSL43**	1	
Navara D21 Diesel **1/86-12/88 4 Cyl 2.5L SD25 Di RWD & 4WD**			
Sensor – Temperature Gauge	**CTS158**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Navara D21 Diesel **1/88-5/92 4 Cyl 2.5L TD25 OHV Di RWD**			
Sensor – Temperature Gauge	**CTS158**	1	

Nissan	Part No	Qty	Notes
Navara D21 Diesel **2/88-5/92 4 Cyl 2.7L TD27 Di 4WD**			
Sensor – Coolant Temperature	**CCS37**	1	
Sensor – Temperature Gauge	**CTS158**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Navara D21 *(NZ Market)* **1992-96 4 Cyl 2.4L KA24E SOHC**			
Ignition – Distributor Cap	**JP666**	1	Hitachi Electronic Distributor
Navara D21 **6/92-2/97 4 Cyl 2.4L KA24E SOHC 12V EFi RWD & 4WD**			
Ignition – Coil – Standard	**CC223**	1	
Ignition – Module	**CM428**	1	
Sensor – Coolant Temperature	**CCS37**	1	
Sensor – Crankshaft	**CSCA72**	1	In Hitachi Distributor
Sensor – Temperature Gauge	**CTS158**	1	
Navara D21 Diesel **6/92-2/97 4 Cyl 2.7L TD27 Di 4WD**			
Sensor – Temperature Gauge	**CTS158**	1	
Navara D21 **6/92-2/97 V6 Cyl 3.0L VG30E SOHC 12V EFi RWD**			
Ignition – Coil – Standard	**CC223**	1	
Ignition – Distributor Cap	**JP826**	1	
Ignition – Distributor Rotor	**DR841A**	1	
Ignition – Module	**CM428**	1	
Sensor – Exhaust Oxygen	**COS798**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS120**	1	
Sensor – Temperature Gauge	**CTS158**	1	
Sensor – Throttle Position	**CTPS156**	1	4 Speed Auto Transmission
Sensor – Throttle Position	**CTPS155**	1	5 Speed Manual
Navara D22 **3/97-6/99 4 Cyl 2.4L KA24E SOHC 12V EFi RWD**			
Ignition – Coil – Standard	**CC223**	1	
Ignition – Distributor Cap	**JP838**	1	Hitachi Electronic Distributor
Ignition – Module	**CM428**	1	
Sensor – Air Temperature – Inlet	**CAT008**	1	
Sensor – Coolant Temperature	**CCS37**	1	
Sensor – Crankshaft	**CSCA64**	1	In Mitsubishi Distributor
Sensor – Temperature Gauge	**CTS158**	1	
Navara D22 Diesel **3/97-12/01 4 Cyl 2.7L TD27: 3.2L QD32 OHV Di 4WD**			
Sensor – Coolant Temperature	**CCS37**	1	
Navara D22 **7/99-7/00 4 Cyl 2.4L KA24DE DOHC 16V ESPFI RWD**			
Ignition – Coil – Standard	**CC223**	1	
Ignition – Distributor Cap	**JP672**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR607**	1	
Ignition – Distributor Rotor	**JR659**	1	Mitsubishi Electronic Distributor: Check
Sensor – Coolant Temperature	**CCS37**	1	
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Knock Control	**CKS120**	1	
Navara D40 **12/05-on V6 Cyl 4.0L VQ40DE DOHC 24V SPFi RWD**			
Ignition – Coil and Igniter	**CC380**	6	Coil With Boot: To 4/2007

Nissan	Part No	Qty	Notes
Nomad GC22 **1/87-10/92 4 Cyl 2.4L Z24 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	Points Ignition
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Points Ignition
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Points Ignition
Ignition – Distributor Cap	**JP672**	1	Mitsubishi Points Distributor: To 9/1987
Ignition – Distributor Cap	**JP716**	1	Hitachi Electronic Distributor: From 9/1987
Ignition – Distributor Condenser	**BC301**	1	Mitsubishi Points Distributor: To 9/1987
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor: To 9/1987
Ignition – Distributor Rotor	**JR615**	1	Mitsubishi Points Distributor: To 9/1987
Ignition – Distributor Rotor	**JR623**	1	Hitachi Electronic Distributor: From 9/1987
Ignition – Module	**CM471**	1	Hitachi Electronic Distributor
Switch – Oil Pressure Warning Light	**CPS28**	1	
NX: NX-R **10/91-1/96 4 Cyl 2.0L SR20DE DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC223**	1	
Ignition – Distributor Cap	**BD887**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR643**	1	Hitachi Electronic Distributor
Ignition – Module	**CM428**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS772**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS141**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	
Pathfinder WD21 **12/86-9/92 4 Cyl 2.4L Z24 SOHC 8V Carb. 4WD**			
Ignition – Distributor Cap	**JP672**	1	Mitsubishi Points Distributor
Ignition – Distributor Cap	**JP716**	1	Hitachi Electronic Distributor
Ignition – Distributor Condenser	**BC301**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR615**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR623**	1	Hitachi Electronic Distributor
Ignition – Module	**CM471**	1	Hitachi Electronic Distributor
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	
Pathfinder WD21 **10/92-11/95 V6 Cyl 3.0L VG30E SOHC 12V MPFi 4WD**			
Ignition – Coil – Standard	**CC223**	1	
Ignition – Distributor Cap	**JP826**	1	
Ignition – Distributor Rotor	**DR841A**	1	
Ignition – Module	**CM428**	1	
Sensor – Exhaust Oxygen	**COS771**	1	Direct Fit 3 Wire: Titania: To 8/1993
Sensor – Exhaust Oxygen	**COS798**	1	Direct Fit 3 Wire: Titania: From 8/1993
Sensor – Temperature Gauge	**CTS141**	1	
Sensor – Throttle Position	**CTPS156**	1	Auto Transmission
Sensor – Throttle Position	**CTPS155**	1	5 Speed Manual
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	

Nissan	Part No	Qty	Notes
Pathfinder R50 **11/95-1/99 V6 Cyl 3.3L VG33E SOHC 12V MPFi 4WD**			
Sensor – Coolant Temperature	**CCS37**	1	
Sensor – Knock Control	**CKS120**	1	
Sensor – Temperature Gauge	**CTS155**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	
Pathfinder R51 **7/05-on V6 Cyl 3.0L VQ40 DOHC 24V ESPFI 4WD**			
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: LH and RH Side Eng Pipe
Patrol G60 **1/61-12/80 6 Cyl 4.0L P40 OHV 12V Carb. 4WD**			
Ignition – Coil – Standard	**CIC31**	1	To 1965
Ignition – Coil – Standard	**CIC32R**	1	From 1965
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	To 1965
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	From 1965
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	From 1965
Ignition – Distributor Cap	**JP526**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor: From 1965
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor: From 1965
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Patrol MQ: MK Diesel **6/80-12/87 6 Cyl 3.3L SD33 OHV 12V Di 4WD**			
Sensor – Oil Pressure Gauge	**CPS56**	1	
Sensor – Temperature Gauge	**CTS100**	1	To 8/1984
Sensor – Temperature Gauge	**CTS158**	1	From 9/1984
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Patrol MQ **6/80-12/85 6 Cyl 4.0L P40 OHV 12V Carb. 4WD**			
Ignition – Distributor Cap	**JP526**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Sensor – Temperature Gauge	**CTS100**	1	To 8/1984
Sensor – Temperature Gauge	**CTS158**	1	From 9/1984
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	
Patrol MQ: MK **9/80-12/87 6 Cyl 2.8L L28 SOHC 12V Carb. 4WD**			
Ignition – Distributor Cap	**JP526**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Sensor – Temperature Gauge	**CTS100**	1	To 8/1984
Sensor – Temperature Gauge	**CTS158**	1	From 9/1984
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	

Nissan	Part No	Qty	Notes
Patrol MQ: MK Turbo Diesel **1/84-12/87 6 Cyl 3.3L SD33T OHV 12V Di 4WD**			
Sensor – Oil Pressure Gauge	**CPS56**	1	
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Patrol GQ **2/88-12/95 6 Cyl 4.2L TB42S OHV 12V Carb. 4WD**			
Ignition – Coil – Standard	**CIC32R**	1	To 10/1994
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD810**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC413**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR249**	1	Mitsubishi Points Distributor
Sensor – Crankshaft	**CSCA79**	1	
Sensor – Oil Pressure Gauge	**CPS56**	1	
Sensor – Temperature Gauge	**CTS141**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	
Patrol GQ **1/90-12/97 6 Cyl 3.0L RB30S SOHC 12V Carb. 4WD**			
Ignition – Coil – Standard	**CC223**	1	
Ignition – Distributor Cap	**BD810**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR251**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM405**	1	From 1/1992
Patrol GQ **2/92-12/97 6 Cyl 4.2L TB42E SOHC 12V EFi 4WD**			
Ignition – Coil – Standard	**CC229**	1	
Ignition – Distributor Cap	**BD136**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR137**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM428**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS748**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Oil Pressure Gauge	**CPS56**	1	
Sensor – Throttle Position	**CTPS156**	1	Auto Transmission
Sensor – Throttle Position	**CTPS155**	1	Manual Transmission
Switch – Oil Pressure Warning Light	**CPS28**	1	
Patrol GQ Turbo Diesel **2/95-12/97 6 Cyl 2.8L RD28T SOHC 12V Di 4WD**			
Sensor – Coolant Temperature	**CCS37**	1	
Sensor – Oil Pressure Gauge	**CPS56**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	
Patrol GU: GU Series II **12/97-9/01 6 Cyl 4.5L TB45E OHV 12V MPFi 4WD**			
Ignition – Distributor Cap	**BD898**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**BD899**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS37**	1	
Sensor – Exhaust Oxygen	**COS748**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Knock Control	**CKS120**	1	
Patrol GU: GU Series II: GU Series III Turbo Diesel **5/99-9/04 6 Cyl 4.2L TD42T OHV 12V Di 4WD**			
Sensor – Coolant Temperature	**CCS37**	1	

Nissan	Part No	Qty	Notes
Pintara R31 **6/86-12/90 4 Cyl 2.0L CA20E SOHC 8V EFi RWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH176**	1	Bosch Electronic Distributor: To 1989
Ignition – Distributor Cap	**JP696**	1	Hitachi Electronic Distributor: To 1989
Ignition – Distributor Rotor	**BH229**	1	Bosch Electronic Distributor: To 1989
Ignition – Distributor Rotor	**JR623**	1	Hitachi Electronic Distributor: To 1989
Ignition – Module	**CM419**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS748**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Throttle Position	**CTPS141**	1	Auto Transmission
Sensor – Throttle Position	**CTPS134**	1	Manual Transmission
Switch – Oil Pressure Warning Light	**CPS22**	1	
Pintara U12 **11/89-10/92 4 Cyl 2.0L CA20E SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC200**	2	
Ignition – Distributor Cap	**BH176**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH229**	1	Bosch Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS748**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS130**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	
Pintara U12 **11/89-10/92 4 Cyl 2.4L KA24E SOHC 12V MPFi FWD**			
Ignition – Coil – Standard	**CC223**	1	
Ignition – Distributor Cap	**JP720**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR643**	1	Hitachi Electronic Distributor
Ignition – Module	**CM428**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS748**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Throttle Position	**CTPS136**	1	Auto Transmission
Sensor – Throttle Position	**CTPS137**	1	Manual Transmission
Switch – Oil Pressure Warning Light	**CPS28**	1	
Prairie M10 **1/82-12/84 4 Cyl 1.5L E15 SOHC 8V Carb. FWD**			
Ignition – Distributor Cap	**JP630**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS17**	1	
Prairie M10 **1/85-12/86 4 Cyl 1.5L E15 SOHC 8V Carb. FWD**			
Ignition – Distributor Cap	**JP594**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR535**	1	Hitachi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CM417**	1	Hitachi Electronic Distributor
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS17**	1	

Nissan	Part No	Qty	Notes
Primera P10 Japan Spec *(NZ Market)* **2/90-9/94 4 Cyl 1.8L SR18DI DOHC**			
Ignition – Coil – Standard	**CC223**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**BD887**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP836**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR643**	1	Hitachi Electronic Distributor
Primera P10 Japan Spec *(NZ Market)* **2/90-9/94 4 Cyl 2.0L SR20D:DE DOHC**			
Ignition – Coil – Standard	**CC223**	1	
Ignition – Distributor Cap	**BD887**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP836**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR643**	1	Hitachi Electronic Distributor
Primera P10 Japan Spec *(NZ Market)* **9/94-on 4 Cyl 1.8L SR18DE DOHC**			
Ignition – Distributor Cap	**JP409**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR815**	1	Mitsubishi Electronic Distributor
Primera P10 Japan Spec *(NZ Market)* **9/94-on 4 Cyl 2.0L SR20DE DOHC**			
Ignition – Distributor Cap	**JP409**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR815**	1	Mitsubishi Electronic Distributor
Primera P10E Europe Spec *(NZ Market)* **4 Cyl 2.0L SR20DE DOHC**			
Ignition – Coil – Standard	**CC223**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**BD887**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR643**	1	Hitachi Electronic Distributor
Primera P11 Japan Spec *(NZ Market)* **9/95-9/98 4 Cyl 1.8L SR18DE DOHC**			
Ignition – Distributor Rotor	**JR815**	1	Mitsubishi Electronic Distributor
Primera P11 Japan Spec *(NZ Market)* **9/95-11/00 4 Cyl 2.0L SR20DE DOHC**			
Ignition – Distributor Rotor	**JR815**	1	Mitsubishi Electronic Distributor
Primera P11E Europe Spec *(NZ Market)* **4 Cyl 2.0L SR20DE DOHC**			
Ignition – Distributor Rotor	**JR815**	1	Mitsubishi Electronic Distributor
Pulsar N10 **10/80-81 4 Cyl 1.4L A14 OHV Carb. FWD**			
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**NC213**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR535**	1	Hitachi Points Distributor
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	

Nissan	Part No	Qty	Notes
Pulsar N10 **10/81-12/82 4 Cyl 1.3L E13: 1.5L E15 SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS15**	1	
Pulsar N12 **1/83-6/87 4 Cyl 1.3L E13: 1.5L E15 SOHC 8V Carb. FWD**			
Ignition – Distributor Cap	**JP520**	1	Points Distributor: To 5/1984
Ignition – Distributor Cap	**JP594**	1	Electronic Distributor: From 5/1984 To 6/1986
Ignition – Distributor Condenser	**MC418**	1	Points Distributor: To 5/1984
Ignition – Distributor Points / Contact Set	**S219VU**	1	Points Distributor: To 5/1984
Ignition – Distributor Rotor	**JR517**	1	Points Distributor: To 5/1984
Ignition – Distributor Rotor	**JR535**	1	Electronic Distributor: From 5/1984 To 6/1986
Ignition – Distributor Rotor	**JR517**	1	Electronic Distributor: From 6/1986
Ignition – Module & Pickup / Trigger	**CM417**	1	Electronic Distributor: From 5/1984
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS17**	1	To 3/1984
Switch – Radiator Fan	**CFS20**	1	From 3/1984
Pulsar N12 Turbo **10/83-7/87 4 Cyl 1.5L E15ET SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC305**	1	Mitsubishi
Ignition – Distributor Cap	**JP666**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR535**	1	Hitachi Electronic Distributor
Sensor – Coolant Temperature	**CCS25**	1	
Sensor – Crankshaft	**CSCA170**	1	Complete Distributor
Sensor – Exhaust Oxygen	**COS738**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS20**	1	
Pulsar N12 *(NZ Market)* **1983-88 4 Cyl 1.3L E13S: 1.5L E15S**			
Ignition – Coil – Standard	**CC211**	1	Hitachi Points Distributor
Ignition – Distributor Cap	**JP544**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR535**	1	Hitachi Points Distributor

Nissan	Part No	Qty	Notes
Pulsar N12 **4/86-7/87 4 Cyl 1.6L E16 SOHC 8V Carb. FWD**			
Ignition – Distributor Cap	**JP594**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR607**	1	Hitachi Electronic Distributor
Ignition – Module & Pickup / Trigger	**CM417**	1	
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Switch – Radiator Fan	**CFS20**	1	
Pulsar N13 *(NZ Market)* **5/86-88 4 Cyl 1.3L E13S**			
Ignition – Distributor Cap	**JP672**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR615**	1	Mitsubishi Electronic Distributor
Pulsar N13 *(NZ Market)* **5/86-4/88 4 Cyl 1.5L E15S**			
Ignition – Distributor Cap	**JP594**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP672**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR615**	1	Mitsubishi Electronic Distributor
Pulsar N13 **6/87-9/91 4 Cyl 1.6L 16LF: 1.8L 18LF SOHC 8V Tbi FWD**			
Ignition – Coil – Standard	**CC207**	1	
Ignition – Distributor Cap	**DR114**	1	Delco Electronic Distributor
Ignition – Distributor Rotor	**DR73**	1	Delco Electronic Distributor
Ignition – Module	**CM415**	1	
Ignition – Pickup / Trigger	**CIT100**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	1.8L MPFi
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS127**	1	
Sensor – Throttle Position	**CTPS132**	1	1.6L Tbi
Sensor – Throttle Position	**CTPS131**	1	1.8L MPFi
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS21**	1	
Switch – Radiator Fan	**CFS28**	1	
Valve – Idle Speed Control	**CIA004**	1	
Pulsar N13 *(NZ Market)* **1988-90 4 Cyl 1.6L CA16DE**			
Ignition – Distributor Cap	**JP594**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR607**	1	Hitachi Electronic Distributor
Pulsar N13 *(NZ Market)* **9/88-on 4 Cyl 1.5L GA15S DOHC 16V**			
Ignition – Distributor Cap	**BD894**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP672**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR615**	1	Mitsubishi Electronic Distributor
Pulsar N13 *(NZ Market)* **9/88-on 4 Cyl 1.5L GA15E DOHC 16V**			
Ignition – Distributor Cap	**BD894**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR773**	1	Hitachi Electronic Distributor
Pulsar N14 *(NZ Market)* **8/90-on 4 Cyl 1.3L GA13DS DOHC 16V**			
Ignition – Distributor Rotor	**JR806**	1	

Nissan	Part No	Qty	Notes
Pulsar N14 *(NZ Market)* **8/90-on 4 Cyl 1.5L GA15DS DOHC 16V**			
Ignition – Distributor Cap	**JP836**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR806**	1	Mitsubishi Electronic Distributor
Pulsar N14 *(NZ Market)* **8/90-on 4 Cyl 1.8L SR18DE DOHC 16V**			
Ignition – Distributor Cap	**BD887**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP836**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR643**	1	Hitachi Electronic Distributor
Pulsar N14 *(NZ Market)* **8/90-on 4 Cyl 2.0L SR20DET DOHC 16V**			
Ignition – Distributor Cap	**BD887**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP836**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR643**	1	Hitachi Electronic Distributor
Pulsar N14 *(NZ Market)* **1990-95 4 Cyl 1.6L GA16DE DOHC 16V**			
Ignition – Coil – Standard	**CC229**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**BD894**	1	Mitsubishi Electronic Distributor
Pulsar N14 Incl. Fully Imported **10/91-9/95 4 Cyl 1.6L GA16DE DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC229**	1	
Ignition – Distributor Cap	**BD894**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP672**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**DR773**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR659**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM428**	1	Hitachi
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Crankshaft	**CSCA01**	1	Hitachi Distributor
Sensor – Crankshaft	**CSCA01B**	1	Hitachi Distributor: Kit supplied with bearing
Sensor – Crankshaft	**CSCA07**	1	Mitsubishi Distributor
Sensor – Exhaust Oxygen	**COS748**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS155**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	
Pulsar N14 Incl. Fully Imported **10/91-9/95 4 Cyl 2.0L SR20DE DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC223**	1	
Ignition – Distributor Cap	**BD887**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP836**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR643**	1	Hitachi Electronic Distributor
Ignition – Module	**CM428**	1	Hitachi
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS772**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS120**	1	
Sensor – Temperature Gauge	**CTS155**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	
Pulsar N15 *(NZ Market)* **1/95-9/97 4 Cyl 1.5L GA15DE DOHC 16V**			
Ignition – Distributor Cap	**JP838**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR820**	1	Hitachi Electronic Distributor

Nissan	Part No	Qty	Notes
Pulsar N15 *(NZ Market)* **1/95-9/97 4 Cyl 1.6L GA16DE DOHC 16V**			
Ignition – Distributor Cap	**JP838**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR820**	1	Hitachi Electronic Distributor
Pulsar N15 *(NZ Market)* **4/96-12/05 4 Cyl 1.8L SR18DE DOHC 16V**			
Ignition – Distributor Rotor	**JR802**	1	Mitsubishi Electronic Distributor
Pulsar N15: N15 Series II **10/95-6/00 4 Cyl 1.6L GA16DE DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC243**	1	
Ignition – Distributor Cap	**JP838**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR820**	1	Hitachi Electronic Distributor
Sensor – Coolant Temperature	**CCS37**	1	
Sensor – Crankshaft	**CSCA72**	1	
Sensor – Exhaust Oxygen	**COS748**	1	Direct Fit 1 Wire: Auto Transmission
Sensor – Exhaust Oxygen	**COS738**	1	Direct Fit 1 Wire: Manual Transmission
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: Auto and Manual Transmission
Pulsar N15: N15 Series II **10/95-6/00 4 Cyl 2.0L SR20DE DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC249**	1	
Ignition – Distributor Cap	**JP409**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR815**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM428**	1	
Sensor – Coolant Temperature	**CCS37**	1	
Sensor – Exhaust Oxygen	**COS772**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS120**	1	
Pulsar N16 **7/00-2/03 4 Cyl 1.6L QG16DE DOHC 16V ESPFI FWD**			
Ignition – Coil and Igniter	**CC322**	4	
Sensor – Coolant Temperature	**CCS37**	1	
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Pulsar N16 **7/00-1/06 4 Cyl 1.8L QG18DE DOHC 16V ESPFI FWD**			
Ignition – Coil and Igniter	**CC322**	4	
Sensor – Air Flow / MAF	**CAF032**	1	
Sensor – Coolant Temperature	**CCS37**	1	
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire: Front Manifold
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Rear Eng Pipe
S-Cargo G20 *(NZ Market)* **1988-90 4 Cyl 1.5L E15S**			
Ignition – Distributor Cap	**JP672**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR535**	1	Hitachi Electronic Distributor
Sentra N13 *(NZ Market)* **5/86-4/88 4 Cyl 1.5L E15S**			
Ignition – Distributor Cap	**JP594**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP672**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR615**	1	Mitsubishi Electronic Distributor
Sentra N13 Carb. *(NZ Market)* **1987-89 4 Cyl 1.3L E13S SOHC**			
Ignition – Distributor Cap	**JP672**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR615**	1	Mitsubishi Electronic Distributor

Nissan	Part No	Qty	Notes
Sentra N13 *(NZ Market)* **1987-91 4 Cyl 1.6L E16**			
Ignition – Distributor Cap	**JP666**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP594**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR607**	1	Hitachi Electronic Distributor
Sentra N13 *(NZ Market)* **9/88-on 4 Cyl 1.5L GA15S DOHC 16V**			
Ignition – Distributor Cap	**BD894**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP672**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR615**	1	Mitsubishi Electronic Distributor
Sentra N13 *(NZ Market)* **9/88-on 4 Cyl 1.5L GA15E DOHC 16V**			
Ignition – Distributor Cap	**JP672**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR659**	1	Mitsubishi Electronic Distributor
Sentra N13 *(NZ Market)* **1989-93 4 Cyl 1.4L GA14S SOHC**			
Ignition – Distributor Rotor	**JR535**	1	Mitsubishi Electronic Distributor
Sentra N14 *(NZ Market)* **8/90-on 4 Cyl 1.3L GA13DS DOHC 16V**			
Ignition – Distributor Rotor	**JR806**	1	Mitsubishi Electronic Distributor
Sentra N14 *(NZ Market)* **8/90-on 4 Cyl 1.5L GA15DS DOHC 16V**			
Ignition – Distributor Cap	**JP836**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR806**	1	Mitsubishi Electronic Distributor
Sentra N14 *(NZ Market)* **8/90-on 4 Cyl 1.8L SR18DE DOHC 16V**			
Ignition – Distributor Cap	**BD887**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP836**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR643**	1	Hitachi Electronic Distributor
Sentra N14 *(NZ Market)* **8/90-on 4 Cyl 2.0L SR20DET DOHC 16V**			
Ignition – Distributor Cap	**BD887**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP836**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR643**	1	Hitachi Electronic Distributor
Sentra N14 *(NZ Market)* **1992-96 4 Cyl 1.6L GA16DE DOHC 16V**			
Ignition – Coil – Standard	**CC229**	1	Mitsubishi Electronic Distributor
Sentra N15 *(NZ Market)* **1/95-9/97 4 Cyl 1.5L GA15DE DOHC 16V**			
Ignition – Distributor Cap	**JP838**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR820**	1	Hitachi Electronic Distributor
Sentra N15 *(NZ Market)* **1/95-9/97 4 Cyl 1.6L GA16DE DOHC 16V**			
Ignition – Distributor Cap	**JP838**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR820**	1	Hitachi Electronic Distributor
Sentra N15 *(NZ Market)* **4/96-12/05 4 Cyl 1.8L SR18DE DOHC 16V**			
Ignition – Distributor Rotor	**JR802**	1	Mitsubishi Electronic Distributor

Nissan	Part No	Qty	Notes
Serena **10/92-11/95 4 Cyl 2.0L SR20DE DOHC 16V EFi RWD**			
Ignition – Coil – Standard	**CC223**	1	
Ignition – Module	**CM428**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Temperature Gauge	**CTS141**	1	
Switch – Brake Light	**CSL43**	1	
Switch – Oil Pressure Warning Light	**CPS28**	1	
Skyline C210 **3/78-3/81 6 Cyl 2.4L L24 SOHC 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP526**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Skyline R30 **3/81-6/86 6 Cyl 2.4L L24E SOHC 12V EFi RWD**			
Ignition – Distributor Cap	**JP738**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR655**	1	Hitachi Electronic Distributor
Ignition – Module	**CM416**	1	Import
Sensor – Coolant Temperature	**CCS25**	1	
Sensor – Exhaust Oxygen	**COS811**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Oil Pressure Gauge	**CPS29**	1	
Sensor – Temperature Gauge	**CTS100**	1	To 9/1983
Sensor – Temperature Gauge	**CTS158**	1	From 10/1983
Sensor – Temperature Gauge Adapter	**CTS101**	1	To 9/1983
Sensor – Throttle Position	**CTPS142**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Skyline R30: R31: R32 *(NZ Market)* **1981-93 4 Cyl 1.8L CA18S: CA18I SOHC Carb.**			
Ignition – Distributor Cap	**JP666**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR607**	1	Hitachi Electronic Distributor
Skyline R31: R32 *(NZ Market)* **1985-93 6 Cyl 2.0L RB20DE**			
Ignition – Distributor Cap	**JP694**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR621**	1	Mitsubishi Electronic Distributor

Nissan	Part No	Qty	Notes
Skyline R31 Series I: R31 Series II: R31 Series III **7/86-12/90 6 Cyl 3.0L RB30E SOHC 12V EFi RWD**			
Ignition – Coil – Standard	**CC221**	1	
Ignition – Distributor Cap	**JP694**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**BD136**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR621**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR137**	1	Mitsubishi Electronic Distributor
Ignition – Module	**CM474**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Crankshaft	**CSCA01**	1	Hitachi Distributor
Sensor – Crankshaft	**CSCA01B**	1	Hitachi Distributor: Kit supplied with bearing
Sensor – Crankshaft	**CSCA07**	1	Mitsubishi Distributor
Sensor – Exhaust Oxygen	**COS737**	1	Direct Fit 3 Wire: Titania
Sensor – Temperature Gauge	**CTS130**	1	
Sensor – Throttle Position	**CTPS129**	1	Auto Transmission
Sensor – Throttle Position	**CTPS103**	1	Manual Transmission
Switch – Oil Pressure Warning Light	**CPS28**	1	
Skyline R32 Twin Turbo **1/89-12/93 6 Cyl 2.6L RB26DETT DOHC 24V EFi 4WD**			
Ignition – Coil and Igniter	**CC349**	6	
Skyline R32 Turbo *(NZ Market)* **1989-93 6 Cyl 2.0L RB20DET**			
Ignition – Coil and Igniter	**CC235**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP694**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR621**	1	Mitsubishi Electronic Distributor
Skyline R32 *(NZ Market)* **5/89-on 6 Cyl 1.8L CA18i**			
Ignition – Distributor Cap	**JP716**	1	
Skyline R33 *(NZ Market)* **1993-97 6 Cyl 2.0L RB20E**			
Ignition – Distributor Cap	**JP694**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR621**	1	Mitsubishi Electronic Distributor
Skyline R33 **1/93-12/98 6 Cyl 2.5L RB25DE DOHC 24V MPFi RWD**			
Ignition – Coil and Igniter	**CC349**	6	From 8/1993 To 1/1995
Skyline R33 Turbo **1/93-12/98 6 Cyl 2.5L RB25DET DOHC 24V MPFi RWD**			
Ignition – Coil and Igniter	**CC349**	6	From 8/1993 To 1/1995
ST Utility XFN **7/88-9/92 6 Cyl 4.1L OHV 12V Carb. RWD**			
Ignition – Coil – Standard	**CC200**	1	
Ignition – Distributor Cap	**BH144**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH139**	1	Bosch Electronic Distributor
Ignition – Module	**CM420**	1	
Sensor – Coolant Temperature	**CCS29**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	

Nissan	Part No	Qty	Notes
Stanza **10/78-9/83 4 Cyl 1.6L L16 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor: To 1980
Ignition – Distributor Cap	**BH90**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor: To 1980
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor: To 1980
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor: To 1980
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS102**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Sunny **3/79-12/83 4 Cyl 1.2L A12 OHV Carb. RWD**			
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Sunny **3/79-9/80 4 Cyl 1.4L A14 OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL32**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Sunny **10/80-10/81 4 Cyl 1.5L A15 OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Sunny B11 *(NZ Market)* **1982-85 4 Cyl 1.3L E13S SOHC**			
Ignition – Coil – Standard	**CC305**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP630**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR517**	1	Mitsubishi Electronic Distributor
Sunny B11 Incl. Turbo *(NZ Market)* **1982-85 4 Cyl 1.5L E15S: E15ET**			
Ignition – Coil – Standard	**CC211**	1	Hitachi Points Distributor
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor

Nissan	Part No	Qty	Notes
Sunny B11 *(NZ Market)* **1985-87 4 Cyl 1.3L E13S SOHC**			
Ignition – Coil – Standard	**CC305**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP594**	1	Mitsubishi Electronic Distributor
Sunny B12 *(NZ Market)* **1988-92 4 Cyl 1.6L E16 SOHC**			
Ignition – Distributor Rotor	**JR607**	1	Hitachi Electronic Distributor
Sunny B14 *(NZ Market)* **1/94-5/97 4 Cyl 1.3L GA13DE**			
Ignition – Distributor Cap	**JP838**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR820**	1	Hitachi Electronic Distributor
Sunny B14 *(NZ Market)* **1/94-5/97 4 Cyl 1.6L GA16DE**			
Ignition – Distributor Cap	**JP838**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR820**	1	Hitachi Electronic Distributor
Sunny B14 *(NZ Market)* **1/94-98 4 Cyl 1.5L GA15DE**			
Ignition – Distributor Cap	**JP838**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR820**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR802**	1	Mitsubishi Electronic Distributor
Sylvia S14 Turbo *(NZ Market)* **1993-97 4 Cyl 2.0L SR20DET DOHC**			
Ignition – Coil and Igniter	**CC303**	1	Hitachi Electronic Distributor
Teranno WD21 *(NZ Market)* **1987-93 V6 Cyl 3.0L VG30E SOHC**			
Ignition – Coil – Standard	**CC221**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**DR841A**	1	Hitachi Electronic Distributor
Terrano II R20 **3/97-6/00 4 Cyl 2.4L KA24E SOHC 12V EFi 4WD**			
Ignition – Distributor Cap	**JP838**	1	Hitachi Electronic Distributor
Ignition – Module	**CM428**	1	
Sensor – Coolant Temperature	**CCS37**	1	
Sensor – Exhaust Oxygen	**COS922**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Terrano II R20 Turbo Diesel **3/97-6/00 4 Cyl 2.7L TD27Ti SOHC 8V Di 4WD**			
Sensor – Coolant Temperature	**CCS37**	1	
Urvan E23 Diesel **11/80-7/83 4 Cyl 2.2L SD22 OHV Di RWD**			
Switch – Brake Light	**CSL28**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Urvan E23 **9/82-12/86 4 Cyl 2.0L Z20 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**MC423**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Points Distributor
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Brake Light	**CSL28**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	

Nissan	Part No	Qty	Notes
Urvan E23 **9/82-12/83 4 Cyl 2.0L H20 OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Urvan E23 Diesel **9/82-12/86 4 Cyl 2.3L SD23 OHV Di RWD**			
Switch – Brake Light	**CSL28**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Urvan E24 **3/87-9/93 4 Cyl 2.4L Z24 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP672**	1	Mitsubishi Points Distributor
Ignition – Distributor Condenser	**BC301**	1	Mitsubishi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Mitsubishi Points Distributor
Ignition – Distributor Rotor	**JR615**	1	Mitsubishi Points Distributor
Switch – Brake Light	**CSL28**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Urvan E24 Diesel **5/87-9/93 4 Cyl 2.7L TD27 OHV Di RWD**			
Switch – Brake Light	**CSL28**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Urvan E24 *(NZ Market)* **1989-92 4 Cyl 2.0L Z20**			
Ignition – Distributor Cap	**JP564**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR533**	1	Mitsubishi Electronic Distributor
Vanette C20: C120 **7/82-12/86 4 Cyl 1.2L A12: 1.5L A15 OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP520**	1	Hitachi Points Distributor: To 1982
Ignition – Distributor Cap	**JP544**	1	Hitachi Points Distributor: From 1982
Ignition – Distributor Condenser	**MC418**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Sensor – Temperature Gauge	**CTS100**	1	
Sensor – Temperature Gauge Adapter	**CTS101**	1	
Switch – Oil Pressure Warning Light	**CPS22**	1	
Vanette C22 **12/87-9/93 4 Cyl 2.0L Z20 SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	To 4/1988
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	To 4/1988
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	To 4/1988
Ignition – Distributor Cap	**JP564**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR533**	1	Hitachi Points Distributor

Nissan	Part No	Qty	Notes
Vanette C22 *(NZ Market)* **1988-90 4 Cyl 1.5L A15**			
Ignition – Distributor Cap	**JP544**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Peugeot			
205: 306: 405 CJ: Cti: Gti *(NZ Market)* **1986-96 4 Cyl 1.4:1.6:1.9L TU3:XU5:9**			
Ignition – Distributor Rotor	**BH107**	1	Bosch Electronic Distributor
205 GTi **10/87-3/91 4 Cyl 1.9L XU9JA SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC362**	1	To 1989
Ignition – Module	**CM413**	1	To 1989
Sensor – Exhaust Oxygen	**COS792**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
205 GTi **4/91-12/94 4 Cyl 1.9L SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC360**	1	
306 **4/94-6/97 4 Cyl 1.8L XU7JPZ SOHC 8V MPFi FWD**			
Ignition – Coil – Standard	**CC365**	1	
Sensor – Exhaust Oxygen	**COS897**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
306 **11/95-6/97 4 Cyl 2.0L XU10J2 SOHC 8V MPFi FWD**			
Sensor – Exhaust Oxygen	**COS897**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
306 **7/97-12/01 4 Cyl 1.8L XU7JP4: 2.0L XU10J4R DOHC 16V MPFi FWD**			
Sensor – Exhaust Oxygen	**COS897**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
405 **2/89-6/91 4 Cyl 1.9L D6A: XU9J2 SOHC 8V EFi FWD**			
Sensor – Exhaust Oxygen	**COS897**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
405 Mi16 **2/89-4/93 4 Cyl 1.9L D6C: XU9J4 DOHC 16V EFi FWD**			
Sensor – Exhaust Oxygen	**COS813**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
405 Mi16: Sti **5/93-5/96 4 Cyl 2.0L XU10J2: XU10J4 DOHC 16V EFi FWD**			
Sensor – Exhaust Oxygen	**COS897**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
406 **9/96-8/99 4 Cyl 2.0L XU10J4R DOHC 16V PFI FWD**			
Sensor – Exhaust Oxygen	**COS897**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire

Peugeot	Part No	Qty	Notes
504 **6/70-4/71 4 Cyl 1.8L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH78**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S1V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH77**	1	Bosch Points Distributor
504 **5/71-12/83 4 Cyl 2.0L OHV Carb. & Fi RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**RB102**	1	Ducellier Points Distributor: To 1981
Ignition – Distributor Condenser	**DC100**	1	Ducellier Points Distributor: To 1981
Ignition – Distributor Points / Contact Set	**S133**	1	Ducellier Points Distributor: To 1981
Ignition – Distributor Rotor	**RB99**	1	Ducellier Points Distributor: To 1981
505 **10/80-2/86 4 Cyl 2.0L XN1 OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Points / Contact Set	**S260**	1	Ducellier Points Distributor
Ignition – Distributor Rotor	**BH107**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**RB105**	1	Ducellier Points Distributor
505 Sti **8/83-2/86 4 Cyl 2.2L SOHC 8V EFi RWD**			
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor: To 1986
Ignition – Module	**CM410**	1	
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
505 **2/86-11/88 4 Cyl 2.0L XN6 OHV EFi RWD**			
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH107**	1	Bosch Electronic Distributor
Ignition – Module	**CM410**	1	
Sensor – Exhaust Oxygen	**COS789**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
604 **4/78-6/82 6 Cyl 2.7L SOHC Carb. RWD**			
Ignition – Distributor Cap	**BH146**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH153**	1	Bosch Electronic Distributor
Porsche			
911T **1970-71 6 Cyl 2.2L Carb. RWD**			
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
911E **1971-73 6 Cyl 2.4L EFi RWD**			
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
911S: 911T **1971-73 6 Cyl 2.4L Carb. & EFi RWD**			
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor

Porsche	Part No	Qty	Notes
911S			
1973-77 6 Cyl 2.7L EFi RWD			
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
911 Turbo			
1975-12/85 6 Cyl 3.0L: 3.3L EFi RWD			
Ignition – Distributor Cap	**BH140**	1	Bosch Electronic Distributor
911SC			
11/77-12/83 6 Cyl 3.0L EFi RWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH140**	1	Bosch Electronic Distributor
Sensor – Exhaust Oxygen	**COS738**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
924			
1976-82 4 Cyl 2.0L EFi RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor: To 1980
Ignition – Distributor Condenser	**BC115**	1	Bosch Points Distributor: To 1980
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor: To 1980
Switch – Oil Pressure Warning Light	**CPS20**	1	
Switch – Radiator Fan	**CFS19**	1	
924 Turbo			
1979-80 4 Cyl 2.0L EFi RWD			
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR460**	1	Bosch Electronic Distributor
924 Carrera Turbo			
1980-82 4 Cyl 2.0L EFi RWD			
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Module	**CM409**	1	
924			
1980-82 4 Cyl 2.0L EFi RWD			
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH95**	1	Bosch Electronic Distributor
Ignition – Module	**CM409**	1	
928			
1977-82 V8 Cyl 4.5L EFi RWD			
Ignition – Distributor Cap	**BH130**	1	Bosch Electronic Distributor
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS787**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Switch – Oil Pressure Warning Light	**CPS20**	1	
Switch – Radiator Fan	**CFS19**	1	
928S			
1979-83 V8 Cyl 4.7L EFi RWD			
Ignition – Distributor Cap	**BH130**	1	Bosch Electronic Distributor
928			
1983-85 V8 Cyl 4.7L EFi RWD			
Ignition – Distributor Cap	**BH126**	1	Bosch Electronic Distributor
Sensor – Exhaust Oxygen	**COS787**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Switch – Radiator Fan	**CFS19**	1	
928S			
1985-91 V8 Cyl 5.0L EFi RWD			
Ignition – Distributor Cap	**BH172**	1	Bosch Electronic Distributor
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire: 1987-91

Porsche	Part No	Qty	Notes
944 **1982-89 4 Cyl 2.5L EFi RWD**			
Ignition – Distributor Cap	**BH126**	1	Bosch Electronic Distributor
Sensor – Exhaust Oxygen	**COS738**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Switch – Oil Pressure Warning Light	**CPS20**	1	
Switch – Radiator Fan	**CFS19**	1	
Proton			
M21 **10/97-11/00 4 Cyl 1.8L 4G93 DOHC 16V MPFi FWD**			
Ignition – Distributor Cap	**JP815**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR814**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA01**	1	
Sensor – Crankshaft	**CSCA01B**	1	Kit supplied with bearing
Sensor – Exhaust Oxygen	**COS848**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Radiator Fan	**CFS29**	1	
Persona **11/96-4/00 4 Cyl 1.5L 4G15 SOHC 12V MPFi FWD**			
Ignition – Distributor Cap	**JP815**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR814**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA78**	1	In Distributor: Optic Type
Sensor – Crankshaft	**CSCA11**	1	In Distributor: Hall Type
Sensor – Exhaust Oxygen	**COS753**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Radiator Fan	**CFS29**	1	
Persona **11/96-11/00 4 Cyl 1.6L 4G92 SOHC 12V MPFi FWD**			
Ignition – Distributor Cap	**JP817**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR815**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Exhaust Oxygen	**COS848**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Radiator Fan	**CFS29**	1	
Persona **10/99-6/02 4 Cyl 1.3L 4G13 SOHC 12V MPFi FWD**			
Ignition – Distributor Cap	**JP815**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR815**	1	Mitsubishi Electronic Distributor
Persona **11/00-6/02 4 Cyl 1.5L 4G15 SOHC 12V MPFi FWD**			
Sensor – Crankshaft	**CSCA78**	1	In Distributor
Satria **2/97-1/05 4 Cyl 1.5L 4G15 SOHC 12V MPFi FWD**			
Ignition – Distributor Cap	**JP815**	1	Mitsubishi Electronic Distributor: To 9/1999
Ignition – Distributor Rotor	**JR814**	1	Mitsubishi Electronic Distributor: To 9/1999
Sensor – Coolant Temperature	**CCS33**	1	
Sensor – Crankshaft	**CSCA11**	1	In Distributor: Hall Type
Sensor – Exhaust Oxygen	**COS753**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Radiator Fan	**CFS29**	1	

Proton	Part No	Qty	Notes
Satria			
2/97-11/00 4 Cyl 1.6L 4G92 SOHC 16V MPFi FWD			
Ignition – Distributor Cap	**JP817**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR815**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Exhaust Oxygen	**COS848**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Radiator Fan	**CFS29**	1	
Satria			
9/99-6/02 4 Cyl 1.3L 4G13 SOHC 12V MPFi FWD			
Ignition – Distributor Cap	**JP817**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR815**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS33**	1	
Switch – Radiator Fan	**CFS29**	1	
Satria Gti			
10/99-on 4 Cyl 1.8L 4G93 DOHC 16V MPFi FWD			
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Crankshaft	**CSCA01**	1	
Sensor – Crankshaft	**CSCA01B**	1	Kit supplied with bearing
Sensor – Exhaust Oxygen	**COS848**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Radiator Fan	**CFS29**	1	
Wira			
5/95-11/96 4 Cyl 1.5L 4G15 SOHC 12V MPFi FWD			
Ignition – Distributor Cap	**JP815**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR814**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS33**	1	
Sensor – Crankshaft	**CSCA11**	1	In Distributor: Hall Type
Sensor – Exhaust Oxygen	**COS753**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS215**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Radiator Fan	**CFS29**	1	
Wira			
5/95-11/96 4 Cyl 1.6L 4G92 SOHC 16V MPFi FWD			
Ignition – Distributor Cap	**JP815**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR814**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS39**	1	
Sensor – Exhaust Oxygen	**COS848**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Radiator Fan	**CFS29**	1	

Rambler	Part No	Qty	Notes
Javelin			
9/68-8/70 V8 Cyl 343ci Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**DR102**	1	Delco Points Distributor
Ignition – Distributor Condenser	**UC11E**	1	Delco Points Distributor
Ignition – Distributor Points / Contact Set	**S143V**	1	Delco Points Distributor
Ignition – Distributor Rotor	**DR65**	1	Delco Points Distributor: Standard Rotor
Ignition – Distributor Rotor	**DR1670**	1	Delco Points Distributor: Performance Rotor
Rebel			
5/67-11/71 V8 Cyl 290ci: 343ci Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**DR102**	1	Delco Points Distributor
Ignition – Distributor Condenser	**UC11E**	1	Delco Points Distributor
Ignition – Distributor Points / Contact Set	**S143V**	1	Delco Points Distributor
Ignition – Distributor Rotor	**DR65**	1	Delco Points Distributor: Standard Rotor
Ignition – Distributor Rotor	**DR1670**	1	Delco Points Distributor: Performance Rotor
Renault			
10			
8/66-6/71 4 Cyl 1.1L Carb. FWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**RB102**	1	Ducellier Points Distributor
Ignition – Distributor Condenser	**DC100**	1	Ducellier Points Distributor
Ignition – Distributor Points / Contact Set	**S133**	1	Ducellier Points Distributor
Ignition – Distributor Rotor	**RB99**	1	Ducellier Points Distributor
12			
11/70-12/76 4 Cyl 1.3L Carb. FWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH96**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
Switch – Oil Pressure Warning Light	**CPS21**	1	
15 TS			
1/73-5/76 4 Cyl 1.6L OHV Carb. FWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**RB102**	1	Ducellier Points Distributor
Ignition – Distributor Condenser	**DC100**	1	Ducellier Points Distributor
Ignition – Distributor Points / Contact Set	**S133**	1	Ducellier Points Distributor
Ignition – Distributor Rotor	**RB99**	1	Ducellier Points Distributor
Switch – Oil Pressure Warning Light	**CPS21**	1	

Renault	Part No	Qty	Notes
16 **6/68-3/71 4 Cyl 1.5L Carb. FWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**RB102**	1	Ducellier Points Distributor
Ignition – Distributor Condenser	**DC100**	1	Ducellier Points Distributor
Ignition – Distributor Points / Contact Set	**S133**	1	Ducellier Points Distributor
Ignition – Distributor Rotor	**RB99**	1	Ducellier Points Distributor
Switch – Oil Pressure Warning Light	**CPS21**	1	
16 TS **4/69-12/77 4 Cyl 1.6L OHV Carb. FWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH96**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
Switch – Oil Pressure Warning Light	**CPS21**	1	
17 **1/73-12/76 4 Cyl 1.6L OHV Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**RB102**	1	Ducellier Points Distributor
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor: From 1974
Ignition – Distributor Condenser	**DC100**	1	Ducellier and Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S133**	1	Ducellier Points Distributor
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor: From 1974
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor: From 1974
Ignition – Distributor Rotor	**RB105**	1	Ducellier Points Distributor
Switch – Oil Pressure Warning Light	**CPS21**	1	
18 GTS **3/80-12/83 4 Cyl 1.6L Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**RB102**	1	Ducellier Points Distributor
Ignition – Distributor Condenser	**DC100**	1	Ducellier Points Distributor
Ignition – Distributor Rotor	**RB105**	1	Ducellier Points Distributor
Switch – Oil Pressure Warning Light	**CPS21**	1	
20 TS **5/79-12/83 4 Cyl 2.0L SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**RB102**	1	Ducellier Points Distributor
Ignition – Distributor Condenser	**DC100**	1	Ducellier Points Distributor
Ignition – Distributor Rotor	**RB105**	1	Ducellier Points Distributor
Fuego GTX **10/82-11/87 4 Cyl 2.0L J6R Carb. FWD**			
Ignition – Distributor Cap	**RB102**	1	Ducellier Electronic Distributor
Ignition – Distributor Rotor	**RB105**	1	Ducellier Electronic Distributor
Ignition – Module	**CM410**	1	
Switch – Oil Pressure Warning Light	**CPS21**	1	

Renault	Part No	Qty	Notes
R25 GTX **7/85-7/89 4 Cyl 2.2L J7T SOHC 8V MPFi FWD**			
Ignition – Module	**CM410**	1	
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Virage **2/78-12/80 4 Cyl 1.4L OHV 8V Carb. FWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH96**	1	Bosch Points Distributor
Ignition – Distributor Cap	**RB102**	1	Ducellier Points Distributor
Ignition – Distributor Condenser	**BC71**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**DC100**	1	Ducellier Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S133**	1	Ducellier Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**RB99**	1	Ducellier Points Distributor
Rover			
3.5 Litre **7/68-2/72 V8 Cyl 3.5L OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD280**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**DR71**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
111 1.1i *(NZ Market)* **1990-98 4 Cyl 1.1L K8 8V**			
Ignition – Distributor Cap	**BD896**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD897**	1	Lucas Electronic Distributor
114 1.4i *(NZ Market)* **1990-98 4 Cyl 1.4L K8 8V**			
Ignition – Distributor Cap	**BD896**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD897**	1	Lucas Electronic Distributor
214 1.4i *(NZ Market)* **1989-96 4 Cyl 1.4L K16 16V**			
Ignition – Distributor Cap	**BD896**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD897**	1	Lucas Electronic Distributor
214 1.4i *(NZ Market)* **1992-93 4 Cyl 1.4L K8 8V**			
Ignition – Distributor Cap	**BD896**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD897**	1	Lucas Electronic Distributor
216 1.6i *(NZ Market)* **1995-on 4 Cyl 1.6L K16 16V**			
Ignition – Distributor Cap	**BD896**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD897**	1	Lucas Electronic Distributor
218 1.8i *(NZ Market)* **1996-on 4 Cyl 1.8L K16 16V**			
Ignition – Distributor Cap	**BD896**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD897**	1	Lucas Electronic Distributor

Rover	Part No	Qty	Notes
220 2.0i Incl. Turbo *(NZ Market)* **1992-96 4 Cyl 2.0L 20T4 16V**			
Ignition – Distributor Cap	**BD896**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD897**	1	Lucas Electronic Distributor
414 1.4i *(NZ Market)* **1992-96 4 Cyl 1.4L K8 8V**			
Ignition – Distributor Cap	**BD896**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD897**	1	Lucas Electronic Distributor
414 1.4i *(NZ Market)* **1990-96 4 Cyl 1.4L K16 16V**			
Ignition – Distributor Cap	**BD896**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD897**	1	Lucas Electronic Distributor
416i **5/86-12/89 4 Cyl 1.6L D16A3 DOHC 16V EFi FWD**			
Ignition – Distributor Cap	**JP660**	1	TEC Electronic Distributor
Ignition – Distributor Rotor	**JR517**	1	TEC Electronic Distributor
Ignition – Module	**CM400**	1	
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS115**	1	
Switch – Radiator Fan	**CFS12**	1	
420 2.0i Incl. Turbo *(NZ Market)* **1992-96 4 Cyl 2.0L 20T4 16V**			
Ignition – Distributor Cap	**BD896**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD897**	1	Lucas Electronic Distributor
620 2.0i Turbo *(NZ Market)* **1995-96 4 Cyl 2.0L 20T4 16V**			
Ignition – Distributor Cap	**BD896**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD897**	1	Lucas Electronic Distributor
623 XWZ *(NZ Market)* **1994-98 4 Cyl 2.3L H23A**			
Ignition – Distributor Cap	**JP968**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR995**	1	Hitachi Electronic Distributor
820 2.0i Turbo *(NZ Market)* **1991-96 4 Cyl 2.0L 20T4 16V**			
Ignition – Distributor Cap	**BD896**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD897**	1	Lucas Electronic Distributor
825Si **9/87-9/88 V6 Cyl 2.5L C25A1 SOHC 12V EFi FWD**			
Ignition – Module	**CM400**	1	
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS115**	1	
Switch – Oil Pressure Warning Light	**CPS20**	1	
827Si Sterling: Vitesse **10/88-1/92 V6 Cyl 2.7L C27A1 SOHC 24V EFi FWD**			
Ignition – Distributor Cap	**BD560**	1	TEC Electronic Distributor
Ignition – Distributor Rotor	**DR561**	1	TEC Electronic Distributor
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire

Rover	Part No	Qty	Notes
2000 **1/65-8/73 4 Cyl 2.0L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD270**	1	Lucas Points Distributor: To 1967
Ignition – Distributor Cap	**BD276**	1	Lucas Points Distributor: From 1967
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS128**	1	
3500 P6: 3500: 3500S **6/69-7/81 V8 Cyl 3.5L Carb. & 2xCarb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD280**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor: To 1972
Ignition – Distributor Points / Contact Set	**S261**	1	Lucas Points Distributor: From 1973
Ignition – Distributor Rotor	**DR71**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	
3500 SDI **8/81-7/87 V8 Cyl 3.5L 20A, 21A EFi RWD**			
Ignition – Distributor Cap	**BD280**	1	Lucas Electronic Distributor
Ignition – Distributor Rotor	**BD299**	1	Lucas Electronic Distributor
Ignition – Module	**CM410**	1	
Quintet **5/83-3/86 4 Cyl 1.6L EL SOHC 8V Carb. FWD**			
Ignition – Distributor Cap	**JP562**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Electronic Distributor
Sensor – Temperature Gauge	**CTS115**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS12**	1	
Range Rover Series I **6/72-12/79 V8 Cyl 3.5L OHV 2xCarb. 4WD**			
Ignition – Distributor Cap	**BD280**	1	Lucas Points Distributor: From 1973
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: From 1973
Ignition – Distributor Points / Contact Set	**S261**	1	Lucas Points Distributor: From 1973
Ignition – Distributor Rotor	**DR71**	1	Lucas Points Distributor: From 1973
Range Rover Series I **4/82-1/89 V8 Cyl 3.5L OHV Carb. 4WD**			
Ignition – Distributor Cap	**BD280**	1	Lucas Electronic Distributor: From 1984
Ignition – Distributor Rotor	**BD299**	1	Lucas Electronic Distributor: From 1984
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS34**	1	
Range Rover Series I **7/93-4/95 V8 Cyl 3.9L 37D, 38D OHV 16V MPFi 4WD**			
Ignition – Module	**CM476**	1	
Range Rover L322 Vogue **8/02-7/05 V8 Cyl 4.4L M62TUB44 DOHC 32V MPFi 4WD**			
Sensor – Exhaust Oxygen	**COS914**	2	Direct Fit 4 Wire: LH and RH Side Eng Pipe
Sensor – Exhaust Oxygen	**COS866**	2	Direct Fit 4 Wire: LH and RH Side Before Catalyst
Sensor – Exhaust Oxygen – Universal	**COS724**	4	Universal 4 Wire: LH and RH Side Eng Pipe: LH and RH side Before Catalyst

SAAB	Part No	Qty	Notes
9-3 Non Turbo			
6/98-1/99 4 Cyl 2.3L B234I DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC262**	1	Motronic
9-3 Turbo			
6/98-1/01 4 Cyl 2.0L B204L: B204E: B204R: B205R DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC262**	1	Motronic
9-3 Turbo			
8/99-1/01 4 Cyl 2.3L B235R DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC262**	1	Motronic
9-5 Turbo			
3/99-10/01 V6 Cyl 3.0L B308 DOHC 24V MPFi FWD			
Sensor – Crankshaft	**CSCA199**	1	With Trionic Engine Management
99			
12/71-3/73 4 Cyl 1.9L Carb. & Fi FWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor: Carb
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor: Fuel Injected
Ignition – Distributor Rotor	**BH89**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS121**	1	
Switch – Oil Pressure Warning Light	**CPS20**	1	
99			
3/73-3/76 4 Cyl 2.0L B201 SOHC 8V Carb. & EFi FWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor: To 1974
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor: To 1974
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor: To 1974
Sensor – Exhaust Oxygen	**COS776**	1	Direct Fit 1 Wire: Fuel Injected
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire: Fuel Injected
Sensor – Temperature Gauge	**CTS121**	1	
Switch – Oil Pressure Warning Light	**CPS30**	1	
900			
3/79-12/84 4 Cyl 2.0L B201 SOHC 8V MPFi FWD			
Sensor – Temperature Gauge	**CTS121**	1	
Switch – Oil Pressure Warning Light	**CPS20**	1	
Switch – Radiator Fan	**CFS18**	1	
900			
1/86-1/90 4 Cyl 2.0L B202 DOHC 16V MPFi FWD			
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH107**	1	Bosch Electronic Distributor
900 Turbo			
1/86-10/93 4 Cyl 2.0L B202 DOHC 16V MPFi FWD			
Sensor – Knock Control	**CKS108**	1	Turbo
Sensor – Throttle Position	**CTPS146**	1	Without Lucas injection
900i			
11/88-2/91 4 Cyl 2.0L B202 DOHC 16V MPFi FWD			
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS121**	1	
Sensor – Throttle Position	**CTPS146**	1	

SAAB	Part No	Qty	Notes
900			
3/91-1/92 4 Cyl 2.1L B212 DOHC 16V MPFi FWD			
Sensor – Exhaust Oxygen	**COS793**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
900i			
3/91-9/93 4 Cyl 2.1L B212 DOHC 16V EFi FWD			
Sensor – Exhaust Oxygen	**COS793**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS108**	1	Turbo
Sensor – Throttle Position	**CTPS100**	1	
900S			
3/94-6/98 4 Cyl 2.0L B206: 2.3L B234 DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC262**	1	
Sensor – Coolant Temperature	**CCS41**	1	From 1996
Sensor – Crankshaft	**CSCA13**	1	
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS106**	1	To 1995
Sensor – Throttle Position	**CTPS100**	1	To 1996
Sensor – Throttle Position	**CTPS108**	1	From 1997
900S: 900SE			
3/94-3/97 V6 Cyl 2.5L B258 DOHC 24V MPFi FWD			
Sensor – Air Flow / MAF	**CAF014**	1	
Sensor – Camshaft	**CSCA196**	1	To 1995
Sensor – Camshaft	**CSCA179**	1	To Engine 55898
Sensor – Camshaft	**CSCA114**	1	From Engine 55899
Sensor – Crankshaft	**CSCA190**	1	To 1995
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
900			
1/97-6/98 4 Cyl 2.0L B206 DOHC 16V EFi FWD			
Ignition – Module	**CM409**	1	
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
9000 Turbo			
5/86-2/91 4 Cyl 2.0L B202T DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Module	**CM409**	1	
Sensor – Exhaust Oxygen	**COS793**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS108**	1	
Sensor – Throttle Position	**CTPS146**	1	
9000			
1/87-4/90 4 Cyl 2.0L B202i DOHC 16V EFi FWD			
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Throttle Position	**CTPS146**	1	
9000 Incl. Turbo			
5/90-12/92 4 Cyl 2.3L B234 DOHC 16V EFi FWD			
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor
Ignition – Module	**CM409**	1	To 1993
Sensor – Crankshaft	**CSCA13**	1	With Trionic Engine Management
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
9000			
2/95-2/97 V6 Cyl 3.0L B308 DOHC 24V EFi FWD			
Sensor – Air Temperature – Inlet	**CAT021**	1	To 1995
Sensor – Crankshaft	**CSCA198**	1	
Sensor – Crankshaft	**CSCA190**	1	With Motronic Engine Management : To 1995

Seat	Part No	Qty	Notes
Cordoba			
1/95-1/97 4 Cyl 1.8L ABS SOHC 8V SPFI FWD			
Sensor – Coolant Temperature	**CCS50**	1	
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Cordoba			
9/98-10/99 4 Cyl 1.6L AFT SOHC 8V MPFi FWD			
Ignition – Coil and Igniter	**CC376**	1	
Ibiza			
1/95-1/97 4 Cyl 1.4L ABD SOHC 8V SPFI FWD			
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Exhaust Oxygen	**COS919**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Oil Pressure Warning Light	**CPS48**	1	
Ibiza			
9/98-10/99 4 Cyl 2.0L ABF DOHC 16V MPFi FWD			
Ignition – Coil and Igniter	**CC376**	1	
Toledo			
1/95-1/97 4 Cyl 2.0L 2E SOHC 8V MPFi FWD			
Ignition – Distributor Cap	**JP987**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR127**	1	Bosch Electronic Distributor
Sensor – Exhaust Oxygen	**COS824**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Toledo			
10/95-1/97 4 Cyl 2.0L ABF DOHC 16V MPFi FWD			
Sensor – Exhaust Oxygen	**COS824**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Ssangyong			
Chairman			
8/05-9/07 6 Cyl 3.2L M104 DOHC 24V EPFI RWD			
Ignition – Coil – Standard	**CC369**	3	
Korando			
2/98-7/98 4 Cyl 2.3L DOHC MPFi 4WD			
Ignition – Coil – Standard	**CC369**	1	From 4/1998 To 9/2001
Musso			
7/96-7/98 6 Cyl 3.2L IL63200 DOHC 24V MPFi 4WD			
Sensor – Camshaft	**CSCA107**	1	
Sensor – MAP	**CMS229**	1	

Subaru	Part No	Qty	Notes
1400 GSR **7/73-3/75 4 Cyl 1.4L EA63 Carb. FWD**			
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS21**	1	
Brumby **5/78-12/80 4 Cyl 1.6L EA71 OHV 8V Carb. 4WD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor: To 1979
Ignition – Distributor Condenser	**MC418**	1	Denso Points Distributor: To 1979
Ignition – Distributor Points / Contact Set	**S214V**	1	Denso Points Distributor: To 1979
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: To 1979
Brumby **10/80-12/81 4 Cyl 1.8L EA81 OHV 8V Carb. 4WD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP630**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**BC393**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Ignition – Module & Pickup / Trigger	**CM417**	1	
Brumby **1/84-3/94 4 Cyl 1.8L EA81 OHV 8V Carb. 4WD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP630**	1	Hitachi Points Distributor
Ignition – Distributor Condenser	**BC393**	1	Hitachi Points Distributor
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor
Ignition – Module & Pickup / Trigger	**CM417**	1	
Brumby AU5 *(NZ Market)* **1986-93 4 Cyl 1.8L EA82 SOHC 8V**			
Ignition – Distributor Cap	**JP630**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Electronic Distributor
DL **7/73-9/80 4 Cyl 1.4L EA63: 1.6L EA71 OHV Carb. FWD & 4WD**			
Switch – Radiator Fan	**CFS81**	1	
DL **12/84-3/85 4 Cyl 1.8L EA82 SOHC 8V Carb. 4WD**			
Ignition – Module & Pickup / Trigger	**CM417**	1	
Switch – Radiator Fan	**CFS27**	1	
Forester SG9 **7/02-6/05 4 Cyl 2.5L EJ251 SOHC 16V ESPFI AWD**			
Ignition – Coil and Igniter	**CC301**	4	
Sensor – Air Temperature – Inlet	**CAT010**	1	
GF **4/75-12/78 4 Cyl 1.4L EA63: 1.6L EA71 OHV Carb. FWD**			
Switch – Radiator Fan	**CFS81**	1	

Subaru	Part No	Qty	Notes
Impreza GC: GF			
4/93-9/98 4 Cyl 1.6L EJ16E: EJ16J: 1.8L EJ18S SOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC269**	1	
Sensor – Coolant Temperature	**CCS45**	1	
Sensor – Crankshaft	**CSCA43**	1	
Sensor – Exhaust Oxygen	**COS773**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Impreza GC: GF WRX Turbo			
2/94-9/98 4 Cyl 2.0L EJ20G DOHC 16V MPFi AWD			
Ignition – Coil – Standard	**CC234**	1	
Sensor – Camshaft	**CSCA88**	1	
Sensor – Coolant Temperature	**CCS45**	1	
Sensor – Crankshaft	**CSCA43**	1	
Sensor – Exhaust Oxygen	**COS931**	1	Direct Fit 3 Wire: To 7/1996
Sensor – Exhaust Oxygen	**COS785**	1	Direct Fit 3 Wire: From 8/1996
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS104**	1	To 7/1996
Sensor – Temperature Gauge	**CTS110**	1	
Impreza GC: GF			
3/96-4/99 4 Cyl 2.0L EJ20E SOHC 16V MPFi AWD			
Ignition – Coil – Standard	**CC234**	1	
Sensor – Camshaft	**CSCA88**	1	
Sensor – Coolant Temperature	**CCS45**	1	
Sensor – Crankshaft	**CSCA43**	1	
Sensor – Exhaust Oxygen	**COS773**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS104**	1	To 7/1996
Sensor – Temperature Gauge	**CTS110**	1	
Impreza GD: GG			
10/00-8/07 4 Cyl 2.0L EJ201 SOHC 16V MPFi AWD			
Sensor – Air Temperature – Inlet	**CAT010**	1	From 7/2005
Justy JKA5BA *(NZ Market)*			
2/84-10/88 3 Cyl 1.0L EF10			
Ignition – Distributor Rotor	**JR517**	1	Mitsubishi Points Distributor
L Series			
9/88-6/90 4 Cyl 1.8L EA82 SOHC 8V EFi 4WD			
Ignition – Coil – Standard	**CC297**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS742**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Switch – Radiator Fan	**CFS27**	1	
Leone			
1/80-12/80 4 Cyl 1.6L EA71 OHV 8V Carb. 4WD			
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS81**	1	

Subaru	Part No	Qty	Notes
Leone **11/79-12/84 4 Cyl 1.8L EA81 OHV 8V Carb. FWD**			
Ignition – Coil – Standard	**CC202**	1	Points ignition
Ignition – Distributor Cap	**JP630**	1	Hitachi Points Distributor: From 1980
Ignition – Distributor Condenser	**BC393**	1	Hitachi Points Distributor: From 1980
Ignition – Distributor Points / Contact Set	**S219VU**	1	Hitachi Points Distributor: From 1980
Ignition – Distributor Rotor	**JR517**	1	Hitachi Points Distributor: From 1980
Ignition – Module & Pickup / Trigger	**CM417**	1	Electronic Ignition
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS81**	1	
Leone **12/84-8/88 4 Cyl 1.8L EA81 OHV 8V Carb. FWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Module & Pickup / Trigger	**CM417**	1	
Sensor – Temperature Gauge	**CTS104**	1	
Leone AA5 *(NZ Market)* **7/84-89 4 Cyl 1.8L EA82 4WD**			
Ignition – Distributor Cap	**JP630**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Electronic Distributor
Leone AA5: AA7 Turbo *(NZ Market)* **7/84-2/89 4 Cyl 1.8L EA82T 4WD**			
Ignition – Distributor Cap	**JP648**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Leone AL5 *(NZ Market)* **10/84-2/89 4 Cyl 1.8L EA82 4WD**			
Ignition – Distributor Cap	**JP648**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Leone AK2: AK4 *(NZ Market)* **1985-87 4 Cyl 1.6L EA71 2WD**			
Ignition – Coil – Standard	**CC211**	1	Hitachi Electronic Distributor
Ignition – Distributor Cap	**JP630**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Electronic Distributor
Leone **8/85-8/87 4 Cyl 1.8L EA82 SOHC 8V Carb. 4WD**			
Ignition – Module & Pickup / Trigger	**CM417**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Switch – Radiator Fan	**CFS27**	1	
Leone Turbo **8/87-6/88 4 Cyl 1.8L EA82 SOHC 8V EFi 4WD**			
Ignition – Coil – Standard	**CC298**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS742**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Switch – Radiator Fan	**CFS27**	1	
Leone **9/88-9/90 4 Cyl 1.8L EA82 SOHC 8V EFi FWD**			
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS27**	1	
Liberty **10/89-6/94 4 Cyl 2.2L EJ22E SOHC 16V MPFi AWD**			
Sensor – Temperature Gauge	**CTS110**	1	

Subaru	Part No	Qty	Notes
Liberty BC6 **10/89-6/94 4 Cyl 2.2L EJ22E SOHC 16V MPFi FWD**			
Sensor – Camshaft	**CSCA88**	1	From 1/1994
Sensor – Coolant Temperature	**CCS45**	1	
Sensor – Crankshaft	**CSCA71**	1	To 12/1993
Sensor – Crankshaft	**CSCA43**	1	From 1/1994
Sensor – Exhaust Oxygen	**COS773**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS104**	1	To 3/1996
Sensor – Temperature Gauge	**CTS110**	1	
Liberty BC7 **8/90-6/94 4 Cyl 2.2L EJ22E SOHC 16V MPFi AWD**			
Ignition – Coil – Standard	**CC234**	1	
Sensor – Coolant Temperature	**CCS45**	1	
Sensor – Exhaust Oxygen	**COS773**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Liberty BC5: BF5 Turbo **10/91-6/94 4 Cyl 2.0L EJ20BUB DOHC 16V MPFi 4WD**			
Sensor – Coolant Temperature	**CCS45**	1	
Sensor – Exhaust Oxygen	**COS931**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS104**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Liberty BD6: BD7: BG7: BG8 **6/94-11/96 4 Cyl 2.2L EJ22E SOHC 16V MPFi FWD**			
Sensor – Temperature Gauge	**CTS110**	1	
Liberty BD9 **11/96-3/99 4 Cyl 2.5L EJ25D DOHC 16V MPFi AWD**			
Ignition – Coil – Standard	**CC234**	1	
Sensor – Coolant Temperature	**CCS45**	1	
Sensor – Exhaust Oxygen	**COS773**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Liberty BH5 **10/98-8/03 4 Cyl 2.0L EJ201 SOHC 16V MPFi AWD**			
Ignition – Coil and Igniter	**CC301**	4	
Sensor – Exhaust Oxygen	**COS773**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Liberty BE9 **3/99-8/99 4 Cyl 2.5L EJ251 SOHC 16V MPFi AWD**			
Sensor – Exhaust Oxygen	**COS773**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Liberty BL9 **9/03-7/07 4 Cyl 2.5L EJ253 SOHC 16V MPFi AWD**			
Sensor – Air Temperature – Inlet	**CAT010**	1	
Omega AC4, AN5 *(NZ Market)* **1988-93 4 Cyl 1.8L EA82**			
Ignition – Distributor Cap	**JP630**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR517**	1	Hitachi Electronic Distributor
Outback BG9 **9/96-10/98 4 Cyl 2.5L EJ25 DOHC 16V MPFi AWD**			
Sensor – Exhaust Oxygen	**COS773**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS110**	1	

Subaru	Part No	Qty	Notes
Outback BHE **10/00-8/03 6 Cyl 3.0L EZ30D DOHC 24V MPFi AWD**			
Ignition – Coil and Igniter	**CC300**	6	
Outback BP9 **9/03-on 4 Cyl 2.5L EJ253 SOHC 16V MPFi AWD**			
Sensor – Air Temperature – Inlet	**CAT010**	1	
RX Turbo **11/85-8/87 4 Cyl 1.8L EA82T SOHC 8V EFi 4WD**			
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS738**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sportswagon **9/87-9/90 4 Cyl 1.8L EA82 SOHC 8V Carb. 4WD**			
Ignition – Module & Pickup / Trigger	**CM417**	1	
SVX **3/92-4/97 6 Cyl 3.3L EG33M DOHC 24V MPFi 4WD**			
Sensor – Exhaust Oxygen	**COS773**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Vortex XT **9/85-9/88 4 Cyl 1.8L EA82 SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP648**	1	Denso Electronic Distributor: From 1986
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor: From 1986
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS738**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS21**	1	
Vortex XT Turbo **1/86-6/89 4 Cyl 1.8L EA82T SOHC 8V EFi FWD**			
Ignition – Distributor Cap	**JP594**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR535**	1	Hitachi Electronic Distributor
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS742**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS21**	1	
Vortex XT Turbo **7/87-9/89 4 Cyl 1.8L EA82T SOHC 8V EFi 4WD**			
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS738**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS21**	1	
Vortex AX Turbo *(NZ Market)* **1988-89 4 Cyl 1.8L EA82T SOHC 8V**			
Ignition – Distributor Cap	**JP594**	1	Hitachi Electronic Distributor
Ignition – Distributor Rotor	**JR535**	1	Hitachi Electronic Distributor

Suzuki	Part No	Qty	Notes
Alto SB308F: SS80 *(NZ Market)* **1981-89 3 Cyl 0.8L F8B**			
Ignition – Coil – Standard	**CC211**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Cap	**JP682**	1	Mitsubishi Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Mitsubishi Electronic Distributor
Alto SB308 **9/85-5/88 3 Cyl 543cc F5A SOHC 6V Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP612**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS142**	1	
Switch – Radiator Fan	**CFS12**	1	
Alto SB308 **1/87-2/89 3 Cyl 796cc F8B SOHC 6V Carb. FWD**			
Switch – Radiator Fan	**CFS89**	1	
Alto SH410 **3/96-4/99 4 Cyl 993cc G10B SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC284**	1	
APV GD416V **6/05-on 4 Cyl 1.6L G16A SOHC 16V EFi FWD**			
Sensor – Crankshaft	**CSCA42**	1	
Baleno GA41 **3/96-1/99 4 Cyl 1.8L J18A DOHC 16V MPFi FWD**			
Sensor – Air Temperature – Inlet	**CAT010**	1	Type 2, 3, 4 & 5
Baleno GC31 (SY416) **1/99-11/01 4 Cyl 1.6L G16B SOHC 16V MPFi FWD**			
Sensor – Air Temperature – Inlet	**CAT010**	1	
Carry Van ST10: ST20 **5/76-78 4 Cyl 796cc F8A SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**MC418**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR537**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Carry Van ST80 **5/78-79 4 Cyl 796cc F8A SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Suzuki	Part No	Qty	Notes
Carry Van ST90 **10/79-85 4 Cyl 796cc F8A SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP642**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Carry Van SK410 *(NZ Market)* **1986-93 4 Cyl 1.0L F10A SOHC**			
Ignition – Coil – Standard	**CC211**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Carry ST100 *(NZ Market)* **1990-94 4 Cyl 1.0L F10A**			
Ignition – Distributor Cap	**JP550**	1	Denso Electronic Distributor
Carry Van GA413 & Carry Truck GA413T **5/99-7/05 4 Cyl 1.3L G13BB SOHC16V MPFi RWD**			
Ignition – Coil – Standard	**CC383**	2	
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Exhaust Oxygen	**COS822**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Cino SY413 (Swift) **5/94-5/00 4 Cyl 1.3L G13BA SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CC383**	2	
Switch – Radiator Fan	**CFS91**	1	
Cultus AB34S *(NZ Market)* **1988-91 4 Cyl 1.3L G13B SOHC**			
Ignition – Distributor Cap	**JP827**	1	Denso Electronic Distributor
Escudo TA01W/R *(NZ Market)* **1988-98 4 Cyl 1.6L G16A SOHC 8V**			
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR645**	1	Denso Electronic Distributor
Grand Vitara SQ420 **4/98-8/05 4 Cyl 2.0L J20A DOHC 16V MPFi 4WD**			
Sensor – Air Temperature – Inlet	**CAT010**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Sensor – Exhaust Oxygen	**COS862**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Grand Vitara SQ625 **4/98-10/01 V6 Cyl 2.5L H25A DOHC 24V MPFi 4WD**			
Sensor – Air Temperature – Inlet	**CAT010**	1	Type 1, 2 & 3
Sensor – Exhaust Oxygen	**COS862**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Brake Light	**CSL67**	1	Type 1, 2
Switch – Oil Pressure Warning Light	**CPS37**	1	
Grand Vitara SQ416 **2/00-9/02 4 Cyl 1.6L G16B DOHC 16V MPFi 4WD**			
Sensor – Air Temperature – Inlet	**CAT010**	1	
Switch – Brake Light	**CSL67**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	

Suzuki	Part No	Qty	Notes
Grand Vitara JB416X **9/05-on 4 Cyl 1.6L M16A DOHC 16V MPFi 4WD**			
Sensor – Crankshaft / Cam	**CSCA149**	1	Crankshaft: From Vin JSAJTA74V0010001
Grand Vitara JB420AW **9/05-on 4 Cyl 2.0L J20A DOHC 16V MPFi 4WD**			
Sensor – Crankshaft	**CSCA128**	1	From Vin JSAJTD54V00100001
Sensor – Crankshaft / Cam	**CSCA149**	1	Camshaft: From Vin JSAJTD54V00100001
Grand Vitara JB627AW **9/05-on V6 Cyl 2.7L H27A DOHC 24V MPFi 4WD**			
Sensor – Crankshaft / Cam	**CSCA149**	2	
Switch – Oil Pressure Warning Light	**CPS25**	1	
Hatch SS40V **2/80-12/85 3 Cyl 543cc F5A SOHC 6V Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP612**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS12**	1	
Hatch SS80 **11/80-12/84 3 Cyl 796cc F8B SOHC 6V Carb. FWD**			
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS12**	1	
Ignis RG413 **10/00-2/05 4 Cyl 1.3L M13A DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC383**	2	
Sensor – Crankshaft	**CSCA146**	1	Type 1, 2, 3 & 4
Sensor – MAP	**CMS223**	1	Type 1, 2, 3 & 4
Ignis RG415 **8/03-2/05 4 Cyl 1.5L M15A DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC383**	2	
Sensor – Air Temperature – Inlet	**CAT010**	1	
Jimny SN413 **10/98-9/02 4 Cyl 1.3L G13BB SOHC 16V MPFi 4WD**			
Ignition – Coil and Igniter	**CC308**	2	
Sensor – Air Temperature – Inlet	**CAT010**	1	Type 1
Sensor – Camshaft	**CSCA89**	1	Type 1
Sensor – Exhaust Oxygen	**COS819**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Jimny SN413 **9/00-on 4 Cyl 1.3L M13A DOHC 16V MPFi 4WD**			
Ignition – Coil and Igniter	**CC308**	2	Type 2, 3 & 4
Sensor – Crankshaft	**CSCA146**	1	Type 2, 3, 4 & 5
Sensor – Exhaust Oxygen	**COS921**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Liana RH416 **9/02-2/04 4 Cyl 1.6L M16A DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC383**	2	
Sensor – Crankshaft	**CSCA146**	1	Type 1, 2 & 3

Suzuki	Part No	Qty	Notes
Liana RH418			
3/04-8/04 4 Cyl 1.8L M18A DOHC 16V MPFi FWD			
Sensor – Camshaft	**CSCA89**	1	Type 4
Sensor – Crankshaft	**CSCA146**	1	Type 4
Sensor – Crankshaft / Cam	**CSCA149**	1	Crankshaft: Type 5
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Manifold and Before Catalyst
LJ50			
7/74-6/78 3 Cyl 539cc 539 OHV 6V Carb. 4WD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**MC418**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR537**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
LJ80			
11/77-12/81 4 Cyl 797cc F8A SOHC 8V Carb. 4WD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor: To 1980
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor: To 1980
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor: To 1980
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: To 1980
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
LJ81K Stockman			
5/78-12/80 4 Cyl 797cc F8A SOHC 8V Carb. 4WD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**MC418**	1	Denso Points Distributor: From 1980
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor: From 1980
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: From 1980
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Mighty Boy SS40T			
7/85-10/88 3 Cyl 543cc F5A SOHC 6V Carb. FWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP612**	1	Denso Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Switch – Radiator Fan	**CFS89**	1	
R+ SR410			
10/97-11/98 4 Cyl 996cc K10A DOHC 16V MPFi FWD			
Ignition – Distributor Cap	**JP828**	1	
Ignition – Module	**CM428**	1	Type 1 & 2
Sensor – Exhaust Oxygen	**COS932**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Oil Pressure Warning Light	**CPS37**	1	

Suzuki	Part No	Qty	Notes
Samurai SJ413 *(NZ Market)* **1984-89 4 Cyl 1.3L G13A**			
Ignition – Coil – Standard	**CC211**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Samurai SJ413 *(NZ Market)* **1990-99 4 Cyl 1.3L G13B**			
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR649**	1	Denso Electronic Distributor
Sierra SJ410 **7/81-7/88 4 Cyl 970cc F10A SOHC 8V Carb. 4WD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Points and Electronic Distributor
Ignition – Distributor Condenser	**MC418**	1	Denso Points Distributor: To 1984
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor: To 1984
Ignition – Distributor Rotor	**JR527**	1	Denso Points and Electronic Distributor
Sensor – Temperature Gauge	**CTS126**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Sierra SJ413 **10/84-12/90 4 Cyl 1.3L G13A SOHC 8V Carb. 4WD**			
Ignition – Coil – Standard	**CC283**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor: To 1988
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor: To 1988
Sierra SJ413 **8/89-5/99 4 Cyl 1.3L G13BA SOHC 8V Carb. 4WD**			
Ignition – Coil – Standard	**CC309**	1	
Ignition – Coil – Standard	**CC283**	1	Type 4, 5 & 6
Sensor – Temperature Gauge	**CTS126**	1	
Sensor – Temperature Gauge	**CTS142**	1	Type 6 & 7: From 1994 To 1996
Sensor – Temperature Gauge	**CTS110**	1	Type 8 & 9: From 1996
Switch – Oil Pressure Warning Light	**CPS23**	1	
Sierra MG410 Stockman **3/90-2/00 4 Cyl 970cc F10A SOHC 8V Carb. 4WD**			
Ignition – Coil – Standard	**CC283**	1	
Ignition – Pickup / Trigger	**CIT105**	1	
Sensor – Temperature Gauge	**CTS142**	1	1/8 Gas Thread: To 1994
Sensor – Temperature Gauge	**CTS126**	1	M16x1.5 Thread: To 1994
ST80: ST90 *(NZ Market)* **1978-85 4 Cyl 797cc F8A**			
Ignition – Coil – Standard	**CC211**	1	Denso Points Distributor
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S214V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Super Carry Van SK410 **7/85-12/90 4 Cyl 970cc F10A SOHC 8V Carb. RWD**			
Ignition – Distributor Cap	**JP642**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR645**	1	Denso Electronic Distributor
Sensor – Temperature Gauge	**CTS142**	1	Type 1, 2 & 3
Switch – Brake Light	**CSL31**	1	

Suzuki	Part No	Qty	Notes
Swift SA310 **1/85-12/88 3 Cyl 993cc G10A SOHC 6V Carb. FWD**			
Ignition – Coil – Standard	**CC201**	1	Auto Transmission: Type 1 & 2 With Manual Transmission
Ignition – Coil – Standard	**CC284**	1	Type 3
Ignition – Distributor Cap	**JP612**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Sensor – Temperature Gauge	**CTS142**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS45**	1	
Swift SA413 **1/85-12/88 4 Cyl 1.3L G13A: G13B DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC201**	1	Type 2
Ignition – Coil – Standard	**CC284**	1	Type 3
Ignition – Distributor Cap	**JP654**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**DR128**	1	Denso Electronic Distributor
Ignition – Module	**CM478**	1	
Ignition – Pickup / Trigger	**CIT105**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS45**	1	
Swift SA413G: SA413F *(NZ Market)* **1985-89 4 Cyl 1.3L G13A SOHC**			
Ignition – Coil – Standard	**CC283**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP654**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**DR128**	1	Denso Electronic Distributor
Swift HEJ574 *(NZ Market)* **1986-89 4 Cyl 1.3L G13B DOHC 16V**			
Ignition – Distributor Cap	**JP827**	1	Denso Electronic Distributor
Swift SF413 *(NZ Market)* **1989-93 4 Cyl 1.3L G13B SOHC**			
Ignition – Coil and Igniter	**CC308**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP827**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**DR128**	1	Denso Electronic Distributor
Swift SF310 **1/89-5/95 3 Cyl 993cc G10A SOHC 6V Carb. FWD**			
Ignition – Coil – Standard	**CC309**	1	Type 2: From Vin JSAEAA44S0016805
Ignition – Distributor Cap	**JP406**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR617**	1	Denso Electronic Distributor
Ignition – Module	**CM405**	1	Type 1: To Vin JSAEAA44S00160804
Ignition – Module	**CM411**	1	Type 2: From Vin JSAEAA44S0016805
Sensor – Temperature Gauge	**CTS142**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS25**	1	
Switch – Radiator Fan	**CFS45**	1	
Swift SF413 Gti **1/89-5/00 4 Cyl 1.3L G13B DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC219**	1	
Ignition – Distributor Cap	**BD894**	1	Hitachi Electronic Distributor
Ignition – Module	**CM422**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS91**	1	

Suzuki	Part No	Qty	Notes
Swift SF416 **10/89-5/95 4 Cyl 1.6L G16B SOHC 16V MPFi FWD & 4WD**			
Ignition – Coil – Standard	**CC284**	1	
Ignition – Distributor Cap	**JP827**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**DR128**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS142**	1	Type 1
Sensor – Temperature Gauge	**CTS110**	1	Type 2
Sensor – Throttle Position	**CTPS102**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS88**	1	
Swift SF413 **12/90-9/95 4 Cyl 1.3L G13A SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CC309**	1	Type 2: From Vin JSAEAA35S00250001 & JSAEAB35S00250001: To Vin JSAEAA35S00268825 & JSAEAB35S00260623
Ignition – Distributor Cap	**BD107**	1	Hitachi Electronic Distributor: Type 1
Ignition – Distributor Cap	**JP718**	1	Hitachi Electronic Distributor: Type 2
Ignition – Distributor Rotor	**JR617**	1	Hitachi Electronic Distributor: Type 1
Ignition – Distributor Rotor	**JR641**	1	Hitachi Electronic Distributor: Type 2
Ignition – Module	**CM405**	1	Type 1: From Vin JSAEH35S00153022
Ignition – Module	**CM411**	1	Type 2: From Vin JSAEAA35S00250001 & JSAEAB35S00250001: To Vin JSAEAA35S00268825 & JSAEAB35S00260623
Sensor – Temperature Gauge	**CTS110**	1	
Swift SY413 (Cino) **5/94-5/00 4 Cyl 1.3L G13BA SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CC309**	1	Type 2: From Vin JSAEAA35S00250001 & JSAEAB35S00250001: To Vin JSAEAA35S00268825 & JSAEAB35S00260623
Ignition – Module	**CM405**	1	Type 1: From Vin JSAEH35S00153022
Swift SF413 **2/98-5/00 4 Cyl 1.3L G13B SOHC 8V EFi FWD**			
Sensor – Temperature Gauge	**CTS110**	1	
Swift RS415 **2/05-on 4 Cyl 1.5L M15A DOHC 16V EPFI FWD**			
Sensor – Crankshaft	**CSCA149**	1	
Sensor – MAP	**CMS223**	1	
Vitara SE416 *(NZ Market)* **1988-93 4 Cyl 1.6L G16A**			
Ignition – Coil – Standard	**CC211**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Vitara SE416 Type 1 **7/88-11/94 4 Cyl 1.6L G16A SOHC 8V Carb. 4WD**			
Ignition – Coil – Standard	**CC284**	1	Type 1 & 2
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR645**	1	Denso Electronic Distributor

Suzuki	Part No	Qty	Notes
Vitara SE416A *(NZ Market)* **1991-95 4 Cyl 1.6L G16B**			
Ignition – Coil – Standard	**CC211**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR645**	1	Denso Electronic Distributor
Vitara SE416 Type 2: Type 3 **8/91-4/00 4 Cyl 1.6L G16B SOHC 16V MPFi 4WD**			
Ignition – Coil – Standard	**CC264**	1	Type 2: Distributor 33100-57B11: To 1995
Ignition – Coil – Standard	**CC366**	1	Type 3: Distributor 33100-58B10: To 1995
Ignition – Distributor Cap	**JP827**	1	Denso Electronic Distributor (A): Type 2
Ignition – Distributor Cap	**JP718**	1	Denso Electronic Distributor (B): Type 3
Ignition – Distributor Rotor	**JR806**	1	Denso Electronic Distributor (B): Type 3
Ignition – Distributor Rotor	**JR802**	1	Denso Electronic Distributor (C): Type 4, 5
Ignition – Module	**CM422**	1	Type 3: Distributor 33100-58B10: To 1995
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS903**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS102**	1	
Vitara SV620 Type 1 **4/95-9/99 V6 Cyl 2.0L H20A DOHC 24V MPFi 4WD**			
Sensor – Exhaust Oxygen	**COS819**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Vitara SV420 Type 5 **5/97-4/00 4 Cyl 2.0L J20A DOHC 16V MPFi 4WD**			
Sensor – Exhaust Oxygen	**COS819**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS142**	1	
X90 SZ416 **4/96-5/98 4 Cyl 1.6L G16B SOHC 16V MPFi 4WD**			
Ignition – Distributor Rotor	**JR815**	1	Mitsubishi Electronic Distributor
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS822**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
XL7 JA627 **7/01-1/06 V6 Cyl 2.7L H27A DOHC 24V MPFi 4WD**			
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Camshaft	**CSCA127**	1	Type 2, 3 & 4
Sensor – Crankshaft	**CSCA128**	1	Type 2, 3 & 4
Sensor – Exhaust Oxygen	**COS822**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire

Toyota	Part No	Qty	Notes
4 Runner YN60 **7/84-10/85 4 Cyl 2.0L 3YC OHV 8V Carb. 4WD**			
Ignition – Coil – Standard	**CC287**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Switch – Radiator Fan	**CFS43**	1	
4 Runner LN60: LN61 Diesel **7/84-12/88 4 Cyl 2.4L 2L SOHC 8V Di 4WD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
4 Runner YN63 **11/85-12/88 4 Cyl 2.2L 4YC OHV Carb. 4WD**			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Module	**CM402**	1	
Ignition – Pickup / Trigger	**CIT104**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS43**	1	
4 Runner YN63 **10/88-9/89 4 Cyl 2.2L 4YE OHV EFi 4WD**			
Ignition – Coil – Standard	**CC217**	1	To 3/1989
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
4 Runner YN130 **10/89-12/90 4 Cyl 2.2L 4YE OHV EFi 4WD**			
Ignition – Coil – Standard	**CC217**	1	To 8/1990
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT140**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Brake Light	**CSL56**	1	With Cruise Control
Switch – Oil Pressure Warning Light	**CPS37**	1	
4 Runner RN130 **10/89-6/96 4 Cyl 2.4L 22R SOHC 8V Carb. 4WD**			
Ignition – Coil – Standard	**CC258**	3	To 8/1992
Ignition – Coil – Standard	**CC231**	1	From 8/1992
Ignition – Distributor Cap	**JP588**	1	Denso Electronic Distributor: To 8/1992
Ignition – Distributor Cap	**JP802**	1	Denso Electronic Distributor: From 8/1992
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT102**	1	To 8/1992
Sensor – Temperature Gauge	**CTS106**	1	To 8/1992
Sensor – Temperature Gauge	**CTS150**	1	From 8/1992 To 8/1993
Switch – Brake Light	**CSL56**	1	
4 Runner LN130 Diesel **10/89-6/96 4 Cyl 2.8L 3L SOHC 8V Di 4WD**			
Sensor – Temperature Gauge	**CTS106**	1	To 8/1992
Sensor – Temperature Gauge	**CTS150**	1	From 8/1992 To 8/1993
Switch – Brake Light	**CSL56**	1	With Cruise Control
Switch – Brake Light	**CSL59**	1	Without Cruise Control

Toyota	Part No	Qty	Notes
4 Runner VZN130			
10/90-6/96 V6 Cyl 3.0L 3VZE SOHC 12V EFi 4WD			
Ignition – Coil – Standard	**CC227**	1	To 8/1991
Ignition – Coil – Standard	**CC231**	1	From 8/1991
Ignition – Distributor Cap	**BD138**	1	Denso Electronic Distributor (A): To 8/1991
Ignition – Distributor Cap	**JP400**	1	Denso Electronic Distributor (B): From 8/1991
Ignition – Distributor Rotor	**DR686**	1	Denso Electronic Distributor (A): To 8/1991
Ignition – Distributor Rotor	**DR839**	1	Denso Electronic Distributor (B): From 8/1991
Ignition – Module	**CM437**	1	To 8/1991
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS774**	1	Direct Fit 4 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS726**	1	Universal 4 Wire With Flange
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS153**	1	To 11/1995
Switch – Brake Light	**CSL60**	1	With Cruise Control
Switch – Brake Light	**CSL59**	1	Without Cruise Control
Switch – Radiator Fan	**CFS83**	1	
Aurion GSV40R			
10/06-on V6 Cyl 3.5L 2GRFE DOHC 24V MPFi FWD			
Sensor – Camshaft	**CSCA147**	1	
Sensor – Crankshaft	**CSCA138**	1	
Sensor – Knock Control	**CKS121**	1	
Avalon MCX10R: MCX10R Mk.II			
7/00-9/03 V6 Cyl 3.0L 1MZFE DOHC 24V ESPFI FWD			
Ignition – Coil – Standard	**CC329**	3	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear
Sensor – Temperature Gauge	**CTS154**	1	
Avalon MCX10R Mk.III			
10/03-3/06 V6 Cyl 3.0L 1MZFE DOHC 24V ESPFI FWD			
Ignition – Coil – Standard	**CC329**	3	
Sensor – Air Flow / MAF	**CAF034**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Temperature Gauge	**CTS154**	1	
Sensor – Throttle Position	**CTPS154**	1	
Avante ST141			
11/84-4/87 4 Cyl 2.0L 2SC SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CC217**	1	To 10/1985
Ignition – Coil – Standard	**CC216**	1	From 10/1985
Ignition – Distributor Cap	**JP580**	1	Denso Electronic Distributor: To 10/1985
Ignition – Distributor Cap and Leads	**JP803**	1	Denso Electronic Distributor: From 10/1985
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor: To 10/1985
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor: From 10/1985
Ignition – Module	**CM402**	1	
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Brake Light	**CSL40**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS24**	1	

Toyota	Part No	Qty	Notes
Avante RT142 **11/84-4/87 4 Cyl 2.4L 22RE SOHC 8V EFi RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP588**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Ignition – Module	**CM479**	1	From 10/1985 To 12/1986
Ignition – Pickup / Trigger	**CIT102**	1	To 10/1985
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS106**	1	
Sensor – Throttle Position	**CTPS101**	1	To 10/1985
Switch – Brake Light	**CSL40**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS24**	1	
Avensis Verso ACM20R **12/01-10/03 4 Cyl 2.0L 1AZFE DOHC 16V MPFi 4WD**			
Ignition – Coil and Igniter	**CC310**	4	
Sensor – Air Flow / MAF	**CAF034**	1	
Sensor – Camshaft	**CSCA103**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA137**	1	
Sensor – Exhaust Oxygen	**COS893**	1	Direct Fit 4 Wire: Front RH Side Upper
Sensor – Throttle Position	**CTPS154**	1	
Avensis Verso ACM21R **11/03-on 4 Cyl 2.4L 2AZFE DOHC 16V MPFi 4WD**			
Ignition – Coil and Igniter	**CC310**	4	
Sensor – Air Flow / MAF	**CAF034**	1	
Sensor – Camshaft	**CSCA103**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA137**	1	
Sensor – Knock Control	**CKS121**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
Blizzard LD10 Diesel **3/82-12/83 4 Cyl 2.2L L SOHC 8V Di 4WD**			
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Bundera RJ70 **1/85-12/91 4 Cyl 2.4L 22RC SOHC 8V Carb. 4WD**			
Ignition – Coil – Standard	**CC258**	1	
Ignition – Distributor Cap	**JP588**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT102**	1	
Sensor – Temperature Gauge	**CTS106**	1	
Bundera LJ70 Diesel **1/86-12/91 4 Cyl 2.4L 2LT SOHC 8V Di 4WD**			
Sensor – Temperature Gauge	**CTS106**	1	
Caldina AT191: AT211 *(NZ Market)* **1996-97 4 Cyl 1.8L 7AFE**			
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor

Toyota	Part No	Qty	Notes
Camry SV11 **4/83-4/87 4 Cyl 2.0L 2SE SOHC 8V EFi FWD**			
Ignition – Coil – Standard	**CC217**	1	To 10/1986
Ignition – Distributor Cap	**JP580**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
Ignition – Module	**CM402**	1	To 8/1985
Ignition – Pickup / Trigger	**CIT104**	1	To 8/1985
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS106**	1	
Sensor – Throttle Position	**CTPS104**	1	To 10/1986
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS32**	1	
Camry SV20 **5/87-8/89 4 Cyl 1.8L 1SE SOHC 8V SPFI FWD**			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Distributor Cap	**JP580**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Ignition – Module	**CM402**	1	To 6/1989
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Brake Light	**CSL47**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS32**	1	
Camry SV21 **5/87-2/93 4 Cyl 2.0L 3SFE DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Distributor Cap and Leads	**JP805**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Ignition – Module	**CM437**	1	External Module: From 7/1989 To 11/1992
Ignition – Pickup / Trigger	**CIT115**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Throttle Position	**CTPS104**	1	
Switch – Brake Light	**CSL56**	1	With Cruise Control
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS32**	1	
Camry VZV21R **6/88-2/93 V6 Cyl 2.5L 2VZFE DOHC 24V EFi FWD**			
Ignition – Coil – Standard	**CC227**	1	
Ignition – Distributor Cap	**JP740**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR657**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	To 8/1988
Sensor – Coolant Temperature	**CCS21**	1	From 8/1988
Sensor – Exhaust Oxygen	**COS735**	1	Direct Fit 4 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS726**	1	Universal 4 Wire With Flange
Sensor – Temperature Gauge	**CTS106**	1	
Sensor – Throttle Position	**CTPS153**	1	From 8/1989
Switch – Brake Light	**CSL56**	1	With Cruise Control
Switch – Brake Light	**CSL47**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS32**	1	

Toyota	Part No	Qty	Notes
Camry SV22			
9/89-6/91 4 Cyl 2.0L 3SFC DOHC 16V Carb. FWD			
Ignition – Coil – Standard	**CC216**	1	
Ignition – Distributor Cap	**DR895**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT103**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Switch – Brake Light	**CSL67**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS32**	1	
Camry SDV10: SXV10			
2/93-3/98 4 Cyl 2.2L 5SFE DOHC 16V EFi FWD			
Ignition – Coil – Standard	**CC263**	1	
Ignition – Distributor Cap	**JP822**	1	Denso Electronic Distributor: To 10/1993
Ignition – Distributor Cap	**BD131**	1	Denso Electronic Distributor: From 10/1993
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Ignition – Module	**CM436**	1	External 5 pin module
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS150**	1	
Sensor – Throttle Position	**CTPS111**	1	From 10/1994
Switch – Brake Light	**CSL60**	1	With Cruise Control
Switch – Brake Light	**CSL59**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS51**	1	
Switch – Radiator Fan	**CFS55**	1	
Camry Vienta VDV10: VCV10			
2/93-9/95 V6 Cyl 3.0L 3VZFE DOHC 24V EFi FWD			
Ignition – Coil – Standard	**CC276**	1	VDV10
Ignition – Coil – Standard	**CC227**	1	VCV10
Ignition – Distributor Cap	**BD138**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**BD139**	1	Denso Electronic Distributor
Ignition – Module	**CM438**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	2	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	2	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Brake Light	**CSL60**	1	With Cruise Control
Switch – Brake Light	**CSL59**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS51**	1	
Switch – Radiator Fan	**CFS55**	1	
Camry SXV20R			
8/97-8/02 4 Cyl 2.2L 5SFE DOHC 16V EFi FWD			
Ignition – Coil and Igniter	**CC291**	1	Cylinder 1 & 4
Ignition – Coil and Igniter	**CC292**	1	Cylinder 2 & 3
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA46**	1	
Sensor – Exhaust Oxygen	**COS774**	1	Direct Fit 4 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS726**	1	Universal 4 Wire With Flange
Sensor – Temperature Gauge	**CTS154**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
Switch – Radiator Fan	**CFS55**	1	

Toyota	Part No	Qty	Notes
Camry MCV20R			
8/97-8/02 V6 Cyl 3.0L 1MZFE DOHC 24V EFi FWD			
Ignition – Coil – Standard	**CC329**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA133**	1	
Sensor – Exhaust Oxygen	**COS861**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS154**	1	
Switch – Radiator Fan	**CFS75**	1	
Camry ACV36R			
9/02-6/06 4 Cyl 2.4L 2AZFE DOHC 16V MPFi FWD			
Sensor – Camshaft	**CSCA103**	1	
Sensor – Crankshaft	**CSCA137**	1	
Sensor – Exhaust Oxygen	**COS895**	1	Direct Fit 4 Wire: Front Manifold
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Front Eng Pipe
Sensor – Knock Control	**CKS121**	1	
Sensor – Throttle Position	**CTPS154**	1	
Camry MCV36R			
9/02-6/06 V6 Cyl 3.0L 1MZFE DOHC 24V MPFi FWD			
Ignition – Coil – Standard	**CC329**	6	
Sensor – Air Flow / MAF	**CAF034**	1	
Sensor – Camshaft	**CSCA159**	1	
Sensor – Coolant Temperature	**CCS58**	1	
Sensor – Crankshaft	**CSCA133**	1	
Sensor – Exhaust Oxygen	**COS893**	2	Direct Fit 4 Wire: Front & Rear: From 1/2006 To 6/2006
Sensor – Throttle Position	**CTPS154**	1	Aisan
Camry ACV40R			
7/06-on 4 Cyl 2.4L 2AZFE DOHC 16V MPFi FWD			
Sensor – Camshaft	**CSCA103**	1	
Sensor – Crankshaft	**CSCA137**	1	
Sensor – Knock Control	**CKS121**	1	
Celica TA22: TA23			
11/71-6/76 4 Cyl 1.6L 2T OHV 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Celica RA23: RA28: RA40			
6/76-10/81 4 Cyl 2.0L 18RC SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS104**	1	To 8/1979
Sensor – Temperature Gauge	**CTS106**	1	From 8/1979
Switch – Oil Pressure Warning Light	**CPS24**	1	

Toyota	Part No	Qty	Notes
Celica RA60 **11/81-9/83 4 Cyl 2.0L 21RC SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP588**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT102**	1	
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Celica SA63 **10/83-9/84 4 Cyl 2.0L 2SC SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Distributor Cap	**JP580**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
Ignition – Module	**CM402**	1	
Ignition – Pickup / Trigger	**CIT104**	1	
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Celica RA65 **10/84-12/85 4 Cyl 2.4L 22REC SOHC 8V EFi RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP588**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT102**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Celica ST162 *(NZ Market)* **1984-89 4 Cyl 2.0L 3SGEL DOHC 16V**			
Ignition – Distributor Cap	**JP700**	1	Denso Electronic Distributor
Celica ST160 *(NZ Market)* **1985-87 4 Cyl 1.8L 1SIL**			
Ignition – Distributor Cap	**JP580**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
Celica ST162 Incl. SX **11/85-10/89 4 Cyl 2.0L 3SGE DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC265**	1	
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Radiator Fan	**CFS24**	1	
Celica AT160 *(NZ Market)* **1986-89 4 Cyl 1.6L 4AGEL**			
Ignition – Distributor Cap	**JP656**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
Celica ST162 ST **11/86-11/89 4 Cyl 2.0L 3SFE DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	To 8/1988
Sensor – Coolant Temperature	**CCS21**	1	From 8/1988
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS104**	1	To 8/1987
Switch – Radiator Fan	**CFS24**	1	

Toyota	Part No	Qty	Notes
Celica ST182: ST183 *(NZ Market)* **1989-94 4 Cyl 2.0L 3SFE DOHC 16V**			
Ignition – Coil – Standard	**CC231**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Celica ST184R **11/89-3/94 4 Cyl 2.2L 5SFE DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC231**	1	To 8/1991
Ignition – Coil – Standard	**CC263**	1	From 9/1991
Ignition – Distributor Cap	**JP742**	1	Denso Electronic Distributor: To 8/1991
Ignition – Distributor Cap	**BD131**	1	Denso Electronic Distributor: From 8/1991
Ignition – Distributor Rotor	**JR649**	1	Denso Electronic Distributor: To 8/1991
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor: From 8/1991
Ignition – Module	**CM437**	1	To 8/1991
Ignition – Module	**CM436**	1	From 8/1991 To 11/1993
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS110**	1	To 8/1991
Sensor – Temperature Gauge	**CTS106**	1	From 8/1991 To 11/1992
Sensor – Temperature Gauge	**CTS150**	1	From 11/1992
Sensor – Throttle Position	**CTPS153**	1	Auto Transmission: To 8/1991
Sensor – Throttle Position	**CTPS101**	1	Manual Transmission: To 8/1991
Sensor – Throttle Position	**CTPS111**	1	From 8/1991
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS44**	1	
Celica ST185R Turbo **3/90-12/92 4 Cyl 2.0L 3SGTE DOHC 16V EFi 4WD**			
Ignition – Coil – Standard	**CC265**	1	To 8/1991
Ignition – Coil – Standard	**CC231**	1	From 8/1991
Ignition – Distributor Cap	**JP810**	1	Denso Electronic Distributor: To 8/1991
Ignition – Distributor Cap	**JP730**	1	Denso Electronic Distributor: From 8/1991
Ignition – Distributor Rotor	**JR649**	1	Denso Electronic Distributor
Ignition – Module	**CM437**	1	To 8/1991
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS735**	1	Direct Fit 4 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS726**	1	Universal 4 Wire With Flange
Sensor – Temperature Gauge	**CTS110**	1	To 8/1991
Sensor – Temperature Gauge	**CTS106**	1	From 8/1991 To 11/1992
Sensor – Temperature Gauge	**CTS150**	1	From 11/1992
Sensor – Throttle Position	**CTPS153**	1	From 8/1991
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS44**	1	
Celica ST202: ST203 *(NZ Market)* **1993-99 4 Cyl 2.0L 3SFE**			
Ignition – Distributor Cap	**JP700**	1	Denso Electronic Distributor

Toyota	Part No	Qty	Notes
Celica ST204R			
3/94-11/99 4 Cyl 2.2L 5SFE DOHC 16V EFi FWD			
Ignition – Coil – Standard	**CC263**	1	
Ignition – Distributor Cap	**BD131**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Ignition – Module	**CM436**	1	
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS778**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS150**	1	To 8/1995
Sensor – Temperature Gauge	**CTS154**	1	From 8/1995
Switch – Oil Pressure Warning Light	**CPS51**	1	
Switch – Radiator Fan	**CFS55**	1	
Celica ST205R Turbo			
5/94-12/94 4 Cyl 2.0L 3SGTE DOHC 16V EFi 4WD			
Ignition – Coil – Standard	**CC280**	1	
Ignition – Distributor Cap	**JP730**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR649**	1	Denso Electronic Distributor
Ignition – Module	**CM436**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS820**	1	Direct Fit 4 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS726**	1	Universal 4 Wire With Flange
Sensor – Temperature Gauge	**CTS150**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
Switch – Radiator Fan	**CFS55**	1	
Celica ZZT231			
11/99-3/06 4 Cyl 1.8L 2ZZGE DOHC 16V MPFi FWD			
Ignition – Coil and Igniter	**CC294**	4	
Sensor – Air Flow / MAF	**CAF034**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA165**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Oil Pressure Warning Light	**CPS51**	1	
Coaster RU18			
1968-73 4 Cyl 2.0L 5R OHV Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP516**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S202V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor
Coaster RU19			
1973-77 4 Cyl 2.0L 5R OHV Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor

Toyota	Part No	Qty	Notes
Coaster RB11 **8/77-8/80 4 Cyl 2.2L 20R SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor
Ignition – Distributor Condenser	**BC556**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Coaster RB13 **1980-82 4 Cyl 2.4L 22R Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP588**	1	Denso Points Distributor: From 1981
Ignition – Distributor Condenser	**BC556**	1	Denso Points Distributor: From 1981
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor: From 1981
Ignition – Distributor Rotor	**JR577**	1	Denso Points Distributor: From 1981
Coaster RB20 **1/82-6/92 4 Cyl 2.4L 22RC SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP588**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT102**	1	
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Coaster BB20: BB21 Diesel **1/84-6/92 4 Cyl 3.4L 3B Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Coaster HB30 Diesel **1/87-12/90 6 Cyl 4.0L 2H Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Coaster HZB30: HZB50 Diesel **1/90-2/03 6 Cyl 4.2L OHC Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	
Corolla KE10: KE11: KE15: KE16 **6/67-6/69 4 Cyl 1.1L K OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**JP516**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor

Toyota	Part No	Qty	Notes
Corolla KE18: KE20: KE25: KE26 **1/70-12/73 4 Cyl 1.2L 3K OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH96**	1	Bosch Points Distributor
Ignition – Distributor Cap	**JP516**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor
Corolla KE30: KE35: KE36: KE50 **11/74-5/78 4 Cyl 1.2L 3KC OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH90**	1	Bosch Points Distributor
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**BC100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Corolla KE38: KE55: KE70 **11/78-4/85 4 Cyl 1.3L 4KC OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH90**	1	Bosch Points Distributor
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor
Ignition – Distributor Condenser	**BC100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Brake Light	**CSL40**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Corolla AE71: AE86 **7/83-12/85 4 Cyl 1.6L 4AC SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP574**	1	Denso Electronic Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S214V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Sensor – Temperature Gauge	**CTS106**	1	AE71
Sensor – Temperature Gauge	**CTS110**	1	AE86
Switch – Radiator Fan	**CFS24**	1	

Toyota	Part No	Qty	Notes
Corolla AE82 *(NZ Market)* **1983-87 4 Cyl 1.6L 4AEL**			
Ignition – Distributor Cap	**JP656**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
Corolla AE80 *(NZ Market)* **1983-88 4 Cyl 1.3L 2A**			
Ignition – Distributor Cap	**JP574**	1	Denso Points Distributor
Corolla AE82R *(NZ Market)* **1984-88 4 Cyl 1.6L 4AL SOHC 8V**			
Ignition – Distributor Cap	**JP574**	1	Denso Points Distributor
Ignition – Distributor Cap	**DR895**	1	Denso Electronic Distributor
Corolla EE80 *(NZ Market)* **1985-87 4 Cyl 1.3L 2EL SOHC 8V**			
Ignition – Coil – Standard	**CC287**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP534**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Corolla AE80 **4/85-5/89 4 Cyl 1.3L 2ALC SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CC287**	1	
Ignition – Distributor Cap	**BH178**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH121**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS24**	1	
Corolla AE82 Carb **4/85-5/89 4 Cyl 1.6L 4ALC SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CC287**	1	
Ignition – Distributor Cap	**BH178**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH121**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS24**	1	
Corolla AE82 EFi **9/86-5/89 4 Cyl 1.6L 4AGE DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP656**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT010**	1	From 11/1987
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS104**	1	
Sensor – Throttle Position	**CTPS153**	1	From 10/1987
Switch – Radiator Fan	**CFS24**	1	
Corolla AE91 Carb. *(NZ Market)* **1987-89 4 Cyl 1.5L 5AFE DOHC 16V**			
Ignition – Distributor Cap	**DR895**	1	Denso Electronic Distributor
Corolla AE95 *(NZ Market)* **1987-90 4 Cyl 1.6L 4AF 4WD**			
Ignition – Distributor Cap	**DR895**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor

Toyota	Part No	Qty	Notes
Corolla EE90 *(NZ Market)* **1987-91 4 Cyl 1.3L 2E SOHC 8V**			
Ignition – Coil – Standard	**CC216**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP534**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Corolla EE90: EE96V: EE97 *(NZ Market)* **1987-91 4 Cyl 1.3L 2EE SOHC 12V EFi**			
Ignition – Distributor Cap	**JP534**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Corolla AE95R **4/88-7/95 4 Cyl 1.6L 4AFE DOHC 16V EFi 4WD**			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Distributor Cap	**JP722**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Ignition – Module	**CM402**	1	
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange: To 8/1989
Sensor – Exhaust Oxygen	**COS782**	1	Direct Fit 2 Wire With Flange: From 8/1989
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange: To 8/1999
Sensor – Exhaust Oxygen – Universal	**COS725**	1	Universal 2 Wire With Flange: From 8/1989
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS104**	1	
Switch – Radiator Fan	**CFS63**	1	
Valve – Idle Speed Control	**CIA007**	1	Manual Transmission: To 9/1993
Corolla AE92 Carb. *(NZ Market)* **1989-3/90 4 Cyl 1.4L 6AFC DOHC 16V**			
Ignition – Coil – Standard	**CC216**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**DR895**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Ignition – Module	**CM418**	1	Denso Electronic Distributor
Corolla AE92 Carb **6/89-9/94 4 Cyl 1.6L 4AFC DOHC 16V Carb. FWD**			
Ignition – Coil – Standard	**CC216**	1	To 3/1990
Ignition – Distributor Cap	**DR895**	1	Denso Electronic Distributor: To 3/1990
Ignition – Distributor Cap	**BH178**	1	Bosch Electronic Distributor: From 3/1990
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor: To 3/1990
Ignition – Distributor Rotor	**BH121**	1	Bosch Electronic Distributor: From 3/1990
Ignition – Module	**CM418**	1	From 3/1990 To 6/1991
Ignition – Pickup / Trigger	**CIT103**	1	To 3/1990
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS63**	1	

Toyota	Part No	Qty	Notes
Corolla AE90 **7/89-11/92 4 Cyl 1.4L 6AFC DOHC 16V Carb. FWD**			
Ignition – Coil – Standard	**CC216**	1	To 3/1990
Ignition – Distributor Cap	**DR895**	1	Denso Electronic Distributor: To 3/1990
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor: To 3/1990
Ignition – Module	**CM418**	1	From 3/1990 To 6/1991
Ignition – Pickup / Trigger	**CIT103**	1	To 3/1990
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Switch – Radiator Fan	**CFS32**	1	
Corolla AE92 EFi **7/89-9/94 4 Cyl 1.6L 4AGE DOHC 16V EFi FWD**			
Ignition – Distributor Cap	**JP708**	1	Denso Electronic Distributor: From 7/1992
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor: From 7/1992
Ignition – Module	**CM437**	1	
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Radiator Fan	**CFS63**	1	
Corolla AE92 Carb. *(NZ Market)* **3/90-92 4 Cyl 1.4L 6AFC DOHC 16V**			
Ignition – Distributor Cap	**BH178**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH121**	1	Bosch Electronic Distributor
Ignition – Module	**CM418**	1	Bosch Electronic Distributor
Corolla EE101 *(NZ Market)* **1991-94 4 Cyl 1.3L 4EFE DOHC 16V**			
Ignition – Coil – Standard	**CC216**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Corolla AE92 EFi **7/91-9/94 4 Cyl 1.6L 4AFE DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Distributor Cap and Leads	**JP801**	1	Denso Electronic Distributor: To 3/1993
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor: To 3/1993
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS24**	1	
Corolla AE101 *(NZ Market)* **1991-94 4 Cyl 1.6L 4AGE DOHC 16V**			
Ignition – Distributor Cap	**JP574**	1	Denso Electronic Distributor
Corolla AE100 *(NZ Market)* **1991-97 4 Cyl 1.5L 5AFE DOHC 16V**			
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor

Toyota	Part No	Qty	Notes
Corolla AE93 **11/92-9/94 4 Cyl 1.8L 7AFE DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC216**	1	To 7/1994
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Oil Pressure Gauge	**CPS26**	1	
Sensor – Temperature Gauge	**CTS154**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
Switch – Radiator Fan	**CFS63**	1	
Corolla EE100 *(NZ Market)* **1992-96 4 Cyl 1.3L 2EL SOHC 8V**			
Ignition – Coil – Standard	**CC216**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP534**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Corolla EE103: EE104 *(NZ Market)* **1994-98 4 Cyl 1.5L 5EFE**			
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Corolla AE101R **9/94-7/00 4 Cyl 1.6L 4AFE DOHC 16V EFi FWD**			
Ignition – Coil – Standard	**CC216**	1	To 12/1996
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS775**	1	Direct Fit 2 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS725**	1	Universal 2 Wire With Flange
Sensor – Temperature Gauge	**CTS154**	1	
Sensor – Throttle Position	**CTPS111**	1	
Switch – Brake Light	**CSL59**	1	
Switch – Radiator Fan	**CFS63**	1	
Corolla AE102X: AE102R: AE112R Incl. Turbo **9/94-12/01 4 Cyl 1.8L 7AFE DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC216**	1	
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor: To 9/1998
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor: To 9/1998
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS775**	1	Direct Fit 2 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS725**	1	Universal 2 Wire With Flange
Sensor – Temperature Gauge	**CTS154**	1	
Sensor – Throttle Position	**CTPS111**	1	
Switch – Brake Light	**CSL59**	1	
Switch – Radiator Fan	**CFS63**	1	
Corolla AE111 *(NZ Market)* **1995-01 4 Cyl 1.6L 4AFE DOHC 16V**			
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor

Toyota	Part No	Qty	Notes
Corolla ZZE122 **12/01-on 4 Cyl 1.8L 1ZZFE DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC295**	4	
Sensor – Air Flow / MAF	**CAF034**	1	
Sensor – Camshaft	**CSCA103**	1	Sedan and Wagon
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA29**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
Corolla ZZE123 **5/03-4/06 4 Cyl 1.8L 2ZZGE DOHC 16V MPFi FWD**			
Ignition – Coil and Igniter	**CC294**	4	
Sensor – Air Flow / MAF	**CAF034**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA165**	1	
Sensor – Knock Control	**CKS121**	1	To 10/2005
Corolla ZRE152R **5/07-on 4 Cyl 1.8L 2ZRFE DOHC 16V MPFi FWD**			
Sensor – Crankshaft	**CSCA147**	1	No 1
Sensor – Knock Control	**CKS121**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
Corona RT40 **11/64-6/69 4 Cyl 1.5L 2R OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**JP516**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S202V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Corona RT40 **9/66-8/68 4 Cyl 1.6L 4R OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD278**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Corona RT72: RT80: RT81 **8/69-2/74 4 Cyl 1.5L 2R: 1.6L 12R: 1.9L 8R SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**JP516**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S202V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Toyota	Part No	Qty	Notes
Corona MX10 Mk.II: MX13: MX22 Mk.II: MX23			
7/72-12/77 6 Cyl 2.0L M: 2.3L 2M: 2.6L 4M Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP514**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR507**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Corona RT104: RT118			
3/74-9/79 4 Cyl 2.0L 18RC SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH96**	1	Bosch Points Distributor
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**BC100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**BH73**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Corona XT130			
10/79-7/83 4 Cyl 1.9L Starfire OHV 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH90**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC100**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**DR463**	1	Bosch Points Distributor
Switch – Oil Pressure Warning Light	**CPS30**	1	
Corona RT132			
1/80-12/81 4 Cyl 2.0L 18RC SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Corona RT133			
1/82-8/82 4 Cyl 2.0L 21RC SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Ignition – Pickup / Trigger	**CIT102**	1	
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	

Toyota	Part No	Qty	Notes
Corona TT141R *(NZ Market)* **1982-85 4 Cyl 1.7L 3T**			
Ignition – Coil – Standard	**CC211**	1	Denso Points Distributor
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Corona ST141 **8/83-4/87 4 Cyl 2.0L 2SC SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC217**	1	To 10/1985
Ignition – Coil – Standard	**CC216**	1	From 10/1985
Ignition – Distributor Cap	**JP580**	1	Denso Electronic Distributor: To 10/1985
Ignition – Distributor Cap and Leads	**JP803**	1	Denso Electronic Distributor: From 10/1985
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor: To 10/1985
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor: From 10/1985
Ignition – Module	**CM402**	1	
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Brake Light	**CSL40**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS24**	1	
Corona ST150 *(NZ Market)* **1983-88 4 Cyl 1.8L 1S SOHC Carb.**			
Ignition – Coil – Standard	**CC211**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP580**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
Corona RT142 **11/84-4/87 4 Cyl 2.4L 22RE SOHC 8V EFi RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP588**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Ignition – Module	**CM479**	1	From 10/1985 To 12/1986
Ignition – Pickup / Trigger	**CIT102**	1	To 10/1985
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS106**	1	
Sensor – Throttle Position	**CTPS101**	1	To 10/1985
Switch – Brake Light	**CSL40**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS24**	1	
Corona ST160 *(NZ Market)* **1985-90 4 Cyl 1.8L 1S**			
Ignition – Distributor Cap	**JP580**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
Corona ST151R *(NZ Market)* **1986-88 4 Cyl 2.0L 2SEL SOHC 8V**			
Ignition – Coil – Standard	**CC217**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP580**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
Corona ST170 *(NZ Market)* **1987-90 4 Cyl 1.8L 4SFI DOHC**			
Ignition – Coil – Standard	**CC265**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor

Toyota	Part No	Qty	Notes
Corona ST171 *(NZ Market)* **1987-92 4 Cyl 2.0L 3SGE DOHC 16V**			
Ignition – Distributor Cap	**JP700**	1	To 11/1989
Ignition – Distributor Cap	**JP810**	1	From 11/1989
Ignition – Distributor Rotor	**JR573**	1	To 11/1989
Ignition – Distributor Rotor	**JR649**	1	From 11/1989
Corona ST171 Carb. *(NZ Market)* **1987-92 4 Cyl 2.0L 3SF DOHC 16V**			
Ignition – Distributor Cap	**DR895**	1	Denso Electronic Distributor
Corona ST191 *(NZ Market)* **1990-96 4 Cyl 2.0L 3SFE DOHC**			
Ignition – Coil – Standard	**CC263**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**BD131**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Corona ST190 *(NZ Market)* **1992-94 4 Cyl 1.8L 4SFE DOHC**			
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Corona AT211 *(NZ Market)* **1996-97 4 Cyl 1.8L 7A-FE**			
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Cressida MX32: MX36 **3/77-12/80 6 Cyl 2.6L 4M SOHC 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP514**	1	Denso Points Distributor: To 8/1979
Ignition – Distributor Cap	**JP626**	1	Denso Points Distributor: From 8/1979
Ignition – Distributor Condenser	**TC210**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR507**	1	Denso Points Distributor: To 8/1979
Ignition – Distributor Rotor	**JR597**	1	Denso Points Distributor: From 8/1979
Sensor – Temperature Gauge	**CTS104**	1	To 8/1979
Sensor – Temperature Gauge	**CTS106**	1	From 8/1979
Switch – Oil Pressure Warning Light	**CPS23**	1	
Cressida MX62 **2/81-10/85 6 Cyl 2.8L 5ME SOHC 12V EFi RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP626**	1	Denso Electronic Distributor: To 8/1983
Ignition – Distributor Cap	**JP554**	1	Denso Electronic Distributor: From 8/1983
Ignition – Distributor Rotor	**JR597**	1	Denso Electronic Distributor: To 8/1983
Ignition – Distributor Rotor	**JR543**	1	Denso Electronic Distributor: From 8/1983
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Temperature Gauge	**CTS106**	1	
Sensor – Throttle Position	**CTPS102**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	

Toyota	Part No	Qty	Notes
Cressida MX73 SOHC **11/84-10/85 6 Cyl 2.8L 5ME SOHC 12V EFi RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP554**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR543**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS106**	1	
Sensor – Throttle Position	**CTPS102**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS43**	1	
Cressida MX73 DOHC **11/85-12/88 6 Cyl 2.8L 5MGE DOHC 24V MPFi RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP702**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR575**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS43**	1	
Cressida MX83R **10/88-1/93 6 Cyl 3.0L 7MGE DOHC 24V MPFi RWD**			
Ignition – Coil – Standard	**CC288**	1	
Ignition – Distributor Cap	**JP582**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**DR839**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Brake Light	**CSL56**	1	With Cruise Control
Switch – Brake Light	**CSL47**	1	Without Cruise Control
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS43**	1	
Crown RS40 **1963-66 4 Cyl 1.9L 3R SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**JP516**	1	Denso Points Distributor: From 1964
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S202V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR507**	1	Denso Points Distributor: To 1964
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor: From 1964
Crown MS41: MS47 **3/66-12/66 6 Cyl 2.0L M SOHC 12V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP514**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR507**	1	Denso Points Distributor

Toyota	Part No	Qty	Notes
Crown MS45: MS55			
2/67-71 6 Cyl 2.3L 2M SOHC 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP514**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR507**	1	Denso Points Distributor
Crown MS65: MS83: MS85			
1971-12/80 6 Cyl 2.6L 4M SOHC 12V Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP514**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**JR507**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Crown MS112			
10/80-9/83 6 Cyl 2.8L 5ME SOHC 12V EFi RWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP626**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR597**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Temperature Gauge	**CTS106**	1	
Sensor – Throttle Position	**CTPS102**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Crown MS123 SOHC			
10/83-11/85 6 Cyl 2.8L 5ME SOHC 12V EFi RWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP554**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Crown MS123 DOHC			
12/85-5/88 6 Cyl 2.8L 5MGE DOHC 12V MPFi RWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP702**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR575**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Radiator Fan	**CFS43**	1	
Cynos EL44: EL54 *(NZ Market)*			
1991-98 4 Cyl 1.5L 5EFE DOHC 16V			
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor

Toyota	Part No	Qty	Notes
Dyna RU10: RU12: RU15: RU19 **1969-77 4 Cyl 2.0L 5R OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	To 1973
Ignition – Coil – Standard	**CIC32R**	1	From 1973
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	To 1973
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	From 1973
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	From 1973
Ignition – Distributor Cap	**JP516**	1	Denso Points Distributor: To 1976
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor: From 1976
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor: To 1976
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor: From 1976
Ignition – Distributor Points / Contact Set	**S202V**	1	Denso Points Distributor: To 1976
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor: From 1976
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor: To 1976
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: From 1976
Dyna BU20 Diesel **1976-84 4 Cyl 3.0L B Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Dyna HU40 Diesel **1976-84 6 Cyl 4.0L 2H Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Dyna RU20: RU25: RU30 **1977-84 4 Cyl 2.0L 5R OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Dyna 100 YH81R **11/85-6/95 4 Cyl 1.8L 2YC OHV Carb. RWD**			
Ignition – Coil – Standard	**CC217**	1	From 9/1991
Ignition – Coil – Standard	**CIC32R**	1	Denso Points Distributor: To 1993
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Denso Points Distributor: To 1993
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Denso Points Distributor: To 1993
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor: To 1993
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor: To 1993
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor: To 1993
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: To 1993
Ignition – Module	**CM402**	1	From 9/1991
Ignition – Pickup / Trigger	**CIT104**	1	From 9/1991
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Dyna 100 LH80R Diesel **11/85-4/91 4 Cyl 2.4L 2L SOHC 8V Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Dyna 100 LY220R Diesel **9/01-4/05 4 Cyl 3.0L 5L SOHC 8V Di RWD**			
Sensor – Temperature Gauge	**CTS150**	1	

Toyota	Part No	Qty	Notes
Dyna 150 LY60R: LY61R Diesel **11/85-6/95 4 Cyl 2.4L 2L: 2.8L 3L SOHC 8V Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Dyna 150 LY211R: LY230R Diesel **7/95-4/05 4 Cyl 2.8L 3L SOHC 8V Di RWD**			
Sensor – Temperature Gauge	**CTS150**	1	
Dyna 200 BU60R: BU63R Diesel **11/84-6/95 4 Cyl 3.0L B Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Dyna 200 YU60R **11/84-10/86 4 Cyl 2.0L 3YC OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Dyna 200 YU62R **11/86-12/91 4 Cyl 2.2L 4YC OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	Denso Points Distributor: To 9/1991
Ignition – Coil – Standard	**CC217**	1	From 9/1991
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	Denso Points Distributor: To 9/1991
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	Denso Points Distributor: To 9/1991
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Ignition – Module	**CM402**	1	From 9/1991
Ignition – Pickup / Trigger	**CIT104**	1	From 9/1991
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Dyna 200 BU100R: BU101R: BU142R: BU212R Diesel **6/95-5/03 4 Cyl 3.5L 3B: 3.7L 14B: 4.1L 15B OHV Di RWD**			
Sensor – Temperature Gauge	**CTS150**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
Dyna 300 BU88R Diesel **9/88-6/95 4 Cyl 3.7L 14B OHV Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	To 9/1993
Sensor – Temperature Gauge	**CTS150**	1	From 9/1993
Switch – Oil Pressure Warning Light	**CPS24**	1	
Dyna 300 BU212R Diesel **7/95-5/03 4 Cyl 4.1L 15B OHV Di RWD**			
Sensor – Temperature Gauge	**CTS150**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
Dyna 400 BU91R Diesel **9/88-7/95 4 Cyl 3.7L 14B OHV Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	To 9/1993
Sensor – Temperature Gauge	**CTS150**	1	From 9/1993
Switch – Oil Pressure Warning Light	**CPS24**	1	

Toyota	Part No	Qty	Notes
Dyna 400 BU212R: BU222R Diesel **7/95-5/03 4 Cyl 4.1L 15B OHV Di RWD**			
Sensor – Temperature Gauge	**CTS150**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
Echo NCP10R: NCP12R: NCP13R **10/99-10/05 4 Cyl 1.3L 2NZFE: 1.5L 1NZFE DOHC 16V EFi FWD**			
Ignition – Coil and Igniter	**CC296**	4	
Sensor – Air Flow / MAF	**CAF034**	1	
Sensor – Camshaft	**CSCA102**	1	
Sensor – Crankshaft	**CSCA136**	1	
Sensor – Exhaust Oxygen	**COS861**	1	Direct Fit 4 Wire: Before Catalyst: From 12/2002
Sensor – Exhaust Oxygen	**COS872**	1	Direct Fit 4 Wire: Before Catalyst: From 12/2002
Sensor – Exhaust Oxygen	**COS857**	1	Direct Fit 4 Wire: After Catalyst: From 12/2002
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Before and After Catalyst
Hi-Ace RH11R: RH16: RH20R **1/72-12/85 4 Cyl 1.6L 12R OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP516**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S202V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Hi-Ace RH32RV: RH42B **5/77-12/82 4 Cyl 2.0L 18RC SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor: From 1978 To 1979
Ignition – Distributor Cap	**JP642**	1	Denso Points Distributor: From 1980
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor: From 1978 To 1979
Ignition – Distributor Condenser	**BC556**	1	Denso Points Distributor: From 1980
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor: From 1978
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: From 1978
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Hi-Ace LH Series Diesel **3/81-9/89 4 Cyl 2.2L L SOHC 8V Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Hi-Ace YH50RV: YH51RV: YH61RV: YH71RB **1/83-9/86 4 Cyl 2.0L 3YC OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CC287**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	

Toyota	Part No	Qty	Notes
Hi-Ace YH50 *(NZ Market)* **1983-89 4 Cyl 1.8L 2Y**			
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Hi-Ace YH53RV: YH63RV: YH73RB **10/86-9/89 4 Cyl 2.2L 4YC OHV Carb. RWD**			
Ignition – Coil – Standard	**CC287**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Hi-Ace YH81 *(NZ Market)* **1987-95 4 Cyl 1.8L 2Y**			
Ignition – Distributor Cap	**JP534**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Ignition – Coil – Standard	**CC211**	1	Denso Points Distributor
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Hi-Ace RZH103R: RZH113R: RZH125R Carb **10/89-9/98 4 Cyl 2.4L 2RZ SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC216**	1	
Ignition – Distributor Cap	**JP823**	1	Denso Electronic Distributor: To 5/1992
Ignition – Distributor Cap	**JP807**	1	Denso Electronic Distributor: From 5/1992
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT103**	1	From 8/1993
Sensor – Temperature Gauge	**CTS106**	1	To 5/1992
Sensor – Temperature Gauge	**CTS150**	1	From 5/1992
Hi-Ace LH103R: LH113R: LH125R Diesel **10/89-9/00 4 Cyl 2.8L 3L SOHC 8V Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	To 8/1993
Sensor – Temperature Gauge	**CTS150**	1	From 8/1993
Hi-Ace RZH101: RZHML *(NZ Market)* **1989-93 4 Cyl 2.4L 2RZE SOHC EFi**			
Ignition – Distributor Cap	**DR895**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Hi-Ace RCH12R: RCH22R EFi **10/95-2/05 4 Cyl 2.4L 2RZ SOHC 8V MPFi RWD**			
Ignition – Coil – Standard	**CC216**	1	
Ignition – Distributor Cap	**JP807**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR800**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Temperature Gauge	**CTS150**	1	

Toyota	Part No	Qty	Notes
Hi-Ace RZH103R: RZH113R: RZH125R EFi **9/98-10/05 4 Cyl 2.4L 2RZE SOHC 8V MPFi RWD**			
Ignition – Coil – Standard	**CC216**	1	
Ignition – Distributor Cap	**JP807**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR800**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT103**	1	
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS842**	1	Direct Fit 4 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS726**	1	Universal 4 Wire With Flange
Sensor – Temperature Gauge	**CTS150**	1	
Sensor – Throttle Position	**CTPS111**	1	
Hi-Ace LH172R Diesel **10/01-2/05 4 Cyl 3.0L 5L SOHC 8V Di RWD**			
Sensor – Temperature Gauge	**CTS150**	1	
Hi-Ace KDH200R: KDH220R: KDH222R Turbo Diesel **3/05-on 4 Cyl 2.5L 2KDFTV DOHC 16V Di RWD**			
Sensor – Air Temperature – Inlet	**CAT010**	1	Turbo boost
Hi-Ace TRH201R: TRH221R: TRH223R **3/05-on 4 Cyl 2.7L 2TRFE DOHC 16V EPFI RWD**			
Sensor – Camshaft	**CSCA118**	1	
Sensor – Knock Control	**CKS121**	1	
Hi-Lux RN13: RN16: RN20: RN40 **2/71-10/83 4 Cyl 1.6L 12R OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP516**	1	Denso Points Distributor: To 1976
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor: From 1976 To 1980
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor: From 1980
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor: To 1976
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor: From 1976
Ignition – Distributor Points / Contact Set	**S202V**	1	Denso Points Distributor: To 1976
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor: From 1976
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor: To 1976
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: From 1976
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Hi-Lux RN41: RN46 **1/78-10/83 4 Cyl 2.0L 18R SOHC 8V Carb. RWD & 4WD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor: To 8/1979
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor: From 1979
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor: To 8/1979
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS104**	1	To 12/1979
Sensor – Temperature Gauge	**CTS106**	1	From 12/1979
Switch – Oil Pressure Warning Light	**CPS23**	1	To 2/1982
Switch – Oil Pressure Warning Light	**CPS37**	1	From 2/1982

Toyota	Part No	Qty	Notes
Hi-Lux RN30 **10/78-10/83 4 Cyl 1.6L 12R OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP516**	1	Denso Points Distributor: To 1/1980
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor: From 1/1980
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor: To 1/1980
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: From 1/1980
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Hi-Lux LN40: LN46 Diesel **6/80-10/83 4 Cyl 2.2L L Di RWD & 4WD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Hi-Lux YN55 **11/83-9/87 4 Cyl 1.6L 1YC OHV Carb. RWD**			
Ignition – Coil – Standard	**CC287**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Hi-Lux YN57: YN65 **11/83-9/87 4 Cyl 2.0L 3YC OHV Carb. RWD & 4WD**			
Ignition – Coil – Standard	**CC287**	1	
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Hi-Lux LN55: LN56: LN65 Diesel **11/83-8/88 4 Cyl 2.2L L: 2.4L 2L SOHC Di RWD & 4WD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Hi-Lux YN57: YN60: YN61: YN65: YN67: YN87 *(NZ Market)* **1983-92 4 Cyl 2.0L 3Y: 2.2L 4Y**			
Ignition – Coil – Standard	**CC211**	1	Denso Points Distributor
Ignition – Distributor Cap	**JP546**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Hi-Lux YN58: YN67 **11/85-9/88 4 Cyl 2.2L 4YC OHV Carb. 4WD**			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Ignition – Module	**CM402**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT104**	1	From 8/1987
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	

Toyota	Part No	Qty	Notes
Hi-Lux YN56: YN85 **10/87-11/97 4 Cyl 1.8L 2YC OHV Carb. RWD**			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Ignition – Module	**CM402**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT104**	1	
Sensor – Temperature Gauge	**CTS106**	1	To 8/1992
Sensor – Temperature Gauge	**CTS150**	1	From 8/1992
Switch – Oil Pressure Warning Light	**CPS24**	1	
Hi-Lux YN80: YN85 *(NZ Market)* **1988-95 4 Cyl 1.8L 2Y**			
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
Hi-Lux RN85: RN90 **10/88-12/97 4 Cyl 2.4L 22R SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC258**	1	To 8/1992
Ignition – Coil – Standard	**CC231**	1	From 8/1992
Ignition – Distributor Cap	**JP588**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT102**	1	To 8/1992
Sensor – Temperature Gauge	**CTS106**	1	To 8/1992
Sensor – Temperature Gauge	**CTS150**	1	From 8/1992
Hi-Lux RN105: RN106: RN110 **10/88-11/97 4 Cyl 2.4L 22R SOHC 8V Carb. 4WD**			
Ignition – Coil – Standard	**CC215**	1	To 8/1992
Ignition – Coil – Standard	**CC231**	1	From 8/1992
Ignition – Distributor Cap	**JP588**	1	Denso Electronic Distributor: To 8/1992
Ignition – Distributor Cap	**JP802**	1	Denso Electronic Distributor: From 8/1992
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT102**	1	To 8/1992
Sensor – Temperature Gauge	**CTS106**	1	To 8/1992
Sensor – Temperature Gauge	**CTS150**	1	From 8/1992
Switch – Brake Light	**CSL59**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Hi-Lux LN85: LN86 Diesel **10/88-11/97 4 Cyl 2.4L 2L SOHC 8V Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	To 8/1992
Sensor – Temperature Gauge	**CTS150**	1	From 8/1992
Switch – Oil Pressure Warning Light	**CPS23**	1	
Switch – Brake Light	**CSL59**	1	
Hi-Lux LN86: LN106: LN107: LN111 Diesel **10/88-12/97 4 Cyl 2.8L 3L SOHC 8V Di 4WD**			
Sensor – Coolant Temperature	**CCS21**	1	From 11/1996
Sensor – Temperature Gauge	**CTS106**	1	To 8/1992
Sensor – Temperature Gauge	**CTS150**	1	From 8/1992
Switch – Brake Light	**CSL59**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	To 8/1995
Hi-Lux YN130 *(NZ Market)* **1989-91 4 Cyl 2.0L 3YE**			
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor

Toyota	Part No	Qty	Notes
Hi-Lux YN81: YN86 *(NZ Market)* **1994-97 4 Cyl 2.0L 3Y**			
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Hi-Lux RZN147R **11/97-10/02 4 Cyl 2.0L 1RZE SOHC 8V EFi RWD**			
Ignition – Coil – Standard	**CC216**	1	
Ignition – Distributor Cap	**JP807**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR800**	1	Denso Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Temperature Gauge	**CTS150**	1	
Hi-Lux RZN149: RZN154: RZN169: RZN174 **11/97-4/05 4 Cyl 2.7L 3RZFE DOHC 16V MPFi RWD & 4WD**			
Ignition – Coil and Igniter	**CC291**	1	Cylinder 1 & 4
Ignition – Coil and Igniter	**CC292**	1	Cylinder 2 & 3
Sensor – Camshaft	**CSCA103**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA134**	1	
Hi-Lux LN147: LN172 Diesel **11/97-4/05 4 Cyl 3.0L 5L SOHC 8V Di RWD & 4WD**			
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Crankshaft	**CSCA150**	1	
Hi-Lux KZN165R Turbo Diesel **11/01-4/05 4 Cyl 3.0L 1KZTE SOHC 8V Di 4WD**			
Sensor – Crankshaft	**CSCA150**	1	
Sensor – Temperature Gauge	**CTS150**	1	
Hi-Lux VZN167R **11/02-4/05 V6 Cyl 3.4L 5VZFE DOHC 24V PFI 4WD**			
Sensor – Crankshaft	**CSCA166**	1	
Sensor – Temperature Gauge	**CTS110**	1	
Hi-Lux TGN16R: TGN26R **3/05-on 4 Cyl 2.7L 2TRFE DOHC 16V MPFi RWD & 4WD**			
Sensor – Camshaft	**CSCA118**	1	
Sensor – Knock Control	**CKS121**	1	
Hi-Lux GGN15R: GGN25R **3/05-on V6 Cyl 4.0L 1GRFE DOHC 24V MPFi RWD**			
Sensor – Air Flow / MAF	**CAF034**	1	
Sensor – Camshaft	**CSCA147**	2	
Sensor – Crankshaft	**CSCA138**	1	
Sensor – Exhaust Oxygen	**COS894**	2	Direct Fit 4 Wire: LH & RH Side Before Catalyst
Sensor – Knock Control	**CKS121**	1	
Kluger MCU28R **11/03-7/07 V6 Cyl 3.3L 3MZFE DOHC 24V EPFI 4WD**			
Sensor – Crankshaft	**CSCA133**	1	
Sensor – Exhaust Oxygen	**COS895**	1	Direct Fit 4 Wire: Front and Rear Manifold
Sensor – Exhaust Oxygen	**COS867**	1	Direct Fit 4 Wire: Front Eng Pipe
Sensor – Exhaust Oxygen	**COS881**	1	Direct Fit 4 Wire: Rear Eng Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire: Front and Rear Eng Pipe
Sensor – Knock Control	**CKS121**	1	
Switch – Brake Light	**CSL60**	1	

Toyota	Part No	Qty	Notes
LandcruiSeries FJ40: FJ45: FJ55 **1/65-12/74 6 Cyl 3.9L F OHV 12V Carb. 4WD**			
Ignition – Coil – Standard	**CC211**	1	
Ignition – Distributor Cap	**JP514**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC204**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S202V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR507**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS106**	1	To 9/1972
Sensor – Temperature Gauge	**CTS104**	1	From 9/1972
Switch – Oil Pressure Warning Light	**CPS23**	1	
LandcruiSeries FJ40: FJ45: FJ55: FJ60 **1/75-12/84 6 Cyl 4.2L 2F OHV 12V Carb. 4WD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP514**	1	Denso Points Distributor: To 1980
Ignition – Distributor Cap	**BD377**	1	Denso Points Distributor: From 1980
Ignition – Distributor Condenser	**TC204**	1	Denso Points Distributor: To 1980
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor: From 1980
Ignition – Distributor Points / Contact Set	**S202V**	1	Denso Points Distributor: To 1978
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor: From 1979
Ignition – Distributor Rotor	**JR507**	1	Denso Points Distributor: To 1980
Ignition – Distributor Rotor	**JR597**	1	Denso Points Distributor: From 1980
Sensor – Temperature Gauge	**CTS104**	1	To 10/1979
Sensor – Temperature Gauge	**CTS106**	1	From 10/1979
Switch – Oil Pressure Warning Light	**CPS37**	1	
LandcruiSeries HJ45: HJ47: HJ60: HJ75 Diesel **9/77-4/90 6 Cyl 3.6L H: 4.0L 2H OHV Di 4WD**			
Sensor – Temperature Gauge	**CTS104**	1	To 10/1979
Sensor – Temperature Gauge	**CTS106**	1	From 10/1979
Switch – Oil Pressure Warning Light	**CPS24**	1	
LandcruiSeries BJ40: BJ42: BJ70: BJ73 Diesel **12/77-3/90 4 Cyl 3.0L B: 3.4L 3B OHV Di 4WD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
LandcruiSeries FJ62: FJ70: FJ73: FJ75 **1/85-10/92 6 Cyl 4.0L 3F OHV 12V Carb. 4WD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**BD377**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR597**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
LandcruiSeries HJ61 Turbo Diesel **2/86-12/91 6 Cyl 4.0L 12HT Di 4WD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
LandcruiSeries BJ74 Turbo Diesel **3/86-12/89 4 Cyl 3.4L 13BT Di 4WD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	

Toyota	Part No	Qty	Notes
LandcruiSeries FJ80 Carb **3/90-10/92 6 Cyl 4.0L 3F OHV Carb. 4WD**			
Ignition – Distributor Cap	**BD377**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
LandcruiSeries FJ80 *(NZ Market)* **1990-92 6 Cyl 4.0L 3F**			
Ignition – Coil – Standard	**CC211**	1	Denso Points Distributor
Ignition – Distributor Cap	**JP514**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
LandcruiSeries FJ80 EFi **3/90-10/92 6 Cyl 4.0L 3FE OHV EFi 4WD**			
Ignition – Coil – Standard	**CC227**	1	
Ignition – Distributor Cap	**JP586**	1	Denso Electronic Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Rotor	**DR686**	1	Denso Electronic Distributor
Ignition – Module	**CM437**	1	
Sensor – Coolant Temperature	**CCS21**	1	
LandcruiSeries FZJ80 **11/92-2/98 6 Cyl 4.5L 1FZE DOHC 24V EFi 4WD**			
Ignition – Coil – Standard	**CC280**	1	
Ignition – Distributor Cap	**JP804**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**DR686**	1	Denso Electronic Distributor
Ignition – Module	**CM436**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS735**	1	Direct Fit 4 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS726**	1	Universal 4 Wire With Flange
LandcruiSeries FZJ75 **11/92-11/99 6 Cyl 4.5L 1FZE DOHC 24V EFi 4WD**			
Ignition – Coil – Standard	**CC231**	1	
Ignition – Distributor Cap	**JP804**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**DR686**	1	Denso Electronic Distributor
Ignition – Module	**CM436**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen – Universal	**COS726**	1	Universal 4 Wire With Flange
Sensor – Temperature Gauge	**CTS150**	1	
Sensor – Throttle Position	**CTPS111**	1	
Switch – Brake Light	**CSL59**	1	
LandcruiSeries FZJ105R **3/98-10/00 6 Cyl 4.5L 1FZE DOHC 24V MPFi 4WD**			
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA167**	1	
LandcruiSeries UZJ100R **3/98-10/00 V8 Cyl 4.7L 2UZFE DOHC 32V MPFi 4WD**			
Ignition – Coil and Igniter	**CC293**	8	
Sensor – Camshaft	**CSCA109**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA135**	1	
Sensor – Exhaust Oxygen	**COS844**	1	Direct Fit 4 Wire: Front
Sensor – Exhaust Oxygen	**COS843**	1	Direct Fit 4 Wire With Flange: Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Front
Sensor – Exhaust Oxygen – Universal	**COS726**	1	Universal 4 Wire With Flange: Rear
Sensor – Temperature Gauge	**CTS154**	1	

Toyota	Part No	Qty	Notes
LandcruiSeries HZJ78R Diesel **10/99-on 6 Cyl 4.2L 1HZ SOHC 12V Di 4WD**			
Sensor – Temperature Gauge	**CTS150**	1	
LandcruiSeries FZJ78R: FZJ79R **10/99-on 6 Cyl 4.5L 1FZFE DOHC 24V EFi 4WD**			
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Throttle Position	**CTPS111**	1	
LandcruiSeries HDJ100R Turbo Diesel **10/00-9/02 6 Cyl 4.2L 1HDFTE SOHC 24V Di 4WD**			
Sensor – Crankshaft	**CSCA150**	1	
LandcruiSeries UZJ100R **10/02-on V8 Cyl 4.7L 2UZFE DOHC 32V MPFi 4WD**			
Sensor – Camshaft	**CSCA109**	1	
Sensor – Crankshaft	**CSCA135**	1	
Sensor – Exhaust Oxygen	**COS844**	1	Direct Fit 4 Wire: Front
Sensor – Exhaust Oxygen	**COS843**	1	Direct Fit 4 Wire With Flange: Rear
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Front
Sensor – Exhaust Oxygen – Universal	**COS726**	1	Universal 4 Wire With Flange: Rear
Sensor – Temperature Gauge	**CTS154**	1	
LandcruiSeries Prado RZJ95R **7/96-5/02 4 Cyl 2.7L 3RZFE DOHC 16V PFI 4WD**			
Ignition – Coil – Standard	**CC263**	1	
Ignition – Distributor Cap	**JP807**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR800**	1	Denso Electronic Distributor
Ignition – Module	**CM436**	1	
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA134**	1	
Sensor – Exhaust Oxygen	**COS843**	1	Direct Fit 4 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS726**	1	Universal 4 Wire With Flange
Sensor – Temperature Gauge	**CTS154**	1	
LandcruiSeries Prado VZJ95R **7/96-2/03 V6 Cyl 3.4L 5VZFE DOHC 24V PFI 4WD**			
Ignition – Coil – Standard	**CC289**	3	
Sensor – Crankshaft	**CSCA166**	1	
Sensor – Temperature Gauge	**CTS110**	1	
LandcruiSeries Prado KZJ95R: KZJ120R Turbo Diesel **3/00-10/06 4 Cyl 3.0L 1KZTE SOHC 8V Di 4WD**			
Sensor – Crankshaft	**CSCA150**	1	
Sensor – Temperature Gauge	**CTS150**	1	
LandcruiSeries Prado RZJ120R **3/03-8/04 4 Cyl 2.7L 3RZFE DOHC 16V MPFi 4WD**			
Sensor – Camshaft	**CSCA103**	1	With Independent Front Suspension
LandcruiSeries Prado GRJ120R **3/03-on V6 Cyl 4.0L 1GRFE DOHC 24V MPFi 4WD**			
Sensor – Air Flow / MAF	**CAF034**	1	
Sensor – Camshaft	**CSCA103**	2	With Independent Front Suspension
Sensor – Camshaft	**CSCA147**	1	With Independent Front Suspension: From 8/2004
Sensor – Crankshaft	**CSCA138**	1	With Independent Front Suspension
Sensor – Exhaust Oxygen	**COS861**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire

Toyota	Part No	Qty	Notes
Lexcen VN			
9/89-11/91 V6 Cyl 3.8L VH OHV 12V MPFi RWD			
Ignition – Coil – Standard	**CC206**	1	To 11/1990
Ignition – Coil – Standard	**CC208**	3	From 11/1990
Ignition – Coil & Module Kit	**CCMLK**	1	With Ignition Leads
Ignition – Coil & Module Kit	**CCMK**	1	Without Ignition Leads
Ignition – Module	**CM407**	1	To 11/1990
Ignition – Module	**CM414**	1	From 11/1990
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS732**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS125**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
Lexcen VP			
11/91-8/93 V6 Cyl 3.8L VH OHV 12V MPFi RWD			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Coil & Module Kit	**CCMLK**	1	With Ignition Leads
Ignition – Coil & Module Kit	**CCMK**	1	Without Ignition Leads
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen	**COS734**	1	Direct Fit 2 Wire
Sensor – Exhaust Oxygen – Universal	**COS723**	1	Universal 2 Wire
Sensor – Knock Control	**CKS103**	1	
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS125**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
Lexcen VR			
8/93-4/95 V6 Cyl 3.8L VH OHV 12V MPFi RWD			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Coil & Module Kit	**CCMLK**	1	With Ignition Leads
Ignition – Coil & Module Kit	**CCMK**	1	Without Ignition Leads
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT009**	1	
Sensor – Coolant Temperature	**CCS26**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – MAP	**CMS206**	1	
Sensor – Temperature Gauge	**CTS125**	1	
Sensor – Throttle Position	**CTPS132**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	
Valve – Idle Speed Control	**CIA008**	1	
Lexcen VS			
5/95-4/97 V6 Cyl 3.8L VH OHV 12V MPFi RWD			
Ignition – Coil – Standard	**CC208**	3	
Ignition – Module	**CM414**	1	
Sensor – Air Temperature – Inlet	**CAT002**	1	
Sensor – Coolant Temperature	**CTS147**	1	
Sensor – Exhaust Oxygen	**COS744**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Knock Control	**CKS101**	2	LH and RH Side
Sensor – Temperature Gauge	**CTS125**	1	
Switch – Oil Pressure Warning Light	**CPS38**	1	

Toyota	Part No	Qty	Notes
Lite-Ace KM20 **2/80-12/85 4 Cyl 1.3L 4KC OHV Carb. RWD**			
Ignition – Distributor Cap	**JP516**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor: To 10/1982
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: From 10/1980
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Lite-Ace YM20 *(NZ Market)* **1983-86 4 Cyl 1.6L 1Y**			
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Lite-Ace CM20: CM35 Diesel **1/83-3/92 4 Cyl 1.8L 1C OHV Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Lite-Ace YM21: YM30: YM35 **1/84-12/92 4 Cyl 1.8L 2YC OHV Carb. RWD**			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor: To 8/1987
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor: From 8/1987
Ignition – Module	**CM402**	1	
Ignition – Pickup / Trigger	**CIT104**	1	
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Lite-Ace KM35V: KM50 *(NZ Market)* **1985-89 4 Cyl 1.3L 4K**			
Ignition – Coil – Standard	**CC211**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP534**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Lite-Ace KM30: KM31 *(NZ Market)* **1985-90 4 Cyl 1.5L 5K**			
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Lite-Ace CM35 Diesel **1/86-3/92 4 Cyl 1.8L 1C OHV Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Lite-Ace YM40: YM41 **3/86-9/88 4 Cyl 2.0L 3YC OHV 8V Carb. 4WD**			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor: To 8/1987
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor: From 8/1987
Ignition – Module	**CM402**	1	
Ignition – Pickup / Trigger	**CIT104**	1	
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Lite-Ace KR27V *(NZ Market)* **1992-96 4 Cyl 1.5L 5K**			
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor

Toyota	Part No	Qty	Notes
Lite-Ace YR25V: YR26: YR30G *(NZ Market)* **1992-96 4 Cyl 1.8L 2Y: 2.0L 3YE**			
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
Master-Ace YR20 *(NZ Market)* **1982-96 4 Cyl 1.8L 2Y**			
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
MR2 AW11 **10/87-2/90 4 Cyl 1.6L 4AGEL DOHC 16V EFi RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP656**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS20**	1	To 8/1988
Sensor – Coolant Temperature	**CCS21**	1	From 8/1988
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange: To 6/1989
Sensor – Exhaust Oxygen	**COS821**	1	Direct Fit 4 Wire With Flange: From 6/1989
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange: To 6/1989
Sensor – Exhaust Oxygen – Universal	**COS726**	1	Universal 4 Wire With Flange: From 6/1989
Sensor – Temperature Gauge	**CTS106**	1	
Sensor – Throttle Position	**CTPS153**	1	Denso: From 8/1987 To 3/1989
MR2 SW20R **3/90-8/99 4 Cyl 2.0L 3SGE DOHC 16V EFi RWD**			
Ignition – Coil – Standard	**CC231**	1	
Ignition – Distributor Cap	**JP810**	1	Denso Electronic Distributor: To 12/1991
Ignition – Distributor Cap	**JP730**	1	Denso Electronic Distributor: From 12/1991
Ignition – Distributor Rotor	**JR649**	1	Denso Electronic Distributor
Ignition – Module	**CM437**	1	External 5 pin module: To 12/1991
Ignition – Module	**CM436**	1	From 11/1993
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS725**	1	Universal 2 Wire With Flange
Sensor – Oil Pressure Gauge	**CPS26**	1	
Sensor – Temperature Gauge	**CTS106**	1	
Sensor – Throttle Position	**CTPS104**	1	3 Terminal: Rectangle Body
Sensor – Throttle Position	**CTPS153**	1	4 Terminal: Round Body
MR2 ZZW30R **10/00-3/06 4 Cyl 1.8L 1ZZFE DOHC 16V ESPFI RWD**			
Ignition – Coil and Igniter	**CC295**	4	
Sensor – Camshaft	**CSCA103**	1	No 1 in Cylinder Head
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA29**	1	Front
Sensor – Exhaust Oxygen	**COS861**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Switch – Oil Pressure Warning Light	**CPS51**	1	

Toyota	Part No	Qty	Notes
Paseo EL44R			
7/91-1/96 4 Cyl 1.5L 5EFE DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC263**	1	
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Ignition – Module	**CM436**	1	External 5 pin module: To 8/1996
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS775**	1	Direct Fit 2 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS725**	1	Universal 2 Wire With Flange
Sensor – Temperature Gauge	**CTS110**	1	
Sensor – Throttle Position	**CTPS111**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Paseo EL54R			
12/95-12/99 4 Cyl 1.5L 5EFE DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC263**	1	
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS760**	1	Direct Fit 2 Wire With Flange: From 8/1996
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: To 8/1996
Sensor – Exhaust Oxygen – Universal	**COS725**	1	Universal 2 Wire With Flange: From 8/1996
Sensor – Temperature Gauge	**CTS154**	1	
Sensor – Throttle Position	**CTPS111**	1	To 8/1996
Prius NHW11R Hybrid			
10/01-10/03 4 Cyl 1.5L 1NZFXE DOHC 16V ESPFI FWD			
Ignition – Coil and Igniter	**CC296**	4	
Sensor – Camshaft	**CSCA102**	1	
Prius NHW20R Hybrid			
11/03-on 4 Cyl 1.5L 1NZFXE DOHC 16V ESPFI FWD			
Ignition – Coil and Igniter	**CC296**	4	
Sensor – Camshaft	**CSCA102**	1	
Sensor – Coolant Temperature	**CCS52**	1	
Sensor – Crankshaft	**CSCA136**	1	
Sensor – Knock Control	**CKS121**	1	
Switch – Brake Light	**CSL60**	1	With Cruise Control
Switch – Oil Pressure Warning Light	**CPS51**	1	
RAV4 SXA10G: SXA11 *(NZ Market)*			
1994-97 4 Cyl 2.0L 3SFE			
Ignition – Coil – Standard	**CC280**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**BD131**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
RAV4 SXA10: SXA11: SXA116			
7/94-9/00 4 Cyl 2.0L 3SFE DOHC 16V MPFi 4WD			
Ignition – Coil – Standard	**CC280**	1	
Ignition – Distributor Cap	**JP806**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Ignition – Module	**CM436**	1	To 9/1997
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Throttle Position	**CTPS111**	1	To 9/1997
Switch – Brake Light	**CSL59**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
Switch – Radiator Fan	**CFS55**	1	

Toyota	Part No	Qty	Notes
RAV4 ACA20R: ACA21R **7/00-9/03 4 Cyl 2.0L 1AZFE DOHC 16V MPFi 4WD**			
Ignition – Coil and Igniter	**CC310**	4	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS838**	1	Direct Fit 4 Wire: LH Side Manifold: After Cat
Sensor – Exhaust Oxygen	**COS892**	1	Direct Fit 4 Wire: LH Side Manifold: Before Cat
Sensor – Exhaust Oxygen	**COS838**	1	Direct Fit 4 Wire: RH Side Manifold: After Cat
Sensor – Exhaust Oxygen	**COS893**	1	Direct Fit 4 Wire: RH Side Manifold: Before Cat
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Univ. 4 Wire: LH and RH Side Manifold: After Cat
Sensor – Throttle Position	**CTPS154**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
RAV4 ACA22R: ACA23R **10/03-1/06 4 Cyl 2.4L 2AZFE DOHC 16V ESPFI 4WD**			
Ignition – Coil and Igniter	**CC310**	4	
Sensor – Camshaft	**CSCA103**	1	
Sensor – Crankshaft	**CSCA137**	1	
Sensor – Exhaust Oxygen	**COS895**	1	Direct Fit 4 Wire: Manifold
Sensor – Exhaust Oxygen	**COS882**	1	Direct Fit 4 Wire: Engine Pipe
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire: Engine Pipe
Sensor – Knock Control	**CKS121**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
RAV4 ACA33R **2/06-on 4 Cyl 2.4L 2AZFE DOHC 16V MPFi 4WD**			
Sensor – Camshaft	**CSCA103**	1	
Sensor – Crankshaft	**CSCA137**	1	
Sensor – Knock Control	**CKS121**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
RAV4 GSA33R **8/07-on V6 Cyl 3.5L 2GRFE DOHC 24V MPFi 4WD**			
Switch – Oil Pressure Warning Light	**CPS51**	1	
Soarer JZZ30 Twin Turbo **1/90-12/97 6 Cyl 2.5L 1JZGTE DOHC 24V MPFi RWD**			
Sensor – Temperature Gauge	**CTS106**	1	To 11/1992
Sensor – Temperature Gauge	**CTS150**	1	From 11/1992
Soarer UZZ31 **1/90-12/97 V8 Cyl 4.0L 1UZFE DOHC 32V MPFi RWD**			
Sensor – Temperature Gauge	**CTS110**	1	To 10/1992
Sensor – Temperature Gauge	**CTS154**	1	From 10/1992
Spacia YR22 **10/93-1/98 4 Cyl 2.2L 4YEC OHV MPFi FWD**			
Ignition – Coil – Standard	**CC217**	1	To 10/1996
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Spacia SR40 **1/98-8/02 4 Cyl 2.0L 3SFE DOHC 16V MPFi FWD**			
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Exhaust Oxygen	**COS858**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Throttle Position	**CTPS154**	1	To 11/2001

Toyota	Part No	Qty	Notes
Sprinter KE15 **1968-69 4 Cyl 1.1L K OHV 8V Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**JP516**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS104**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Sprinter AE86 **7/83-12/85 4 Cyl 1.6L 4AC SOHC 8V Carb. RWD**			
Ignition – Coil – Standard	**CC202**	1	
Ignition – Distributor Cap	**JP574**	1	Denso Electronic Distributor
Ignition – Distributor Condenser	**TC209**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S214V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Radiator Fan	**CFS24**	1	
Sprinter AE102R **5/94-11/96 4 Cyl 1.8L 7AFE DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC216**	1	
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS775**	1	Direct Fit 2 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS725**	1	Universal 2 Wire With Flange
Sensor – Temperature Gauge	**CTS154**	1	
Sensor – Throttle Position	**CTPS111**	1	
Switch – Brake Light	**CSL59**	1	
Switch – Radiator Fan	**CFS63**	1	
Starlet KP61R *(NZ Market)* **1983-85 4 Cyl 1.3L 4K**			
Ignition – Coil – Standard	**CC211**	1	Denso Points Distributor
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Starlet EP76V *(NZ Market)* **1984-90 4 Cyl 1.3L 2EL**			
Ignition – Distributor Cap	**JP534**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Starlet EP71: EP81 *(NZ Market)* **1984-93 4 Cyl 1.3L 2EE**			
Ignition – Distributor Cap	**JP534**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Starlet EPKD: EEMX *(NZ Market)* **1986-90 4 Cyl 1.0L 1EL**			
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor
Starlet EP80 *(NZ Market)* **1990-93 4 Cyl 1.0L 1EL**			
Ignition – Distributor Cap	**JP546**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Electronic Distributor

Toyota	Part No	Qty	Notes
Starlet EP82 EFi *(NZ Market)* **1/92-8/95 4 Cyl 1.3L 4EFE DOHC 16V**			
Ignition – Distributor Cap	**BD112**	1	
Ignition – Distributor Rotor	**JR613**	1	
Starlet EP91R **4/96-10/99 4 Cyl 1.3L 4EFE DOHC 16V MPFi FWD**			
Ignition – Coil – Standard	**CC216**	1	
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS861**	1	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	1	Universal 4 Wire
Sensor – Temperature Gauge	**CTS110**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
Stout RK40: RK43: RK100 **1963-68 4 Cyl 1.9L 3R OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Condenser	**TC204**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR507**	1	Denso Points Distributor
Stout RK101J: RK110R **1/70-12/83 4 Cyl 2.0L 5R OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP516**	1	Denso Points Distributor: To 1976
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor: From 1976
Ignition – Distributor Condenser	**TC205**	1	Denso Points Distributor: To 1976
Ignition – Distributor Condenser	**TC206**	1	Denso Points Distributor: From 1976
Ignition – Distributor Points / Contact Set	**S202V**	1	Denso Points Distributor: To 1976
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor: From 1976
Ignition – Distributor Rotor	**JR513**	1	Denso Points Distributor: To 1976
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: From 1976
Sensor – Temperature Gauge	**CTS104**	1	To 12/1979
Sensor – Temperature Gauge	**CTS106**	1	From 12/1979
Switch – Oil Pressure Warning Light	**CPS23**	1	To 3/1979
Switch – Oil Pressure Warning Light	**CPS24**	1	From 4/1979
Supra MA61 **10/83-3/86 6 Cyl 2.8L 5ME SOHC MPFi RWD**			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**JP554**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR543**	1	Denso Electronic Distributor
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Supra MA70 **3/86-9/88 6 Cyl 3.0L 7MGE DOHC 24V MPFi RWD**			
Ignition – Coil – Standard	**CC288**	1	
Ignition – Distributor Cap	**JP582**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR575**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	2	To 8/1988
Sensor – Coolant Temperature	**CCS21**	1	From 8/1988
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS106**	1	

Toyota	Part No	Qty	Notes
Supra MA70 *(NZ Market)* **1987-89 6 Cyl 3.0L 7MGE**			
Ignition – Distributor Cap	**JP582**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor
Supra MA71 Turbo **10/88-4/93 6 Cyl 3.0L 7MGTE DOHC 24V MPFi RWD**			
Ignition – Distributor Cap	**JP582**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**DR839**	1	Denso Electronic Distributor
Sensor – Coolant Temperature	**CCS20**	1	To 8/1988
Sensor – Coolant Temperature	**CCS21**	1	From 8/1988
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS106**	1	
T18 TE72 **10/79-7/83 4 Cyl 1.8L 3TC OHV Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor
Ignition – Distributor Condenser	**MC418**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS37**	1	
Tarago CR21 Diesel **1/83-12/88 4 Cyl 2.0L 2C OHC Di RWD**			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Brake Light	**CSL40**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	
Tarago YR20: YR21 **2/83-10/90 4 Cyl 1.8L 2YC: 2.0L 3YC OHV Carb. RWD**			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor: 1.8L
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor: 2.0L
Ignition – Module	**CM402**	1	
Ignition – Pickup / Trigger	**CIT104**	1	
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Brake Light	**CSL40**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS60**	1	
Tarago YR31R *(NZ Market)* **1984-85 4 Cyl 2.0L 3Y**			
Ignition – Coil – Standard	**CC211**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR573**	1	Denso Electronic Distributor

Toyota	Part No	Qty	Notes
Tarago YR22: YR31 **10/85-10/90 4 Cyl 2.2L 4YEC OHV MPFi RWD**			
Ignition – Coil – Standard	**CC217**	1	To 1/1990
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT140**	1	From 9/1989
Sensor – Coolant Temperature	**CCS20**	1	To 8/1988
Sensor – Coolant Temperature	**CCS21**	1	From 8/1988
Sensor – Exhaust Oxygen	**COS730**	1	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	1	Universal 1 Wire With Flange
Sensor – Temperature Gauge	**CTS106**	1	
Sensor – Throttle Position	**CTPS102**	1	To 1/1990
Switch – Brake Light	**CSL40**	1	
Switch – Radiator Fan	**CFS60**	1	
Tarago TCR10: TCR11: TCR20: TCR21 **9/90-8/00 4 Cyl 2.4L 2TZFE DOHC 16V MPFi 4WD**			
Ignition – Coil – Standard	**CC275**	1	
Ignition – Distributor Cap	**JP824**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR649**	1	Denso Electronic Distributor
Ignition – Module	**CM437**	1	To 8/1993
Ignition – Module	**CM436**	1	From 8/1996
Sensor – Air Temperature – Inlet	**CAT010**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS774**	1	Direct Fit 4 Wire With Flange: Front Before Catalyst
Sensor – Exhaust Oxygen	**COS775**	1	Direct Fit 2 Wire With Flange: Rear After Catalyst
Sensor – Exhaust Oxygen – Universal	**COS726**	1	Univ. 4 Wire With Flange: Front Before Catalyst
Sensor – Exhaust Oxygen – Universal	**COS725**	1	Universal 2 Wire With Flange: Rear After Catalyst
Sensor – Temperature Gauge	**CTS106**	1	To 5/1992
Sensor – Temperature Gauge	**CTS150**	1	From 5/1992
Sensor – Throttle Position	**CTPS153**	1	
Switch – Brake Light	**CSL47**	1	
Tarago ACR30R **6/00-2/06 4 Cyl 2.4L 2AZFE DOHC 16V ESPFI FWD**			
Ignition – Coil and Igniter	**CC310**	4	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Crankshaft	**CSCA137**	1	
Sensor – Knock Control	**CKS121**	1	From 4/2003
Sensor – Throttle Position	**CTPS154**	1	
Tarago ACR50 **3/06-on 4 Cyl 2.4L 2AZFE DOHC 16V ESPFI FWD**			
Sensor – Camshaft	**CSCA103**	1	
Sensor – Crankshaft	**CSCA137**	1	
Sensor – Knock Control	**CKS121**	1	
Tarago GSR50R **4/06-on V6 Cyl 3.5L 2GRFE DOHC 24V MPFi FWD**			
Sensor – Camshaft	**CSCA147**	4	
Sensor – Crankshaft	**CSCA138**	1	
Sensor – Knock Control	**CKS121**	1	

Toyota	Part No	Qty	Notes
Tercel AL25			
10/83-4/88 4 Cyl 1.5L 3AC SOHC 8V Carb. 4WD			
Ignition – Coil – Standard	**CIC32R**	1	Points ignition
Ignition – Coil – Standard	**CC216**	1	Electronic Ignition
Ignition – Coil – Heavy Duty	**C80R**	1	Points ignition
Ignition – Distributor Cap	**JP574**	1	Denso Points Distributor
Ignition – Distributor Cap	**JP800**	1	Denso Electronic Distributor
Ignition – Distributor Condenser	**MC418**	1	Denso Points Distributor
Ignition – Distributor Points / Contact Set	**S214V**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Ignition – Pickup / Trigger	**CIT103**	1	Denso Electronic Distributor: From 11/1985
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS24**	1	
Switch – Radiator Fan	**CFS24**	1	
Tercel EL43 *(NZ Market)*			
1991 4 Cyl 1.5L 5E-FHE			
Ignition – Distributor Cap	**BD112**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Townace YR39			
4/92-1/97 4 Cyl 2.0L 3YC OHV 8V Carb. RWD			
Ignition – Coil – Standard	**CC217**	1	
Ignition – Distributor Cap	**JP584**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR577**	1	Denso Electronic Distributor
Ignition – Module	**CM402**	1	
Ignition – Pickup / Trigger	**CIT104**	1	
Sensor – Temperature Gauge	**CTS106**	1	To 9/1993
Sensor – Temperature Gauge	**CTS150**	1	From 9/1993
Townace KR42			
2/97-12/98 4 Cyl 1.8L 7KC OHV Carb. RWD			
Ignition – Coil – Standard	**CC231**	1	
Ignition – Distributor Rotor	**JR527**	1	
Townace KR42R			
12/98-2/05 4 Cyl 1.8L 7KE OHV 8V MPFi RWD			
Ignition – Coil – Standard	**CC231**	1	
Sensor – Air Temperature – Inlet	**CAT010**	1	To 10/2003
Sensor – Temperature Gauge	**CTS150**	1	
Sensor – Throttle Position	**CTPS154**	1	
Toyo-Ace RY16			
1968-79 4 Cyl 2.0L 5R OHV Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**JP534**	1	Denso Points Distributor: To 1977
Ignition – Distributor Condenser	**MC418**	1	Denso Points Distributor: To 1977
Ignition – Distributor Points / Contact Set	**S204V**	1	Denso Points Distributor: To 1977
Ignition – Distributor Rotor	**JR527**	1	Denso Points Distributor: To 1977
Toyo-Ace LY31 Diesel			
9/83-12/85 4 Cyl 2.4L 2L SOHC 8V Di RWD			
Sensor – Temperature Gauge	**CTS106**	1	
Switch – Oil Pressure Warning Light	**CPS23**	1	

Toyota	Part No	Qty	Notes
Vienta VCV10: VCV10R **10/95-8/97 V6 Cyl 3.0L 3VZFE DOHC 24V EFi FWD**			
Ignition – Coil – Standard	**CC227**	1	
Ignition – Distributor Cap	**BD138**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**BD139**	1	Denso Electronic Distributor
Ignition – Module	**CM438**	1	
Sensor – Coolant Temperature	**CCS21**	1	
Sensor – Exhaust Oxygen	**COS730**	2	Direct Fit 1 Wire With Flange
Sensor – Exhaust Oxygen – Universal	**COS722**	2	Universal 1 Wire With Flange
Switch – Radiator Fan	**CFS55**	1	
Vienta MCV20R **8/97-10/00 V6 Cyl 3.0L 1MZFE DOHC 24V EFi FWD**			
Ignition – Coil – Standard	**CC329**	6	
Sensor – Exhaust Oxygen	**COS861**	2	Direct Fit 4 Wire
Sensor – Exhaust Oxygen – Universal	**COS724**	2	Universal 4 Wire
Switch – Radiator Fan	**CFS75**	1	
Vista SV21 *(NZ Market)* **1988-90 4 Cyl 2.0L 3S-GE DOHC 16V**			
Ignition – Distributor Cap and Leads	**JP805**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**JR613**	1	Denso Electronic Distributor
Windom VCV10 *(NZ Market)* **10/91-8/96 V6 Cyl 3.0L 3VZFE DOHC 24V**			
Ignition – Coil – Standard	**CC227**	1	Denso Electronic Distributor
Ignition – Distributor Cap	**BD138**	1	Denso Electronic Distributor
Ignition – Distributor Rotor	**BD139**	1	Denso Electronic Distributor
Windom VCV11 *(NZ Market)* **8/93-8/96 V6 Cyl 2.5L 4VZFE DOHC**			
Ignition – Distributor Cap	**BD138**	1	
Ignition – Distributor Rotor	**BD139**	1	
Yaris NCP90R: NCP91R: NCP93R **11/05-on 4 Cyl 1.3L 2NZFE: 1.5L 1NZFE DOHC 16V ESPFI FWD**			
Ignition – Coil and Igniter	**CC296**	4	
Sensor – Camshaft	**CSCA102**	1	
Sensor – Crankshaft	**CSCA136**	1	
Sensor – Knock Control	**CKS121**	1	
Switch – Oil Pressure Warning Light	**CPS51**	1	
Triumph			
2.5 Pi **1969-75 6 Cyl 2.5L EFi RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD250**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
2000 Mk.1 **1964-69 6 Cyl 2.0L Carb. RWD**			
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	

Triumph	Part No	Qty	Notes
2000 Mk.2 **1970-77 6 Cyl 2.0L Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD290**	1	Lucas Points Distributor: From 1973
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor: To 1973
Ignition – Distributor Condenser	**LC104**	1	Lucas Points Distributor: From 1973
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor: To 1973
Ignition – Distributor Points / Contact Set	**L24V**	1	Lucas Points Distributor: From 1973
Ignition – Distributor Rotor	**BD256**	1	Lucas Points Distributor: To 1973
Ignition – Distributor Rotor	**BD287**	1	Lucas Points Distributor: From 1973
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
2500 **3/73-6/78 6 Cyl 2.5L Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD290**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L24V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD287**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Dolomite **9/75-6/78 4 Cyl 1.9L SOHC 8V 2xCarb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Condenser	**UC11E**	1	Delco Points Distributor
Ignition – Distributor Points / Contact Set	**S50**	1	Delco Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Dolomite Sprint **9/75-6/78 4 Cyl 2.0L SOHC 8V 2xCarb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD288**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC104**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L24V**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
GT6 Mk.I: Mk.II: Mk.III **3/67-7/73 6 Cyl 2.0L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**DR86**	1	Delco Points Distributor
Ignition – Distributor Condenser	**UC11E**	1	Delco Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**S52**	1	Delco Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**RE85**	1	Delco Points Distributor
Ignition – Distributor Rotor	**BD250**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS20**	1	

Triumph	Part No	Qty	Notes
Herald **1959-64 4 Cyl 948cc Carb. RWD**			
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Herald **1959-64 4 Cyl 1.1L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Herald **1967-71 4 Cyl 1.3L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD276**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD229**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Spitfire **1963-65 4 Cyl 1.1L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**DR101**	1	Delco Points Distributor
Ignition – Distributor Condenser	**UC11E**	1	Delco Points Distributor
Ignition – Distributor Points / Contact Set	**S52**	1	Delco Points Distributor
Ignition – Distributor Rotor	**RE85**	1	Delco Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Spitfire Mk.II: Mk.III: Mk.IV **1966-80 4 Cyl 1.3L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD288**	1	Lucas Points Distributor: From 1968 To 1973
Ignition – Distributor Condenser	**LC104**	1	Lucas Points Distributor: From 1968 To 1973
Ignition – Distributor Points / Contact Set	**L24V**	1	Lucas Points Distributor: From 1968 To 1973
Ignition – Distributor Rotor	**BD287**	1	Lucas Points Distributor: From 1968 To 1973
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Stag **7/72-6/78 V8 Cyl 3.0L Carb. RWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD280**	1	Lucas Points Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD257**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	

Triumph	Part No	Qty	Notes
Toledo			
1970-78 4 Cyl 1.3, 1.5L Carb. RWD			
Sensor – Temperature Gauge	**CTS119**	1	
TR4: TR4A			
1956-67 4 Cyl & 6 Cyl Carb. RWD			
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
TR5: TR6			
1967-75 6 Cyl 2.5L EFi RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BD286**	1	Lucas Points Distributor: From 1969
Ignition – Distributor Condenser	**LC103**	1	Lucas Points Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Points Distributor
Ignition – Distributor Rotor	**BD250**	1	Lucas Points Distributor
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
TR7			
1975-82 4 Cyl 2.0L Carb. RWD			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BD288**	1	Lucas Electronic Distributor: From 1978
Ignition – Distributor Condenser	**UC11E**	1	Delco Points Distributor: From 1978
Ignition – Distributor Points / Contact Set	**S50**	1	Delco Points Distributor: From 1978
Ignition – Distributor Rotor	**BD287**	1	Lucas Electronic Distributor: From 1978
Sensor – Temperature Gauge	**CTS119**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
Universal			
Universal Applications			
Sensor – MAP	**CMS206**	1	Universal 1 Bar for Performance Applications
Sensor – MAP	**CMS207**	1	Universal 2 Bar for Performance Applications
Sensor – MAP	**CMS208**	1	Universal 3 Bar for Performance Applications
Vauxhall			
Viva HA: HB			
1963-68 4 Cyl 1.1L Carb. RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**DR101**	1	Delco Distributor
Ignition – Distributor Cap	**BD278**	1	Lucas Distributor: From 1966 To 1967
Ignition – Distributor Condenser	**UC11E**	1	Delco Distributor
Ignition – Distributor Condenser	**LC103**	1	Lucas Distributor: From 1966 To 1967
Ignition – Distributor Points / Contact Set	**S52**	1	Delco Distributor
Ignition – Distributor Points / Contact Set	**L19V**	1	Lucas Distributor: From 1966 To 1967
Ignition – Distributor Rotor	**RE85**	1	Delco Distributor
Ignition – Distributor Rotor	**BD256**	1	Lucas Distributor: From 1966 To 1967

Volkswagen	Part No	Qty	Notes
1600 TLE Type 3 **8/71-7/73 4 Cyl 1.6L EFi RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH78**	1	
Ignition – Distributor Condenser	**BC89**	1	
Ignition – Distributor Points / Contact Set	**S11V**	1	
Ignition – Distributor Rotor	**BH77**	1	
Beetle 1200 **1960-2/67 4 Cyl 1.2L Carb. RWD**			
Ignition – Distributor Cap	**BH78**	1	Bosch Points Distributor: From 1964
Ignition – Distributor Condenser	**BC63**	1	Bosch Points Distributor: To 1964
Ignition – Distributor Condenser	**BC58**	1	Bosch Points Distributor: From 1964
Ignition – Distributor Points / Contact Set	**S2V**	1	Bosch Points Distributor: From 1964
Ignition – Distributor Rotor	**BH75**	1	Bosch Points Distributor: To 1964
Ignition – Distributor Rotor	**BH77**	1	Bosch Points Distributor: From 1964
Switch – Oil Pressure Warning Light	**CPS20**	1	
Beetle 1500 **1960-71 4 Cyl 1.5L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor: From 1968
Ignition – Distributor Condenser	**BC98**	1	Bosch Points Distributor: From 1968
Ignition – Distributor Condenser	**BC89**	1	Bosch Points Distributor: From 1968
Ignition – Distributor Points / Contact Set	**S12**	1	Bosch Points Distributor: Check lead direction: From 1968
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor: Check lead direction: From 1968
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor: From 1968
Switch – Oil Pressure Warning Light	**CPS20**	1	
Beetle 1300 **1964-75 4 Cyl 1.3L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH78**	1	Bosch Points Distributor: From 1966 To 1970
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor: From 1970 To 1971
Ignition – Distributor Cap	**BH78**	1	Bosch Points Distributor: From 1971 To 1974
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor: From 1974
Ignition – Distributor Condenser	**BC58**	1	Bosch Points Distributor: From 1966 To 1970
Ignition – Distributor Condenser	**BC89**	1	Bosch Points Distributor: From 1970 To 1974
Ignition – Distributor Condenser	**BC58**	1	Bosch Points Distributor: From 1974
Ignition – Distributor Points / Contact Set	**S2V**	1	Bosch Points Distributor: From 1966 To 1970
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor: From 1970 To 1971
Ignition – Distributor Points / Contact Set	**S1V**	1	Bosch Points Distributor: From 1971 To 1974
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor: From 1974
Ignition – Distributor Rotor	**BH77**	1	Bosch Points Distributor: From 1966 To 1970
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor: From 1970 To 1971
Ignition – Distributor Rotor	**BH77**	1	Bosch Points Distributor: From 1971 To 1974
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor: From 1974
Switch – Oil Pressure Warning Light	**CPS20**	1	

Volkswagen	Part No	Qty	Notes
Beetle 1600 **1966-76 4 Cyl 1.6L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor: From 1971 To 1971
Ignition – Distributor Cap	**BH78**	1	Bosch Points Distributor: From 1971
Ignition – Distributor Condenser	**BC89**	1	Bosch Points Distributor: From 1971
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor: From 1971 To 1971
Ignition – Distributor Points / Contact Set	**S1V**	1	Bosch Points Distributor: From 1971
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor: From 1971 To 1971
Ignition – Distributor Rotor	**BH77**	1	Bosch Points Distributor: From 1971
Switch – Oil Pressure Warning Light	**CPS20**	1	
Beetle 1600 **1/02-on 4 Cyl 1.6L AYD SOHC 8V MPFi FWD**			
Ignition – Coil and Igniter	**CC377**	1	
Sensor – Air Flow / MAF	**CAF019**	1	
Beetle 2000 **5/03-on 4 Cyl 2.0L AQY SOHC 16V EPFI FWD**			
Ignition – Coil and Igniter	**CC377**	1	
Caravelle **1984-12/92 4 Cyl 1.9L: 2.1L OHV Carb. FWD**			
Ignition – Distributor Cap	**BH136**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor
Ignition – Module	**CM409**	1	
Caravelle **5/89-12/92 4 Cyl 2.1L MV OHV PFI RWD & 4WD**			
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Golf **1/76-12/80 4 Cyl 1.6L SOHC 8V Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH136**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC115**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor
Golf A1 **3/77-12/80 4 Cyl 1.6L SOHC 8V Carb. FWD**			
Sensor – Temperature Gauge	**CTS116**	1	
Switch – Oil Pressure Warning Light	**CPS20**	1	
Switch – Radiator Fan	**CFS18**	1	
Golf A2 **9/90-7/94 4 Cyl 1.8L JH, 2H SOHC 8V EFi FWD**			
Sensor – Air Flow / MAF	**CAF012**	1	
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Golf 13J4 *(NZ Market)* **1994-98 4 Cyl 1.8L ADZ**			
Ignition – Distributor Rotor	**DR127**	1	Bosch Electronic Distributor
Golf GL **8/94-9/98 4 Cyl 2.0L 2E SOHC 8V ESPFI FWD**			
Ignition – Distributor Cap	**JP987**	1	Bosch Electronic Distributor: To 9/1997
Ignition – Distributor Rotor	**DR127**	1	Bosch Electronic Distributor: To 9/1997

Volkswagen	Part No	Qty	Notes
Golf VR6 **3/94-10/98 V6 Cyl 2.8L AAA SOHC 12V MPFi FWD**			
Sensor – Crankshaft	**CSCA184**	1	
Sensor – Knock Control	**CKS110**	1	
Sensor – Temperature Gauge	**CTS161**	1	Oil Temperature Gauge: 0-150°C: M10x1
Golf GL **3/95-6/00 4 Cyl 2.0L ADY SOHC 8V MPFi FWD**			
Ignition – Coil and Igniter	**CC376**	1	To 9/1998
Golf GL **3/95-3/03 4 Cyl 2.0L AGG SOHC 8V MPFi FWD**			
Sensor – Temperature Gauge	**CTS160**	1	2 Pin M20 Green/Black
Golf CL **10/95-12/96 4 Cyl 1.8L ADZ SOHC 8V MPFi FWD**			
Ignition – Coil and Igniter	**CC376**	1	
Sensor – Air Flow / MAF	**CAF012**	1	
Golf GLE **10/98-6/99 4 Cyl 1.8L ADZ DOHC 20V MPFi FWD**			
Ignition – Coil and Igniter	**CC377**	1	
Sensor – Air Flow / MAF	**CAF012**	1	
Golf GL **10/98-2/02 4 Cyl 1.6L AKL SOHC 8V MPFi FWD**			
Ignition – Coil and Igniter	**CC377**	1	
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Golf **10/98-7/00 4 Cyl 1.8L AEB SOHC 8V MPFi FWD**			
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Golf GTi Turbo **3/99-7/04 4 Cyl 1.8L AGU DOHC 20V MPFi FWD**			
Sensor – Air Flow / MAF	**CAF013**	1	
Golf GLE **7/99-2/02 4 Cyl 2.0L AGY SOHC 8V MPFi FWD**			
Ignition – Coil and Igniter	**CC376**	1	
Golf GL Rally **11/99-3/01 4 Cyl 1.6L AKL SOHC 8V MPFi FWD**			
Sensor – Air Flow / MAF	**CAF019**	1	
Kombi **1965-67 4 Cyl 1.5L Carb. RWD**			
Ignition – Distributor Cap	**BH78**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC58**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S2V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH77**	1	Bosch Points Distributor
Kombi **1968-72 4 Cyl 1.6L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor: From 1968 To 1969
Ignition – Distributor Cap	**BH78**	1	Bosch Points Distributor: To 1970
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor: From 1971
Ignition – Distributor Condenser	**BC58**	1	Bosch Points Distributor: To 1970
Ignition – Distributor Condenser	**BC89**	1	Bosch Points Distributor: From 1971
Ignition – Distributor Points / Contact Set	**S12**	1	Bosch Points Distributor: To 1970
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor: From 1971
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor: From 1968 To 1969
Ignition – Distributor Rotor	**BH77**	1	Bosch Points Distributor: From 1968 To 1970

Volkswagen	Part No	Qty	Notes
Kombi **1971-73 4 Cyl 1.7L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Kombi **1974-75 4 Cyl 1.8L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC119**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH213**	1	Bosch Points Distributor
Kombi **1976-83 4 Cyl 2.0L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC115**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor
Kombi **1984-86 4 Cyl 1.9L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH136**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor
Kombi MPFi **1988-92 4 Cyl 2.1L EFi RWD**			
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Micro Bus **1973 4 Cyl 1.7L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC89**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH213**	1	Bosch Points Distributor
Micro Bus **1974-75 4 Cyl 1.8L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC119**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH213**	1	Bosch Points Distributor
Micro Bus **11/75-12/83 4 Cyl 2.0L Carb. RWD**			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC115**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor

Volkswagen	Part No	Qty	Notes
Passat **2/74-11/75 4 Cyl 1.3L: 1.5L Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC58**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor
Passat **11/75-12/81 4 Cyl 1.6L Carb. FWD**			
Ignition – Coil – Standard	**CIC32R**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80R**	1	
Ignition – Coil – Heavy Duty Epoxy Type	**CC254**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC115**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS116**	1	
Switch – Oil Pressure Warning Light	**CPS20**	1	
Switch – Radiator Fan	**CFS18**	1	
Passat Z31 *(NZ Market)* **1988-94 4 Cyl 2.0L 2E**			
Ignition – Distributor Rotor	**DR127**	1	Bosch Electronic Distributor
Passat **8/95-2/97 4 Cyl 2.0L EA87 SOHC 8V Digifant FWD**			
Ignition – Coil and Igniter	**CC376**	1	
Passat Turbo **3/98-10/02 4 Cyl 1.8L AEB DOHC 20V MPFi FWD**			
Ignition – Coil – Standard	**CC371**	4	
Sensor – Air Flow / MAF	**CAF013**	1	
Sensor – Air Flow / MAF	**CAF020**	1	
Passat V6 4Motion **8/00-7/04 V6 Cyl 2.8L DOHC 30V MPFi AWD**			
Switch – Brake Light	**CSL67**	1	
Switch – Radiator Fan	**CFS91**	1	
Polo 6N10N4: GN10C4 *(NZ Market)* **1995-99 4 Cyl 1.4:1.6L AEX: AEA**			
Ignition – Distributor Rotor	**DR127**	1	Bosch Electronic Distributor
Polo **10/96-10/00 4 Cyl 1.6L AEE SOHC 8V EFi FWD**			
Ignition – Coil and Igniter	**CC376**	1	
Polo **9/00-12/01 4 Cyl 1.4L AHW DOHC 16V MPFi FWD**			
Sensor – Crankshaft	**CSCA197**	1	To 2001
Touareg **9/03-on V6 Cyl 3.2L AZZ DOHC 24V EPFI 4WD**			
Sensor – Camshaft	**CSCA201**	2	
Sensor – Knock Control	**CKS118**	1	Without Harness
Touareg **9/03-on V8 Cyl 4.2L AXQ DOHC 30V EPFI 4WD**			
Sensor – Air Flow / MAF	**CAF007**	1	
Sensor – Camshaft	**CSCA202**	2	

Volkswagen	Part No	Qty	Notes
Transporter Kombi			
1/84-12/86 4 Cyl 1.9L OHV Carb. RWD			
Ignition – Module	**CM409**	1	
Transporter T4			
1/93-7/04 4 Cyl 2.0L AAC EFi FWD & RWD			
Ignition – Coil and Igniter	**CC376**	1	
Ignition – Distributor Cap	**JP987**	1	Bosch Electronic Distributor
Transporter			
1/94-7/04 5 Cyl 2.5L AAF: AET SOHC 10V EFi RWD & 4WD			
Ignition – Coil and Igniter	**CC376**	1	
Vento GL			
6/95-2/97 4 Cyl 2.0L 2E SOHC 8V MPFi FWD			
Ignition – Coil and Igniter	**CC376**	1	
Sensor – Temperature Gauge	**CTS161**	1	Oil Temperature: 0-150 Celsius: M10x1
Volvo			
142: 144: 145			
10/68-3/75 4 Cyl 2.0L B20A Carb. RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH72**	1	Bosch Points Distributor: From 1971
Ignition – Distributor Condenser	**BC74**	1	Bosch Points Distributor: From 1971
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor: From 1971 To 1974
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor: From 1975
Ignition – Distributor Rotor	**BH89**	1	Bosch Points Distributor: From 1971 To 1974
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor: From 1975
Sensor – Temperature Gauge	**CTS117**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
142			
3/71-2/73 4 Cyl 2.0L B20E OHV 8V Fi RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC86**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS117**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
144			
3/71-3/75 4 Cyl 2.0L B20D OHV 8V Fi RWD			
Ignition – Coil – Standard	**CIC31**	1	
Ignition – Coil – Heavy Duty Oil Filled Type	**C80**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor: From 1973
Ignition – Distributor Condenser	**BC74**	1	Bosch Points Distributor: From 1973
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor: From 1973
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor: From 1973
Sensor – Temperature Gauge	**CTS117**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	

Volvo	Part No	Qty	Notes
164			
3/69-7/72 6 Cyl 3.0L B30A OHV 8V Carb. RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH74**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC74**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S15V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH89**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS117**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
164E: 164TE			
8/72-12/75 6 Cyl 3.0L B30E / F OHV 8V EFi RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH140**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH177**	1	Bosch Points Distributor
240			
2/83-12/84 4 Cyl 2.1L B21A SOHC 8V Carb. RWD			
Ignition – Module	**CM413**	1	Inductive Pickup
Ignition – Module	**CM409**	1	Hall Pickup
240			
2/83-10/83 4 Cyl 2.3L B23E SOHC 8V K-jet RWD			
Ignition – Coil – Standard	**CC212**	1	
Sensor – Exhaust Oxygen	**COS738**	1	Direct Fit 1 Wire
Sensor – Exhaust Oxygen – Universal	**COS720**	1	Universal 1 Wire
Sensor – Temperature Gauge	**CTS117**	1	
240			
11/83-12/85 4 Cyl 2.3L B230E SOHC 8V K-jet RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor:
Ignition – Distributor Rotor	**BH95**	1	Bosch Electronic Distributor: To 1984
Ignition – Distributor Rotor	**BH89**	1	Bosch Electronic Distributor: From 1985
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
240			
3/86-10/93 4 Cyl 2.3L B230F SOHC 8V LH-jet RWD			
Ignition – Coil – Standard	**CC215**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
Sensor – Crankshaft	**CSCA171**	1	
Sensor – Exhaust Oxygen	**COS790**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
242			
3/75-12/76 4 Cyl 2.1L B21A SOHC 8V Carb. RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC446**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS117**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	

Volvo	Part No	Qty	Notes
242			
3/79-12/81 4 Cyl 2.3L B23E SOHC 8V EFi RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH95**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
244			
3/75-12/80 4 Cyl 2.1L B21E DOHC 8V K-jet RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC446**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS117**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
244			
1978-82 4 Cyl 2.1L B21A Carb. RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Points Distributor
Ignition – Distributor Condenser	**BC446**	1	Bosch Points Distributor
Ignition – Distributor Points / Contact Set	**S11V**	1	Bosch Points Distributor
Ignition – Distributor Rotor	**BH95**	1	Bosch Points Distributor
Sensor – Temperature Gauge	**CTS117**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
244			
1/81-12/82 4 Cyl 2.3L B23E DOHC 8V K-jet RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH95**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
Sensor – Temperature Gauge	**CTS117**	1	
260			
1983-86 V6 Cyl 2.8L B28E EFi RWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH146**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH153**	1	Bosch Electronic Distributor
262			
1980 V6 Cyl 2.7L B27E EFi RWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH146**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH153**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
264			
1/75-12/80 V6 Cyl 2.7L B27E SOHC 12V EFi RWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH146**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH153**	1	Bosch Electronic Distributor
Sensor – Temperature Gauge	**CTS117**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
264			
2/81-3/83 V6 Cyl 2.8L B28E SOHC 12V EFi RWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Module	**CM413**	1	

Volvo	Part No	Qty	Notes
265			
6/76-12/80 V6 Cyl 2.7L B27E SOHC 12V EFi RWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH146**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH153**	1	Bosch Electronic Distributor
Ignition – Module	**CM413**	1	
Sensor – Temperature Gauge	**CTS117**	1	
Switch – Oil Pressure Warning Light	**CPS31**	1	
265			
2/81-12/82 V6 Cyl 2.8L B28E SOHC 12V EFi RWD			
Ignition – Coil – Standard	**CC213**	1	
Ignition – Distributor Cap	**BH146**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH153**	1	Bosch Electronic Distributor
360			
3/84-12/87 4 Cyl 2.0L B200E SOHC 8V EFi RWD			
Ignition – Coil – Standard	**CC212**	1	
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Module	**CM409**	1	
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS117**	1	
440			
10/93-9/96 4 Cyl 2.0L B20F SOHC EFi FWD			
Sensor – Exhaust Oxygen	**COS790**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
740			
6/85-12/91 4 Cyl 2.3L B230E SOHC 8V EFi RWD			
Ignition – Distributor Cap	**BH172**	1	Bosch Electronic Distributor: To 1985
Ignition – Distributor Rotor	**BH224**	1	Bosch Electronic Distributor: To 1985
Ignition – Module	**CM409**	1	
Ignition – Pickup / Trigger	**CIT120**	1	Hall Sensor
Sensor – Knock Control	**CKS108**	1	
Sensor – Temperature Gauge	**CTS117**	1	
Switch – Radiator Fan	**CFS10**	1	
740 Turbo			
3/86-12/90 4 Cyl 2.3L B230FT SOHC 8V EFi RWD			
Ignition – Distributor Cap	**BH172**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH224**	1	Bosch Electronic Distributor
Sensor – Crankshaft	**CSCA171**	1	
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS108**	1	
Sensor – Temperature Gauge	**CTS117**	1	
Sensor – Throttle Position	**CTPS145**	1	
Switch – Radiator Fan	**CFS10**	1	

Volvo	Part No	Qty	Notes
740			
1/88-12/91 4 Cyl 2.3L B230F SOHC 8V EFi RWD			
Ignition – Distributor Cap	**BH172**	1	Bosch Electronic Distributor: From 1986
Ignition – Distributor Rotor	**BH224**	1	Bosch Electronic Distributor: From 1986
Ignition – Module	**CM409**	1	
Ignition – Pickup / Trigger	**CIT120**	1	Hall Sensor
Sensor – Crankshaft	**CSCA171**	1	
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Knock Control	**CKS108**	1	
Sensor – Temperature Gauge	**CTS117**	1	
Sensor – Throttle Position	**CTPS145**	1	
Switch – Radiator Fan	**CFS10**	1	
740			
5/89-12/90 4 Cyl 2.3L B234 DOHC 16V EFi RWD			
Sensor – Temperature Gauge	**CTS117**	1	
Switch – Radiator Fan	**CFS10**	1	
760			
2/83-12/90 V6 Cyl 2.8L B28F SOHC 8V EFi RWD			
Ignition – Distributor Cap	**BH146**	1	Bosch Electronic Distributor: To 1986
Ignition – Distributor Cap	**BD580**	1	Bosch Electronic Distributor: From 1986
Ignition – Distributor Rotor	**BH153**	1	Bosch Electronic Distributor: To 1986
Ignition – Distributor Rotor	**BH225**	1	Bosch Electronic Distributor: From 1986
Ignition – Module	**CM409**	1	
Sensor – Temperature Gauge	**CTS117**	1	
760 Turbo			
1/84-3/86 4 Cyl 2.3L B230T SOHC 8V EFi RWD			
Ignition – Distributor Cap	**BH172**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**BH224**	1	Bosch Electronic Distributor
Ignition – Module	**CM409**	1	
Sensor – Exhaust Oxygen	**COS786**	1	Direct Fit 3 Wire
Sensor – Exhaust Oxygen – Universal	**COS721**	1	Universal 3 Wire
Sensor – Temperature Gauge	**CTS117**	1	
Switch – Oil Pressure Warning Light	**CPS35**	1	
960			
11/90-10/91 V6 Cyl 2.8L B280F SOHC 12V EFi RWD			
Ignition – Module	**CM409**	1	
Sensor – Crankshaft	**CSCA189**	1	
Sensor – Knock Control	**CKS107**	2	
Sensor – Throttle Position	**CTPS145**	1	
960			
11/91-1/97 6 Cyl 2.9L B6304F DOHC 24V EFi RWD			
Sensor – Crankshaft	**CSCA191**	1	
Sensor – Knock Control	**CKS108**	1	
Sensor – Throttle Position	**CTPS100**	1	
S40			
2/97-7/00 4 Cyl 2.0L B4204S DOHC 16V EFi FWD			
Sensor – Air Temperature – Inlet	**CAT026**	1	
Sensor – Crankshaft	**CSCA203**	1	
S40: V40 Turbo			
9/97-7/00 4 Cyl 1.9L B4194T: 2.0L B4204T DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC372**	1	Cylinder 1 & 4
Ignition – Coil – Standard	**CC373**	1	Cylinder 2 & 3

Volvo	Part No	Qty	Notes
S40: V40			
7/99-3/01 4 Cyl 1.8L B4184S DOHC 16V EPFI FWD			
Sensor – Air Temperature – Inlet	**CAT026**	1	
V40			
2/97-9/00 4 Cyl 2.0L B4240S DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC372**	1	Cylinder 1 & 4
Ignition – Coil – Standard	**CC373**	1	Cylinder 2 & 3
V40 Turbo			
9/97-7/99 4 Cyl 1.9L B4194T DOHC 16V MPFi FWD			
Ignition – Coil – Standard	**CC372**	1	Cylinder 1 & 4
Ignition – Coil – Standard	**CC373**	1	Cylinder 2 & 3
V40			
7/99-3/01 4 Cyl 1.8L B4184S2 DOHC 16V EPFI FWD			
Sensor – Air Temperature – Inlet	**CAT026**	1	
V70 Turbo			
11/97-8/00 5 Cyl 2.4L DOHC 20V MPFi AWD			
Sensor – Air Flow / MAF	**CAF015**	1	
Yugo			
45A *(NZ Market)*			
1986-89 4 Cyl 903cc 146A			
Ignition – Distributor Cap	**BH100**	1	Bosch Electronic Distributor
Ignition – Distributor Rotor	**DR541**	1	Bosch Electronic Distributor

FUELMISER

IDENTIFICATION GUIDE

CONTENTS

IGNITION

Coils 330-339
Coil Resistors 339
Condensers 340-343
Distributor Caps 343-357
Modules 358-360
Pickup and Triggers 360-361
Points and Contact Sets 362-364
Rotors 365-374

SENSORS, SWITCHES AND RELAYS

Air Flow and Air Mass Sensors 374-376
Air Temperature Sensors 377-378
Camshaft and Crankshaft Sensors 378-390
Coolant Temperature Sensors / Switches 391-396
Exhaust Oxygen Sensors 397-408
Idle Speed Control Valves 408-409
Knock Control Sensors 409-410
MAP Sensors 411-412
Throttle Position Sensor / Switches 412-414
Brake and Clutch Pedal Switches 415-417
Headlight and Dimmer Switches 426
Ignition Switches 427
Neutral Start Switches 427
Oil Pressure Sensors / Switches 418-420
Power Steering Switches 427
Radiator Fan Switches 421-426
Reverse Light Switches 428
Starter Relays / Switches 428

IGNITION COILS

FUELMISER

CIC31

Use Without Resistor

CIC32R

Use With Resistor

C80

Heavy Duty – Use Without Resistor

C80R

Heavy Duty – Use With Resistor

CC200

Suits: Ford, Holden, Mitsubishi

CC201

Suits: Holden, Suzuki
Use With Resistor

CC202

Suits: Ford, Hyundai, Mazda, Toyota
Use With Resistor

CC204



Suits: Chev

CC205

Suits: Ford

CC206



Suits: Holden, Toyota
Waste Spark

CC207

Suits: Chev, Holden, Nissan

CC208

Suits: Holden, Toyota
Waste Spark

CC209

Suits: Ford, Mazda

CC210

Suits: Ford
Waste Spark

CC211

Suits: Mitsubishi, Toyota

IGNITION COILS

FUELMISER

CC212

Suits: Fiat, Mercedes, SAAB, Volvo

CC213

Suits: BMW, Mercedes, Volvo

CC215

Suits: Ford, Holden, Mitsubishi, Toyota

CC216

Suits: Holden, Toyota

CC217

Suits: Daihatsu, Holden, Toyota

CC218

Suits: Mitsubishi

CC219

Suits: Ford, Mazda, Suzuki

CC220



Suits: Hyundai, Mitsubishi

CC221

Suits: Daewoo, Holden, Nissan

CC222

Suits: Ford

CC223

Suits: Ford, Nissan

CC224

Suits: Honda

CC225

Suits: Honda

CC226

Suits: Ford, Mazda

CC227

Suits: Toyota

IGNITION COILS

FUELMISER

CC228

Suits: Honda

CC229

Suits: Nissan

CC230

Suits: Honda

CC231

Suits: Lexus, Toyota

CC232

Suits: Hyundai, Mitsubishi

CC233

Suits: Hyundai, Mitsubishi
Waste Spark

CC234

Suits: Subaru
Waste Spark

CC235

Suits: Nissan
Includes Igniter

CC236

Suits: Ford

CC237



Suits: Ford
Waste Spark

CC238

Suits: Ford
Waste Spark

CC239

Suits: Ford
Waste Spark

CC240

Suits: Ford, Mazda
Waste Spark

CC241

Suits: Ford

CC242

Suits: Ford, Mitsubishi

IGNITION COILS

FUELMISER

CC243

Suits: Nissan

CC244

Suits: Mitsubishi

CC245

Suits: Ford

CC246

Suits: Mitsubishi

CC248

Suits: Eunos, Ford

CC249

Suits: Ford, Nissan

CC250

Suits: Ford, Mazda

CC252

Suits: Eunos, Ford, Mazda

CC253

Suits: Ford, Mazda

CC254

Heavy Duty Epoxy Filled –
Can use in place of C80R

CC255

Suits: Daihatsu

CC258

Suits: Toyota

CC259

Suits: Ford, Mazda, Mitsubishi

CC262

Suits: Holden, SAAB

CC263

Suits: Holden, Toyota

IGNITION COILS

FUELMISER

CC264

Suits: Suzuki

CC265

Suits: Toyota

CC266

Suits: Honda

CC267



Suits: Honda

CC269

Suits: Subaru
Waste Spark

CC270

Suits: Holden
Waste Spark

CC271

Suits: Holden

CC272

Suits: Honda

CC273

Suits: Ford

CC274

Suits: Honda

CC275

Suits: Toyota

CC276

Suits: Audi, Holden, Toyota, VW

CC277

Suits: Honda

CC279

Suits: Holden

CC280

Suits: Toyota

IGNITION COILS

FUELMISER

CC281



Suits: Daihatsu, Mitsubishi

CC282

Suits: Daihatsu

CC283

Suits: Holden, Suzuki

CC284

Suits:
Holden, Suzuki

CC285

Suits: Holden

CC287



Suits: Toyota

CC288

Suits: Toyota

CC289

Suits: Toyota
Waste Spark

CC290

Suits: Lexus
Waste Spark

CC291



Suits: Toyota
Waste Spark – Includes Igniter

CC292



Suits: Toyota
Waste Spark – Includes Igniter

CC293

Suits: Lexus, Toyota
Includes Igniter

CC294

Suits: Toyota
Includes Igniter

CC295

Suits: Toyota
Includes Igniter

CC296



Suits: Toyota
Includes Igniter

IGNITION COILS

FUELMISER

CC297

Suits: Subaru

CC298

Suits: Subaru

CC300



Suits: Subaru
Includes Igniter

CC301

Suits: Subaru
Includes Igniter

CC302

Suits: Nissan
Includes Igniter

CC303

Suits: Nissan
Includes Igniter

CC305

Suits: Nissan

CC307

Suits: Honda

CC308

Suits: Suzuki
Waste Spark – Includes Igniter

CC309

Suits: Holden, Suzuki

CC310

Suits: Toyota
Includes Igniter

CC311



Suits: Ford, Mazda
Waste Spark – Includes Igniter

CC312



Suits: Mitsubishi
Waste Spark

CC313

Suits: Mitsubishi
Waste Spark

CC314

Suits: Mitsubishi
Waste Spark

IGNITION COILS

FUELMISER

CC315

Suits: Mitsubishi
Waste Spark – Includes Igniter

CC316



Suits: Ford, Mazda
Waste Spark – Includes Igniter

CC318

Suits: Daewoo

CC319

Suits: Holden

CC320

Suits: Hyundai
Waste Spark

CC321

Suits: Hyundai
Waste Spark

CC322

Suits: Nissan
Includes Igniter

CC327

Suits: Hyundai

CC328

Suits: Hyundai
Waste Spark

CC329

Suits: Toyota
Waste Spark

CC332

Suits: Mitsubishi
Waste Spark

CC333

Suits: Hyundai
Waste Spark

CC334

Suits: Kia
Waste Spark

CC335

Suits: Kia

CC336

Suits: Hyundai
Waste Spark – Includes Igniter

IGNITION COILS

FUELMISER

CC339

Suits: Hyundai
Waste Spark

CC340



Suits: Hyundai
Waste Spark

CC341



Suits: Hyundai
Waste Spark

CC342



Suits: Hyundai
Waste Spark

CC343

Suits: Hyundai
Includes Igniter

CC346



Suits: Hyundai
Waste Spark

CC348

Suits: Daewoo, Holden
Waste Spark – Includes Igniter

CC349

Suits: Nissan
Includes Igniter

CC350

Suits: Ford, Mazda

CC351

Suits: Ford
Waste Spark

CC352

Suits: Mitsubishi

CC353



Suits: Ford

CC354

Suits: Holden
Includes Igniter

CC355

Suits: Holden
Includes Igniter: Supplied with spark plug boots

CC356

Suits: Holden
Includes Igniter

IGNITION COILS & RESISTORS

FUELMISER

CC357

Suits: Holden
Includes Igniter

CC358

Suits: Holden
Includes Igniter

CC360

Suits: Holden, Peugeot
Waste Spark

CC367

Suits: Hyundai

CCB1

Round Coil Mounting Bracket

CCMK

Suits: Holden, Toyota
Coil and Module Kit

CCMLK

Suits: Holden, Toyota
Coil, Module and Lead Kit

CBR40



1.35 ohms Resistance

CBR41

1.82 ohms Resistance

CBR42

1.2 ohms Resistance

CBR43



Suits: Chrysler, Mitsubishi
1.2 ohms Primary: 5.0 ohms Secondary

CBR44



1.4 ohms Resistance

CBR45

1.8 ohms Resistance

CBR46



1.6 ohms Resistance

CONDENSERS

FUELMISER

AC61

Suits: Ford

BC3



Suits: Mallory

BC22

Suits: Lucas

BC58

Suits: VW

BC63



Suits: BMW, Holden, Mercedes, VW

BC70

Suits: Chrysler, Holden

BC71

Suits: Chrysler, Ford, Renault

BC74



Suits: BMW, Volvo

BC86

Suits: Alfa, BMW

BC89

Suits: VW

BC98

Suits: VW

BC100

Suits: Mitsubishi, Toyota

BC101

Suits: Ford

BC115



Suits: VW

BC119

Suits: VW

CONDENSERS

FUELMISER

BC147



Suits: Mercedes

BC231

Suits: Chev

BC301

Suits: Nissan

BC393



Suits: Subaru

BC446



Suits: BMW, Volvo

BC556

Suits: Toyota

BC660



Suits: Ford

BC842

Suits: Mercedes

BC868



Suits: Chrysler

DC10

Suits: Holden, Jeep, Lancia

DC100

Suits: Peugeot, Renault

FC79

Suits: Ford

LC103

Suits: Ford, Holden, Nissan, Toyota

LC104

Suits: Jaguar, Leyland, Triumph

MC40

Suits: Lada

CONDENSERS

FUELMISER

MC41



Suits: Fiat, Niki

MC405

Suits: Mazda

MC409

Suits: Chrysler, Mazda, Mitsubishi

MC410

Suits: Mazda

MC411

Suits: Mazda

MC412

Suits: Mazda

MC413



Suits: Ford, Mazda, Nissan

MC414

Suits: Mitsubishi

MC417

Suits: Ford, Mazda

MC418

Suits: Holden, Mazda, Mitsubishi, Toyota

MC423

Suits: Mitsubishi, Nissan

NC203

Suits: Isuzu, Nissan

NC207

Suits: Nissan

NC213

Suits: Honda, Nissan

PNT380

Radio Noise Suppressor

CONDENSERS

FUELMISER

TC204



Suits: Toyota

TC205



Suits: Mazda, Suzuki, Toyota

TC206



Suits: Daihatsu, Nissan, Toyota

TC209



Suits: Holden, Mitsubishi, Toyota

TC210



Suits: Toyota

UC11E



Suits: Bedford, Holden

DISTRIBUTOR CAPS

AL103

Suits: Chrysler

AL105

Suits: Chrysler

AL105A

Suits: Mallory

BC146

Suits: Ford
Cap Base

BC195

Suits: Chev
Cap Cover

BD2

Suits: Mallory

DISTRIBUTOR CAPS

FUELMISER

BD6

Suits: Mallory

BD30

Suits: Jeep

BD63

Suits: Chrysler, Prestolite

BD65

Suits: Mallory

BD70

Suits: Prestolite

BD100

Suits: Mitsubishi

BD102



Suits: Daihatsu

BD107

Suits: Holden, Mazda, Suzuki

BD109

Suits: Holden, Isuzu

BD112

Suits: Holden, Toyota

BD123

Suits: Holden

BD124

Suits: Holden

BD126

Suits: Citroen, Hyundai

BD129

Suits: Ford

BD130

Suits: Prestolite

DISTRIBUTOR CAPS

FUELMISER

BD131

Suits: Holden, Toyota

BD132

Suits: Ford, Mazda

BD134

Suits: Eunos, Ford, Mazda

BD136

Suits: Nissan

BD138

Suits: Holden, Toyota

BD162

Suits: Prestolite

BD171



Suits: Chev

BD201

Suits: Lada

BD249

Suits: Chev

BD268

Suits: Ford, Hillman, MG, Morris

BD270

Suits: Ford, Landrover, Rover

BD276

Suits: Ford, Leyland

BD278

Suits: Ford, Nissan, Toyota

BD280

Suits: Chrysler, Dodge, Leyland

BD286

Suits: Jaguar, Landrover, Triumph

DISTRIBUTOR CAPS

FUELMISER

BD288



Suits: Leyland, MG, Triumph

BD290

Suits: Daimler, Jaguar, Triumph

BD294

Suits: Daimler, Jaguar

BD377

Suits: Toyota

BD560



Suits: Honda, Rover

BD580



Suits: Alfa, BMW, Volvo

BD708

Suits: Honda

BD740

Suits: Jaguar

BD741



Suits: Nissan

BD810

Suits: Ford, Nissan

BD841

Suits: Nissan

BD887

Suits: Nissan

BD894

Suits: Nissan, Suzuki

BD896

Suits: Landrover, MG

BD898

Suits: Nissan

DISTRIBUTOR CAPS

FUELMISER

BD1290

Suits: Mallory

BD1580

Suits: Mallory

BD2000

Suits: Mallory

BH72

Suits: Alfa, BMW, Volvo

BH74

Suits: BMW, Holden, Mercedes, Volvo

BH78

Suits: Peugeot, VW

BH80

Suits: Ford, Holden

BH82

Suits: Chrysler, Ford, Holden

BH84

Suits: Chrysler, Ford, Holden

BH86

Suits: Holden

BH90

Suits: Holden, Mitsubishi, Toyota

BH96

Suits: Chrysler, Renault, Toyota

BH100

Suits: Audi, Ford, Mercedes, VW

BH112

Suits: Holden

BH116

Suits: Holden

DISTRIBUTOR CAPS

FUELMISER

BH118

Suits: Ford

BH122

Suits: Ford, Mitsubishi, Nissan

BH126

Suits: Mercedes, Porsche

BH128

Suits: Mercedes

BH130

Suits: Mercedes, Porsche

BH136

Suits: Audi, BMW, Lancia, VW

BH138

Suits: BMW

BH140

Suits: Alfa, BMW, Mercedes, Volvo

BH144

Suits: Ford, Nissan

BH146

Suits: Peugeot, Volvo

BH150

Suits: Chrysler, Mercedes

BH166

Suits: Mercedes

BH172

Suits: Volvo

BH176

Suits: Ford, Nissan

BH178

Suits: Holden, Toyota

DISTRIBUTOR CAPS

FUELMISER

BH232

Suits: BMW

DR86

Suits: Holden, Triumph

DR101

Suits: Holden, Triumph, Vauxhall

DR102



Suits: Holden, Jeep, Rambler

DR114



Suits: Daewoo, Holden, Nissan

DR895

Suits: Holden, Toyota

FO91

Suits: Ford

FO92

Suits: Ford

FO98

Suits: Ford

FO100

Suits: Ford

FT558

Suits: Fiat

JP400

Suits: Toyota

JP401

Suits: Honda

JP402

Suits: Honda

JP403

Suits: Mazda

DISTRIBUTOR CAPS

FUELMISER

JP404

Suits: Ford, Mazda

JP405

Suits: Nissan

JP406

Suits: Suzuki

JP407

Suits: Daewoo

JP408

Suits: Eunos

JP409

Suits: Nissan

JP410

Suits: Daewoo

JP514

Suits: Toyota

JP516

Suits: Daihatsu, Toyota

JP520

Suits: Holden, Honda, Mazda, Nissan

JP524

Suits: Mazda

JP526

Suits: Nissan

JP534

Suits: Holden, Isuzu, Toyota

JP540

Suits: Mazda

JP542

Suits: Ford, Hyundai, Mazda, Mitsubishi

DISTRIBUTOR CAPS

FUELMISER

JP544

Suits: Honda, Nissan

JP546

Suits: Holden, Mitsubishi, Toyota

JP550

Suits: Suzuki

JP554

Suits: Toyota

JP556

Suits: Daihatsu

JP558

Suits: Mitsubishi

JP562

Suits: Honda, Rover

JP564

Suits: Ford, Hyundai, Mazda, Nissan

JP568

Suits: Ford, Mazda, Mitsubishi

JP570

Suits: Mazda

JP572

Suits: Daihatsu

JP574

Suits: Holden, Toyota

JP580

Suits: Toyota

JP582

Suits: Toyota

JP584

Suits: Daihatsu, Toyota

DISTRIBUTOR CAPS

FUELMISER

JP586

Suits: Toyota

JP588

Suits: Toyota

JP594

Suits: Holden, Nissan, Subaru

JP600

Suits: Honda

JP612

Suits: Suzuki

JP626

Suits: Toyota

JP630

Suits: Honda, Nissan, Subaru

JP642

Suits: Daihatsu, Holden, Toyota

JP648

Suits: Mitsubishi, Subaru

JP652

Suits: Mitsubishi

JP654

Suits: Holden, Suzuki

JP656

Suits: Toyota

JP660

Suits: Honda, Rover

JP662

Suits: Honda

JP666

Suits: Nissan

DISTRIBUTOR CAPS

FUELMISER

JP672

Suits: Nissan

JP678

Suits: Mazda

JP680

Suits: Ford, Mazda

JP682

Suits: Ford

JP684

Suits: Ford, Mazda

JP686

Suits: Daihatsu

JP692

Suits: Daihatsu

JP694

Suits: Holden, Nissan

JP696

Suits: Nissan

JP698

Suits: Ford, Kia, Mazda

JP700

Suits: Toyota

JP702

Suits: Toyota

JP706

Suits: Ford, Mazda

JP708

Suits: Toyota

JP710

Suits: Ford, Mazda

DISTRIBUTOR CAPS

FUELMISER

JP714

Suits: Chrysler, Mitsubishi

JP716

Suits: Nissan

JP718

Suits: Ford, Holden, Mazda, Suzuki

JP720

Suits: Ford, Nissan

JP722



Suits: Toyota

JP726

Suits: Eunos, Ford, Mazda

JP728



Suits: Hyundai

JP730



Suits: Toyota

JP732



Suits: Daihatsu

JP734

Suits: Holden

JP736

Suits: Ford, Mazda

JP738

Suits: Nissan

JP740

Suits: Toyota

JP742

Suits: Toyota

JP800

Suits: Holden, Isuzu, Toyota

DISTRIBUTOR CAPS

FUELMISER

JP801

Suits: Holden, Toyota
Cap and Leads

JP802

Suits: Toyota

JP803

Suits: Toyota
Cap and Leads

JP804

Suits: Toyota

JP805

Suits: Holden, Toyota Cap and Leads

JP806

Suits: Toyota

JP807

Suits: Toyota

JP808

Suits: Daihatsu

JP809

Suits: Daihatsu

JP810

Suits: Toyota

JP813

Suits: Mazda

JP814

Suits: Mitsubishi

JP815

Suits: Mitsubishi, Proton

JP816

Suits: Mitsubishi

JP817

Suits: Mitsubishi, Proton

DISTRIBUTOR CAPS

FUELMISER

JP819

Suits: Mitsubishi

JP820

Suits: Holden

JP821

Suits: Holden

JP822

Suits: Holden, Toyota

JP823

Suits: Toyota

JP824

Suits: Toyota

JP825

Suits: Nissan

JP826

Suits: Nissan

JP827

Suits: Suzuki

JP828

Suits: Suzuki

JP829

Suits: Mazda

JP830

Suits: Mitsubishi

JP831

Suits: Mitsubishi

JP832

Suits: Landrover

JP834

Suits: Daihatsu

DISTRIBUTOR CAPS

FUELMISER

JP836

Suits: Nissan

JP837

Suits: Mitsubishi

JP838

Suits: Nissan

JP968

Suits: Honda

JP969

Suits: Honda

JP971

Suits: Honda

JP976

Suits: Honda

JP980

Suits: Honda

JP986

Suits: Honda

JP987

Suits: Audi, Seat, VW

JP988

Suits: Ford

RB102

Suits: Chrysler, Peugeot, Renault

IGNITION MODULES

FUELMISER

CM400



Suits: Honda, Rover

CM401

Suits: Honda

CM402

Suits: Toyota

CM404

Suits: Ford, Hyundai, Mazda, Mitsubishi
Includes Pickup / Trigger

CM405

Suits: Ford, Holden, Mazda, Nissan

CM406

Suits: Mitsubishi

CM407

Suits: Holden, Toyota

CM408



Suits: Ford, Mazda, Mitsubishi

CM409

Suits: Audi, Holden, VW, Volvo

CM410

Suits: Chev, Jaguar, Peugeot, Rover

CM411

Suits: Ford, Holden, Mazda, Suzuki

CM413



Suits: Alfa, BMW, Citroen, Peugeot

CM414

Suits: Holden, Toyota

CM415

Suits: Daewoo, Holden, Nissan

CM416

Suits: Nissan

IGNITION MODULES

FUELMISER

CM417

Suits: Holden, Honda, Nissan
Includes Pickup / Trigger

CM418

Suits: Ford, Holden, Mitsubishi, Toyota

CM419



Suits: Nissan

CM420



Suits: Ford, Nissan

CM421

Suits: Ford, Mazda

CM422

Suits: Ford, Hyundai, Mitsubishi, Nissan

CM423

Suits: Chrysler

CM424

Suits: Ford

CM425



Suits: Ford, Mazda

CM426



Suits: Ford

CM427

Suits: Holden

CM428

Suits: Ford, Mitsubishi, Nissan

CM429

Suits: Honda

CM474

Suits: Holden, Nissan

CM475

Suits: Mitsubishi

IGNITION MODULES

FUELMISER

CM476

Suits: Landrover, Rover

CM477

Suits: Holden

PICKUPS / TRIGGERS

CIT101

Suits: Mazda

CIT102

Suits: Toyota

CIT103



Suits: Holden, Toyota

CIT104



Suits: Toyota

CIT106

Suits: Ford, Mazda

CIT107

Suits: Ford, Mazda

CIT109

Suits: Mitsubishi

CIT110

Suits: Ford, Mazda

CIT111

Suits: Ford, Mazda

PICKUPS / TRIGGERS

FUELMISER

CIT112

Suits: Mitsubishi

CIT113



Suits: Ford, Mazda, Mitsubishi

CIT114

Suits: Ford

CIT116

Suits: Ford, Holden

CIT120



Suits: Volvo

CIT140

Suits: Toyota

CIT141

Suits: Audi

IGNTION POINTS / CONTACT SETS

FUELMISER

L10

Suits: Hillman, Landrover

L19V

Suits: Ford, Holden, Nissan, Toyota

L24V

Suits: Daimler, Leyland, Triumph

S1 / S1V

Suits: Ford, Mitsubishi, VW

S2V

Suits: VW

S3

Suits: Mercedes

S4V

Suits: BMW, Holden, Mercedes

S11 / S11V

Suits: Ford, Holden, Toyota, VW

S12

Suits: BMW, VW

S15V

Suits: BMW, Ford, Mercedes, Nissan

S44

Suits: Chevrolet 1953-62

S50



Suits: Bedford, Holden, Triumph

S53V



Suits: Bedford, Buick, Chev, Jeep

S63

Suits: Holden

S80V



Suits: Ford

IGNTION POINTS / CONTACT SETS

FUELMISER

S82V

Suits: Ford

S83V



Suits: Ford

S84V

Suits: International

S85V

Suits: Dodge, IHC

S95V



Suits: Chrysler

S97V

Suits: Rambler

S133

Suits: Peugeot, Renault

S143V



Suits: Holden, Jeep, Rambler

S152V

Suits: Fiat, Lada

S156

Suits: Alfa, Lancia

S202V



Suits: Daihatsu, Toyota

S204V



Suits: Holden, Mitsubishi, Toyota

S207A

Suits: Rover, Triumph

S208

Suits: Mazda

S214V



Suits: Daihatsu, Holden, Toyota

IGNTION POINTS / CONTACT SETS

FUELMISER

S217

Suits: Mazda, Nissan

S219VU

Suits: Ford, Holden, Mazda, Nissan

S225

Suits: Niki

S226

Suits: Citroen

S260

Suits: Peugeot

S261

Suits: Landrover, Rover

S321

Suits: Volkswagen

S360A

Suits: Mazda

S367A

Suits: Mazda

S778A

Suits: Holden

S791

Suits: Chevrolet

S7550

Suits: Accel

S7860



Suits: Accel

S9000

Suits: Mallory

S9100

Suits: Mallory

IGNITION ROTORS

FUELMISER

AL104

Suits: Chrysler

BD139

Suits: Holden, Toyota

BD229

Suits: Ford, Leyland

BD250

Suits: Jaguar, Landrover, Triumph

BD256

Suits: Ford, Holden, Nissan, Toyota

BD257

Suits: Chrysler, Dodge, Leyland

BD287



Suits: Jaguar, Leyland, Triumph

BD299

Suits: Landrover, Rover

BD897

Suits: Landrover, MG

BD899

Suits: Nissan

BH73

Suits: BMW, Holden, Toyota

BH75

Suits: VW

BH77

Suits: Peugeot, VW

BH79

Suits: Chrysler, Holden

BH87

Suits: Chrysler, Ford, Holden

IGNITION ROTORS

FUELMISER

BH89

Suits: BMW, Ford, Holden, Volvo

BH95

Suits: Audi, Mercedes, SAAB, VW

BH101

Suits: Ford

BH103

Suits: Holden

BH105

Suits: Holden

BH107

Suits: Citroen, Holden, Peugeot

BH121

Suits: Ford, Holden, Mitsubishi, Toyota

BH129

Suits: BMW, Mercedes
RPM Governed to 6550rpm

BH139

Suits: Ford, Nissan

BH153

Suits: Mercedes, Peugeot, Volvo

BH177

Suits: Alfa, BMW, Mercedes, Volvo

BH213

Suits: VW
RPM Governed to 5400rpm

BH222

Suits: Holden

BH224

Suits: Volvo

BH225

Suits: Alfa, BMW, Citroen, Volvo

IGNITION ROTORS

FUELMISER

BH227

Suits: Mitsubishi

BH229

Suits: Ford, Nissan

BH231

Suits: Ford, Holden

DR7

Suits: Mallory

DR31

Suits: Jeep

DR64

Suits: Chevrolet

DR65

Suits: Holden, Jeep, Rambler

DR66

Suits: Mallory

DR71

Suits: Landrover, MG, Rover

DR73

Suits: Daewoo, Holden, Nissan

DR105

Suits: Mallory

DR127

Suits: Audi, Holden, Hyundai, VW

DR128

Suits: Daihatsu, Holden, Suzuki

DR133



Suits: Ford, Mazda
Triangle Distributor Shaft approx 12mm

DR135

Suits: Ford, Mazda, Mitsubishi

IGNITION ROTORS

FUELMISER

DR137

Suits: Nissan

DR157

Suits: Jeep

DR158

Suits: Ford

DR163

Suits: IHC

DR173

Suits: Chev

DR204

Suits: Lada

DR460

Suits: BMW, Lancia, Porsche
RPM Governed to 6600rpm

DR463

Suits: Ford, Holden, Mitsubishi, Toyota

DR541

Suits: Audi, Mercedes, VW, Volvo

DR561

Suits: Honda, Rover

DR686

Suits: Toyota

DR761

Suits: Nissan

DR773

Suits: Nissan

DR782

Suits: Honda

DR792

Suits: Ford, Kia, Mazda
Triangle Distributor Shaft 12mm

IGNITION ROTORS

FUELMISER

DR839

Suits: Toyota

DR841A

Suits: Nissan

DR843

Suits: Daihatsu

DR886

Suits: Mitsubishi
Triangle Distributor Shaft 12mm

DR1250

Suits: Accel

DR1570

Suits: Accel

DR1670

Suits: Holden, Jeep, Rambler
High Performance Version of DR65

DR6500

Suits: Mallory

FO74

Suits: Ford

FO75

Suits: Ford

FO77

Suits: Ford

FO95

Suits: Ford

FR519

Suits: Alfa

JR249

Suits: Nissan
RPM Governed

JR251



Suits: Nissan
RPM Governed

IGNITION ROTORS

FUELMISER

JR401

Suits: Honda

JR402

Suits: Honda

JR404

Suits: Nissan

JR405

Suits: Eunos

JR507

Suits: Toyota

JR513

Suits: Daihatsu, Honda, Toyota

JR517

Suits: Holden, Honda, Mazda, Nissan

JR521

Suits: Mazda

JR527

Suits: Holden, Mitsubishi, Toyota

JR533

Suits: Ford, Hyundai, Mazda, Mitsubishi

JR535

Suits: Holden, Honda, Nissan

JR537

Suits: Suzuki

JR543

Suits: Toyota

JR555

Suits: Ford, Mazda, Mitsubishi

JR557

Suits: Mazda

IGNITION ROTORS

FUELMISER

JR573

Suits: Daihatsu, Toyota

JR575

Suits: Mazda, Toyota

JR577

Suits: Holden, Toyota

JR597

Suits: Toyota

JR607

Suits: Nissan

JR611

Suits: Hyundai, Mitsubishi

JR613

Suits: Holden, Toyota

JR615

Suits: Nissan

JR617

Suits: Ford, Holden, Mazda, Suzuki
Round Distributor Shaft approx 14mm

JR619

Suits: Ford, Mazda

JR621

Suits: Holden, Nissan

JR623

Suits: Nissan

JR625

Suits: Ford, Mazda
Round Distributor Shaft approx 14.3mm

JR627



Suits: Ford, Mazda
Round Distributor Shaft approx 12.3mm

JR639

Suits: Hyundai, Mitsubishi

IGNITION ROTORS

FUELMISER

JR641



Suits: Ford, Holden, Mazda, Suzuki
Triangle Distributor Shaft approx 12mm

JR643



Suits: Ford, Nissan

JR645

Suits: Holden, Suzuki

JR647

Suits: Ford, Mazda

JR649

Suits: Toyota

JR651

Suits: Holden

JR653



Suits: Ford, Mazda

JR655

Suits: Nissan

JR657



Suits: Toyota

JR659

Suits: Nissan

JR800

Suits: Toyota

JR801

Suits: Daihatsu

JR802

Suits: Suzuki

JR803

Suits: Mazda

JR804

Suits: Mazda

IGNITION ROTORS

FUELMISER

JR806

Suits: Mitsubishi, Suzuki
Triangle Distributor Shaft approx 13mm

JR807

Suits: Holden

JR808

Suits: Nissan

JR814

Suits: Mitsubishi, Proton

JR815

Suits: Mitsubishi, Nissan, Proton

JR817

Suits: Holden

JR818

Suits: Daihatsu

JR819

Suits: Daihatsu

JR820

Suits: Ford, Mazda, Nissan

JR981

Suits: Honda

JR982

Suits: Honda

JR992

Suits: Honda

JR995

Suits: Honda

JR997

Suits: Honda

RB99

Suits: Chrysler, Citroen, Renault

IGNITION ROTORS

FUELMISER

RB105

Suits: Peugeot, Renault

RE85

Suits: Holden, Triumph, Vauxhall

AIR FLOW & AIR MASS SENSORS

CAF001

Suits: Alfa

CAF002

Suits: Alfa

CAF003

Suits: Mercedes

CAF004

Suits: Holden

CAF005

Suits: Holden

CAF006

Suits: Audi

CAF007

Suits: VW

CAF008

Suits: Mercedes

CAF009

Suits: BMW

AIR FLOW & AIR MASS SENSORS

FUELMISER

CAF010

Suits: Mercedes

CAF011

Suits: Mercedes

CAF012

Suits: Audi, VW

CAF013

Suits: VW

CAF014

Suits: Holden, SAAB

CAF015

Suits: Volvo

CAF016

Suits: BMW, Hyundai, Kia

CAF017

Suits: Hyundai

CAF018

Suits: BMW

CAF019

Suits: Audi, VW

CAF020

Suits: Audi, VW

CAF021

Suits: Hyundai

CAF022

Suits: Holden

CAF023

Suits: Hyundai, Kia

CAF024

Suits: Holden

AIR FLOW & AIR MASS SENSORS

FUELMISER

CAF025

Suits: Hyundai, Kia

CAF026

Suits: Hyundai

CAF027

Suits: Audi

CAF028

Suits: BMW

CAF029

Suits: Ford

CAF030

Suits: Holden

CAF031

Suits: Ford

CAF032

Suits: Nissan

CAF033

Suits: Mazda

CAF034

Suits: Lexus, Toyota

AIR TEMPERATURE SENSORS

FUELMISER

CAT002

Suits: Holden, Toyota

CAT003

Suits: Ford

CAT004

Suits: Hyundai

CAT005

Suits: Ford, Hyundai, Kia

CAT006

Suits: Holden

CAT009

Suits: Daewoo, Holden, Toyota

CAT013

Suits: Eunos, Ford, Mazda

CAT019

Suits: Holden

CAT020

Suits: Holden

CAT021

Suits: Holden, SAAB

CAT023

Suits: Daewoo, Holden

CAT024

Suits: Audi

CAT025

Suits: Ford

CAT026

Suits: Volvo

CAT027

Suits: Ford

AIR TEMPERATURE SENSORS

FUELMISER

CAT028

Suits: Ford

CAMSHAFT & CRANKSHAFT SENSORS

CSCA01

Suits: Holden, Mitsubishi, Nissan
Crankshaft – Includes Plug, Boot and Terminals

CSCA01B

Suits: Holden, Mitsubishi, Nissan
Crankshaft – Includes Bearing, Plug, Boot and Terminals

CSCA02

Suits: Holden
Crankshaft

CSCA03

Suits: Holden
Crankshaft

CSCA04

Suits: Holden
Crankshaft

CSCA05

Suits: Nissan, Ford
Camshaft / Crankshaft

CSCA06

Suits: Hyundai
Crankshaft

CSCA07

Suits: Nissan
Crankshaft

CSCA08

Suits: Ford
Crankshaft

CAMSHAFT & CRANKSHAFT SENSORS

FUELMISER

CSCA09

Suits: Ford, Mazda
Crankshaft

CSCA10

Suits: Ford
Is also Ignition Trigger

CSCA11

Suits: Mitsubishi
Crankshaft

CSCA12

Suits: Kia
Crankshaft

CSCA13

Suits: Holden, SAAB
Crankshaft

CSCA14

Suits: Hyundai, Kia
Crankshaft

CSCA15

Suits: Holden
Crankshaft

CSCA16

Suits: Holden
Crankshaft

CSCA17

Suits: Holden
Crankshaft

CSCA18

Suits: Hyundai
Crankshaft

CSCA19

Suits: Holden
Crankshaft

CSCA20

Suits: Hyundai
Crankshaft

CSCA21

Suits: Holden
Crankshaft

CSCA23

Suits: Holden
Crankshaft

CSCA24

Suits: Holden
Crankshaft

CAMSHAFT & CRANKSHAFT SENSORS

FUELMISER

CSCA25

Suits: Daewoo, Holden
Crankshaft

CSCA27

Suits: Jeep
Crankshaft

CSCA28

Suits: Nissan
Crankshaft

CSCA29

Suits: Toyota
Crankshaft

CSCA30

Suits: Nissan
Crankshaft

CSCA31

Suits: Hyundai
Crankshaft

CSCA32

Suits: Hyundai
Crankshaft

CSCA33

Suits: Hyundai
Crankshaft

CSCA34

Suits: Hyundai
Crankshaft

CSCA35

Suits: Hyundai
Crankshaft

CSCA36

Suits: Hyundai
Crankshaft

CSCA37

Suits: Mitsubishi
Crankshaft

CSCA39

Suits: Mitsubishi
Crankshaft

CSCA40



Suits: Mitsubishi
Crankshaft

CSCA41

Suits: Ford
Crankshaft

CAMSHAFT & CRANKSHAFT SENSORS

FUELMISER

CSCA42

Suits: Suzuki
Crankshaft

CSCA43

Suits: Subaru
Crankshaft

CSCA44

Suits: Ford
Crankshaft

CSCA45

Suits: Holden
Crankshaft

CSCA46

Suits: Toyota
Crankshaft

CSCA47

Suits: Ford, Mazda
Crankshaft

CSCA48

Suits: Holden
Crankshaft

CSCA49

Suits: Eunos, Ford, Mazda
Crankshaft

CSCA50

Suits: Holden
Crankshaft

CSCA51

Suits: Hyundai, Mitsubishi
Crankshaft

CSCA52

Suits: Mazda
Crankshaft

CSCA53

Suits: Ford
Crankshaft

CSCA54

Suits: Hyundai, Mitsubishi
Crankshaft

CSCA57

Suits: Mitsubishi
Crankshaft

CSCA58

Suits: Mitsubishi
Includes Igniter and Ignition Trigger

CAMSHAFT & CRANKSHAFT SENSORS

FUELMISER

CSCA59

Suits: Eunos, Ford, Mazda
Includes Igniter and Ignition Trigger

CSCA60



Suits: Mitsubishi
Crankshaft

CSCA61

Suits: Eunos
Crankshaft

CSCA62

Suits: Mitsubishi
Crankshaft

CSCA63

Suits: Ford
Crankshaft

CSCA64

Suits: Nissan
Crankshaft

CSCA65

Suits: Ford
Crankshaft

CSCA66

Suits: Mitsubishi
Includes Igniter and Ignition Trigger

CSCA67

Suits: Ford, Mazda
Crankshaft

CSCA68

Suits: Ford
Crankshaft

CSCA69

Suits: Mazda
Crankshaft

CSCA71



Suits: Subaru
Crankshaft

CSCA72

Suits: Nissan
Crankshaft

CSCA73

Suits: Kia
Camshaft

CSCA74

Suits: Kia
Crankshaft

CAMSHAFT & CRANKSHAFT SENSORS

FUELMISER

CSCA75

Suits: Mazda
Crankshaft

CSCA76

Suits: Mazda
Crankshaft

CSCA78

Suits: Mitsubishi, Proton
Crankshaft

CSCA79

Suits: Nissan
Crankshaft

CSCA80



Suits: Ford
Is also Ignition Trigger

CSCA81

Suits: Holden
Camshaft

CSCA82

Suits: Holden
Camshaft

CSCA83

Suits: Holden
Camshaft

CSCA84

Suits: Daewoo, Holden
Camshaft

CSCA85

Suits: Ford
Camshaft

CSCA87

Suits: Mitsubishi
Camshaft

CSCA88

Suits: Subaru
Camshaft

CSCA92

Suits: Ford
Camshaft

CSCA93

Suits: Ford, Mazda
Camshaft / Crankshaft

CSCA94

Suits: Holden
Camshaft

CAMSHAFT & CRANKSHAFT SENSORS

FUELMISER

CSCA95

Suits: Holden
Camshaft

CSCA96

Suits: Hyundai
Camshaft

CSCA97

Suits: Hyundai
Camshaft

CSCA98

Suits: Hyundai
Camshaft

CSCA99

Suits: Hyundai
Camshaft

CSCA100

Suits: Kia
Camshaft

CSCA101

Suits: Mitsubishi
Camshaft

CSCA102

Suits: Toyota
Camshaft

CSCA104

Suits: Chrysler
Camshaft

CSCA105

Suits: Jeep
Camshaft

CSCA106

Suits: Ford
Camshaft

CSCA107

Suits: Daewoo, Ssangyong
Camshaft

CSCA108

Suits: Ford, Mazda
Camshaft

CSCA109



Suits: Lexus, Toyota
Camshaft

CSCA110

Suits: Mitsubishi
Camshaft

CAMSHAFT & CRANKSHAFT SENSORS

FUELMISER

CSCA111

Suits: Ford
Camshaft

CSCA113

Suits: Holden
Camshaft

CSCA114

Suits: Holden, SAAB
Camshaft

CSCA115

Suits: Hyundai
Camshaft

CSCA116

Suits: Hyundai
Camshaft

CSCA117

Suits: Holden
Camshaft

CSCA118

Suits: Lexus, Toyota
Camshaft

CSCA119

Suits: BMW
Camshaft

CSCA121

Suits: BMW
Camshaft

CSCA122

Suits: BMW
Camshaft

CSCA124

Suits: Ford
Camshaft

CSCA125

Suits: Ford
Camshaft

CSCA126

Suits: Ford
Camshaft / Crankshaft

CSCA127

Suits: Suzuki
Camshaft

CSCA130

Suits: Holden
Crankshaft

CAMSHAFT & CRANKSHAFT SENSORS

FUELMISER

CSCA131

Suits: Holden
Crankshaft

CSCA133

Suits: Lexus, Toyota
Crankshaft

CSCA134

Suits: Toyota
Crankshaft

CSCA135

Suits: Lexus, Toyota
Crankshaft

CSCA138

Suits: Lexus, Toyota
Crankshaft

CSCA139

Suits: BMW
Crankshaft

CSCA140

Suits: BMW
Crankshaft

CSCA141

Suits: BMW
Crankshaft

CSCA143

Suits: Ford
Camshaft / Crankshaft

CSCA144

Suits: Ford
Crankshaft

CSCA145

Suits: Ford, Mazda
Crankshaft

CSCA146

Suits: Suzuki
Crankshaft

CSCA147

Suits: Lexus, Toyota
Camshaft

CSCA148

Suits: Mitsubishi
Camshaft

CSCA149

Suits: Suzuki

CAMSHAFT & CRANKSHAFT SENSORS

FUELMISER

CSCA150

Suits: Toyota
Crankshaft

CSCA151

Suits: Mitsubishi
Camshaft

CSCA152

Suits: Mitsubishi
Crankshaft

CSCA153

Suits: Mitsubishi
Crankshaft

CSCA154

Suits: Ford
Crankshaft

CSCA155



Suits: Ford, Mazda
Crankshaft

CSCA156



Suits: Holden
Camshaft

CSCA157

Suits: Holden
Crankshaft

CSCA159

Suits: Lexus, Toyota
Camshaft

CSCA161

Suits: Mitsubishi
Crankshaft

CSCA162

Suits: Mitsubishi
Crankshaft

CSCA163

Suits: Mitsubishi
Crankshaft

CSCA164

Suits: Mitsubishi
Crankshaft

CSCA165

Suits: Toyota
Crankshaft

CSCA166

Suits: Toyota
Crankshaft

CAMSHAFT & CRANKSHAFT SENSORS

FUELMISER

CSCA167

Suits: Toyota
Crankshaft

CSCA168

Suits: Nissan
Crankshaft

CSCA169

Suits: BMW
Crankshaft

CSCA170

Suits: Nissan
Crankshaft: Complete Distributor

CSCA171

Suits: Volvo
Crankshaft

CSCA172

Suits: Holden
Camshaft

CSCA173

Suits: Holden
Camshaft

CSCA174

Suits: Holden
Camshaft

CSCA175

Suits: Holden
Camshaft

CSCA176

Suits: Holden
Crankshaft

CSCA177

Suits: Holden
Crankshaft

CSCA178

Suits: Daewoo, Holden
Crankshaft

CSCA179

Suits: Holden, SAAB
Camshaft

CSCA180

Suits: BMW
Crankshaft

CSCA181

Suits: BMW
Camshaft

CAMSHAFT & CRANKSHAFT SENSORS

FUELMISER

CSCA182

Suits: BMW
Crankshaft

CSCA183

Suits: BMW
Camshaft

CSCA184

Suits: VW
Crankshaft

CSCA185

Suits: BMW
Camshaft

CSCA186

Suits: BMW
Crankshaft

CSCA187

Suits: BMW
Crankshaft

CSCA188

Suits: BMW
Crankshaft

CSCA189

Suits: Volvo
Crankshaft

CSCA190

Suits: SAAB
Crankshaft

CSCA191

Suits: Volvo
Crankshaft

CSCA192

Suits: Kia
Crankshaft

CSCA193

Suits: BMW
Camshaft

CSCA194

Suits: Holden
Crankshaft

CSCA195

Suits: Ford
Crankshaft

CSCA196

Suits: SAAB
Camshaft

CAMSHAFT & CRANKSHAFT SENSORS

FUELMISER

CSCA198

Suits: SAAB
Crankshaft

CSCA199

Suits: SAAB
Crankshaft

CSCA200

Suits: Ford
Camshaft

CSCA201

Suits: VW
Camshaft

CSCA202

Suits: VW
Camshaft

CSCA203

Suits: Volvo
Crankshaft

CSCA204

Suits: Holden
Speed / RPM

CSCA205

Suits: BMW
Crankshaft

COOLANT TEMP. SENSOR & SWITCHES

FUELMISER

CCS20



Suits: Ford, Holden, Mazda, Toyota
Thread M12x1.5

CCS21

Suits: Ford, Holden, Mazda, Toyota
Thread M12x1.5

CCS22

Suits: Honda
Thread M12x1.5

CCS23

Suits: Holden, Honda
Thread M12x1.5

CCS24

Suits: Hyundai, Mitsubishi
Thread 3/8 Gas

CCS25



Suits: Alfa, BMW, Holden, Nissan
Thread M12x1.5

CCS26



Suits: Ford, Holden, Mitsubishi, Toyota
Also used as temperature gauge sensor:
Thread M12x1.5

CCS27

Suits: Honda
Thread M16x1.5

CCS29

Suits: Ford, Nissan
Thread M16x1.5

CCS30

Suits: Daihatsu
Thread 3/8 Gas

CCS31

Suits: Daewoo, Holden
Thread M12x1.5

CCS32

Suits: Audi, BMW
Thread M14x1.5

CCS33



Suits: Mitsubishi, Proton
Thread 3/8 Gas

CCS34

Suits: Audi
Thread M10x1

CCS35

Suits: Landrover
Thread M12x1.5

COOLANT TEMP. SENSOR & SWITCHES

FUELMISER

CCS37



Suits: Nissan
Thread M12x1.5

CCS38

Suits: Audi
Thread M10x1

CCS39

Suits: Hyundai, Mitsubishi, Proton
Thread 3/8 Gas

CCS40



Suits: Ford
Thread M12x1.5

CCS41



Suits: Holden, SAAB
Thread M12x1.5

CCS42



Suits: Holden
Thread M12x1.5

CCS43

Suits: Ford
Thread 3/8x18NPT

CCS44



Suits: Ford
Thread Not Applicable

CCS45

Suits: Subaru
Thread M12x1.5

CCS46

Suits: Ford, Mazda

CCS47

Suits: Holden
Thread Not Applicable

CCS48

Suits: Holden
Thread M12x1.5

CCS49

Suits: Holden
Thread M12x1.5

CCS50

Suits: Seat
Thread Not Applicable

CCS51

Suits: Holden
Thread M12x1.5

COOLANT TEMP. SENSOR & SWITCHES

FUELMISER

CCS53

Suits: Audi
Temperature Gauge Sensor –
Thread Not Applicable

CCS54

Suits: Audi
Temperature Gauge Sensor –
Thread Not Applicable

CCS55

Suits: BMW
Thread M12x1.5

CCS56

Suits: BMW
Thread Not Applicable

CCS57

Suits: Ford
Thread Not Applicable

CCS58

Suits: Toyota
Thread M12x1.5

CTS100

Suits: Holden, Nissan
Temperature Gauge Sensor –
Thread Not Applicable

CTS101

Suits: Holden, Nissan
Adapter – Thread M16x1.5

CTS102

Suits: Holden, Nissan
Temperature Gauge Sensor –
Thread Not Applicable

CTS104

Suits: Daihatsu, Subaru, Toyota
Temperature Gauge Sensor – Thread M16x1.5

CTS106

Suits: Daihatsu, Toyota
Temperature Gauge Sensor – Thread M16x1.5

CTS108

Suits: Chrysler, Hyundai, Mitsubishi
Temperature Gauge Sensor – Thread M16x1.5

CTS110

Suits: Ford, Holden, Hyundai, Toyota
Temperature Gauge Sensor – Thread 1/8 Gas

CTS111

Suits: Ford, Mazda
Temperature Gauge Sensor – Thread M8x0.75

CTS112

Suits: Ford, Honda, Mazda
Temperature Gauge Sensor – Thread M16x1.5

COOLANT TEMP. SENSOR & SWITCHES

FUELMISER

CTS113

Suits: Daihatsu
Temperature Gauge Sensor – Thread M16x1.5

CTS114

Suits: Daihatsu, Honda
Temperature Gauge Sensor – Thread 1/8 Gas

CTS115

Suits: Ford, Honda, Mazda, Rover
Temperature Gauge Sensor – Thread 1/8 Gas

CTS116

Suits: Audi, VW
Temperature Gauge Sensor – Thread M10x1

CTS117

Suits: Volvo
Temperature Gauge Sensor – Thread 5/8x18 UNF

CTS119

Suits: Jaguar, Landrover, Triumph
Temperature Gauge Sensor – Thread 5/8x18 UNF

CTS120

Suits: Ford
Temperature Gauge Sensor – Thread 3/8x18 NPT

CTS121

Suits: Chrysler, SAAB
Temperature Gauge Sensor – Thread 1/8 Gas

CTS122

Suits: Ford
Temperature Gauge Sensor – Thread 1/8 Gas

CTS123

Suits: Bedford, Holden, Leyland
Temperature Gauge Sensor – Thread 1/2x14 NPT

CTS124

Suits: Holden
Coolant Temperature Warning Light Switch – Thread 1/2x14 NPT

CTS125

Suits: Holden, Toyota
Temperature Gauge Sensor – Thread 1/8 Gas

CTS126

Suits: Daihatsu, Ford, Mazda
Temperature Gauge Sensor – Thread M16x1.5

CTS127

Suits: Daewoo, Holden, Nissan
Temperature Gauge Sensor – Thread 1/8 Gas

CTS128

Suits: Austin, Leyland, MG, Rover
Temperature Gauge Sensor – Thread 5/8x18 UNF

COOLANT TEMP. SENSOR & SWITCHES

FUELMISER

CTS130

Suits: Holden, Nissan
Temperature Gauge Sensor – Thread M12x1.5

CTS131

Suits: Ford
Temperature Gauge Sensor – Thread 1/8 Gas

CTS132

Suits: Lada
Temperature Gauge Sensor – Thread M16x1.5

CTS133

Suits: Alfa
Temperature Gauge Sensor – Thread M16x1.5

CTS134

Suits: Holden, Daewoo
Temperature Gauge Sensor – Thread 1/8x27 NPT

CTS136

Suits: Daewoo
Temperature Gauge Sensor – Thread 1/8x27 NPT

CTS137

Suits: BMW
Temperature Gauge Sensor – Thread M14x1.5

CTS138

Suits: Holden, Isuzu
Temperature Gauge Sensor – Thread M16x1.5

CTS139

Suits: Holden
Temperature Gauge Sensor – Thread M16x1.5

CTS140

Suits: BMW
Temperature Gauge Sensor – Thread M14x1.5

CTS141

Suits: Nissan
Temperature Gauge Sensor – Thread M12x1.25

CTS142

Suits: Holden, Suzuki
Temperature Gauge Sensor – Thread 1/8 Gas

CTS144

Suits: Ford
Temperature Gauge Sensor – Thread 1/8x27 NPT

CTS145

Suits: Alfa
Temperature Gauge Sensor – Thread M14x1.5

CTS146

Suits: Daewoo
Temperature Gauge Sensor – Thread M12x1.5

COOLANT TEMP. SENSOR & SWITCHES

FUELMISER

CTS147

Suits: Daewoo, Holden, Toyota
Coolant Temperature Sensor – Thread 3/8x18 NPT

CTS148

Suits: Ford
Temperature Gauge Sensor – Thread 1/8x27 NPT

CTS149



Suits: Ford
Temperature Gauge Sensor – Thread 1/8x27 NPT

CTS150

Suits: Holden, Toyota
Temperature Gauge Sensor – Thread M16x1.5

CTS151

Suits: Ford
Temperature Gauge Sensor – Thread 1/8x27 NPT

CTS152

Suits: Holden
Temperature Gauge Sensor – Thread 1/8x27 NPT

CTS153

Suits: BMW
Temperature Gauge Sensor – Thread M14x1.5

CTS154

Suits: Holden, Lexus, Toyota
Temperature Gauge Sensor – Thread 1/8 Gas

CTS155

Suits: Nissan
Temperature Gauge Sensor – Thread M12x1.5

CTS156

Suits: BMW
Temperature Gauge Sensor – Thread M14x1.5

CTS157

Suits: Audi
Temperature Gauge Sensor –
Thread Not Applicable

CTS158

Suits: Nissan
Temperature Gauge Sensor – Thread M16x1.5

CTS159

Suits: Mazda
Temperature Gauge Sensor – Thread M8x0.75

CTS160

Suits: VW
Temperature Gauge Sensor – Thread Not Applicable

CTS161

Suits: VW
Temperature Gauge Sensor – Thread M10x1.0

EXHAUST OXYGEN SENSORS

FUELMISER

COS720

Universal 1 wire

COS721

Universal 3 wire

COS722

Universal 1 wire with flange

COS723

Universal 2 wire

COS724

Universal 4 wire

COS725

Universal 2 wire with flange

COS726

Universal 4 wire with flange

COS730

Suits: Daihatsu, Holden, Toyota

COS732

Suits: Daewoo, Holden, Nissan, Toyota

COS733

Suits: Ford

COS734

Suits: Daewoo, Holden, Toyota

COS736

Suits: Ford, Mazda

COS737

Suits: Holden, Nissan

COS738

Suits: Audi, Ford, Nissan, Subaru

COS742

Suits: Mitsubishi, Subaru

EXHAUST OXYGEN SENSORS

FUELMISER

COS744

Suits: Daewoo, Holden, Toyota

COS745

Suits: Honda

COS748

Suits: Ford, Jaguar, Nissan

COS750

Suits: Holden

COS752



Suits: Mitsubishi

COS753

Suits: Proton

COS754

Suits: Chrysler

COS755

Suits: Holden

COS757

Suits: Ford, Hyundai, Mitsubishi

COS758

Suits: Mercedes

COS760

Suits: Toyota

COS761

Suits: Ford

COS762

Suits: Hyundai, Mitsubishi

COS764

Suits: Eunos, Ford, Mazda

COS765

Suits: Ford

EXHAUST OXYGEN SENSORS

FUELMISER

COS766

Suits: Ford, Mazda

COS767

Suits: Ford

COS768

Suits: Ford, Mazda

COS769

Suits: Honda

COS770

Suits: Mazda

COS771

Suits: Nissan

COS772

Suits: Nissan

COS774

Suits: Toyota

COS775

Suits: Holden, Toyota

COS776

Suits: BMW, SAAB

COS777

Suits: Ford

COS778



Suits: Holden, Toyota

COS779

Suits: Ford, Mazda

COS780

Suits: Lexus

COS781

Suits: Lexus

EXHAUST OXYGEN SENSORS

FUELMISER

COS782

Suits: Toyota

COS783

Suits: Mitsubishi

COS784

Suits: Holden

COS785

Suits: BMW, Subaru

COS786

Suits: Alfa, Audi, SAAB, Volvo

COS787

Suits: Porsche

COS788

Suits: Audi, Ferrari

COS789

Suits: Audi, Peugeot

COS790

Suits: Alfa, Volvo

COS792

Suits: Peugeot

COS793

Suits: Audi, SAAB

COS794

Suits: Mercedes

COS795

Suits: Mercedes

COS796

Suits: Mazda

COS797

Suits: Nissan

EXHAUST OXYGEN SENSORS

FUELMISER

COS799

Suits: Mazda

COS800

Suits: Nissan

COS802

Suits: Ford

COS803

Suits: Jeep

COS804



Suits: Chrysler

COS805

Suits: Chrysler

COS806

Suits: Hyundai

COS807

Suits: Chrysler

COS808

Suits: Ford

COS810

Suits: BMW

COS813

Suits: Peugeot

COS814

Suits: Mercedes

COS816

Suits: Mercedes

COS818

Suits: Mercedes

COS819

Suits: Suzuki

EXHAUST OXYGEN SENSORS

FUELMISER

COS820

Suits: Toyota

COS821

Suits: Toyota

COS822

Suits: Suzuki

COS824

Suits: Seat

COS826

Suits: Mazda

COS827

Suits: Jeep

COS828

Suits: Mazda

COS829

Suits: BMW

COS830

Suits: Honda

COS831



Suits: Honda

COS832



Suits: Honda

COS834

Suits: BMW

COS835

Suits: Mitsubishi

COS836

Suits: Ford

COS837

Suits: Ford, Mazda

EXHAUST OXYGEN SENSORS

FUELMISER

COS838

Suits: Lexus, Toyota

COS842

Suits: Toyota

COS843

Suits: Lexus, Toyota

COS844

Suits: Lexus, Toyota

COS847



Suits: Lexus

COS848

Suits: Proton

COS849

Suits: Mitsubishi

COS850

Suits: Mitsubishi

COS851

Suits: Mitsubishi

COS852

Suits: Mitsubishi

COS853

Suits: Lexus

COS855

Suits: Holden

COS856

Suits: Hyundai

COS857

Suits: Toyota

COS858

Suits: Lexus, Toyota

EXHAUST OXYGEN SENSORS

FUELMISER

COS859

Suits: Honda

COS860

Suits: Hyundai

COS861

Suits: Toyota

COS862

Suits: Suzuki

COS865

Suits: BMW

COS866

Suits: BMW, Rover

COS867

Suits: Lexus, Toyota

COS868

Suits: Hyundai

COS869

Suits: Hyundai

COS871

Suits: Lexus

COS872

Suits: Toyota

COS880

Suits: Eunos

COS881

Suits: Lexus, Toyota

COS882

Suits: Toyota

COS883

Suits: Holden

EXHAUST OXYGEN SENSORS

FUELMISER

COS884

Suits: Holden

COS885

Suits: Hyundai

COS886

Suits: Hyundai

COS887

Suits: Mitsubishi

COS888

Suits: Ford

COS889

Suits: BMW

COS890

Suits: Honda

COS891

Suits: BMW

COS892

Suits: Toyota

COS893

Suits: Toyota

COS894

Suits: Lexus, Toyota

COS895

Suits: Lexus, Toyota

COS896

Suits: Kia

COS897

Suits: Peugeot

COS898

Suits: Holden

EXHAUST OXYGEN SENSORS

FUELMISER

COS899

Suits: Holden

COS900

Suits: BMW

COS901

Suits: Holden

COS902

Suits: Ford

COS903

Suits: Suzuki

COS904



Suits: Holden

COS905

Suits: Hyundai

COS906

Suits: Kia

COS907

Suits: Mazda

COS908

Suits: Ford, Mazda

COS909

Suits: Ford, Mazda

COS910

Suits: Mazda

COS911

Suits: Hyundai

COS912

Suits: BMW

COS913

Suits: BMW

EXHAUST OXYGEN SENSORS

FUELMISER

COS914

Suits: Rover

COS915

Suits: Kia

COS916

Suits: Ford

COS917

Suits: Holden

COS918

Suits: Holden

COS919

Suits: Seat

COS920

Suits: Ford

COS921

Suits: Suzuki

COS922

Suits: Ford, Mazda, Nissan

COS924

Suits: Ford

COS925

Suits: Ford

COS926

Suits: Kia

COS927

Suits: Kia

COS929

Suits: Ford

COS930

Suits: Ford

EXHAUST OXYGEN SENSORS

FUELMISER

COS931

Suits: Subaru

COS932

Suits: Suzuki

COS933

Suits: BMW

COS934

Suits: BMW

COS935

Suits: BMW

COS938

Suits: Hyundai, Kia

IDLE SPEED CONTROL VALVES

CIA002

Suits: Hyundai

CIA004

Suits: Holden, Nissan

CIA005

Suits: Ford

CIA008

Suits: Daewoo, Holden, Toyota

CIA009

Suits: Ford

CIA011

Suits: Ford

IDLE SPEED CONTROL VALVES

FUELMISER

CIA015

Suits: Mitsubishi

CIA017

Suits: Holden

CIA018

Suits: Holden

KNOCK CONTROL SENSORS

CKS101

Suits: Holden, Toyota

CKS102

Suits: Ford

CKS103

Suits: Holden, Toyota

CKS104

Suits: Subaru

CKS105

Suits: Ford

CKS106

Suits: SAAB

CKS107

Suits: Holden, Hyundai, Volvo

CKS108

Suits: Holden, SAAB, Volvo

CKS109

Suits: Audi

KNOCK CONTROL SENSORS

FUELMISER

CKS110

Suits: VW

CKS111

Suits: Daewoo

CKS112

Suits: Holden

CKS113

Suits: Daewoo

CKS115

Suits: Hyundai, Kia

CKS116

Suits: Audi

CKS117

Suits: Holden

CKS118

Suits: VW

MAP SENSORS

FUELMISER

CAT022

Suits: Holden
Includes Inlet Air Temperature Sensor

CMS205

Suits: Ford

CMS206

Suits: Ford, Holden, Hyundai, Toyota

CMS207

Suits: Holden, Universal

CMS208

Suits: Universal

CMS209

Suits: Hyundai

CMS210

Suits: Daewoo, Holden

CMS211

Suits: Hyundai

CMS212

Suits: Hyundai

CMS213

Suits: Hyundai

CMS215

Suits: Proton

CMS216

Suits: Ford
Includes Inlet Air Temperature Sensor

CMS217

Suits: Ford
Includes Inlet Air Temperature Sensor

CMS218

Suits: Honda

CMS223

Suits: Suzuki

MAP SENSORS

FUELMISER

CMS226

Suits: Ford
Includes Air Temperature Sensor

CMS227

Suits: Mini

CMS228

Suits: Chrysler

CMS229

Suits: Daewoo, Ssangyong

CMS230

Suits: Mini

THROTTLE POSITION SENSORS & SWITCHES

CTPS100

Suits: Ford, Holden, Kia, Mitsubishi

CTPS101

Suits: Toyota
Switch Assembly

CTPS102

Suits: Holden, Suzuki, Toyota
Switch Assembly

CTPS103

Suits: Holden, Nissan
Switch Assembly

CTPS104

Suits: Ford, Holden, Mazda, Toyota
Switch Assembly

CTPS105

Suits: Holden
Switch Assembly

THROTTLE SENSORS & SWITCHES

FUELMISER

CTPS106

Suits: Holden
Switch Assembly

CTPS107

Suits: Holden

CTPS108

Suits: Ford, Holden, Hyundai, SAAB

CTPS109

Suits: Ford

CTPS110

Suits: Ford

CTPS111

Suits: Holden, Lexus, Toyota

CTPS113

Suits: Mitsubishi

CTPS117

Suits: Holden, Nissan, Toyota

CTPS119

Suits: Ford

CTPS121

Suits: Ford

CTPS124

Suits: Holden

CTPS129

Suits: Holden, Nissan

CTPS131

Suits: Daewoo, Holden, Nissan

CTPS132

Suits: Daewoo, Holden, Toyota

CTPS133

Suits: Nissan

THROTTLE SENSORS & SWITCHES

FUELMISER

CTPS134

Suits: Nissan
Switch Assembly

CTPS135

Suits: Nissan

CTPS136

Suits: Ford, Nissan

CTPS137

Suits: Ford, Nissan

CTPS138

Suits: Nissan

CTPS139

Suits: Nissan

CTPS141

Suits: Nissan

CTPS142

Suits: Nissan
Switch Assembly

CTPS143

Suits: Ford

CTPS144

Suits: BMW
Switch Assembly

CTPS145

Suits: Volvo
Switch Assembly

CTPS146

Suits: Holden, SAAB
Switch Assembly

CTPS155

Suits: Nissan

CTPS156

Suits: Nissan

BRAKE & CLUTCH PEDAL SWITCHES

FUELMISER

CSL20

Suits: Holden
Brake Light Switch –
Mounting Stem 12.5mm diameter: Contacts N.C.

CSL21



Suits: Ford, IHC
Brake Light Switch – Hydraulic:
Thread 1/8x27 NPT: Contacts N.O.

CSL22



Suits: Austin, Rover, Triumph
Brake Light Switch – Hydraulic:
Thread 1/8x27 NPT: Contacts N.O.

CSL23

Suits: Alfa, Fiat
Brake Light Switch – Hydraulic:
Thread 1/8x27 NPT: Contacts N.O.

CSL25



Suits: Ford, Mazda, Toyota
Brake Light Switch –
2 Circuits: Red switches immediately:
Green switches when pedal fully depressed

CSL26

Suits: Ford, Mazda, Mitsubishi, Toyota
Brake Light Switch – Thread M10x1.25: Contacts N.C.

CSL27



Suits: Daihatsu, Mitsubishi
Brake Light Switch – Thread M10x1.25: Contacts N.C.

CSL28

Suits: Nissan
Brake Light Switch – Thread M10x1.25: Contacts N.C.

CSL29



Suits: Nissan
Brake Light Switch – Hydraulic:
Thread 1/8x28 (JIS): Contacts N.C.

CSL30

Suits: Holden
Brake Light Switch – Thread M10x1.25: Contacts N.C.

CSL31



Suits: Holden, Suzuki
Brake Light Switch – Contacts N.C.

CSL32

Suits: Chrysler, Nissan
Brake Light Switch – Contacts N.C.

CSL34

Suits: Ford 1966-68
Brake Light Switch

CSL36

Suits: Ford 1669-91
Brake Light Switch

CSL37

Suits: Ford
Brake Light Switch

BRAKE & CLUTCH PEDAL SWITCHES

FUELMISER

CSL38 / CSL46

Suits: Ford
Brake Light Switch

CSL40

Suits: Toyota
Brake Light Switch – Thread M10x1.25: Contacts N.C.

CSL41

Suits: Holden
Brake Light Switch

CSL42

Suits: Chrysler
Brake Light Switch – Contacts N.C.

CSL43

Suits: Holden, Nissan
Brake Light Switch – Contacts N.C.

CSL44

Brake Light Switch

CSL45

Brake Light Switch

CSL47



Suits: Ford, Holden, Mazda, Toyota
Brake Light Switch and Clutch Pedal Switch – Contacts N.C.

CSL50

Suits: Ford
Brake Light Switch

CSL51

Suits: Ford
Brake Light Switch – Thread M12x1.75: Contacts N.C.

CSL54

Suits: Holden, Honda, Mitsubishi
Brake Light Switch – Thread M10x1.25:
Contacts one pair N.C. and one pair N.O.

CSL55

Suits: Daewoo, Holden
Brake Light Switch –
With auto adjustment: Contacts N.C.

CSL56

Suits: Toyota
Brake Light Switch – Thread M10x1.25:
Contacts one pair N.C. and one pair N.O.

CSL57

Suits: Hyundai
Brake Light Switch – Thread M10x1.25: Contacts N.C.

CSL58

Suits: Holden
Brake Light Switch –
Contacts 3 Terminal Change Over

BRAKE & CLUTCH PEDAL SWITCHES

FUELMISER

CSL59



Suits: Holden, Toyota
Brake Light Switch – Thread M10x1.25: Contacts N.C.

CSL60



Suits: Holden, Toyota
Brake Light Switch – Thread M10x1.25: Contacts one pair N.C. and one pair N.O.

CSL61

Suits: Holden
Brake Light Switch – Contacts N.C.

CSL62

Suits: Ford
Brake Light Switch – Contacts N.C.

CSL63

Suits: Hyundai
Brake Light Switch – Thread M10x1.25: Contacts one pair N.C. and one pair N.O.

CSL64



Suits: Holden
Brake Light Switch – Contacts N.C.

CSL65

Suits: Holden
Brake Light Switch –
Contacts one pair N.C. and one pair N.O.

CSL66



Suits: Hyundai
Clutch Pedal Switch –
Thread M10x1.25: Contacts N.O.

CSL67

Suits: Holden, Hyundai, Toyota, VW
Brake Light Switch – Thread M10x1.25: Contacts N.C.

CSL68

Suits: Hyundai
Clutch Pedal Switch –
Thread M10x1.25: Contacts N.O.

CSL69

Suits: Eunos, Ford
Brake Light Switch – Contacts N.C.

CSL70

Suits: Ford
Brake Light Switch –
Contacts one pair N.C. and one pair N.O.

CSL71



Suits: Mitsubishi
Brake Light Switch

CSL72

Suits: Mitsubishi
Brake Light Switch

CSL73



Suits: Holden
Brake Light Switch –
Contacts one pair N.C. and one pair N.O.

OIL PRESSURE SENSOR & SWITCHES

FUELMISER

CPS20

Suits: Audi, Nissan, SAAB, VW
Oil Pressure Switch – Thread M10x1:
Contacts N.C.: Open at 30Kpa

CPS21

Suits: Holden, Mazda, Nissan
Oil Pressure Switch – Thread M14x1.5:
Contacts N.C.: Open at 35Kpa

CPS22

Suits: Ford, Holden, Honda, Nissan
Oil Pressure Switch – Thread 1/8x28 BSPT:
Contacts N.C.: Open at 40Kpa

CPS23

Suits: Ford, Holden, Mazda, Toyota
Oil Pressure Switch – Thread 1/8x28 BSPT:
Contacts N.C.: Open at 40Kpa

CPS24

Suits: Ford, Holden, Mazda, Toyota
Oil Pressure Switch – Thread 1/8x28 BSPT:
Contacts N.C.: Open at 20Kpa

CPS25

Suits: Ford, Honda, Mazda, Suzuki
Oil Pressure Switch – Thread 1/8 Gas:
Contacts N.C.: Open at 40Kpa

CPS26



Suits: Nissan, Toyota
Oil Pressure Gauge Sensor – Thread 1/8 Gas:
Resistance Variable

CPS27

Suits: Mitsubishi
Oil Pressure Gauge Sensor – Thread 1/8 Gas:
Resistance Variable

CPS28

Suits: Ford, Holden, Nissan
Oil Pressure Switch – Thread 1/8 Gas:
Contacts N.C.: Open at 20Kpa

CPS29



Suits: Nissan
Oil Pressure Gauge Sensor – Thread 1/8 Gas:
Resistance Variable

CPS30

Suits: Ford, Holden, SAAB, Toyota
Oil Pressure Switch – Thread 1/4x18 Dryseal:
Contacts N.C.: Open at 40Kpa

CPS31



Suits: Chrysler, Ford, Volvo
Oil Pressure Switch – Thread 1/8x27 NPT:
Contacts N.C.: Open at 50Kpa

CPS32

Suits: Ford, Holden
Oil Pressure Switch – Thread 1/8x27 Dryseal:
Contacts N.C.: Open at 35Kpa

CPS33

Suits: Holden
Oil Pressure Switch – Thread 1/4x18 Dryseal:
Contacts N.C.: Open at 30Kpa

CPS34

Suits: Ford, Holden, Nissan
Oil Pressure Switch – Thread 1/4x18 Dryseal:
Contacts N.C.: Open at 40Kpa

OIL PRESSURE SENSOR & SWITCHES

FUELMISER

CPS35

Suits: Austin, Jaguar, MG, Volvo
Oil Pressure Switch – Thread 1/8x27 Dryseal:
Contacts N.C.: Open at 40Kpa

CPS36

Suits: Holden
Oil Pressure Switch – Thread 1/4x18 Dryseal:
Contacts N.C.: Open at 40Kpa

CPS37

Suits: Ford, Holden, Hyundai, Toyota
Oil Pressure Switch – Thread 1/8 Gas:
Contacts N.C.: Open at 30Kpa

CPS38

Suits: Holden, Toyota
Oil Pressure Switch – Thread 3/8 NPT:
Contacts N.C. & N.O.

CPS39

Suits: Chrysler
Oil Pressure Switch – Thread 1/8 Gas:
Contacts N.C.

CPS40

Suits: Audi
Oil Pressure Switch – Thread M10x1:
Contacts N.C.: Open at 30Kpa

CPS41



Suits: Ford
Oil Pressure Switch – Thread 1/4x18 NPT:
Contacts N.C.: Open at 30Kpa

CPS42

Suits: BMW
Oil Pressure Switch – Thread M16x1.5:
Contacts N.C.: Open at 60Kpa

CPS43



Suits: BMW
Oil Pressure Switch – Thread M12x1.5:
Contacts N.C.: Open at 15Kpa

CPS44

Suits: BMW
Oil Pressure Switch – Thread M12x1.5:
Contacts N.C.: Open at 35Kpa

CPS45

Suits: Ford
Oil Pressure Switch – Thread 1/8x27 NPT:
Contacts N.C.: Open at 50Kpa

CPS46

Suits: Holden
Oil Pressure Switch – Thread 1/8 Gas:
Contacts N.C.: Open at 30Kpa

CPS47

Suits: Holden
Oil Pressure Switch – Thread 1/8 Gas:
Contacts N.C.: Open at 30Kpa

CPS48

Suits: Daewoo, Holden, Seat
Oil Pressure Switch – Thread M14x1.5:
Contacts N.C.: Open at 50Kpa

CPS49

Suits: BMW
Oil Pressure Switch – Thread M12x1.5:
Contacts N.C.: Open at 30Kpa

OIL PRESSURE SENSOR & SWITCHES

FUELMISER

CPS50

Suits: Hyundai, Mitsubishi
Oil Pressure Switch – Thread 1/8 Gas:
Contacts N.C.: Open at 40Kpa

CPS51

Suits: Holden, Lexus, Toyota
Oil Pressure Switch – Thread 1/8 Gas:
Contacts N.C.: Open at 20Kpa

CPS52

Suits: Ford
Oil Pressure Switch – Thread 1/4x18 NPT:
Contacts N.C.: Open at 40Kpa

CPS53

Suits: Ford
Oil Pressure Switch – Thread 3/8 NPT:
Contacts N.C.: Open at 50Kpa

CPS54



Suits: Holden
Oil Pressure Gauge Sensor – Thread M14x1.5:
Resistance Variable

CPS55

Suits: Hyundai
Oil Pressure Gauge Sensor – Thread 1/8 Gas:
Resistance Variable

CPS56

Suits: Nissan
Oil Pressure Gauge Sensor – Thread 1/8 Gas:
Resistance Variable

CPS57

Suits: Daewoo, Holden
Oil Pressure Switch – Thread M14x1.5

CPS58

Suits: Holden
Oil Pressure Switch – Thread M14x1.5:
Contacts N.C.: Open at 30Kpa

CPS59



Suits: Mitsubishi
Oil Pressure Switch – Thread 1/8 Gas:
Contacts N.C.: Open at 20Kpa

RADIATOR FAN SWITCHES

FUELMISER

CFS10

Suits: Holden, Volvo
Thread M14x1.5: Contacts N.O.:
Close at 100°C Open at 95°C

CFS11

Suits: Mitsubishi
Thread M16x1.5: Contacts N.O.:
Close at 85°C Open at 80°C

CFS12

Suits: Honda, Rover, Suzuki
Thread M16x1.5: Contacts N.O.:
Close at 92°C Open at 87°C

CFS13

Suits: Honda
Thread M16x1.5: Contacts N.O.:
Close at 92°C Open at 87°C

CFS14

Suits: Honda
Thread M16x1.5: Contacts N.O.:
Close at 92°C Open at 87°C

CFS15

Suits: Nissan
Thread M16x1.5: Contacts N.O.:
Close at 85°C Open at 80°C

CFS16

Suits: Nissan
Thread M16x1.5: Contacts N.O.:
Close at 85°C Open at 80°C

CFS17

Suits: Nissan
Thread M16x1.5: Contacts N.O.:
Close at 90°C Open at 85°C

CFS18

Suits: Audi, Citroen, SAAB, VW
Thread M22x1.5: Contacts N.O.:
Close at 95°C Open at 90°C

CFS19

Suits: Audi, Porsche
Thread M22x1.5: Dual Contacts N.O.: 1 Close at 95°C Open at 85°C: 2 Close at 102°C Open at 100°C

CFS20



Suits: Holden, Nissan
Thread M16x1.5: Contacts N.O.:
Close at 92°C Open at 82°C

CFS21

Suits: Subaru
Thread M16x1.5: Contacts N.O.:
Close at 92°C Open at 87°C

CFS22

Suits: Chev, Chrysler, Mitsubishi
Thread M16x1.5: Contacts N.O.:
Close at 85°C Open at 80°C

CFS24

Suits: Holden, Toyota
Thread M16x1.5: Contacts N.C.:
Open at 90°C Close at 85°C

CFS26

Suits: Ford, Mazda
Thread M16x1.5: Contacts N.C.:
Open at 97°C Close at 92°C

RADIATOR FAN SWITCHES

FUELMISER

CFS27

Suits: Subaru
Thread M16x1.5: Contacts N.O.:
Close at 95°C Open at 90°C

CFS28

Suits: Holden, Nissan
Thread M16x1.5: Contacts N.O.:
Close at 95°C Open at 85°C

CFS29

Suits: Mitsubishi, Proton
Thread M16x1.5: Contacts N.O.:
Close at 85°C Open at 80°C

CFS30

Suits: Hyundai
Thread M16x1.5: Contacts N.O.:
Close at 90°C Open at 85°C

CFS31



Suits: Hyundai
Thread M16x1.5: Contacts N.O.:
Close at 85°C Open at 80°C

CFS32

Suits: Holden, Toyota
Thread M16x1.5: Contacts N.C.:
Open at 90°C Close at 85°C

CFS33

Suits: Alfa, Lada
Thread M22x1.5: Contacts N.O.:
Close at 92°C Open at 87°C

CFS34

Suits: Alfa
Thread M22x1.5: Contacts N.O.:
Close at 90°C Open at 80°C

CFS35

Suits: Alfa
Thread M22x1.5: Contacts N.O.:
Close at 85°C Open at 75°C

CFS36

Suits: Audi
Thread M22x1.5: Contacts N.O.:
Close at 95°C Open at 90°C

CFS37



Suits: Daihatsu
Thread 3/8 Gas: Contacts N.O.:
Close at 95°C Open at 90°C

CFS38

Suits: Holden
Thread M16x1.5: Contacts N.O.:
Close at 87°C Open at 77°C

CFS39

Suits: BMW
Thread M14x1.5: Contacts N.O.:
Close at 102°C Open at 97°C

CFS40

Suits: BMW
Thread M14x1.5: Contacts N.O.:
Close at 95°C Open at 90°C

CFS41

Suits: Hyundai
Thread M16x1.5: Contacts N.O.:
Close at 85°C Open at 80°C

RADIATOR FAN SWITCHES

FUELMISER

CFS42



Suits: Ford, Mazda
Thread M16x1.5: Contacts N.C.:
Open at 90°C Close at 85°C

CFS43

Suits: Toyota
Thread M16x1.5: Contacts N.C.:
Open at 50°C Close at 45°C

CFS44



Suits: Toyota
Thread M16x1.5: Contacts N.C.:
Open at 90°C Close at 85°C

CFS45

Suits: Holden, Suzuki
Thread M16x1.5: Contacts N.O.:
Close at 90°C Open at 85°C

CFS46

Suits: Holden
Thread M22x1.5: Contacts N.O.:
Close at 87°C Open at 82°C

CFS47



Suits: Honda
Thread M16x1.5: Contacts N.O.:
Close at 105°C Open at 90°C

CFS48

Suits: Mitsubishi
Thread M16x1.5: Contacts N.O.:
Close at 85°C Open at 80°C

CFS49

Suits: Holden
Thread M22x1.5: Contacts N.O.:
Close at 100°C Open at 95°C

CFS51

Suits: Ford
Thread 3/8 Gas: Contacts N.C.:
Open at 72°C Close at 67°C

CFS52

Suits: Daewoo
Thread M22x1.5: Contacts N.O.:
Close at 90°C Open at 85°C

CFS53



Suits: Honda
Thread M16x1.5: Contacts N.O.:
Close at 92°C Open at 87°C

CFS54



Suits: Honda
Thread M16x1.5: Contacts N.O.:
Close at 95°C Open at 90°C

CFS55

Suits: Holden, Toyota
Thread M16x1.5: Contacts N.C.:
Open at 90°C Close at 85°C

CFS56

Suits: Daihatsu
Thread 3/8 Gas: Contacts N.O.:
Close at 87°C Open at 82°C

CFS57

Suits: Honda
Thread M18x1.5: Contacts N.O.:
Close at 112°C Open at 107°C

RADIATOR FAN SWITCHES

FUELMISER

CFS58

Suits: Holden
Thread M22x1.5: Contacts N.O.:
Close at 100°C Open at 98°C

CFS59



Suits: Ford, Kia, Mazda
Thread M16x1.5: Contacts N.O.:
Close at 97°C Open at 92°C

CFS60

Suits: Toyota
Thread M16x1.5: Contacts N.C.:
Open at 50°C Close at 45°C

CFS61

Suits: Mazda
Thread M16x1.5: Contacts N.O.:
Close at 107°C Open at 102°C

CFS62

Suits: Honda
Thread M18x1.5: Contacts N.O.:
Close at 95°C Open at 90°C

CFS63



Suits: Holden, Toyota
Thread M16x1.5: Contacts N.C.:
Open at 92°C Close at 87°C

CFS65

Suits: Ford, Mazda
Thread M16x1.5: Contacts N.O.:
Close at 90°C Open at 85°C

CFS66

Suits: Holden
Thread M16x1.5: Contacts N.O.:
Close at 87°C Open at 77°C

CFS67



Suits: Ford
Thread M12x1.5: Contacts N.O.:
Close at 105°C Open at 100°C

CFS69

Suits: Lexus
Thread M16x1.5: Contacts N.O.:
Close at 90°C Open at 85°C

CFS70



Suits: Hyundai
Thread 3/8 Gas: Contacts N.O.:
Close at 105°C Open at 100°C

CFS71



Suits: Hyundai
Thread 3/8 Gas: Contacts N.C.:
Open at 115°C Close at 110°C

CFS72



Suits: Daihatsu
Thread 3/8 Gas: Contacts N.O.:
Close at 92°C Open at 87°C

CFS73

Suits: Ford
Thread M16x1.5: Contacts N.C.:
Open at 90°C Close at 85°C

CFS74

Suits: Daihatsu, Ford
Thread 3/8 Gas: Contacts N.O.:
Close at 87°C Open at 82°C

RADIATOR FAN SWITCHES

FUELMISER

CFS75

Suits: Toyota
Thread M16x1.5: Contacts N.C.:
Open at 95°C Close at 90°C

CFS76

Suits: BMW
Thread M14x1.5: Dual Contacts N.O.: 1 Close at 91°C Open at 86°C: 2 Close at 99°C Open at 94°C

CFS77

Suits: Holden
Thread M22x1.5: Dual Contacts N.O.: 1 Close at 95°C Open at 90°C: 2 Close at 105°C Open at 100°C

CFS78



Suits: Holden
Thread M22x1.5: Dual Contacts 1 N.O. 1 N.C.:
N.O. Close at 120°C Open at 115°C: N.C.
Open at 105°C Close at 100°C

CFS79

Suits: Holden
Thread M22x1.5: Dual Contacts N.O.: 1 Close at 100°C Open at 95°C: 2 Close at 105°C Open at 100°C

CFS80



Suits: Holden
Thread M22x1.5: Dual Contacts 1 N.O. 1 N.C.:
N.O. Close at 120°C Open at 115°C: N.C.
Open at 110°C Close at 105°C

CFS81

Suits: Subaru
Thread M16x1.5: Contacts N.O.:
Close at 97°C Open at 92°C

CFS82

Suits: Citroen
Thread M22x1.5: Contacts N.O.:
Close at 97°C Open at 92°C

CFS83

Suits: Toyota
Thread M16x1.5: Contacts N.O.:
Close at 105°C Open at 100°C

CFS84

Suits: Landrover
Thread M22x1.5: Contacts N.C.:
Open at 115°C Close at 110°C

CFS85

Suits: Holden
Thread M16x1.5: Contacts N.O.:
Close at 100°C Open at 95°C

CFS86

Suits: Holden
Thread M16x1.5: Contacts N.O.:
Close at 95°C Open at 85°C

CFS87

Suits: Honda
Thread M16x1.5: Contacts N.O.:
Close at 92°C Open at 77°C

CFS88

Suits: Suzuki
Thread M18x1.5: Contacts N.O.:
Close at 100°C Open at 95°C

CFS89

Suits: Suzuki
Thread M16x1.5: Contacts N.O.:
Close at 87°C Open at 82°C

RADIATOR FAN SWITCHES

FUELMISER

CFS90

Suits: Daihatsu
Thread 3/8 Gas: Contacts N.O.:
Close at 92°C Open at 87°C

CFS91



Suits: Holden, Suzuki, VW
Thread M18x1.5: Contacts N.O.:
Close at 95°C Open at 90°C

CFS92

Suits: Holden
Thread M22x1.5: Dual Contacts 1 N.O. 1 N.C.
105-100°C 120-115°C

CFS93

Suits: Holden
Thread M22x1.5: Dual Contacts 1 N.O. 1 N.C.
95-90°C 120-115°C

CFS94



Suits: Holden
Thread M22x1.5: Dual Contacts 1 N.O. 1 N.C.
110-115°C 120-115°C

CFS95

Suits: Holden
Thread M22x1.5: Dual Contacts N.O.
95-90°C 105-100°C

HEADLIGHT & DIMMER SWITCHES

CHL20



Suits: Universal 6 or 12 volt
Headlight Switch

CHL21



Suits: Holden FE to HG
Headlight Switch

CHL22



Suits: Chrysler AP5 to VG
Headlight Switch

CHL23



Suits: Ford 1965 to 1970
Headlight Switch

CDS14

Suits: Ford XM to XY
Dimmer Switch

CDS15

Suits: Holden FE to HJ
Dimmer Switch

IGNTION SWITCHES

FUELMISER

CIS20

Suits: Holden FE to HG

CIS21

Suits: Universal – Acc On Start

CIS23

Suits: Holden
Key and Barrel

CIS24

Suits: Universal – On Off

CIS25

Suits: International

CIS26



Suits: Holden FE to HG
Key and Barrel

CIS27

Suits: Chrysler to 1968
Without Key and Barrel

CIS28

Suits: Universal – Acc On Start
With ground terminal for circuit test

POWER STEERING SWITCHES

CP100

Suits: Ford

CP101

Suits: Ford

NEUTRAL SWITCH

CNS10

Suits: Kenworth, Mack

REVERSE LIGHT SWITCHES

FUELMISER

CRS100

Suits: Holden

CRS101

Suits: Daihatsu

CRS102

Suits: Holden

STARTER RELAY SWITCHES

CS50



Continuous duty – 12 volt, insulated base, silver contacts – Rated Current 80 Amps

CS51

Suits: Ford, Universal
12 volt, grounded base with ballast bypass terminal – Rated Current 200 Amps Intermittent

CS52

12 volt, grounded base

CS53

Continuous duty – 12 volt, insulated base, copper contacts. – Rated Current 80 Amps

CS54

Continuous duty – 24 volt, insulated base, copper contacts. – Rated Current 60 Amps

CS55

Foot operated, starter switch

CS56

12 volt, grounded base – As per CS52 but with manual button in cap

FUELMISER

motospecs

ABN 97 097 993 283

PO Box 339
Hornsby NSW 1630
Australia